4.2.4 MRAPI_NODE_ID_GET

NAME

mrapi_node_id_get

SYNOPSIS

```
mrapi_node_t mrapi_node_id_get(
   MRAPI_OUT mrapi_status_t* status
);
```

DESCRIPTION

Returns the node id associated with the local node and domain.

RETURN VALUE

On success, *status is set to MRAPI_SUCCESS. On error, *status is set to the appropriate error defined below.

ERRORS

MRAPI_ERR_NODE_NOTINIT	The calling node is not intialized.

NOTE

SEE ALSO