MRAPI_SHMEM_ADDRESS	if MRAPI_SHMEM _ANY then not necessarily contiguous, if <address> then contiguous;non -contiguous should be used with care and will not work in contexts that cannot handle virtual memory	mrapi_addr_t	MRAPI_SHMEM_ANY_C ONTIGUOUS

RETURN VALUE

On success *status is set to MRAPI_SUCCESS. On error, *status is set to the appropriate error defined below.

ERRORS

MRAPI_ERR_ATTR_READONLY	Attribute can not be modified.
MRAPI_ERR_PARAMETER	Invalid attribute parameter.
MRAPI_ERR_ATTR_NUM	Unknown attribute number
MRAPI_ERR_ATTR_SIZE	Incorrect attribute size
MRAPI_ERR_NODE_NOTINIT	The calling node is not intialized.

NOTE

SEE ALSO