## Winlink Introductions






### Winlink Is

- Communications system for License Hams
- Able to send and receive email over radio
- Particularly useful in Emergencies
- Users can use various methods
  - Telnet
  - UHF/VHF, HF



## System Setup



Most items can be purchased on Amazon.


- Cables
- Digirig sound cards

#### Installation

- Go to downloads.winlink.org
- Perform a regular install on your system
- Obtain winlink account email address
- Fill out Setup Screen
  - Call sign
  - Password
  - Locator number, etc



### Download.winlink.com





## Setup screen

Name: Gary Hutton  Street address 1: 509 West 1930 North  Street address 2: City: Orem
Street address 2: City:
City: Orem
Country: USA
Postal code: 64057-1096  eb Site URL (optional): 801.310.9314  Non-Winlink e-mail: huttonator@gnai.com
dditional information (optional):  CARES, DEM, UVARC, Emergency #801,226-1526
logs for 2 weeks. Keep deleted messages for 720 days.
isplay list of pending incoming messages prior to download 'am about connections to stations holding messages utomaticaly install field-test (beta) versions of Winlink Express utomatically install updates without prompting





#### Obtain email address

- Read instructions on winlink.org
- Youtube.com is your friend
- Your winlink email address is just your call sign
- Example = ie. ke7uia




### **Install Drivers**








### Com Ports






#### Download VARA FM






## VARA Settings




### VARA – Sound Card






### VARA – PTT Port







### Create Message




## Create Message 2



## Select Session Type



### Select Channel




### Select Channel 2

		.:CI Selector					
-	Select Channe	el Update T	able Via Interne	t Updace			
KE7UI	Stations found within 185 miles of your grid square.						
anel Selection  ect ▼ WN7I-	Callsign	Frequency (MHz)	Channel Width	Grid Square	Group	Distance (mi)	1.
JCS-10 @ 145,030	WN7I-10	144.930	Wide	DN40CK	PUBLIC	004	2.
5C3-10 @ 143.030	WA7FFM-10	144.950	Wide	DN40DI	PUBLIC	006	180
BPM: 0/0 Disconnec	KE7AU-10	144.950	Wide	DN40DH	PUBLIC	009	180
RA FM TNC: C:\VARA F	N7YUT-10	431.070	Wide	DN40BN	PUBLIC	012	313
onnected to VARA FM T	K7DOD-10	145.050	Narrow	DN40BO	PUBLIC	014	321
	K7UCS-10	145.030	Wide	DN40ED	PUBLIC	020	168
	K7XRD-10	145.050	Wide	DN40BR	PUBLIC	022	336
	K7DAV-10	431.450	Wide	DN40BX	PUBLIC	038	347
	K7DAV-10	145.070	Wide	DN40BX	PUBLIC	038	347
	NS7K-10	145.070	Narrow	DN31XC	PUBLIC	049	339
	AC7II-10	145.050	Wide	DN41BN	PUBLIC	DMC Everage	
	KD7IIW-10	431.070	Wide	DN42BC	PUBLIC	RMS Express	
	AG7MM-10	438.500	Wide	DN32EH	PUBLIC	A request *	
			1	1			




#### **Press Start**



### Message Path with VARA

- Message: Posted in outbox. Addressed correctly
- Session Type: VARA FM, VARA HF
- Configuration: Sound cards, PTT
- Select Gateway: one near you
- Cables to Sound Card: short and choked
- Cables to Radio: short and choked
- Sound Card: digirig, Tigertronics
- Radio: frequency, settings, power
- Antenna: Type, Position, Connections
- Gateway: is it up and running
   When this method of sending winlink email is broken, which one of these is broken?



### Winlink Info Locations

- https://winlink.org/
  - User Programs, Book of Knowledge, Support, Maps, My Account
- https://github.com/ke7uia/Winlink
- Linux installations
  - https://github.com/km4ack/73Linux
- https://www.youtube.com/@WaveTalkers



# Questions:

