SCEMATIC FILE

Schematic - Symbol.

01. kicad → file → New project → Named " → kicad → okay → choose schematic editor → up options select → Symbol editor opened → choose file → click new library → add name Boost_Symbol_library nametag → click okay → now in symbol editor in filter Q box search for Boost_Symbol_library → select & Right click → import symbol file from files dowloaded
[the symbol and foot print files we can get from mouser "go to mouser → search for component → under search for kicad files → download and extract them from that you can get derived sym & mod (foot-print) files you can access] → Sym & mod (foot print) files from mouser or wurth components website
once you click that file so many options will come search for what you want and lick the box → click import → Click control + S to save now
02. Go back → right top click → in search → search Boost_Symbol_library in that what you selected double click and place the symbol.
03. for next symbol from ★ (mentioned above) repeat from here [∴ Before going to new symbol do its footprint (mentioned below) and then go to new symbol placement

Schematic - foot print:

01. up options select → footprint editor opened → choose file → click new library → add name Boost_footprint_library nametag → click okay → now in footprint editor in filter Q box search for Boost_footprint_library → select & Right click → import [footprint or mod] file from files dowloaded
[the symbol and footprint files we can get from mouser "go to mouser → search for component → under search for kicad files → download and extract them from that you can get derived sym & mod (foot-print) files you can access]
once you click that file so many options will come search for what you want and click the import footprint → click control + S → click the library "Boost_footprint_library" & click okay
02. for next footprint from ▲ (mentioned above) repeat from here

Footprint - whether it is attached to symbol
01. double click → symbol properties → Name: footprint, Value: (empty), click this → footprint chooser → in that if it shows [no footprint Select] → in search "search for that footprint" → select that → click ok → done