09FLP - GAL Selection Table.

Туре	I/O	G1	Programmer
GAL16V8A-15LP	2	09FLP	1, 2
GAL16V8B-15LP	1	09FLP	1, 2
GAL16V8D-15LP	1	09FLP	1, 2
GAL16V8D-25LP	1	09FLP	1, 2
GAL22V10B-15LP	3	Х	1, 2
GAL22V10D-15LP	3	Х	1, 2
ATF16V8B-15PC	1	ATF-09FLP	2, 3, 1
ATF16V8B-25PC	1	ATF-09FLP	2, 3, 1
ATF22V10B-15PC	1	X	2, 3, 1
ATF22V10C-15PC	5	X	2, 3, 1
PALCE16V8-15PC	1	09FLP	2
PALCE16V8-25PC	1	09FLP	2
PALCE16V8H-15PC/4	4	09FLP	2, 3
PALCE16V8H-25PC	4	09FLP	2, 3
PALCE22V10H-15PC/4	4	X	2
PALCE22V10H-25PC/4	4	X	X
PALCE22V10Q-25PC	4	X	2

Tested Any open field means not used/tested First nr prefered

I/O: 1 = I/O 50K pull up	Programmer:
2 = I/O No pull up	1 = Xgpro TL866II Plus, Sw 12.90 - Fw 04.2.132
3 = I/O Active pull up	2 = GALEP-4, Galep32 Version 1.20.4
4 = 100K 50K No pull up	3 = TOP2013, Sw Topall 8.92 - Fw 6.30
5 = I/O Pin keeper	x = No programmer available

Remarks: I/O type 4 depending on device suffix /4 = 100K, /5 = 50K, otherwise NO pull-up
I/O type 2,4 and 5 may need a pull-up on floating input pins.
Some ATF16V8B had errors on the TL866II Plus but not on the GALEP-4.
Do select the full name in the programmer A, B, C, D, H or Q version!
Otherwise you will get programming errors!
TOP2013 also select the correct speed -10, -15 or -25!