# **Networking Utils**

# ifconfig

display or apply the local settings for the network adapter

### **USAGE**

```
ifconfig <device> [<command> <data>]
```

where <device> is 'net0' or 'net1'

# ifconfig net0

```
inet 192.168.1.1 netmask 255.255.255.0 up gateway 192.168.1.10 ether 54:53:43:55:46:3F
```

### commands:

inet specify the IP address for the adapter netmask specify the netmask for the IP address

gateway specify the IP address for the network gateway

ether specify the MAC-Address with which the adapter will be setup

up the networking interface is switched on down the networking interface is switched off

## **DESCRIPTION**

with 'ifconfig' the network interface is setup and switched. Error checking is done on the IP addresses and on the MAC-Address values.

All the commands can be given at once or one or some at a time.

i.e.

If config net 0 inet 192.168.2.3 sets the IP address for the interface to 192.168.2.3

ifconfig net0 gateway 192.168.10.20 down sets the gateway address to 192.168.10.20 and switches the interface to an inactive state.