


CPU09 Serial to DB9 crimp connector for USB to RS232 unit/cable.




Split the flat cable ^----- 5cm -----^



^ Swap the two sets in the middle

Place DB9 like this.



< No wire 10

^ 10pin connector like this.