
Section 5.4

After you finish setting up the parameters, you can go back to ADE XL Editing window. Choose "Single Run, Sweeps and Corners". You can group PMOS width as a parametric set and NMOS input pair width as a parametric set. Select the parameters and right click to set the "Group as Parametric Set". Then, right click on the parameters again and click "Edit Parameter" setup the sweeping range and # of steps in the new window.



Now, click **run** button and find out your optimum sizes to meet the spec...

Deliverable 2

Screenshot of the simulation result from section 5.4. Pick the optimum device sizes from the result.