

UART Serial Communication Using LPC2148

Code:-

```
#include<lpc214x.h>

void uart_init(void);
unsigned int delay;
unsigned char *ptr;
unsigned char arr[]="HELLO WORLD\r";

int main()
{
    while(1)
    {
        uart_init();
        ptr = arr;
        while(*ptr!='\0')
        {
            U0THR=*ptr++;
            while(!(U0LSR & 0x20)== 0x20);
            for(delay=0;delay<=600;delay++);
        }
        for(delay=0;delay<=60000;delay++);
    }
}

void uart_init(void)
{
    PINSEL0=0X00000005;           //select TXD0 and RXD0 lines
    U0LCR = 0X00000083;           //enable baud rate divisor
loading and
    U0DLM = 0X00;                 //select the data format
    U0DLL = 0x13;                 //select baud rate 9600 bps
    U0LCR = 0X00000003;

}
```