
CB-C2 V.2 for LGX Lite Assembly Manual



Notice 1: This mount was built to work with Eytecz StealthBurner CW2 style mount and will work with that only

Notice 2: While the images in this document show multiple parts from Eytecz StealthBurner CW2 style mount the are included for instructional purposes only, you will not need to print new ones to build CB-C2

Bill of Materials	03
Prerequisites	04
Cable Gland Mount	05
PCB Mount	06
Rear Door Mount	10

Screws Button Head

2 x M3x4 BHCS 1 x M3x6 BHCS 2 x M3x8 BHCS

Screws Socket Head

1 x M3x6 SHCS 1 x M3x8 SHCS 1 x M3x12 SHCS 1 x M3x16 SHCS 2 x M3x30 SHCS

Inserts and Bolts

1 x M3 Hexnut 8 x M3 - M3x5x4 Threaded Inserts (Voron standard)


Additional Hardware

1x 2010 fan 1x EBB36 1x PG7 Cable Gland (I used the ones from DFH other ones may not fit)

Place1x Threaded Insert into the CB-C2 Cable door as shown below


Remove the cable chain mount and cable door from the CW2 style mount and set aside (these will no longer be needed).

This will require you to temporarily take apart the CW2 style mount to reach the cable door screw. While removed go ahead and install the new CB-C2 Cable door on CW2 style mount.




While reassembling CW2 style mount, replace the following screws holding the motor to the LGX lite

2x M3x30 SHCS screws



Install the **2x Threaded Inserts** into the Cable Gland Mount as show in the following image

Notice: The cable can be removed and added from cable gland through the side slit



Mount the Cable Gland mount the rear of the CW2 style mount using the same mounting points used by the cable chain mount.




Front for of CW2 style mount

1x M3x8 SCHS

Rear of CW2 style mount

1x M3x6 BHCS




Insert a heated insert on either side of the spacers






Install the spacers onto the motor using the extended length of the screws from the back




Install 1x Threaded Insert into the PCB Mount



Install the 1x M3 Hexnut into the backside of the PCB Mount

Notice 1: The Hexnut should press fit, but glue may be needed


Notice 2: When printing this part there are included supports, be sure to pull them away



١


Mount the PCB mount to the two spacers and 2X BHCS M3x8 screws

Notice: The lip on the PCB mount should fit securely to the Cable Gland Mount to help with the overall strength of the mount.





Install the EBB36 to PCB Mount the using 2x M3x4 BHCS

Notice: On the side of the PCB Mount you will find a cable tie to help manage the cables from the back door to the cable cover on the side.



Press fit the 2010 Fan into its position





Using 1x M3x16 SHCS attach the cable door to the Cable Gland Mount as shown below

After installing your Umbilical and wiring your Canbus close the door and attach it to the side cable door using 1x M3x6 S

