Driving

Out and about in Ken



When you are heading out

1. Unlock the cab



Press unlock on the remote once

2. Unlock the rear

Press unlock on the remote twice

3. Remove steering lock



Use the key on the keyring - lock can be stored under the handbrake when driving




1. Mirrors

Check the wing mirrors are pushed out and usable



2. Hook Up Cable



Make sure the hook up power cable is removed and inside the van

3. Air Vents



Ensure the two roof air vents are both closed Press the button on the vent to open and close

4. Rear Windows



Ensure the two side windows at the rear are both closed

5. Child seats

Ensure the rear child seats are tethered to the floor point

• Use the cables located on the back of the seats



 A secure anchor point is located on the floor in front of the fridge



- First attach the car seat threading the lap belt through its bottom
- Then attach the anchor cable to the back of the car seat down to the anchor point on the floor behind

6. Baby Seat



Use the front seats for the baby car seat



1. Ignition

With a foot on the brake, hold the clutch down and turn the key to start the engine

2. Handbrake

Make sure the handbrake is fully down - the dashboard will warn you if not

3. Changing Gear

The gearbox feels different to a car and requires a two part movement.

First put the gear stick into neutral and then into the new gear.

It feels like a one - two movement and soon becomes familiar.

Use the gear selection prompt next to the speedometer to help know which gear to use

4. Braking

You're almost 3 tonnes so will need ample time to slow down

5. Cornering

It's a great drive being up high, just watch out for kerbs as you'll need to go wider to avoid clipping the back tyres

6. Reversing



Use the rear view camera on the dashboard that turns on when reversing

Ensure the cable is plugged into the lighter slot

1. Headlights



There is a dial on the right hand side for sidelights or dipped headlights

2. Full Beams



Use the larger stick on the left side.

- Push forward Flash
- o Pull back Full Beams On

3. Wipers



Use the larger stick on the left side.

- Twist Set wiper speed.
- Push from end towards wheel Spray water

4. Climate Control



Use the climate control dial to turn on the heaters or fans in the cab. There is no air conditioning so you may need to let the windows down on hot days

5. Cruise Control



There is a smaller stick on the left of the steering wheel

- Pull forward start cruise control at current speed
- Push back / brake stop cruise control
- Push up increase speed
- Push down decrease speed

6. Audio

There is Bluetooth available as well as Radio

To connect do the following:

- 1. Select the bluetooth menu to show 'No Bluetooth audio device connected'
- 2. Select 'BT Audio'



3. Then select bluetooth audio device list



4. If all three slots are in use, hit right arrow to select on, and then 'De-authorise' to remove it



5. Then you can select 'Update' on the list of device to scan for your device




6. When scanning you are prompted to enter a passkey e.g. 0 0 0 0 and then select 'OK'

Please enter passkey



7. Your phone should then prompt to connect and enter the same passkey



8. Now you should see the 'Connected with' message



- 9. After you have done this you can use 'Connect' on the main bluetooth menu
- 10. You should now be able to play music through the speakers



1. Flat Ground

The van is very heavy so avoid parking on hills or the handbrake will not be enough to hold the van

2. Parking Spaces



You can bay park into a standard car parking spot.

Remember there is a tow bar at the back

You will need to reverse park and use the reverse camera

3. Height Restrictions

You will need 2.4m so will not be able to park in many places with a height restriction

4. Sun Protection



Use the sun screens to prevent the cab overheating while you stop

5. Leave in Gear

To be safe, first put the van in gear and then switch off the engine.

If slightly uphill put in first
If slightly downhill put in reverse

6. Lock Up

Use the steering lock to secure the wheel. Press once on the remote to lock the whole van



Key remote does not work



Fix

For the drivers door. Pull out the manual key from inside the remote and use that to lock/unlock manually on the drivers side - contact us to sort out replacing battery

You will need to lock the side door and passengers side door using the push down locks on the inside of the door then closing them.

Roof air vents do not lower when pressing the button



Fiv

Twist the black vent knobs to manually lower the vent until it is closed

Issues with reversing camera



Fix

Check for mud or dust on the camera located above the rear number plate.

Note: The camera is activated through bluetooth so can be triggered by other vehicles when driving on motorways if they are using the same device

