## The Doping of Semiconductors

The addition of a small percentage of foreign atoms in the regular <u>crystal lattice</u> of silicon or germanium produces dramatic changes in their electrical properties, producing <u>n-type</u> and <u>p-type</u> semiconductors.

## Pentavalent impurities


Impurity atoms with 5 <u>valence electrons</u> produce n-type semiconductors by contributing extra electrons.

Antimony Arsenic Phosphorous (Sb) donor impurity Antimony

<u>Index</u>

Semiconductor concepts

Boron Aluminum Gallium



Trivalent impurities

Impurity atoms with 3 valence electrons produce p-type semiconductors by producing a "hole" or electron deficiency.

<u>HyperPhysics</u>\*\*\*\*\* <u>Condensed Matter</u>


R Nave

Go Back

## P- and N- Type Semiconductors

<u>Index</u>

Semiconductor concepts



<u>HyperPhysics</u>\*\*\*\*\* Condensed Matter

Go Back

R Nave

