10/27/2019 Intrinsic Semiconductors


Intrinsic Semiconductor

A silicon crystal is different from an <u>insulator</u> because at any temperature above absolute zero temperature, there is a finite probability that an electron in the <u>lattice</u> will be knocked loose from its position, leaving behind an electron deficiency called a "<u>hole</u>".

If a voltage is applied, then both the electron and the hole can contribute to a small <u>current</u> flow.

The conductivity of a semiconductor can be modeled in terms of the band theory of solids. The band model of a semiconductor suggests that at ordinary temperatures there is a finite possibility that electrons can reach the conduction band and contribute to electrical conduction.

The term intrinsic here distinguishes between the properties of pure "intrinsic" silicon and the dramatically different properties of <u>doped n-type</u> or <u>p-type</u> semiconductors.



<u>Index</u>

Semiconductor concepts

<u>HyperPhysics</u>***** <u>Condensed Matter</u>

R Nave Go Back


Semiconductor Current


Both <u>electrons and holes</u> contribute to current flow in an <u>intrinsic</u> semiconductor.

<u>Index</u>

Semiconductor concepts

10/27/2019 Intrinsic Semiconductors





10/27/2019 Intrinsic Semiconductors

The current flow in an intrinsic semiconductor is influenced by the density of energy states which in turn influences the electron density in the conduction band. This current is highly temperature dependent.

| HyperPhysics***** Condensed Matter | Rave | Go Back | Go Back | Condensed Matter | Condensed Matter | Rave | Condensed Matter | Condensed Matte

