

A.4.25 SMS/CBS 7-bit Santali (Ol Chiki script) Alphabet (0x25)

A.4.25.1 SMS/CBS 7-bit Santali (Ol Chiki script) Alphabet (0x25) base table

				b7	0	0	0	0	1	1	1	1
				b6	0	0	1	1	0	0	1	1
				b5	0	1	0	1	0	1	0	1
b4	b3	b2	b1		0	1	2	3	4	5	6	7
0	0	0	0	0	@ 0040	– 2212	SP 0020	0 0030	ᱠ 1C5A	ᱡ 1C6A		p 0070
0	0	0	1	1	₹ 00A3	— 005F	! 0021	1 0031	ᱢ 1C5B	ᱣ 1C6B	a 0061	q 0071
0	0	1	0	2	\$ 0024		" 0022	2 0032	ᱤ 1C5C	ᱥ 1C6C	b 0062	r 0072
0	0	1	1	3	¥ 00A5	₹ 20B9	# 0023	3 0033	ᱦ 1C5D	ᱧ 1C6D	c 0063	s 0073
0	1	0	0	4	§ 00A7		€ 20AC	4 0034	ᱨ 1C5E	ᱩ 1C6E	d 0064	t 0074
0	1	0	1	5			% 0025	5 0035	ᱪ 1C5F	ᱫ 1C6F	e 0065	u 0075
0	1	1	0	6			& 0026	6 0036	ᱬ 1C60	ᱭ 1C70	f 0066	v 0076
0	1	1	1	7			' 0027	7 0037	ᱮ 1C61	ᱯ 1C71	g 0067	w 0077
1	0	0	0	8			(0028	8 0038	ᱰ 1C62	ᱱ 1C72	h 0068	x 0078
1	0	0	1	9			) 0029	9 0039	ᱲ 1C63	ᱳ 1C73	i 0069	y 0079
1	0	1	0	A	LF 000A		* 002A	: 003A	ᱴ 1C64	ᱵ 1C74	j 006A	z 007A
1	0	1	1	B		SS2 ----	+ 002B	; 003B	ᱶ 1C65	ᱷ 1C75	k 006B	. 1C78
1	1	0	0	C			, 002C	< 003C	ᱸ 1C66	ᱹ 1C76	l 006C	. 1C79
1	1	0	1	D	CR 000D		- 002D	= 003D	ᱺ 1C67	ᱻ 1C77	m 006D	: 1C7A
1	1	1	0	E			. 002E	> 003E	ᱼ 1C68		n 006E	~ 1C7B
1	1	1	1	F			/ 002F	? 003F	ᱽ 1C69	᱾ 1C7D	o 006F	- 1C7C

In the event that an MS receives a code where a symbol is not represented in the above table then the MS shall display the REPLACEMENT CHARACTER (U+FFFD).

LF: LINE FEED; moves to the next line (with implied carriage return).

CR: CARRIAGE RETURN; CR is not used as CR but is used as a filler after the actual SMS/CBS message text. CR should not occur inside a message text, but if it does, it must be converted to LF. Note though that <SS2,CR> is actually CSI (see next table), and that "CR" is not a filler, nor LF.

SS2: SINGLE SHIFT TWO; This code shifts the next 7-bit code unit to refer to an extension of this table (subclause A.4.15.2).

When splitting a message text into submessages, there must be no cut right after an SS2.

A.4.25.2 SMS/CBS 7-bit Santali (Ol Chiki script)Alphabet (0x25) extension (SS2) table

				b7	0	0	0	0	1	1	1	1
				b6	0	0	1	1	0	0	1	1
				b5	0	1	0	1	0	1	0	1
b4	b3	b2	b1	1B	0	1	2	3	4	5	6	7
0	0	0	0	0			୮ 1C54		 007C	P 0050	¼ 00BC	△ 26A0
0	0	0	1	1			୮ 1C55		A 0041	Q 0051	½ 00BD	∞ 221E
0	0	1	0	2			୯ 1C56		B 0042	R 0052	¾ 00BE	² 00B2
0	0	1	1	3			୧୦ 1C57		C 0043	S 0053	“ 201C	³ 00B3
0	1	0	0	4		^ 005E	୧୧ 1C58		D 0044	T 0054	” 201D	
0	1	0	1	5			୧୨ 1C59		E 0045	U 0055	¤ 00A4	
0	1	1	0	6					F 0046	V 0056	Ω 03A9	
0	1	1	1	7					G 0047	W 0057	μ 03BC	
1	0	0	0	8			{ 007B		H 0048	X 0058	° 00B0	
1	0	0	1	9		' 1C7E	} 007D		I 0049	Y 0059	× 00D7	
1	0	1	0	A	FF 000C	" 1C7F	୧୩ 1C51,2044,1C54	≈ 2248	J 004A	Z 005A	÷ 00F7	
1	0	1	1	B		SS3 ----	୧୪ 1C51,2044,1C52	≠ 2260	K 004B		± 00B1	
1	1	0	0	C		0 1C50	୧୫ 1C53,2044,1C54	[005B	L 004C		‰ 2030	
1	1	0	1	D	CSI 009B	୧୬ 1C51	≤ 2A7D	~ 007E	M 004D		« 00AB	
1	1	1	0	E		୧୭ 1C52	≥ 2A7E	] 005D	N 004E		» 00BB	
1	1	1	1	F		୧୮ 1C53	\ 005C	· 00B7	O 004F		' 2019	

In the event that an MS receives a code where a symbol is not represented in the above table then the MS shall display the REPLACEMENT CHARACTER (U+FFFD).

FF: FORM FEED; This code is defined as a Page Break character (with implied carriage return). Any mobile station which does not have pagination shall treat it as a LF (with implied carriage return).

CSI: CONTROL SEQUENCE INTRODUCER; enables decimal character references, enables styling. An MS which does not support CSI shall convert it to REPLACEMENT CHARACTER.

SS3: SINGLE SHIFT THREE; This code is reserved for the extension to another extension table. When splitting a message text into submessages, there must be no cut right after an SS3.

U+2044 FRACTION SLASH; the sequence may need to be isolated from adjacent digits by ZWNJ.