The rtw\_usb\_id\_tbl array inside os\_dep\linux\usb\_intf.c file defines all the vid/pids which this Realtek WiFi USB Linux driver supports currently. To support WiFi USB devices with new vid/pid(s) which is compatible with this driver, you can add the new vid/pid entries into the rtw\_usb\_id\_tbl array. For example, adding 0x2019,0x4902 for CU and 0x07B8,0x8193 for DU compatible WiFi devices into rtw usb id tbl array:

```
static struct usb_device_id rtw_usb_id_tbl[] ={
#ifdef CONFIG_RTL8192C
     /*=== Realtek demoboard ===*/
     {USB DEVICE(0x0BDA, 0x8191)},//Default ID
     {USB_DEVICE(0x0B05, 0x17AB)},//ASUS - Edimax
     {USB_DEVICE(0x2019, 0x4902)}, //add here for CU compatible WiFi devices
#endif
#ifdef CONFIG RTL8192D
     /*=== Realtek demoboard ===*/
     /***** 8192DU ******/
     {USB_DEVICE(USB_VENDER_ID_REALTEK, 0x8193)},//8192DU-VC
     /***** 8192DU-WiFi Display Dongle ******/
     {USB_DEVICE(0x2019, 0xAB2D)},//Planex - Abocom ,5G dongle for WiFi Display
     {USB_DEVICE(0x07B8, 0x8193)}, // add here for DU compatible WiFi devices
#endif
     {}
           /* Terminating entry */
};
```

After adding the new vid/pid entries into the rtw\_usb\_id\_tbl array, and re-compile the driver, the new driver image can support the device with the new vid/pid now.