
Spinning Light Wand Toy Adaptation USER QUICK GUIDE (FOR V1.1 PRINTED BASE)

Introduction

The Switch Adapted Spinning Light Wand toy provides a way to activate and hold the toy for users who may otherwise have difficulty playing with it independently.

Features



Usage

An assistive switch with a 3.5 mm mono plug is connected to the Switch input port on the Base. When the switch is activated, the lights will turn on and spin within the plastic globe.

Compatibility

This adapted toy is compatible with assistive switches that have a 3.5 mm plug.

Cleaning

The 3D printed base can be wiped down with a cloth. Do not submerge.