# CS2002 Logic and Architecture Lecture 3 CISC and RISC

Ian Gent

closing

opening

#### Issues in ISA design:

- registers
- operands
- memory addressing
- CISC vs RISC
- Compilation process:
  - compiler
  - assembler
  - linker
  - loader

### Recommended reading from last time

#### Comer:

opening

- Section 3.12 (endianness)
- Sections 3.19–3.20 (BCD)
- Sections 5.7, 5.9 (general-purpose registers)
- Section 5.11 (CISC/RISC)
- Sections 7.7–7.14 (addressing modes)

#### This time

- Introduction to the x86-64 ISA:
  - registers
  - flags
  - memory addressing
- Looking at a compiled assembly file

### Compilers and interpreters

Given CPU that understands certain ISA how to run program written in Java, C, Haskell or Python?

Compiler converts high-level program into low level instructions for specific machine not (usually) needed at run time

**Interpreter** is a program that reads a high-level program and carries it out

done at run time

opening

Compilers often actually create assembly code e.g. clang, gcc do this

**Assembler** converts **assembly language** for ISA to more detailed object code

think of it as compiler for low level language where that language is based on ISA of intended hardware

**Linker** combines object code files together to make an executable program that can actually run incorporating necessary library object code files and determining memory offsets for functions in different files

#### After:

opening

- compiling
- assembling
- linking

#### the next step is:

loading

The **loader** loads programs and libraries into memory to prepare them for execution

Provided by the operating system (OS)

which also provides access to hardware resources

# Examples with clang

Normal way to compile simple program to create executable foo:

This is the default behaviour so you don't realise how many stages are involved

But this is multiple stages in one and we can break it up

# Examples with clang (cont.)

Do C preprocessor only, create new C file with e.g. header files included:

```
clang -E foo.c -o foo-preprocessed.c
```

Compile preprocessed file, create assembler file foo.s:

```
clang -S foo-preprocessed.c -o foo.s
```

Assemble the assembly code. Create object code file foo.o:

```
clang -c foo.s -o foo.o
```

Link object code foo.o and create executable foo:

```
clang foo.o -o foo
```

#### **Exercise**

Try out the different stages of compilation with clang, e.g. using the following C program in foo.c:

```
#include <stdio.h>
int main() {
    int rows, i;
    printf("Enter number of rows: ");
    scanf("%d",&rows);
    for(i=0; i<rows; ++i)
        printf("Hello, World!\n");
    return 0;
}</pre>
```

# Good reasons to teach assembly language

- It gives you an insight into computer architecture because there is a match between assembly instructions and hardware
- It shows you how statements in a high level language are broken down for execution on an actual CPU
- It helps you understand how compilers work because you can understand the output of (e.g.) clang
- It especially helps you understand how function calling works
- You may need to use a few lines of assembly to get at special-purpose optimised instructions for the specific CPU

# Why Teach x86?

Not in the syllabus but labs are full of x86 machines

But we used to teach *MIPS*, a lovely orthogonal RISC architecture

And easy to emulate

So why did we change to x86?

It's a good idea to teach on active ISAs

They are under active development

Toolchains for using it are up to date

It is (was?) the most widely used ISA on modern computers/servers

ARM dominates phones/tablets

opening

#### x86-64 ISA

# Intel 64 and IA-32 Architectures Software Developer's Manuals

```
https:
//software.intel.com/en-us/articles/intel-sdm
```

In several volumes, altogether 5066 pages (November 2020)

Not compulsory reading for this module!

We can only cover the main points, for now:

registers

Our focus will be on the 64 bit version

#### General Purpose Registers in x86-64

16 registers of 64 bits

8 historical names 8 numerical names

opening

64 bit registers
%rax
%rbx
%rcx
%rdx
%rsi
%rdi
%rbp
%rsp
%r8
%r9
%r10
%r11
%r12
%r13
%r14
9.m1E

# General Purpose Registers in x86-64 (cont.)

Low 32 bits addressable So 16 GPR of 32 bits

First 8 are %e\*\*
e for Extended
Next 8 are %r\*\*d
d for Double

Changing %eax also changes %rax

64 bit registers	low 32 bits
%rax	%eax
%rbx	%ebx
%rcx	%ecx
%rdx	%edx
%rsi	%esi
%rdi	%edi
%rbp	%ebp
%rsp	%esp
%r8	%r8d
%r9	%r9d
%r10	%r10d
%r11	%r11d
%r12	%r12d
%r13	%r13d
%r14	%r14d
%r15	%r15d

opening

Low 16 bits addressable So 16 GPR of 16 bits each

First 8, just delete e/r Second 8, replace d with w for Word

Changing %ax also changes %eax %rax

64 bit registers	low 32 bits	low 16 bits
%rax	%eax	%ax
%rbx	%ebx	%bx
%rcx	%ecx	%cx
%rdx	%edx	%dx
%rsi	%esi	%si
%rdi	%edi	%di
%rbp	%ebp	%bp
%rsp	%esp	%sp
%r8	%r8d	%r8w
%r9	%r9d	%r9w
%r10	%r10d	%r10w
%r11	%r11d	%r11w
%r12	%r12d	%r12w
%r13	%r13d	%r13w
%r14	%r14d	%r14w
%r15	%r15d	%r15w

#### General Purpose Registers in x86-64 (cont.)

Low 8 bits addressable So 16 GPR of 8 bits each

Compilation

First 4, replace x by I for Low Second 4, add I for Low Third 8, replace w with b for Byte

%al Changing also changes %ax %eax %rax

64 bit registers	low 32 bits	low 16	low 8 bits
%rax	%eax	%ax	%al
%rbx	%ebx	%bx	%bl
%rcx	%ecx	%cx	%cl
%rdx	%edx	%dx	%dl
%rsi	%esi	%si	%sil
%rdi	%edi	%di	%dil
%rbp	%ebp	%bp	%bpl
%rsp	%esp	%sp	%spl
%r8	%r8d	%r8w	%r8b
%r9	%r9d	%r9w	%r9b
%r10	%r10d	%r10w	%r10b
%r11	%r11d	%r11w	%r11b
%r12	%r12d	%r12w	%r12b
%r13	%r13d	%r13w	%r13b
%r14	%r14d	%r14w	%r14b
%r15	%r15d	%r15w	%r15b

opening

# General Purpose Registers in x86-64 (cont.)

Four more 8 bit GPR

The high byte of the low 16 bits of the first four registers

Replace I with h for High

Changing %ah also changes %ax %eax %rax

Where on earth are we?

64 bit registers	low 32 bits	low 16	low 8 bits
%rax	%eax	%ax/ah	%al
%rbx	%ebx	%bx/bh	%bl
%rcx	%ecx	%cx/ch	%cl
%rdx	%edx	%dx/dh	%dl
%rsi	%esi	%si	%sil
%rdi	%edi	%di	%dil
%rbp	%ebp	%bp	%bpl
%rsp	%esp	%sp	%spl
%r8	%r8d	%r8w	%r8b
%r9	%r9d	%r9w	%r9b
%r10	%r10d	%r10w	%r10b
%r11	%r11d	%r11w	%r11b
%r12	%r12d	%r12w	%r12b
%r13	%r13d	%r13w	%r13b
%r14	%r14d	%r14w	%r14b
%r15	%r15d	%r15w	%r15b

Compiled Assembler File

# General Purpose Registers in x86-64 (cont.)

Total  $16 \times 4 + 4 = 68$  GPR

But they overlap in many ways

Names are very inconsistent

To keep backwards compatibility

There's special purpose registers too ...

64 bit registers	low 32 bits	low 16	low 8 bits
%rax	%eax	%ax/ah	%al
%rbx	%ebx	%bx/bh	%bl
%rcx	%ecx	%cx/ch	%cl
%rdx	%edx	%dx/dh	%dl
%rsi	%esi	%si	%sil
%rdi	%edi	%di	%dil
%rbp	%ebp	%bp	%bpl
%rsp	%esp	%sp	%spl
%r8	%r8d	%r8w	%r8b
%r9	%r9d	%r9w	%r9b
%r10	%r10d	%r10w	%r10b
%r11	%r11d	%r11w	%r11b
%r12	%r12d	%r12w	%r12b
%r13	%r13d	%r13w	%r13b
%r14	%r14d	%r14w	%r14b
%r15	%r15d	%r15w	%r15b

#### General-purpose registers in x86 with 64 bits

There are (only!) 16 general-purpose 64-bit registers

So  $16 \cdot 8 = 128$  bytes of the fastest storage in a modern ISA

x86-32 had 8 32-bit registers

When 64-bit architecture was introduced:

- registers doubled in length from 32 to 64 bits
- and number doubled from 8 to 16

New registers are called:

r8 r9 r10 r11 r12 r13 r14 r15

The names of the extended versions of old registers were:

rax rbx rcx rdx rsi rdi rbp rsp

opening

Compiled Assembler File

Where do these names come from?

Originally from Intel 8086 (1978), which had:

- 4 16-bit registers AX BX CX DX
  - AX was (primary) accumulator, some instructions could only use this register
  - BX was 'base' accumulator
  - CX was counter, some instructions intended for loops could only use this
  - AL and AH were low and high bytes of AX, etc.
- two index registers for memory access: SI (source index) and DI (destination index)
- SP was the stack pointer, BP something similar called a base pointer

#### General-purpose registers in x86 with 64 bits (cont.)

Then Intel 80386 (1985) introduced 32-bit version

More orthogonal

Registers now called:

EAX EBX ECX EDX ESI EDI EBP ESP

with E for 'extended'

Then came the 64-bit version (2000)

with r now simply for 'register' (with say rax instead of r1 for historical reasons)

Similar story for two special-purpose registers:

- rip (instruction pointer, a.k.a. program counter)
- rflags (binary flags, e.g. for comparisons)

# Flags register

opening

Let us look more closely at the *rflags* register:

- 64 bits, but not available as general purpose register
- individual bits reflect execution of preceding instruction
- conditional jumps executed based on these flags

#### E.g.

- bit **0** is **carry flag** (did add/sub result in carry bit?)
- bit 2 is parity flag (last result had even number of bits = 1 ?)
- bit 6 is zero flag (last result was zero?)
- bit 7 is sign flag (last result was negative?)
- bit 11 is overflow flag (did add/sub result in overflow?)

#### More information:

closing

# Reminder - Memory Addressing

There are a number of ways you can give operands values Two don't involve memory at all

- Registers
   Just give an argument as a register
- Immediate mode
   value is specified in instruction itself
   used for constants that can be fixed at compile/linking time

#### Be careful:

"Immediate" is often called a "memory addressing mode" but actually it doesn't address memory

The value encoded in the instruction is used - hence "immediate"

# Reminder - Memory Addressing (cont.)

Other addressing modes get values stored in memory

- Direct mode
   Memory address encoded in the instruction
- Indirect mode
   Memory address is stored in a register
- Index mode
   Memory address is a given value plus an offset determined by a register

Compiled Assembler File

#### Memory Addressing in x86-64

x86-64 only has three addressing modes

(Two if you don't count immediate)

- Immediate
- General
- RIP Relative Addressing

We don't need to talk much about immediate, so will look at the others.

opening

# Memory addressing in x86

Main addressing mode in x86 is fairly general (AT&T syntax):

disp(%reg1, %reg2, scale)

- disp is constant integer (displacement, a.k.a. offset)
- reg1 is the base register of the operand
- reg2 is the index register of the operand
- scale can only be 1,2,4,8

Refers to address:

where (reg1) and (reg2) denote the values in the two registers

# Special Cases of General Mode

We can use this one mode to get many others by careful omission

General:

```
disp(%reg1, %reg2, scale)
```

E.g. we can omit displacement (default 0) and scale (default 1):

```
(%reg1, %reg2)
```

E.g. we can omit displacement and *reg1*:

```
(, % reg2, scale)
```

closing

### Special Cases of General Mode (cont.)

Why don't we have modes like direct/indirect/index?

#### We do!

Just omit the rights bits of the general case

#### **Direct mode:**

disp

#### Indirect mode:

(%reg1)

**Index mode:** (based on a register)

(%reg1, %reg2, scale)

Index mode: (based on a direct address)

disp(,%reg2,scale)

#### RIP relative addressing

RIP relative addressing was introduced with x86-64 disp (%rip)

Avoids absolute address required by direct addressing mode Instead address is current value of *rip* plus displacement (Current value of *rip* is of instruction **following** current instruction)

Advantage of RIP rel. addressing: **position-independent code**Code that runs no matter where it is loaded in memory

Disadvantage: displacement is limited to 32 bits

#### From C to assembly

#### Example file sam.c:

```
long sample(long x) {
    static long total;
    total += x;
    return total;
}
```

#### Compiled to assembly file sam.s with:

```
clang -S sam.c -o sam.s \
   -fno-verbose-asm -fomit-frame-pointer
```

- ¬S produces assembly code instead of object code
- don't worry about other flags

# The whole assembly file

```
.text
        .file
               "sam.c"
        .globl sample
               16, 0x90
        .align
               sample, @function
        .type
sample:
        .cfi startproc
       mova
               %rdi, -8(%rsp)
       movq -8(%rsp), %rdi
       addq sample.total, %rdi
       movq %rdi, sample.total
               sample.total, %rax
       mova
       reta
.Lfunc end0:
        .size
               sample, .Lfunc end0-sample
        .cfi endproc
        .tvpe
               sample.total,@object
        .local sample.total
        .comm sample.total,8,8
               "clang version 3.8.0-2ubuntu4 (tags/ etc. "
        .ident
                       ".note.GNU-stack", "", @progbits
        .section
```

#### The actual x86 instructions

```
.text
     .file "sam.c"
     .globl sample
     .align 16, 0x90
              sample, @function
     .type
sample:
     .cfi_startproc
     movq %rdi, -8(%rsp)
     movq -8(%rsp), %rdi
     addq sample.total, %rdi
     movq %rdi, sample.total
            sample.total, %rax
     movq
     retq
.Lfunc end0:
     . . .
```

What is the rest?

Compilation

opening

```
.text
     .file
             "sam.c"
     .qlobl
             sample
             16, 0x90
     .aliqn
             sample, @function
     .type
sample:
     .cfi_startproc
     movq
             %rdi, -8(%rsp)
             -8(%rsp), %rdi
     movq
     addq
             sample.total, %rdi
             %rdi, sample.total
     movq
             sample.total, %rax
     movq
     retq
.Lfunc end0:
```

Names for places in program

E.g. for jumps

Turned into addresses by assembler and/or linker

#### Assembler directives

```
.text
   .file "sam.c"
   .globl sample
   .align 16, 0x90
   .type sample,@function
sample:
   .cfi_startproc
   movq %rdi, -8(%rsp)
   retq
.Lfunc end0:
   .size sample, .Lfunc_end0-sample
   .cfi_endproc
   .type sample.total,@object
   .local sample.total
   . . .
```

Meant for assembler/linker

# Assembler directives (cont.)

```
.text
.file "sam.c"
.globl sample
.align 16, 0x90
```

- .text defines current section as text (not data)
- .file where code comes from
- .globl identifiers in partial program
  - to be made available to other partial programs
  - here only sample
- align how next data is to be aligned
  - here next data should be at multiple of 16
  - padding with bytes 0x90

# Assembler directives (cont.)

```
...
.type sample,@function
sample:
.cfi_startproc
...
.size sample, .Lfunc_end0-sample
.cfi_endproc
.type sample.total,@object
...
```

- .type declares type of symbol
- .cfi\_ ... used for debugging
- .size size of symbol, used by debugger

# Assembler directives (cont.)

```
...
.local sample.total
.comm sample.total,8,8
.ident "clang version 3.8.0-2 etc."
.section ".note.GNU-stack","",@progbits
```

- .local says symbol not externally visible
- .comm declares common symbol of length, with alignment
- .ident used to place tags in object files
- section new section is created.

#### Next time

- x86:
  - dissecting an assembly file
  - Calling Conventions
  - Stack Frames
  - function calling