


# **TLB-6700 Series Quick Start Guide**



### **Package Contents:**

This package contains the following components:

- (1) Model TLB-6700 Series Tunable Laser Controller
- (1) Power Cord (US)
- (1) Software CD (contains Device User's Manual and Software)
- (1) USB Cable
- (2) On/Off Switch Keys
- (2) 250VAC, 1.0A, Slo-Blo Fuses for 220-240VAC operation
- This Quick Start Guide

## **Getting Started:**

Before operating this device, refer to the Device User's Manual, starting with the section on Safety Precautions. The User Manual is contained on the Software CD enclosed in this package.

#### **Proper Voltage Selection:**


Verify that the proper fuses are installed and the correct voltage is selected for your region per the User Manual.

This unit is shipped set at 120VAC. If it intended for use in a country with 220-240VAC

- 1) Replace the (2) internal fuses with the (2) supplied 250VAC, 1.0A, Slo-Blo fuses
- 2) Set the IPC tumbler to 240VAC

#### **Software Information:**

TLB-6700 software will start automatically when the CD is inserted into your PC. If it does not, then run **Setup.exe** from the root folder on the CD. Follow the on-screen instructions to complete the installation process. For more information refer to the **TLB-6700 Readme** file contained on the CD.



Verify fuses are installed and voltage is selected properly for your region

Newport Corporation U.S.A Office: 800-222-6440

P/N: 90048817 REV. A