## Swerve Drive

Yousuf Soliman Noah Sutton-Smolin Kian Sheik

September 3, 2013

## 1 Introduction

The drive train is one of the fundemental systems that a robot uses to move. There are countless different drive trains that robots could employ to maneuver. Most drive trains can fall under one of two distinct categories, **Omnidirectional** or **Standard**.

Omnidirectional drive trains have the ability to move in any direction. Omnidirectional robots can simply move in any desired direction without the need to rotate, they can also employ more advanced techniques that allow a driver to control the Omnidirectional robot in relation to the field rather than in relation to the robot itself. In other words, it allows the driver to move the robot forward regardless of its orientation.

When we look at the other class of drive trains, we can see that Standard drive trains cannot strafe and must rotate before moving in order to move to the side. The heading of these drive trains are modified through an arc. Standard drive trains do not have as much maneuverability as Omnidirectional systems, but they are much simpiler and *generally* provide more torque and power.

## 1.1 An Overview of Several Drive Trains

Tank Drive/Differential This is one of the simplest Standard drive trains. There are two sets of wheels on either side of the robot (left/right). When both sides spin in the same direction, the robot will move straight; however, if one side drives faster than the other side, the robot will move in an arc in the direction of the side that is moving slower. To turn in spot with a Differential drive train one set of wheels moves in one direction while the second set moves in the opposite direction. Wheels in a Differential drive train can often skip or skid. The greater the width of the robot, the less the skidding will occur. Differential drive trains only require two motors.

Ackerman The Ackerman drive train, a Standard drive train, is one of the most widely used. It is often known due to its implementation in automobiles. The rear set of wheels is stationary and provides all of the power to the system. The front wheels provide the robot the ability to steer. If the front wheels slip at all, the ability of the robot to navigate is greatly negated. The Ackerman drive train is most beneficial when maneuverability is not a concern and the robot will be moving mostly straight with gentle turns. This is almost never the case and thus it is rarely found in the realm of robotics. Ackerman drive trains require one drive motor and one steering motor.

Holonomic The Holonomic drive train is one of the more simple Omnidirectional systems. Its omnidirectional ability is achieved through the use of special wheels that have rotating "mini rollers" across the circumferance of the wheel. The rollers allow the side to side motion of the wheel. Each of the wheels is placed at either a ±45° angle at the corners of the robot. If we inscribe a circle within the perimiter of a square base, the wheels will be placed tangentially near the corners. This shape forms two distinct sets of parallel wheels which are perpendicular to each other. When all the wheels are powered the robot will spin around itself. When one set of wheels spin in the same direction the robot will move in that direction as the rollers on the other set will allow them to slide with the robot. This system provides outstandinding maneuverability in any plane. To achieve this, the Holonomic drive sacrifices torque and is easily to be pushed around. The Holonomic drive train requires a drive motor for each wheel.




Figure 1: A basic Differential drive train. It only has 2 axes of rotation.




Figure 2: A basic Holonomic drive train. It has 3 axes of rotation

The following table provides an overview of the advantages and downsides to the drive trains discussed above:

Drive Trai	n Pros	Cons
Differentia	l Simple, Durable, Light	Skids, Chassis Shape Restriction
Ackerman	Simple, Sturdy	Poor Maneuverability, Unable to Spin
Holonomic	High Maneuverability, Moderate Complexity	High Cost, Low Traction

The rest of the document will be dedicated to an understanding of the Swerve drive, both intuitively and mathematically.

## 2 Swerve Drive