DELIQUENCER

The *Delinquencer* application consists of four screens: Sequencer, Note Entry, PatterMaker and Delinquencer. You can access these by pressing the **[K2]** button on your Norns. The four screens loop around as you continue to press the **[K2]** button, see Figure 1 below:


Figure 1: Menu Navigation