Trouble Shooting

1. The smart home does not response.

A:

- (1) Please keep batteries fresh.
- (2) Please ensure the correctness of wiring.

Note: The control board have not burned related programs of smart home before leaving the factory, so you need to burn them manually if you want to implement those functions.

2. USB port cannot be recognised by computer

A:

- (1) Please install the development board driver according to "Development Environment Configuration".
 - (2) Please make sure the USB is in good contact.

3. The programs cannot be uploaded.

A:

Please disconnect Bluetooth when burning programs, otherwise the code fails to be uploaded. Remember installing the Bluetooth after finishing uploading.

4. The servo is burning hot.

A:

- (1) Before installing the window servo, please reset it to 90° to avoid blocking and burning when executing programs.
- (2) When installing window, please tighten the self-locking nuts too much to guarantee the slip of the window. Otherwise, servo may be burning hot for blocking.

