

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
A		H	
Amplifier assy. (ignition current)	12A027	Holder (distributor housing clamp)	12144
Arm assy. (distributor timing)	12273	Hose & grommet assy. (vacuum)	12A161
		Housing assy. (distributor terminal)	12106
B			
Bleed assy. (distributor vacuum air)	12A168	I	
Bracket (ignition cable mounting)	12111-2	Ignition cable (high tension)	12A024
Bracket (ignition current amplifier)	12A072	Insulator (circuit breaker)	12289
Breaker assy. (distributor)	12151	Insulator (spark plug wire)	12113
Bushing (distributor base lower)	12132		
Bushing (distributor base upper)	12120		
Button (distributor breaker plate support)	12072		
C		K	
Cam assy. (distributor)	12210	KIT - refer to appropriate noun name	
Clamp (distributor terminal housing hold down)	12144	For example	
Clamp (distributor to cylinder head)	12270	Distributor kit (dual point)	12050
Cobra kit (ignition parts)	12050		
Coil assy. (ignition less mounting strap)	12029		
Collar (distributor shaft)	12195	L	
Condenser assy. (distributor)	12300	Link (distributor breaker plate)	12A186
Connector (distributor vacuum pipe)	12224		
Contact (distributor carbon)	12011		
Cover (distributor breaker dust)	12239, 12276	O	
		Oiler (distributor housing)	12135
D			
Diaphragm assy. (distributor vacuum control)	12370	P	
Distributor assy. (less terminal housing & rotor)	12127	Plate assy. (distributor breaker)	12151
Distributor kit (dual point)	12050	Plate kit (distributor)	12A132
Distributor repair kit	12000	Plug (distributor diaphragm)	12A022
		Point set (distributor arm & breaker)	12171
F			
Felt (distributor cam lubricator)	12A055	R	
Filter (distributor vacuum control valve)	12A120	Relay (ignition current amplifier)	12A042
		Resistor assy. (ignition coil)	12250
		Resistor & bracket assy. (ignition ballast)	12A046
G			
Gasket (distributor base)	12143	Retainer (distributor breaker plate)	12146
Gasket (distributor diaphragm vacuum connector)	12320	Retainer (distributor cam)	12177
Gear (distributor driven)	12390	Retainer (distributor rotor)	12213
Governor assy. (eng.)	12450		
		Rivet (distributor terminal housing hold down clamp)	12145
		Rotor assy. (distributor)	12200

INDEX

PART NAME	GROUP NUMBER
S	
Screw (carb. float shaft)	12230
Screw (distributor point)	12230
Seal (wire terminal weather)	12113
Seperator (ignition wire)	12297
Shaft (distributor)	12175
Shaft & cam assy. (distributor)	12175
Sleeve (distributor shaft plate)	12A075
Snap ring (distributor breaker plate)	12146
Spark plug assy.	12405
Spring (distributor breaker plate)	12A187
Spring (distributor weight)	12191-2
Stop (distributor vacuum advance)	12202
Strap (ignition coil mounting)	12043-4
Switch assy. (distributor modulator ambient)	12A164
T	
Tab (distributor vacuum advance control bracket lock)	12A143
Tube (distributor vacuum)	12226
Tube & bracket assy. (vacuum)	12A163
Tune-up kit	12405

PART NAME	GROUP NUMBER
V	
Valve assy. (distributor modulator)	12A170
Valve assy. (distributor vacuum control)	12A091
Valve assy. (distributor vacuum delay control)	12A091
Valve & bracket assy. (distributor vacuum advance control)	12A111
W	
Washer (distributor driven gear thrust)	12179
Weight assy. (distributor)	12188
Wick (distributor shaft)	12133
Wire assy. (distributor breaker ground)	12264
Wire assy. (distributor primary terminal)	12216
Wire assy. (distributor to spark plug radio resistance)	12286
Wire assy. (distributor vacuum control valve)	12A190
Wire assy. (eng. governor control valve)	12K454
Wire assy. (ignition coil ground)	12A069
Wire assy. (ignition current amplifier)	12045
Wire assy. (starter motor circuit jumper)	12638
Wire assy. (transistorized ignition system)	12071
Wire set (spark plug)	12259
Wiring assy. (ignition coil to distributor high tension)	12298

HOW TO FIND DISTRIBUTORS and COMPONENTS

To find Distributor (other than Calibration) Parts:

(Calibration Parts are listed by Code Number on Pages 9, 10 and 11 of this section.)

By IDENTIFICATION:

1. Refer to Identification Chart below.
2. Check marking (on distributor) against identification numbers.
3. Select and refer to appropriate Parts List Section and Number.
4. If basic number is not known, refer to illustration page shown in the Ford Car Master Illustrations Catalog (Form FP 7635-B), or to the Index at the beginning of this section.
5. Select part number shown from appropriate Parts List. If more than one part number is shown, refer to Description and Restrictions for clarification.
6. Quantity of parts shown in columns A, B, C etc.
7. Part numbers are listed numerically.

By MODEL APPLICATION:

1. Refer to Model Application Chart beginning on Page 11.
2. Refer to appropriate Engine, Year and Model.

Identification Example: C8AF 12127-A is listed in Parts List Section 120.2, Column D. Calibration parts are listed by Code number on pages 9, 10 and 11 of this section. (Cam-basic 12210, Springs-basic 12191-2 and Stop-basic 12202) are listed by Code Number etc.

Model Application Example: For an 8 cyl. 390 engine on a 1967 Ford use distributor C7AZ 12127-D (identified C7AF 12127-D or C7AF 12127-AA). Internal parts for this distributor are listed in Parts List Section 120.4, column G.

12127**DISTRIBUTOR IDENTIFICATION CHART**

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES . NO.	CALIBRATION CODE NUMBER						REFER TO ILLUS. SEC. 120 PAGE
				DIAPHRAGM ASSY. (12370)	CAM (12210)	SPRINGS (12191-2)			STOP (12202)	
						PRIMARY	SECOND- ARY	VACUUM		
A72SX 12100-BA	#	D2FZ 12127-E	(DA-1223)	309						
701F 12100-EA	120.5A	★D1FZ 12127-B r/b D2FZ 12127-A	(DA-1092)	316	114	234	240	218	9	10
701F 12100-DA		★D1FZ 12127-B r/b D2FZ 12127-A	(DA-1092)							10
71HM 12100-ABA	120.5B	D1FZ 12127-A	(DA-1047)	319		256	257			9
71HM 12100-AEA	120.5C	D1FZ 12127-C	(DA-1105)	320		258	259			9
72HF 12100-DC	#	★D2FZ 12127-C r/b D3FZ 12127-A	(DA-1221)	396						9
72HF 12100-FA	#	★D2FZ 12127-D r/b D3FZ 12127-B	(DA-1222)	395						9
72HF 12100-SC	#	D2FZ 12127-E	(DA-1223)	396						9
721F 12100-YA	120.5D	D2FZ 12127-A	(DA-1219)	324	123	236	240	229	20	10
721F 12100-TA	120.5D	D2FZ 12127-B	(DA-1220)	324	123	236	240	229	20	10
721F 12100-AJA	120.5E	★D2FZ 12127-F Not replaced	(DAE-1238)	397	122	240				10
721F 12100-AHA	120.5E	D2FZ 12127-G	(DAE-1239)	397	122	240				10
73HF 12100-AA	#	D3FZ 12127-A	(DA-1271)	318						
73HF 12100-GA	#	D3FZ 12127-B	(DA-1288)							9
C3OF 12127-D	120.3A	★C3OZ 12127-D r/b C5OZ 12127-E			104	222	232			5
C3OF 12127-F	120.3A	★C3OZ 12127-D r/b C5OZ 12127-E			104	222	232			5
C4AF 12127-M	120.4N	★C4AZ 12127-M r/b C4AZ 12127-P	(DA-624)	301	103	210	201	217	2	5
C4DF 12127 B	120.1A	★C4DZ 12127-B r/b C4DZ 12127-E	(DA-627)	302		231	211			3
C4GF 12127-B	120.4A	★C4GY 12127-B r/b C7ZZ 12127-A		301	103	228	201	216	10	6
C4OF 12127-B	120.4A	C4OZ 12127-B	(DA-631)		103	223	206	218	1	6
C4ZF 12127-A	120.1A	★C5ZZ 12127-A r/b C4DZ 12127-D	(DA-661)	302		226	231			3
C4ZF 12127-B	120.4A	★C5ZZ 12127-B r/b C4OZ 12127-B	(DA-662)	301	103	222	230	211	3	6
C4ZF 12127-C	120.4A	★C5ZZ 12127-C r/b C7ZZ 12127-A		301	103	222	204	216	10	6
C4ZF 12127-D	120.3A	★C5ZZ 12127-D r/b C5OZ 12127-E								6

Not available

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

12127 IDENTIFICATION CHART - continued

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES NO.	CALIBRATION CODE NUMBER						REFER TO ILLUS. SEC. 120 PAGE
				DIAPHRAGM ASSY. (12370)	CAM (12210)	SPRINGS (12191-2)			STOP (12202)	
						PRIMARY	SECOND- ARY	VACUUM		
C4ZF 12127-E	120.4A	★C5ZZ 12127-E r/b C4OZ 12127-B		301	103					6
C5AF 12127-A	120.4H	C5AZ 12127-A	(DA-674)	303	107	241	233	229	2	6
C5AF 12127-AD	120.1C	★C5AZ 12127-K r/b C5TZ 12127-AD		302						4
C5AF 12127-AE	120.1C	★C5AZ 12127-L r/b C5AZ 12127-P		302		212	212			4
C5AF 12127-AK	120.2C	★C5AZ 12127-AA r/b C5AZ 12127-BU	(DA-683)	304	111	241	240	217	2	4
C5AF 12127-AL	120.2C	★C5AZ 12127-AL r/b C5AZ 12127-BU		304	110	236	233	225	7	4
C5AF 12127-AM	120.2C	★C5AZ 12127-AL r/b C5AZ 12127-BU		304	110	236	233	225	7	4
C5AF 12127-B	120.4H	★C5AZ 12127-B r/b C5AZ 12127-W	(DA-675)	303	107	234	233	229	2	6
C5AF 12127-BG	120.4M	★C4AZ 12127-M r/b C4AZ 12127-P	(DA-624)	303	108	243	244	229	2	6
C5AF 12127-BU	120.2C	C5AZ 12127-BU	(DA-728)	304	110	238	233	216	5	4
C5AF 12127-C	120.4H	★C5AZ 12127-C r/b C5AZ 12127-W		303	107	234	233	229	3	6
C5AF 12127-E	120.3D	★C5AZ 12127-E r/b C0AZ 12127-L	(DA-677)		108	236	233			6
C5AF 12127-E	120.3D	C0AZ 12127-L	(DA-909)		108	236	233			6
C5AF 12127-F	120.3E	★C5AZ 12127-F r/b C0AZ 12127-L	(DA-678)		108	236	233			6
C5AF 12127-M	120.4E	★C5AZ 12127-M r/b C7ZZ 12127-A		303	107	241	240	216	1	6
C5AF 12127-N	120.4E	★C5AZ 12127-N r/b C7ZZ 12127-A	(DA-680)	303	107	234	233	216	11	6
C5DF 12127-C	120.1A	★C5DZ 12127-C r/b C4DZ 12127-D		302		226	212			3
C5DF 12127-D	120.1B	★C5DZ 12127-D r/b C4OZ 12127-F		302		231	213			3
C5DF 12127-E	120.1A	★C5DZ 12127-E r/b C4DZ 12127-D	(DA-687)	302		226	215			3
C5DF 12127-F	120.1B	★C5DZ 12127-F r/b C4OZ 12127-F	(DA-688)	302		212	212			3
C5DF 12127-K	120.1B	★C5DZ 12127-F r/b C4OZ 12127-F	(DA-688)	302		226	213			3
C5GF 12127-A	120.4E	★C5GY 12127-A r/b C7ZZ 12127-A	(DA-690)	303	108	234	235	218	1	6
C5GF 12127-B	120.4E	★C5GY 12127-B Not replaced		303						6
C5GF 12127-C	120.4D	★C4GY 12127-B r/b C7ZZ 12127-A		303	107	241,210	233	216	10	6
C5JF 12127-B	120.4D	C4OZ 12127-B	(DA-631)	303	108	237	240	218	1	6
C5MF 12127-A	120.4H	★C5MY 12127-A r/b C5AZ 12127-A	(DA-693)	303	107	241	240	225	5	6
C5OF 12127-E	120.3C	C5OZ 12127-E	(DA-691)		107	236	235			6
C5SF 12127-B	120.4P	★C5SZ 12127-B r/b C5AZ 12127-W	(DA-692)	303	109	234	233	229	3	6
C5TF 12127-AC	120.1C	★C5TZ 12127-AC r/b C5TZ 12127-AD				231	215			3
C5UF 12127-B	120.4D	C4OZ 12127-B	(DA-631)	303	108	237	240	218	1	6
C5ZF 12127-J	120.4D	★C5ZZ 12127-B r/b C4OZ 12127-B	(DA-662)	303	108	236	240	218	6	6
C6AF 12127-A	120.4H	★C6AZ 12127-A r/b C7AZ 12127-A	(DA-733)	303	107	238	240	218	9	6
C6AF 12127-AA	120.2C	★C5AZ 12127-AA r/b C5AZ 12127-BU	(DA-683)	304	111	241	240	217	2	4

12127 IDENTIFICATION CHART - continued

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES NO.	CALIBRATION CODE NUMBER						REFER TO ILLUS. SEC. 120 PAGE
				DIAPHRAGM ASSY. (12370)	CAM (12210)	SPRINGS (12191-2)			STOP (12202)	
						PRIMARY	SECOND- ARY	VACUUM		
C6AF 12127-AB	120.2C	C5AZ 12127-BU	(DA-728)	304	110	238	233	218	5	4
C6AF 12127-AC	120.2C	C6AZ 12127-G	(DA-749)	304	110	234	240	217	3	4
C6AF 12127-AD	120.2C	C6AZ 12127-N	(DA-750)	304	111	241	233	225	3	4
C6AF 12127-AG	120.4H	★C6AZ 12127-AG r/b C6AZ 12127-L		303	108	243	233	229	2	6
C6AF 12127-AH	120.4L	C6AZ 12127-AH	(DA-756)	303	107	237	233	216	9	13
C6AF 12127-AJ	120.4E	★C6AZ 12127-J r/b C7AZ 12127-U	(DA-751)	303	108	237	240	216	11	6
C6AF 12127-AK	120.4E	C6AZ 12127-S	(DA-752)	303	108	236	219	216	11	6
C6AF 12127-B	120.4H	C7AZ 12127-E	(DA-784)	303	107	236	233	218	9	6
C6AF 12127-BA	120.4H	★C6AZ 12127-BA r/b C7SZ 12127-H	(DA-817)	303	108	234	240	229	6	6
C6AF 12127-C	120.4H	★C6AZ 12127-C r/b C7AZ 12127-E	(DA-735)	303	107	241	233	218	9	6
C6AF 12127-D	120.4H	★C6AZ 12127-D r/b C4AZ 12127-P	(DA-736)	303	107	236	244	218	9	6
C6AF 12127-E	120.4H	★C6AZ 12127-F r/b C4AZ 12127-P		303	108	237	233	216	9	6
C6AF 12127-E	120.4H	★C6AZ 12127-E r/b C4AZ 12127-P	(DA-737)	303	108	237	233	216	9	6
C6AF 12127-J	120.4E	★C6AZ 12127-J r/b C7AZ 12127-U	(DA-751)	303	108	243	233	218	11	6
C6AF 12127-K	120.4H	★C6AZ 12127-K r/b C8AZ 12127-J	(DA-738)	303	108	243	240	218	9	6
C6AF 12127-L	120.4H	★C6AZ 12127-L Not Replaced	(DA-739)	303	108	243	233	218	5	6
C6AF 12127-M	120.4H	★C6AZ 12127-M r/b C4AZ 12127-P		303						6
C6AF 12127-S	120.4E	C6AZ 12127-S	(DA-752)	303	108	241	233	218	7	6
C6AF 12127-T	120.4H	C6AZ 12127-T	(DA-740)	303	108	243	240	218	9	6
C6AF 12127-U	120.4H	★C6AZ 12127-U r/b C6AZ 12127-L		303						6
C6AF 12127-V	120.4H	★C6AZ 12127-V r/b C4AZ 12127-P or r/b C6AZ 12127-L		303						6
C6AF 12127-Y	120.1D	C5AZ 12127-P	(DA-912)	302		212	212			4
C6DF 12127-A	120.2A	C6DZ 12127-A	(DA-741)	304	110	241	240	229	2	3
C6DF 12127-C	120.2A	C6DZ 12127-C	(DA-742)	304	110	238	240	217	3	3
C6DF 12127-D	120.2A	C6DZ 12127-D	(DA-743)	304	110	234	240	229	2	3
C6DF 12127-E	120.2A	★C6DZ 12127-E r/b C6DZ 12127-K		304	110	234	240	218	7	3
C6DF 12127-K	120.2A	C6DZ 12127-K	(DA-774)	304	110	234	240	217	3	3
C6MF 12127-A	120.4H	C4AZ 12127-P	(DA-911)	303	108	236	233	218	1	6
C6OF 12127-E	120.4H	★C6OZ 12127-E r/b C6AZ 12127-K		303						6
C6OF 12127-F	120.4H	★C6OZ 12127-F r/b C6AZ 12127-T		303						6
C6OF 12127-G	120.4H	★C6OZ 12127-G r/b C6AZ 12127-L		303						6
C6OF 12127-H	120.4H	★C6OZ 12127-H r/b C6AZ 12127-L		303						6
C6OF 12127-J	120.4H	C6OZ 12127-J	(DA-771)	303	107	234	233	249	5	6
C6SF 12127-B	120.4R	★C6SZ 12127-B r/b C4AZ 12127-P	(DA-745)	303	109	237	233	218	5	6
C6SF 12127-D	120.4R	C6SZ 12127-D	(DA-746)	303	108	243	233	218	5	6
C6TF 12127-AC	120.1D	C5TZ 12127-AD	(DA-917)	302						4
C6TF 12127-BH	120.4E	★C6TZ 12127-BH r/b C7AZ 12127-U		303						6
C6ZF 12127-A	120.4E	★C6ZZ 12127-A r/b C7ZZ 12127-A	(DA-747)	303	108	243	235	216	6	6

12127 IDENTIFICATION CHART - continued

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES NO.	CALIBRATION CODE NUMBER						REFER TO ILLUS. SEC. 120 PAGE
				DIAPHRAGM ASSY. (12370)	CAM (12210)	SPRINGS (12191-2)			STOP (12202)	
						PRIMARY	SECOND- ARY	VACUUM		
C6ZF 12127-B	120.4E	★C6ZZ 12127-B r/b C7OZ 12127-E	(DA-748)	303	108	234	235	218	2	6
C7AF 12127-A	120.4G	C7AZ 12127-A	(DA-780)	303	107	238	240	218	9	6
C7AF 12127-B	120.4G	C7AZ 12127-B	(DA-781)	303	107	236	233	218	9	6
C7AF 12127-C	120.4G	C8AZ 12127-J	(DA-872)	303	108	243	240	218	9	6
C7AF 12127-D	120.4G	C7AZ 12127-D	(DA-783)	303	108	243	240	218	9	6
C7AF 12127-E	120.4G	C7AZ 12127-E	(DA-784)	303	107	241	233	★	9	6
C7AF 12127-F	120.4G	★C7AZ 12127-F r/b C6MY 12127-B		303						
C7AF 12127-H	120.4G	★C7AZ 12127-H r/b C7SZ 12127-B		303						
C7AF 12127-J	120.4G	★C7AZ 12127-J r/b C6MY 12127-B	(DA-788)	303	107	237	233	218	9	6
C7AF 12127-L	120.4G	C7AZ 12127-L	(DA-790)	303	108	243	240	229	11	6
C7AF 12127-M	120.4G	★C7AZ 12127-M r/b C7SZ 12127-B		303						6
C7AF 12127-N	120.4G	C8AZ 12127-J	(DA-872)	303	107	237	233	218	9	6
C7AF 12127-S	120.4G	★C7AZ 12127-S r/b C8AZ 12127-J		302						6
C7AF 12127-T	120.4G	★C7AZ 12127-T r/b C8AZ 12127-J		303						6
C7AF 12127-U	120.4G	C7AZ 12127-U	(DA-796)	303	107	243	244	216	12	6
C7AF 12127-V	120.4G	C7AZ 12127-U	(DA-796)	303	107	243	244	216	12	6
C7AF 12127-Z	120.4G	C8AZ 12127-J	(DA-872)	303	107	236	240	216	2	6
C7AF 12127-AA	120.4G	C7AZ 12127-D	(DA-783)	303	107	241	233	216	9	6
C7AF 12127-AC	120.4G	C7AZ 12127-L	(DA-790)	303	107	234	233	218	9	6
C7AF 12127-AD	120.4G	C7AZ 12127-A	(DA-780)	303	107	238	240	216	11	6
C7AF 12127-AE	120.4G	★C7AZ 12127-AE r/b C7ZZ 12127-A		303	107	243	235	216	2	6
C7AF 12127-AF	120.4G	C8AZ 12127-J	(DA-872)	303	107	237	233	218	9	6
C7AF 12127-AG	120.4G	C7AZ 12127-AG	(DA-841)	303	107	236	233	218	2	6
C7AF 12127-AH	120.4F	★C7AZ 12127-AH r/b C7AZ 12127-AJ		303	107	236	244	216	10	6
C7DF 12127-A	120.2A	C7DZ 12127-A	(DA-798)	304	111	234	240	225	14	3
C7DF 12127-B	120.2A	C7DZ 12127-A	(DA-798)	304	111	234	240	225	14	3
C7DF 12127-C	120.2A	C7DZ 12127-F	(DA-842)	304	111	238	244	217	3	3
C7DF 12127-D	120.2A	C7DZ 12127-F	(DA-842)	304	111	234	233	217	3	3
C7DF 12127-F	120.2A	C7DZ 12127-F	(DA-842)	304	111	236	242	217	14	3
C7DF 12127-G	120.2A	C7DZ 12127-G	(DA-844)	304	110	237	255	229	13	3
C7MF 12127-A	120.4G	C6MY 12127-B	(DA-836)	303	107	236	244	218	1	6
C7MF 12127-G	120.4G	★C7SZ 12127-D r/b C6MY 12127-B	(DA-848)	303	107	236	233	216	4	6
C7MF 12127-H	120.4G	C7SZ 12127-H	(DA-805)	303	107	243	233	216	4	6
C7OF 12127-A	120.4F	C7OZ 12127-A	(DA-802)	303	107	241	240	218	1	6
C7OF 12127-B	120.4F	★C7OZ 12127-B r/b C7ZZ 12127-A		303	107	234	244	216	11	6
C7OF 12127-D	120.4F	C7OZ 12127-D	(DA-805)	303	108	237	240	218	2	6
C7OF 12127-E	120.4F	C7OZ 12127-E	(DA-806)	303	108	236	233	218	2	6
C7OF 12127-F	120.4G	C7OZ 12127-F	(DA-807)	303	108	243	233	216	12	6
C7OF 12127-G	120.4G	C7OZ 12127-F	(DA-807)	303	108	243	233	216	12	6
C7OF 12127-H	120.4G	★C7OZ 12127-H r/b C7AZ 12127-U	(DA-847)	303	107	243	244	216	11	6
C7OF 12127-J	120.4F	C7AZ 12127-AJ	(DA-895)	303	107	236	244	217	9	6
C7OF 12127-K	120.3C	C7ZZ 12127-K	(DA-904)		107	236	235			6
C7SF 12127-A	120.4G	★C7SZ 12127-A r/b C6MY 12127-B	(DA-809)	303	107	236	244	218	9	6
C7SF 12127-B	120.4G	C7SZ 12127-B	(DA-810)	303	108	243	233	218	9	6
C7SF 12127-C	120.4G	★C7SZ 12127-C r/b C6MY 12127-B		303						6

12127 IDENTIFICATION CHART - continued

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES NO.	CALIBRATION CODE NUMBER						REFER TO ILLUS. SEC. 120 PAGE
				DIAPHRAGM ASSY. (12370)	CAM (12210)	SPRINGS (12191-2)			STOP (12202)	
						PRIMARY	SECOND- ARY	VACUUM		
C7SF 12127-E	120.4G	★C7SZ 12127-E r/b C6MY 12127-B		303	107	234	233	218	9	6
C7SF 12127-F	120.4G	★C7SZ 12127-F r/b C6MY 12127-B	(DA-849)	303	107	234	233	218	9	6
C7TF 12127-F	120.4G	C5AZ 12127-W	(DA-913)	303	107	234	233	229	2	6
C7TF 12127-J	120.2A	★C7TZ 12127-J r/b C6DZ 12127-A		304	110	237	240	225	14	3
C7TF 12127-L	120.2A	★C7TZ 12127-J r/b C6DZ 12127-A		304	110	237	240	225	14	3
C7TF 12127-T	120.4F	C7TZ 12127-T	(DA-851)	303	107	236	233	225	7	6
C7ZF 12127-A	120.4F	C7ZZ 12127-A	(DA-813)	303	108	234	235	218	1	6
C7ZF 12127-B	120.4F	★C7ZZ 12127-B r/b C7ZZ 12127-A		303						6
C7ZF 12127-C	120.4F	C7ZZ 12127-C	(DA-815)	303	107	243	235	216	11	6
C7ZF 12127-D	120.4F	★C7ZZ 12127-D r/b C7ZZ 12127-C		303	107	234	235	218	2	6
C7ZF 12127-E	120.4F	C7ZZ 12127-C	(DA-815)	303	107	243	235	216	2	6
C7ZF 12127-F	120.4F	C7ZZ 12127-A	(DA-813)	303	107	243	235	218	2	6
C7ZF 12127-G	120.4F	★C7ZZ 12127-G r/b C7OZ 12127-E		303	107	241	244	225	2	6
C7ZF 12127-H	120.4F	C7OZ 12127-E	(DA-806)	303	107	234	235	216	2	6
C7ZF 12127-J	120.3C	★C7ZZ 12127-J r/b C7ZZ 12127-K			107	236	235			6
C8AF 12127-A	120.2D	★C8AZ 12127-A r/b D2UZ 12127-A	(DA-1141)	360		238	244	225	7	4
C8AF 12127-AD	120.4G	★C8AZ 12127-AD r/b C7OZ 12127-F		303						6
C8AF 12127-AE	120.4AY	C8AZ 12127-E	(DA-893)	365	107	236	233			11
C8AF 12127-AF	120.4BC	C8AZ 12127-M	(DA-873)	335	108	236	233			11
C8AF 12127-AG	120.4BC	C8AZ 12127-R	(DA-875)	335	107	234	233			11
C8AF 12127-AH	120.4BC	C8AZ 12127-S	(DA-876)		107	234	233			11
C8AF 12127-AJ	120.4BC	C8AZ 12127-T	(DA-877)	335	107	236	244			11
C8AF 12127-B	120.2D	★C8AZ 12127-B r/b D2AZ 12127-B	(DA-1125)	360	110	236	244	225	14	4
C8AF 12127-E	120.4AC	C8AZ 12127-E	(DA-893)	356	107	236	233	217	11	6
C8AF 12127-F	120.4J	★C8AZ 12127-F r/b C8OZ 12127-C		335						6
C8AF 12127-J	120.4G	C8AZ 12127-J	(DA-872)	303	107	234	233	249	11	6
C8AF 12127-M	120.4C	★C8AZ 12127-M	(DA-873)	355	107	236	233	245	9	6
C8AF 12127-N	120.4C	★C8AZ 12127-N r/b C7AZ 12127-D	(DA-874)	356	107	241	233	216	8	6
C8AF 12127-R	120.4C	C8AZ 12127-R	(DA-875)	356	107	234	233	249	11	6
C8AF 12127-S	120.4C	C8AZ 12127-S	(DA-876)	356	107	243	233	216	4	6
C8AF 12127-T	120.4C	C8AZ 12127-T	(DA-877)	356	107	236	233	249	2	6
C8AF 12127-Y	120.4G	C8AZ 12127-Y	(DA-905)	303	107	236	244	249	11	6
C8DF 12127-A	120.2B	C8DZ 12127-A	(DA-859)	360	111	238	233	229	14	3
C8DF 12127-B	120.2B	★C8DZ 12127-B r/b C8DZ 12127-J	(DA-860)	361	111	237	244	247	3	3
C8DF 12127-C	120.2B	C8DZ 12127-C	(DA-861)	374	111	238	244	245	16	3
C8DF 12127-D	120.2B	C8DZ 12127-D	(DA-862)	374	111	237	246	245	11	3
C8DF 12127-G	120.1A	C4DZ 12127-D	(DA-889)	302		226	212			3
C8DF 12127-H	120.1B	C4OZ 12127-F	(DA-891)	302		226	213			3
C8DF 12127-J	120.2B	C8DZ 12127-J	(DA-965)	361	110	237	239	216	13	3
C8DF 12127-K	120.2K	C8DZ 12127-D	(DA-862)	393	111	237	246			13
C8DF 12127-L	120.2K	C8DZ 12127-C	(DA-861)	394	111	238	244			13
C8DF 12127-N	120.2K	C8DZ 12127-J	(DA-965)	393	110	237	239			13
C8OF 12127-B	120.4J	★C8OZ 12127-B r/b C8TZ 12127-F	(DA-879)	355	107	237	233	250	1	6
C8OF 12127-C	120.4J	C8OZ 12127-C	(DA-880)	356	107	236	233	229	2	6
C8OF 12127-D	120.4Q	C8OZ 12127-D	(DA-881)	357	108	243	233	216	11	6

12127 IDENTIFICATION CHART - continued

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES NO.	DIAPHRAGM ASSY. (12370)	CALIBRATION CODE NUMBER					REFER TO ILLUS. SEC. 120 PAGE
					CAM (12210)	SPRINGS (12191-2)		VACUUM	STOP (12202)	
C8OF 12127-G	120.4G	C8OZ 12127-G	(DA-927)	303	108	236	235	216	12	6
C8OF 12127-H	120.4Q	C8OZ 12127-H	(DA-969)	357	107	243	244	216	11	6
C8OF 12127-J	120.4G	C8OZ 12127-J	(DA-970)	303	107	243	244	216	12	6
C8OF 12127-K	120.4AY	C8OZ 12127-C	(DA-880)	372	107	236	233			11
C8OF 12127-M	120.4BC	C8OZ 12127-D	(DA-881)	371	108	234	233			11
C8OF 12127-N	120.4BC	C8OZ 12127-H	(DA-969)	371	107	234	244			11
C8TF 12127-A	120.2B	*C8TZ 12127-A r/b C8UZ 12127-A		361						3
C8TF 12127-F	120.4J	C8TZ 12127-F	(DA-882)	356	108	237	233	229	2	6
C8UF 12127-A	120.2B	C8UZ 12127-A	(DA-868)	361	110	237	239	203	14	3
C8UF 12127-J	120.1A	C4DZ 12127-E	(DA-890)	302		231	211			3
C8VF 12127-A	120.4S	C8VY 12127-C	(DA-885)	303	107	243	235	217	10	6
C8VF 12127-C	120.4T	C9AZ 12127-F	(DA-933)	356	107	236	235	217	16	6
C8VF 12127-H	120.4AZ	C9AZ 12127-F	(DA-933)	377	107	236	235			11
C8WF 12127-B	120.4C	C8WY 12127-B	(DA-906)	356	107	236	233	216	10	6
C8WF 12127-C	120.4BC	C8WY 12127-B	(DA-906)	355	107	236	233			11
C8ZF 12127-A	120.4J	C8ZZ 12127-A	(DA-887)	307	108	236	235	248	2	6
C8ZF 12127-B	120.4J	*C8ZZ 12127-B r/b C8ZZ 12127-A		307						6
C8ZF 12127-D	120.4F	C8ZZ 12127-D	(DA-907)	303	108	238	235	217	11	6
C8ZF 12127-F	120.4AY	C8ZZ 12127-A	(DA-887)	385	108	236	235			11
C9AF 12127-J	120.4C	C9AZ 12127-B	(DA-929)	303	108	236	233	216	11	6
C9AF 12127-K	120.4G	C9AZ 12127-D	(DA-931)	303	107	236	233	229	2	6
C9AF 12127-M	120.4F	C9AZ 12127-M	(DA-971)	303	107	236	233	225	2	6
C9AF 12127-N	120.4F	C9AZ 12127-M	(DA-971)	303	107	234	235	229	2	6
C9AF 12127-R	120.4J	C9AZ 12127-R	(DA-973)	356	107	234	235	245	9	6
C9AF 12127-U	120.4W	*C9AZ 12127-U r/b C9ZZ 12127-D	(DA-986)	311	112	237	244	229	11	6
C9AF 12127-Y	120.4AD	C9AZ 12127-Y	(DA-981)	394	107	234	235	229	13	6
C9AF 12127-AB	120.4AY	C9AZ 12127-R	(DA-973)	366	107	234	243			11
C9AF 12127-AC	120.4AZ	C9AZ 12127-Y	(DA-981)	338	107	234	235			11
C9DF 12127-B	120.2B	*C9DZ 12127-B r/b D2DZ 12127-A	(DA-937)	360	111	241	233	217	7	3
C9OF 12127-M	120.4V	*C9OZ 12127-E r/b D0OZ 12127-M	(DA-943)	303	107	241	233	218	13	6
C9OF 12127-N	120.4V	*C9OZ 12127-G r/b D0OZ 12127-N	(DA-945)	303	107	237	235	229	6	6
C9OF 12127-R	120.2E	C9OZ 12127-A	(DA-939)	304	111	234	244	217	15	7
C9OF 12127-T	120.4V	*C9OZ 12127-T r/b D0OZ 12127-R	(DA-975)	303	107	236	235	218	6	6
C9OF 12127-U	120.2E	*C9OZ 12127-U r/b C9OZ 12127-V		304	110	236	244	248	1	7
C9OF 12127-V	120.2E	C9OZ 12127-V	(DA-983)	304	110	243	240	225	3	7
C9OF 12127-Z	120.4V	*C9OZ 12127-Z r/b D0OZ 12127-R	(DA-984)	303	107	241	244	245	11	6
C9UF 12127-F	120.2B	C9UZ 12127-F	(DA-972)	360	111	237	244	225	3	3
C9ZF 12127-B	120.4X	*C9ZZ 12127-B r/b D1ZZ 12127-A	(DA-985)	311	112		233	218	16	6
C9ZF 12127-D	120.4AU	C9ZZ 12127-D	(DA-1024)	307	112	238	233	225	10	6
C9ZF 12127-E	120.4X	*C9ZZ 12127-E r/b D1ZZ 12127-A	(DA-1023)	311	112	238	235	225	15	6
C9ZF 12127-F	120.4AV	C9ZZ 12127-D	(DA-1024)	386	112	238	233			6
D0AF 12127-H	120.4K	D0AZ 12127-H	(DA-994)	307	107	241	233	248	#7	6
D0AF 12127-M	120.4C	D0AZ 12127-M	(DA-998)	356	107	234	233	249	2	6
D0AF 12127-T	120.4B	*D0AZ 12127-T r/b D0OZ 12127-AL	(DA-1025)	310	113	236	252	217	3	6
D0AF 12127-V	120.4K	D0AZ 12127-V	(DA-1032)	354	107	241	233	248	#7	6
D0AF 12127-Y	120.4AB	D0AZ 12127-Y	(DA-1033)	356	113	236	235	217	1	6
D0AF 12127-Z	120.4S	D0AZ 12127-Z	(DA-1034)	303	107	236	235	218	12	6

12127 IDENTIFICATION CHART - continued

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES NO.	CALIBRATION CODE NUMBER						REFER TO ILLUS. SEC. 120 PAGE
				DIAPHRAGM ASSY. (12370)	CAM (12210)	SPRINGS (12191-2)			STOP (12202)	
						PRIMARY	SECOND- ARY	VACUUM		
D0AF 12127-AC	120.4K	D0AZ 12127-V	(DA-1032)	354	113	236	235	248	#16	6
D0AF 12127-AE	120.4AT	D0AZ 12127-AE	(DA-1046)	376	113	241	252	218	7	6
D0AF 12127-AG	120.4AX	D0AZ 12127-AE	(DA-1046)	381	113	241	252			11
D0AF 12127-AH	120.4AX	D0AZ 12127-Y	(DA-1033)	370	113	236	235			11
D0AF 12127-AJ	120.4U	D0AZ 12127-V	(DA-1032)	379	107	241	233			11
D0AF 12127-AK	120.4U	D0AZ 12127-H	(DA-994)	367	107	241	233			11
D0AF 12127-AL	120.4BC	D0AZ 12127-M	(DA-998)	335	107	234	233			11
D0AH 12127-A	120.5A	D1FZ 12127-B	(DA-1092)	316	120	234	240	218	19	10
D0DF 12127-C	120.2B	D0DZ 12127-C	(DA-979)	360	110	236	235	241	3	3
D0DF 12127-E	120.2F	D0DZ 12127-B	(DA-978)	361	119	236	233	250		3
D0DF 12127-H	120.2E	*D0DZ 12127-H r/b D2DZ 12127-A	(DA-1029)	304	111	241	233	247	1	3
D0DF 12127-J	120.2E	*D0DZ 12127-J r/b D0DZ 12127-C	(DA-1030)	304	110	236	235	217	14	3
D0DF 12127-K	120.2M	D0DZ 12127-B	(DA-978)	393	119	236	233			3
D0DF 12127-L	120.2K	D0DZ 12127-C	(DA-979)	349	110	236	244			13
D0OF 12127-A	120.2B	*D0OZ 12127-A r/b D2OZ 12127-P	(DA-1006)	360	110	243	241	218	13	7
D0OF 12127-F	120.4T	*D0OZ 12127-F r/b D0OZ 12127-E	(DA-1011)	321						6
D0OF 12127-G	120.4T	D0OZ 12127-T	(DA-1112)	321	107	241	243	217	2	6
D0OF 12127-M	120.4Y	D0OZ 12127-M	(DA-943A)	303	107	241	233	248	5	6
D0OF 12127-N	120.4Y	D0OZ 12127-N	(DA-945A)	303	107	237	235	229	6	6
D0CF 12127-R	120.4Y	D0OZ 12127-R	(DA-984A)	303	107	241	244	245	11	6
D0OF 12127-T	120.4AD	D0OZ 12127-E	(DA-1010)	355	107	251	240	245	9	6
D0OF 12127-U	120.4AA	D0OZ 12127-U	(DA-1036)	303	107	241	233	217	1	6
D0OF 12127-V	120.4T	D0OZ 12127-V	(DA-1037)	356	107	238	233	217	5	6
D0OF 12127-Y	120.4Z	D0OZ 12127-K	(DA-1014)	354	108	236	233	247	12	6
D0OF 12127-Z	120.4AS	D0OZ 12127-G	(DA-1012)	357	107	241	235	217	2	6
D0OF 12127-AA	120.4AQ	D0OZ 12127-J	(DA-1022)	317	112	234	233	225	2	12
D0OF 12127-AC	120.4AT	*D0OZ 12127-AC r/b D2OZ 12127-H	(DA-1045)	375	113	236	252	245	7	6
D0OF 12127-AE	120.4AZ	D0OZ 12127-T	(DA-1112)	373	107	241	235			11
D0OF 12127-AF	120.4AZ	D0OZ 12127-V	(DA-1037)	372	107	238	233			11
D0OF 12127-AG	120.4AZ	D0OZ 12127-K	(DA-1014)	338	108	243	233			11
D0OF 12127-AH	120.4AV	D0OZ 12127-J	(DA-1022)	359	118	234	233			12
D0OF 12127-AK	120.4AZ	D0OZ 12127-G	(DA-1012)	372	107	241	235			11
D0OF 12127-AL	120.4BE	D0OZ 12127-AL	(DA-1307)	383	107	234	261			
D0TF 12127-M	120.4AB	D0TZ 12127-M	(DA-1044)	354	113	238	252	249	2	6
D0ZF 12127-C	120.4AE	D0ZZ 12127-C	(DA-1020)	322	118	234	244	218	17	6
D0ZF 12127-G	120.4G	D0ZZ 12127-D	(DA-1021)	303	107	236	233	217	11	6
D0ZF 12127-J	120.4BC	D0ZZ 12127-C	(DA-1020)	362	118	234	244			11
D1AF 12127-CA	120.2H	D1AZ 12127-C	(DA-1090)	360	119	251	252	249	8	4
D1AF 12127-GA	120.4AG	D1AZ 12127-G	(DA-1086)	352	107	241	233	249	11	6
D1AF 12127-GB	120.4U	D1AZ 12127-G	(DA-1086)	369	107	241	233			12
D1AF 12127-HA	120.4AG	D1AZ 12127-H	(DA-1085)	354	107	234	233	249	2	6
D1AF 12127-HB	120.4U	D1AZ 12127-H	(DA-1085)	379	107	234	233			11
D1AF 12127-KB	120.4AN	D1AZ 12127-K	(DA-1083)	354	113	236	244	249	2	6
D1AF 12127-KC	120.4BA	D1AZ 12127-K	(DA-1083)	379	113	234	244			11
D1AF 12127-LB	120.4C	D1AZ 12127-L	(DA-1082)	310	107	234	235	217	2	6
D1AF 12127-LC	120.4BC	D1AZ 12127-L	(DA-1082)		107	243	240			11
D1AF 12127-NA	120.4AH	D1AZ 12127-N	(DA-1080)	354	107	241	244	218	2	6
D1AF 12127-NB	120.4AZ	D1AZ 12127-N	(DA-1080)	382	107	241	244			11
D1AF 12127-SA	120.4AW	D1AZ 12127-S	(DA-1124)	357	113	241	244	217	6	6
D1AF 12127-SB	120.4AX	D1AZ 12127-S	(DA-1124)	331	113	241	244			11
D1AF 12127-TA	120.4AR	*D1AZ 12127-T r/b D2AZ 12127-K	(DA-1215)	355	107	241	233	218	2	12
D1DF 12127-BB	120.2B	*D1DZ 12127-B r/b D2DZ 12127-C	(DA-1076)	360	111	237	252	225	14	3
D1DF 12127-EA	120.4AT	D1DZ 12127-E	(DA-1110)	356	113	236	252	245	10	6

For 1970 Mustang Shelby GT350 with A/Trans it is necessary to change stop #7 or #16 to #14

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

12127 IDENTIFICATION CHART - continued

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES NO.	CALIBRATION CODE NUMBERS						REFER TO ILLUS. SEC. 120 PAGE
				DIAPHRAGM ASSY. (12370)	CAM (12210)	SPRINGS (12191-2)			STOP (12202)	
D1DF 12127-EB	120.4AX	D1DZ 12127-E	(DA-1110)	366	113	236	252			11
D1DF 12127-FA	120.2B	D1DZ 12127-F	(DA-1113)	360	111	238	233	249	13	3
D1DF 12127-FB	120.2K	D1DZ 12127-F	(DA-1113)	384	111	238	233			13
D1DF 12127-GA	120.2J	D1DZ 12127-G	(DA-1075A)	360	117	237	240	229	7	13
D1MF 12127-FA	120.4AP	D1MY 12127-F	(DA-1069)	353	107	236	235	249	17	6
D1MF 12127-FB	120.4AZ	D1MY 12127-F	(DA-1069)	369	107	236	235			11
D1OF 12127-AB	120.2E	D1OZ 12127-A	(DA-1060)	304	111	241	233	229	7	7
D1OF 12127-BB	120.2G	D1OZ 12127-B	(DA-1059)	304	117	237	244	225	5	7
D1OF 12127-CA	120.2B	D1OZ 12127-C	(DA-1058)	361	111	241	233	218	7	7
D1OF 12127-CB	120.2H	D1OZ 12127-C	(DA-1058)	340	111	241	233			7
D1OF 12127-GA	120.4AK	*D1OZ 12127-G r/b D2ZZ 12127-C	(DA-1065)	356	107	241	244	217	9	6
D1OF 12127-LA	120.4AM	D1OZ 12127-L	(DA-1061)	354	116	236	252	217	2	6
D1OF 12127-LB	120.4BA	D1OZ 12127-L	(DA-1061)	372	116	236	252			11
D1OF 12127-PA	120.4AJ	D1OZ 12127-P	(DA-1213)	354	107	241	235	229	6	6
D1ZF 12127-AA	120.4AL	D1ZZ 12127-A	(DA-1048)	363	112	238	235	225		6
D1ZF 12127-AB	120.4BD	D1ZZ 12127-A	(DA-1048)	363	112	238	235			11
D1ZF 12127-BA	120.4AQ	*D1ZZ 12127-B r/b D1ZZ 12127-E or D1ZZ 12127-G	(DA-1111)	317	112	238	244	229	9	12
D1ZF 12127-DA	120.4AV	D1ZZ 12127-D	(DA-1118)	351	112	251	251	229	9	12
D1ZF 12127-DB	120.4AV	D1ZZ 12127-D	(DA-1118)	351	112	251	251			12
D1ZF 12127-EA	120.4AR	D1ZZ 12127-E	(DA-1211)	358	118	238	244	245	11	12
D1ZF 12127-EB	120.4AV	D1ZZ 12127-E	(DA-1211)	358	118	238	244			12
D1ZF 12127-FA	120.4AF	*D1ZZ 12127-F r/b D1ZZ 12127-G	(DA-1212)	303	107	238	240	248	2	6
D1ZF 12127-GA	120.4AH	D1ZZ 12127-G	(DA-1212-A)	307	107	242	233	250	2	6
D1ZF 12127-GB	120.4AZ	D1ZZ 12127-G	(DA-1212-A)	378	108	238	233			11
D2AF 12127-BA	120.2L	D2AZ 12127-B	(DA-1125)	330	110	236	244			13
D2AF 12127-CA	120.4AX	D2AZ 12127-C	(DA-1146)	326	113	237	252			11
D2AF 12127-DA	120.4AX	D2AZ 12127-D	(DA-1147)	326	113	237	252			11
D2AF 12127-EA	120.4AZ	D2AZ 12127-E	(DA-1210)	328	107	241	233			11
D2AF 12127-FA	120.4AZ	D2AZ 12127-F	(DA-1176)	333	108	238	240			11
D2AF 12127-KA	120.4AZ	D2AZ 12127-K	(DA-1180)	329	107	241	233			11
D2AF 12127-MA	120.4BB	*D2AZ 12127-M r/b D2AZ 12127-R	(DA-1182)	332	113	238	252			11
D2AF 12127-MB	120.4AZ	D2AZ 12127-R	(DA-1224-A)	368	107	233	244			11
D2AF 12127-NA	120.4BB	*D2AZ 12127-N r/b D2AZ 12127-R	(DA-1224)	332	113	238	219			11
D2AF 12127-NC	120.4AZ	*D2AZ 12127-N r/b D2AZ 12127-R	(DA-1224)	368	107	237	244			11
D2AF 12127-PA	120.4BA	D2MY 12127-B	(DA-1172)	338	113	238	244			11
D2AF 12127-RA	120.4AZ	D2AZ 12127-E	(DA-1210)	328	107	243	240			11
D2AF 12127-SA	120.4AZ	D2AZ 12127-F	(DA-1176)	333	108	238	240			11
D2BF 12127-AA	120.2K	D2BZ 12127-A	(DA-1126)	336	111	237	244			13
D2BF 12127-EA	120.4AX	D2BZ 12127-E	(DA-1162)		113					11
D2DF 12127-AA	120.2K	D2DZ 12127-A	(DA-1127)	349	111	241	233			13
D2DF 12127-BA	120.2K	D2DZ 12127-B	(DA-1128)	349	111	241	233			13
D2DF 12127-CA	120.2K	D2DZ 12127-C	(DA-1129)	349	111	237	244			13
D2DF 12127-DA	120.2K	D2DZ 12127-D	(DA-1130)	344	110	236	244			13
D2DF 12127-EA	120.2K	D2DZ 12127-E	(DA-1131)	349	111	237	244			13
D2DF 12127-FA	120.2M	D2DZ 12127-F	(DA-1132)	337		238	252			13
D2MF 12127-EA	120.4BB	D2AZ 12127-J	(DA-1179)	331	113	238	252			11
D2MF 12127-FA	120.4BB	D2AZ 12127-H	(DA-1178)	331	113	238	252			11
D2MF 12127-GA	120.4BB	D2MY 12127-G	(DA-1230)	398	113	238	235			11
D2OF 12127-AA	120.4AX	D2OZ 12127-A	(DA-1148)	341	107	238	240			11
D2OF 12127-DA	120.2K	D2OZ 12127-D	(DA-1135)	339	111	241	244			13
D2OF 12127-EA	120.2K	D2OZ 12127-E	(DA-1149)	342	111	251	244			13

12127 IDENTIFICATION CHART - continued

IDENTIFICATION	DISTRIBUTOR PARTS LIST SECTION & NUMBER	SERVICE REPLACEMENT DISTRIBUTOR	MOTORCRAFT SALES NO.	CALIBRATION CODE NUMBERS						REFER TO ILLUS. SEC. 120 PAGE
				DIAPHRAGM ASSY. (12370)	CAM (12210)	SPRINGS (12191-2)			STOP (12202)	
						PRIMARY	SECOND- ARY	VACUUM		
D2OF 12127-HA	120.4AX	D2OZ 12127-H	(DA-1152)	326	113	237	252			11
D2OF 12127-JA	120.4AX	D2OZ 12127-J	(DA-1153)	326	113	237	252			11
D2OF 12127-PA	120.2K	D2OZ 12127-P	(DA-1225)	340	110	234	240			13
D2OF 12127-RA	120.4AX	D2OZ 12127-R	(DA-1226)	343	113	237	219			11
D2SF 12127-EA	120.4BB	D2SZ 12127-E	(DA-1232)	346	113	237	252			11
D2UF 12127-AA	120.2L	D2UZ 12127-A	(DA-1141)	349	111	238	244			13
D2UF 12127-EA	120.4AX	D2UZ 12127-E	(DA-1155)	350	113	238	252			11
D2UF 12127-GA	120.4AX	D2UZ 12127-G	(DA-1157)	350	113	238	252			11
D2VF 12127-AA	120.4BB	D2VY 12127-A	(DA-1200)	346	113	238	219			11
D2VF 12127-BA	120.4BB	D2VY 12127-B	(DA-1201)	347	113	238	252			11
D2ZF 12127-AA	120.4AZ	D2ZZ 12127-A	(DA-1175)	335	107	251	239			11
D2ZF 12127-CA	120.4AZ	D2ZZ 12127-C	(DA-1203)	334	107	241	244			11
D2ZF 12127-EA	120.4AV	★D2ZZ 12127-E r/b D3OZ 12127-F	(DA-1205)	399	107					11
D2ZF 12127-FA	120.4AZ	D2ZZ 12127-F	(DA-1206)		107					11
D2ZF 12127-GA	120.4AZ	D2ZZ 12127-G	(DA-1207)	348	107	238	240			11
D2ZF 12127-GB	120.4AZ	D2ZZ 12127-G	(DA-1207)	348	107	238	240			11
D2ZF 12127-GC	120.4AZ	D2ZZ 12127-G	(DA-1207)	348	107	238	238			11
D2ZF 12127-HA	120.4AZ	D2ZZ 12127-H	(DA-1208)	348	107	238	240			11
D2ZF 12127-HB	120.4AZ	D2ZZ 12127-H	(DA-1208)	348	108	238	238			11
D2ZF 12127-LA	120.4AY	D2OZ 12127-A	(DA-1148)	#	107	238	240			11
Z5AF 12127-B	120.4D	★C5ZZ 12127-C r/b C7ZZ 12127-A	(DA-663)		108	237	235	216	11	6

HOW TO FIND DISTRIBUTOR CALIBRATION PARTS**(Primary, Secondary & Vacuum Springs, Cam & Stop)**

You must know the Distributor Identification Number -

1. Refer to Identification Chart beginning on page 1.
2. Check distributor for marking or identification number and locate same in chart.
3. Find Calibration parts listed by code number in adjacent columns.
4. Refer to Calibration Code and Part Number Cross Reference listed below for appropriate part number.

EXAMPLE: Calibration parts for Distributor identified C8AF 12127-A are -

PRIMARY SPRING - 238 - C5AZ 12192-F, SECONDARY SPRING - 244 - C5VY 12192-A,
VACUUM SPRING - 225 - C0TZ 12192-A, CAM - 111 - C6TZ 12210-B and STOP - 7 - C0TZ 12202-A

DISTRIBUTOR CALIBRATION PARTS CROSS REFERENCE LIST

CODE	PART NUMBER	MOTORCRAFT SALES NUMBER	DESCRIPTION	CODE	PART NUMBER	MOTORCRAFT SALES NUMBER	DESCRIPTION
12202 STOPS - Codes 1 thru 99							
1	FEW 12202-A			11	C5GY 12202-A		
2	B7A 12202-A			12	C7AZ 12202-A		
3	B7A 12202-B			13	C7DZ 12202-A		
4	★B7A 12202-C		Not replaced	14	C7DZ 12202-B		
5	B8A 12202-A			15	★FFA 12202-A r/b B8A 12202-A		
6	B8E 12202-A			16	B8S 12202-A	(DZ-414)	
7	C0TZ 12202-A			17	C7OZ 12202-A		
8	★C3AZ 12202-A		Not replaced	18	D0RY 12202-A		
9	C3AZ 12202-B			19	D1FZ 12202-A		
10	C4AZ 12202-A			20	D1RY 12202-A		

Not available

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

DISTRIBUTOR CALIBRATION PARTS CROSS REFERENCE LIST - continued

CODE	PART NUMBER	MOTORCRAFT SALES NUMBER	DESCRIPTION	CODE	PART NUMBER	MOTORCRAFT SALES NUMBER	DESCRIPTION
12210				CAMS - Codes 101 thru 199			
103	C0TF 12210-B	(DF-329)		112	C9AZ 12210-A	(DF-371)	
104	C3AZ 12210-A	(DF-306)		113	D0AZ 12210-A	(DF-375)	
107	C5AZ 12210-A	(DF-342)		114	D0RY 12210-A	(DFE-376)	
108	C5AZ 12210-B	(DF-343)		116	D1OZ 12210-A	(DF-382)	
109	C5SZ 12210-A	(DF-347)		117	D1TZ 12210-A		
110	C5TZ 12210-A	(DF-344)		118	C9AZ 12210-B	(DF-379)	
111	C6TZ 12210-B	(DF-352)		119	D0DZ 12210-A	(DF-378)	
12191-2				123	D2FZ 12210-A		
201	FFA 12191-A			SPRINGS - Codes 201 thru 299			
203	B7A 12191-B			234	C5AZ 12192-B	(MS-468)	
204	B7A 12191-D	(DZ-353)		235	C5AZ 12192-C	(MS-469)	
206	B8A 12191-A	(DZ-380)		236	C5AZ 12192-D	(MS-470)	
209	B8A 12192-A	(MS-2)		237	C5AZ 12192-E	(MS-471)	
210	B8A 12192-B	(MS-3)		238	C5AZ 12192-F	(MS-472)	
211	A7AZ 12192-A			239	C5AZ 12192-H	(MS-475)	
212	A8TZ 12192-A			240	C5AZ 12192-J	(MS-473)	
213	B2AZ 12192-A			241	C5AZ 12192-K	(MS-474)	
215	B4TZ 12192-A	(MS-20)		242	C5AZ 12192-L	(MS-484)	
216	B7AZ 12192-A			243	C5AZ 12192-M	(MS-483)	
217	B7AZ 12192-B			244	C5VY 12192-A	(MS-476)	
218	B7AZ 12192-C	(MS-429)		245	C8AZ 12192-E	(MS-491)	
219	B7AZ 12192-D	(MS-479)		246	C8AZ 12192-B	(MS-488)	
222	B7QH 12192-C			247	C8AZ 12192-C	(MS-489)	
223	C0AF 12192-A			248	C8AZ 12192-D	(MS-490)	
225	C0TZ 12192-A			249	C6AZ 12192-A	(MS-486)	
226	C1DF 12192-A			250	C8AZ 12192-A	(MS-487)	
228	C2OZ 12192-A			251	D0OZ 12192-A	(MS-492)	
229	C2OZ 12192-B	(MS-431)		252	C9AZ 12192-A	(MS-494)	
230	C2SZ 12192-A			255	C5AZ 12192-N	(MS-493)	
231	C3DZ 12192-A			256	D1FZ 12192-A		
232	C3OZ 12192-A	(MS-480)		257	D1FZ 12192-B		
233	C5AZ 12192-A	(MS-467)		258	D1FZ 12192-C		
261	D3AZ 12192-A	(MS-510)		259	D1FZ 12192-D		
				260	D2WY 12192-A	(MS-506)	
12370 DIAPHRAGM ASSY. - Codes 301 thru 399				329	D2AZ 12370-E	(DD-354)	
301	B9AF 12370-A	(DD-9)		330	D2AZ 12370-F	(DD-351)	
302	C0DF 12370-A	(DD-12)		331	D2AZ 12370-G	(DD-359)	
303	C5AZ 12370-A	(DD-190)		332	D2AZ 12370-H	(DD-366)	
304	C5TZ 12370-A	(DD-191)		333	D2AZ 12370-J	(DD-364)	
307	D2PZ 12370-H	(DD-381)		334	D2AZ 12370-K	(DD-355)	
309	D2FZ 12370-D	(DD-727)		335	D2AZ 12370-L	(DD-362)	
310	★C8AZ 12370-F	(DD-268)		336	D2BZ 12370-A	(DD-349)	
	r/b D2PZ 12370-M			337	D2DZ 12370-A	(DD-350)	
311	C9AZ 12370-A	(DD-256)		338	D2MY 12370-A	(DD-358)	
312	★C9ZZ 12370-A	(DD-630)	Not replaced	339	D2OZ 12370-A	(DD-346)	
313	★C9ZZ 12370-B	(DD-627)		340	D2OZ 12370-B	(DD-345)	
	r/b D2ZZ 12370-H			341	D2OZ 12370-C	(DD-361)	
315	★D0OZ 12370-B	(DD-631)		342	D2OZ 12370-D	(DD-348)	
	r/b D2PZ 12370-M			343	D2OZ 12370-F	(DD-363)	
316	D0RY 12370-B	(DDE-260)		344	D2TZ 12370-A	(DD-352)	
317	★D1AZ 12370-A	(DD-267)		345	D2TZ 12370-H	(DD-353)	
	r/b D2OZ 12370-J			346	D2VY 12370-A	(DD-343)	
318	D3FZ 12370-B	(DD-650)		347	D2VY 12370-B	(DD-341)	
319	D1FZ 12370-A	(DD-262)		348	D2ZZ 12370-A	(DD-339)	
320	D1FZ 12370-B	(DD-261)		349	D2UZ 12370-A	(DD-347)	
321	C8AZ 12370-G	(DD-255)		350	D2UZ 12370-C	(DD-365)	
322	D0ZZ 12370-B	(DD-258)		351	D2ZZ 12370-D	(DD-270-A)	
324	D1RY 12370-A	(DDE-269)		352	D2PZ 12370-D	(DD-376)	
325	★D1ZZ 12370-B	(DD-271)		353	D2PZ 12370-E	(DD-378)	
326	D2AZ 12370-A	(DD-356)		354	D2PZ 12370-F	(DD-259-A)	
327	D2AZ 12370-C	(DD-367)		355	D2PZ 12370-G	(DD-375)	
328	D2AZ 12370-D	(DD-357)					

DISTRIBUTOR CALIBRATION PARTS CROSS REFERENCE LIST - continued

CODE	PART NUMBER	MOTORCRAFT SALES NUMBER	DESCRIPTION	CODE	PART NUMBER	MOTORCRAFT SALES NUMBER	DESCRIPTION
12370 DIAPHRAGM ASSY. - continued							
356	D2PZ 12370-L	(DD-377)		375	D2PZ 12370-J	(DD-382)	
357	D2PZ 12370-M	(DD-631-A)		376	D2PZ 12370-K	(DD-383)	
358	D2AZ 12370-X	(DD-371)		377	D2VY 12370-C	(DD-389)	
359	D2OZ 12370-J	(DD-267-A)		378	D2TZ 12370-E	(DD-360)	
360	D2PZ 12370-A	(DD-237-A)		379	D2UZ 12370-E	(DD-368)	
361	D2PZ 12370-B	(DD-374)		380	D2AZ 12370-M	(DD-397)	
362	D2ZZ 12370-E	(DD-258-A)		381	D2AZ 12370-R	(DD-369)	
363	D2ZZ 12370-G	(DD-372)		382	D2AZ 12370-V	(DD-393)	
364	D2AZ 12370-B	(DD-344)		383	D2PZ 12370-N	(DD-699)	
365	D2AZ 12370-N	(DD-384)		384	D2DZ 12370-C	(DD-396)	
366	D2AZ 12370-P	(DD-386)		385	D2ZZ 12370-C	(DD-392)	
367	D2AZ 12370-S	(DD-401)		386	D2ZZ 12370-H	(DD-380)	
368	D2AZ 12370-Y	(DD-632)		393	D2DZ 12370-E	(DD-460)	
369	D2MY 12370-B	(DD-391)		394	D2DZ 12370-F	(DD-399)	
370	D2MY 12370-C	(DD-385)		395	D2FZ 12370-A	(DDE-402)	
371	D2OZ 12370-E	(DD-388)		396	D2FZ 12370-B	(DDE-403)	
372	D2OZ 12370-G	(DD-387)		397	D2FZ 12370-C	(DDE-276)	
373	D2OZ 12370-H	(DD-390)		398	D2MY 12370-D	(DD-635)	
374	D2PZ 12370-C	(DD-373)		399	D2ZZ 12370-F	(DD-659)	

12127**DISTRIBUTOR APPLICATION CHART**

Determine engine (number of cylinders and C.I.D.), year, model and/or identification.

Find service Distributor as well as Cap, Condenser, Points, Repair and Rotor in adjacent columns.

(Also see Pages 1 thru 9 of this section for PARTS LISTS instructions and DISTRIBUTOR IDENTIFICATION CHART)

PARTS LIST SECTION FOR 4 CYL. 98 1600 cc (1600 cc) and 4 CYL. 122 2000 cc (2000 cc) DISTRIBUTOR COMPONENTS											ILLUS. SEC. 120 PAGE
YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	CAP	CON-DEN-SER	POINTS	REPAIR KIT	ROTOR		
4 CYL. 98 (1600 cc)											
71	L	701F 12100-EA	120.5A	★D1FZ 12127-B (DA-1092) r/b D2FZ 12127-A	e	j	C5AZ 12171-A (DP-77)		D0RY 12200-B (DRE-91)	10	
72	L(exc. Calif.)	721F 12100-YA	120.5D	★D2FZ 12127-A (DA-1219) r/b D2FZ 12127-G	e	j	C5AZ 12171-A (DP-77)		D0RY 12200-B (DRE-91)	10	
72	L(Calif.)	721F 12100-TA	120.5D	D2FZ 12127-B (DA-1220)	e	j	C5AZ 12171-A (DP-77)		D0RY 12200-B (DRE-91)	10	
72	L	721F 12100-AHA	120.5E	D2FZ 12127-G (DA-1239)	e	j	C5AZ 12171-A (DP-77)		D0RY 12200-B (DRE-91)	10	
4 CYL. 122 (2000 cc)											
71	L(S/T)	71HM 12100-ABA	120.5B	D1FZ 12127-A (DA-1047)	d	m	D1FZ 12171-A (DP-124)		D1FZ 12200-A (DR-92)	9	
71	L(A/T)-exc. Calif.	71HM 12100-AEA	120.5C	D1FZ 12127-C (DA-1105)	d	m	D1FZ 12171-A (DP-124)		D1FZ 12200-A (DR-92)	9	
72	L(S/T)	72HF 12100-DC	#	D2FZ 12127-C (DA-1221) R/B D3FZ 12127-A	d	m	D1FZ 12171-A (DP-124)		D1FZ 12200-A (DR-92)	9	
72	L(A/T) - exc. Calif.	72HF 12100-FA	#	D2FZ 12127-D (DA-1222) R/B D3FZ 12127-B	d	m	D1FZ 12171-A (DP-124)		D1FZ 12200-A (DR-92)	9	
72	L(A/T)-Calif.	72HF 12100-SC, A725X 12100-BA	#	D2FZ 12127-E (DA-1223)	d	m	D1FZ 12171-A (DP-124)		D1FZ 12200-A (DR-92)	9	
72	L(A/T)-exc. Calif.	73HF 12100-GA	#	D3FZ 12127-B (DA-1288)	d	p	D1FZ 12171-A (DP-124)		D1FZ 12200-A (DR-92)	9	
72	L(S/T)	73HF 12100-AA	#	D3FZ 12127-A (DA-1271)	d	p	D1FZ 12171-A (DP-124)		D1FZ 12200-A (DR-92)	9	
d - D1FZ 12106-A (DH-157) e - D0RY 12106-A (DHE-156) j - D0RY 12300-A (DCE-238) m - D1FZ 12300-A (DC-88) p - D3FZ 12300-A (DC-89) # Not available											

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS						ILLUS. SEC. 120 PAGE
					CAP	CON-DEN-SER	POINTS	REPAIR KIT	ROTOR		
6 CYL. 170											
65	F(C4)	C4DF 12127-B, C8UF 12127-J	120.1A	C4DZ 12127-E (DA-890)	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3	
65	F(S/T)	C4ZF 12127-A	120.1A	C5ZZ 12127-A r/b C4DZ 12127-D	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3	
65/66	X, U(S/T)- exc. T/E	C5DF 12127-C	120.1A	C5DZ 12127-C R/B C4DZ 12127-D	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3	
65/67	X, U(S/T)- exc. T/E	C8DF 12127-G	120.1A	C4DZ 12127-D (DA-889)	a	k	C3DZ 12171-A (DP-70)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3	
65/66	U, X(S/T)- exc. T/E	C5DF 12127-D, F, K, C8DF 12127-H	120.1B	C4OZ 12127-F (DA-891)	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3	
66	F(3/S/T)- with T/E	C6DF 12127-A, C7TF 12127-J, L	120.2A	C6DZ 12127-A (DA-741)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
67	U(S/T)-with T/E										
66/67	X(C4)-with T/E or Imco	C6DF 12127-D	120.2A	C6DZ 12127-D (DA-742)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
67	X(C4)-exc. T/E	C5DF 12127-F, K C8DF 12127-H	120.1B	C4OZ 12127-F (DA-891)	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3	
67	X(C4)-with Imco	C7DF 12127-G	120.2A	C7DZ 12127-G (DA-844)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
67	X(3/S/T)- with T/E	C7DF 12127-A, B	120.2A	C7DZ 12127-A (DA-798)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
68	U(3/S/T)- with T/E	C8TF 12127-A, C8UF 12127-A	120.2B	C8UZ 12127-A (DA-868)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
68	X(3/S/T)- with T/E	C8DF 12127-A	120.2B	C8DZ 12127-A (DA-859)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
69	U(3/S/T)- with T/E										
70	U(3/S/T)- with Imco										
71	U(3/S/T)-with Imco, exc. Calif.										
69/70	U(3/S/T)- w/Imco, ev/em	C9UF 12127-F	120.2B	C9UZ 12127-F (DA-972)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
71	U(3/S/T)-Calif.										
68/69	X(C4)-with Imco	C8DF 12127-B, J	120.2B	C8DZ 12127-J (DA-965)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
69	X(3/S/T)- with Imco	C9DF 12127-B	120.2B	C9DZ 12127-B r/b D2DZ 12127-A	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
70	P(S/T)-with Imco										
71	P(S/T)-exc. Calif.										
71	P(S/T)-Calif.	D1DF 12127-FA	120.2B	D1DZ 12127-F (DA-1113)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3	
70	P(S/T, Imco)	D0DF 12127-H	120.2E	D0DZ 12127-H R/B C9DZ 12127-B	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13	
70	P(A/T)-w/Imco	D0DF 12127-E	120.2F	D0DZ 12127-B (DA-978)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13	
72	U(S/T, Imco)	D2BF 12127-AA	120.2K	D2BZ 12127-A (DA-1126)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13	
72	P(S/T, Imco) exc. Calif.	D2DF 12127-AA	120.2K	D2DZ 12127-A (DA-1127)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13	
72	P(S/T, Imco)- Calif.	D2DF 12127-BA	120.2K	D2DZ 12127-B (DA-1128)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13	
a - 7HA 12106-A (DH-4)			k - 7RA 12300-C (DC-6)			l - C9AZ 12300-A (DC-13A)					

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS					ILLUS. SEC. 120 PAGE
					CAP	CON- DEN- SER	POINTS	REPAIR KIT	ROTOR	
6 CYL. 200										
65/66	B, F, X(C4)- exc. T/E	C8DF 12127-H	120.1B	C4OZ 12127-F (DA-891)	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3
66	B, F, X(C4)- with T/E	C6DF 12127-E,K	120.2A	C6DZ 12127-K (DA-774)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
66	B, F, X(3/4/S/T)- with T/E	C6DF 12127-C	120.2A	C6DZ 12127-C (DA-742)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
65/67	B, F, X(S/T)- exc. T/E	C5DF 12127-E, C8DF 12127-G	120.1A	C4DZ 12127-D (DA-889)	a	k	C3DZ 12171-A (DP-70)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3
65/67	B, F, X(C4)- with T/E	C5DF 12127-F,K C8DF 12127-H	120.1B	C4OZ 12127-F (DA-891)	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	3
67	B, F, X(C4)- with T/E	C7DF 12127-D	120.2A	C7DZ 12127-F (DA-842)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
67	B, F, X(3/S/T)- with T/E	C7DF 12127-C	120.2A	C7DZ 12127-F (DA-842)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
67	B, F, X(C4)- with Imco	C6DF 12127-D	120.2A	C6DZ 12127-D (DA-743)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
67	B, F, X(C4)- with Imco	C7DF 12127-F	120.2A	C7DZ 12127-F (DA-842)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
68	B, F, X(3/S/T)- with Imco	C8DF 12127-C	120.2B	C8DZ 12127-C (DA-861)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
69	F, X(3/S/T)- with Imco									
68	B, F, X(C4)- with Imco	C8DF 12127-D	120.2B	C8DZ 12127-D (DA-862)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
69	F, X(C4)-with Imco									
70	F(S/T)	D0DF 12127-J	120.2E	D0DZ 12127-J r/b D0DZ 12127-C	a	1	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	C5TZ 12200-B (DR-87)	13
70	P, X(A/T, S/T) F(A/T)	D0DF 12127-C	120.2B	D0DZ 12127-C (DA-979)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
70										
71	P, (A/T, S/T)- exc. California									
71	P(S/T)- California	D1DF 12127-BB	120.2B	D1DZ 12127-B r/b D2DZ 12127-C	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	3
71	P(A/T)-Calif.	D1DF 12127-GA	120.2J	D1DZ 12127-G (DA-1075-A)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
72	P(S/T, Imco)- exc. Calif.	D2DF 12127-CA	120.2K	D2DZ 12127-C (DA-1129)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
72	P(A/T, Imco)- exc. Calif.	D2DF 12127-DA	120.2K	D2DZ 12127-D (DA-1130)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
72	P(S/T, Imco)- Calif.	D2DF 12127-EA	120.2K	D2DZ 12127-E (DA-1131)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
72	P(A/T, Imco)- Calif.	D2DF 12127-FA	120.2M	D2DZ 12127-F (DA-1132)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
6 CYL. 240										
65	A, Taxi, P/C(S/T)- exc. econ. carb.	C5AF 12127-AD	120.1C	C5AZ 12127-K r/b C5TZ 12127-AD	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	4
65/67	A, Taxi, P/C(C4, C/M)-exc. T/E and econ. carb.	C5AF 12127-AE	120.1C	C5AZ 12127-L r/b C5AZ 12127-P	a	k	C9AZ 12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	4
65/67	A, Taxi, P/C(C4, C/M)-exc. econ. carb. & T/E	C6AF 12127-Y	120.1D	C5AZ 12127-P (DA-912)	a	k	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	4
65/67	Taxi, P/C exc. T/E-w/ econ. carb.	C5AF 12127-AK, AL, AM, BU, C6AF 12127-AA, AB	120.2C	C5AZ 12127-BU (DA-728)	a	1	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	4

a - 7HA 12106-A(DH-4)

k - 7RA 12300-C (DC-6)

l - C9AZ 12300-A (DC-13-A)

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS					ILLUS. SEC. 120 PAGE
					CAP	CONDEN-SER	POINTS	REPAIR KIT	ROTOR	
6 CYL. 240 - continued										
65/67	A, Taxi, P/C(S/T-exc. T/E)-exc. econ. carb.	C5TF 12127-AC	120.1C	C5TZ 12127-AC r/b C5TZ 12127-AD	a	k	C9AZ12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	4
65/67	A, Taxi, P/C(S/T-exc. econ. carb.)-exc. T/E	C6TF 12127-AC	120.1D	C5TZ 12127-AD (DA-917)	a	k	C9AZ12171-B (DP-3)	A7A 12000-B (DK-2)	FAA 12200-B (DR-1)	4
66/67	A, Taxi, P/C (3/S/T-w/T/E)-exc. special econ. carb.	C6AF 12127-AC	120.2C	C6AZ 12127-G (DA-749)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	4
66/67	A, Taxi, P/C(C4, T/E)-exc. econ. carb.	C6AF 12127-AD	120.2C	C6AZ 12127-N (DA-750)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	4
68/70 71	A(S/T-w/T/E) A(S/T)	C8AF 12127-A	120.2D	C8AZ 12127-A r/b D2UZ 12127-A	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	4
68/70 71	A(C4 & Imco) A, Taxi, P/C-(C4 trans.)	C8AF 12127-B	120.2D	C8AZ 12127-B r/b D2AZ 12127-B	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	4
71	A, Taxi, P/C-(S/T)	D1AF 12127-CA	120.2H	D1AZ 12127-C (DA-1090)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
68/70 71	A(S/T with T/E) A(S/T)	D2UF 12127-AA	120.2L	D2UZ 12127-A (DA-1141)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-81)	13
72	A, Taxi, P/C-w/A/T, Imco	D2AF 12127-BA	120.2L	D2AZ 12127-B (DA-1125)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
6 CYL. 250										
69	B, F(S/T)	C9OF 12127-R	120.2E	C9OZ 12127-A	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
69	B, F-A/T	C9OF 12127-U,V	120.2E	C9OZ 12127-V	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
70	B, F, P(A/T,S/T, Imco)	D0OF 12127-A	120.2B	D0OZ 12127-A r/b D2OZ 12127-P	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	7
71	B, F, P(S/T) Calif.	D1OF 12127-AB	120.2E	D1OZ 12127-A (DA-1060)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
71	B, F, P(A/T) Calif.	D1OF 12127-BB	120-2G	D1OZ 12127-B (DA-1059)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
71	B, F, P(A/T,S/T)-exc. Calif.	D1OF 12127-CA	120.2B	D1OZ 12127-C (DA-1058)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	7
72	B, F, P(A/T)-California	D2OF 12127-EA	120.2K	D2OZ 12127-E (DA-1149)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
72	B, F, P(A/T)-exc. California	D2OF 12127-DA	120.2K	D2OZ 12127-D (DA-1135)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
72	B, F, P(S/T)	D2OF 12127-PA	120.2K	D2OZ 12127-P (DA-1225)	a	l	C9AZ 12171-B (DP-3)	C5AZ 12000-D (DK-16)	C5TZ 12200-B (DR-87)	13
8 CYL. 260										
65	F(S/T, C4)	C4OF 12127-B, C4ZF 12127-B,E C5ZF 12127-J C5JF 12127-B,	120.4A 120.4D	C4OZ 12127-B (DA-631)	b	l	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6 6
8 CYL. 289										
65	B Special (4/B carb.)	C5OF 12127-E	120.3C	C5OZ 12127-E (DA-691)	b	l	C9AZ12171-C (DP-6)	C5ZZ 12000-A (DK-14)	B7A 12200-A (DR-5)	6
65/67	F Special (4/B carb.)-w/T/E									
65/67	F Special (4/B carb. -S/T)-exc. T/E									
a - 7HA 12106-A (DH-4) b - B7A 12106-A (DH-6) k - 7RA 12300-C (DC-6) l - C9AZ 12300-A (DC-13-A)										

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS					ILLUS. SEC. 120 PAGE
					CAP	CON- DEN- SER	POINTS	REPAIR KIT	ROTOR	
8 CYL. 289 - continued										
65	F Special (4/B carb.)	C3OF 12127-D, C3OF 12127-F	120. 3A	C3OZ 12127-D r/b C5OZ 12127-E	b	1	C9AZ 12171-C (DP-6)	C5ZZ 12000-A (DK-14)	B7A 12200-A (DR-5)	5
65	F(4/B carb. - S/T)-exc. Spec.	C4ZF 12127-C, Z5AF 12127-B	120. 4A 120. 4D	C5ZZ 12127-C r/b C7ZZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6 6
65	F Special	C4ZF 12127-D	120. 3A	C5ZZ 12127-D r/b C5OZ 12127-E	b	k	C9AZ 12171-C (DP-6)	C5ZZ 12000-A (DK-14)	B7A 12200-A (DR-5)	5
65	F(C4)-exc. Special	C4GF 12127-B, C5GF 12127-C	120. 4A 120. 4D	C4GY 12127-B r/b C7ZZ 12127-A	b	k	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6 6
65/66	A, B, F, X(2/B carb.)-S/T exc. T/E	C5AF 12127-M	120. 4E	C5AZ 12127-M r/b C7ZZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
65/66	A, B, F, X(2/B carb.) (C4, C/M- exc. T/E	C5AF 12127-N	120. 4E	C5AZ 12127-N (DA-680) r/b C7ZZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
65/66	B, F, X(4/B carb.) -exc. T/E	C5GF 12127-A	120. 4E	C5GY 12127-A r/b C7ZZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, B, F, X(2/B, 3/4/S/T & T/E)	C6AF 12127-J	120. 4E	C6AZ 12127-J r/b C7OZ 12127-D	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, B, F, X(2/B, C/M, C4 & T/E)	C6AF 12127-AK	120. 4E	C6AZ 12127-S (DA-752)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK10)	B7A 12200-A (DR-5)	6
66	F, X(4/B, 3/4/S/T & T/E)	C6ZF 12127-A	120. 4E	C6ZZ 12127-A (DA-747) r/b C7ZZ 12127-C	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	F, X(4/B, C4 & T/E)	C6ZF 12127-B	120. 4E	C7OZ 12127-E (DA-806)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	A, B, F, X(2/B carb.) (C4-exc. T/E)	C7AF 12127-AE	120. 4G	C7AZ 12127-AE R/B C7OZ 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	A, B, F, X, U(2/B carb.) (C4-exc. T/E)	C7OF 12127-B	120. 4F	C7OZ 12127-B R/B C7ZZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	A, B, F, X(2/B, C4, T/E)-P/C & Taxi	C7AF 12127-AH	120. 4F	C7AZ 12127-AH R/B C7AZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	A, B, F, X(2/B, C4, T/E)-P/C & Taxi	C7OF 12127-J	120. 4F	C7AZ 12127-AJ (DA-895)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	A, B, F, X, U(2/B carb.) (3/4/S/T- exc. T/E)	C7OF 12127-A	120. 4F	C7OZ 12127-A (DA-802)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	A, B, F, X(2/B, C4 & T/E)	C7OF 12127-E	120. 4F	C7OZ 12127-E (DA-806)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	F, X(4/B, C4)- exc. T/E	C7ZF 12127-B	120. 4F	C7ZZ 12127-B R/B C7ZZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	F, X(4/B, 3/4/S/T & T/E)	C7ZF 12127-C, C7ZF 12127-E	120. 4F	C7ZZ 12127-C (DA-815)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	F, X(4/B, C4 & T/E)	C7ZF 12127-D	120. 4F	C7ZZ 12127-D R/B C7ZZ 12127-C	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	F, X(4/B, C4 & T/E)	C7ZF 12127-G	120. 4F	C7ZZ 12127-G R/B C7ZZ 12127-H	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	F, X(4/B, C4 & T/E)	C7ZF 12127-H	120. 4F	C7OZ 12127-E (DA-806)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	F Special (4/B carb. & T/E)	C7ZF 12127-J	120. 3C	C7ZZ 12127-J R/B C7ZZ 12127-K	b	k	C9AZ 12171-C (DP-6)	C5ZZ 12000-A (DK-14)	B7A 12200-A (DR-5)	6
67	U(T/E)	C7TF 12127-T	120. 4F	C7TZ 12127-T (DA-851)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6

b - B7A 12106-A (DH-6)

k - 7RA 12300-C (DC-6)

l - C9AZ 12300-A (DC-13-A)

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

SECTION 120

FORD CAR PARTS

See PAGE 1 of this SECTION for
DISTRIBUTOR COMPONENT INFORMATION

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS						ILLUS. SEC. 120 PAGE
					CAP	CON DEN- SER	POINTS	REPAIR KIT	ROTOR		
8 CYL. 289 - continued											
67	A, B, F, X(2/B, 3/4/S/T & T/E)	C7OF 12127-D	120.4F	C7OZ 12127-D R/B C7AZ 12127-U	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	B, F, X, U(2/B, 3/S/T & T/E)										
67/68	B, F, X Special (4/B carb. & T/E)	C7OF 12127-K	120.3C	C7ZZ 12127-K (DA-904)	b	k	C9AZ 12171-C (DP-6)	C5ZZ 12000-A (DK-14)	B7A 12200-A (DR-5)	6	
67/68	F, X(4/B, 3 or 4 S/T-exc. T/E)	C7ZF 12127-A, C7ZF 12127-F	120.4F	C7ZZ 12127-A (DA-813)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	B, F, X(2/B, A/T & Imco)	C8OF 12127-C	120.4J	C8OZ 12127-C (DA-880)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	U(3/S/T & T/E)	C8TF 12127-F	120.4J	C8TZ 12127-F (DA-882)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
8 CYL. 302											
68	A, B(2/B, A/T & Imco)-Taxi, P/C	C8AF 12127-F	120.4J	C8AZ 12127-F R/B C8OZ 12127-C	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	B, F, X(2/B, A/T & Imco)	C8OF 12127-C	120.4J	C8OZ 12127-C (DA-880)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	F(4/B, A/T & Imco)	C8ZF 12127-B	120.4J	C8ZZ 12127-B R/B C8ZZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	F, X(4/B, A/T & Imco)	C8ZF 12127-D	120.4F	C8ZZ 12127-D (DA-907)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	F, X(4/B, 3/S/T & T/E)	C8ZF 12127-A	120.4J	C8ZZ 12127-A (DA-887)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68/69	A, B(2/B, S/T & T/E)	C8AF 12127-E	120.4AC	C8AZ 12127-E (DA-893)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	A, Taxi, P/C, B, F, X(S/T & Imco)										
69	A, B, F, X, Taxi, P/C(2/B, A/T & Imco)w/o A/C	C9AF 12127-N	120.4F	C9AZ 12127-M (DA-971)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	A, B, F, X, Taxi, P/C(A/T w/A/C)	C9AF 12127-R	120.4J	C9AZ 12127-R (DA-973)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	F Boss(4/B, S/T w/ T/E)	C9ZF 12127-B	120.4X	C9ZZ 12127-B R/B C9ZZ 12127-E	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	6	
70/71	A(Taxi, P/C)-A/T	D0OF 12127-AL	120.4BE	D0OZ 12127-AL (DA-1307)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69/70	F-Boss(4/B, S/T w/ T/E)	C9ZF 12127-E	120.4X	C9ZZ 12127-E (DA-1023) r/b D1ZZ 12127-A	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	6	
69/70	U(2/B, S/T/Imco)	C8TF 12127-F	120.4J	C8TZ 12127-F (DA-882)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
70	A, B, F, P/C, Taxi, (2/B, A/T, Imco)	D0AF 12127-T	120.4B	D0AZ 12127-T (DA-1025) R/B D0OZ 12127-AL	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
70	A, B, F, P/C, Taxi (2/B, S/T, Imco)	D0AF 12127-Y	120.4AB	D0AZ 12127-Y (DA-1033)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
70/71	A, P/C, Taxi (2/B, A/T, Imco)-exc. A/C	D0AF 12127-AE	120.4AT	D0AZ 12127-AE (DA-1046)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
70/71	B, F, X(2/B, A/T, Imco)	D0OF 12127-AC	120.4AT	D0OZ 12127-AC (DA-1045) r/b D2OZ 12127-H	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
71	A, B, F, P(2/B, S/T)	D0AF 12127-Y	120.4AB	D0AZ 12127-Y (DA-1033)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
71	A, B, F, P(2/B, A/T)	D0AF 12127-T	120.4B	D0AZ 12127-T (DA-1025)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	

b - B7A 12106-A(DH-6) k - 7RA 12300-C(DC-6) 1 - C9AZ 12300-A(DC-13A)

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	CAP	CON-DEN-SER	DISTRIBUTOR COMPONENTS				ILLUS. SEC. 120 PAGE
							POINTS	REPAIR KIT	ROTOR		
8 CYL. 302 - continued											
71	A, Taxi, P/C,	D1AF 12127-SA	120.4AW	D1AZ 12127-S (DA-1124)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6	
71	F(4/B,S/T)-with T/E	D1ZF 12127-AA AB	120.4AI	D1ZZ 12127-A (DA-1048)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6	
71	P(2/B,A/T)	D1DF 12127-EA	120.4AT	D1DZ 12127-E (DA-1110)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
71	U(2/B,S/T)	D0TF 12127-M	120.4AB	D0TZ 12127-M (DA-1044)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
72	A,B,Taxi,P/C-(2/B,A/T)-exc.California	D2AF 12127-CA	120.4AX	D2AZ 12127-C (DA-1146)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	A,Taxi,P/C (2/B,A/T)-California	D2AF 12127-DA	120.4AX	D2AZ 12127-D (DA-1147)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	B(2/B,A/T)-California	D2OF 12127-RA	120.4AX	D2OZ 12127-R (DA-1226)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	B,F,P(2/B,S/T)	D2OF 12127-AA	120.4AX	D2OZ 12127-A (DA-1148)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	B,F,P(2/B,S/T)	D2ZF 12127-LA	120.4AY	D2OZ 12127-A (DA-1148)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	F,P(2/B,A/T)-California	D2OF 12127-JA	120.4AX	D2OZ 12127-J (DA-1153)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	F,P(2/B,A/T)-exc.California	D2OF 12127-HA	120.4AX	D2OZ 12127-H (DA-1152)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	U(2/B,S/T)-exc. Calif.	D2UF 12127-EA	120.4AX	D2UZ 12127-E (DA-1155)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	U(2/B,S/T)-California	D2UF 12127-GA	120.4AX	D2UZ 12127-G (DA-1157)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
8 CYL. 351											
69	A,B,F(S/T,A/T, 2/B,Imco)	C9OF 12127-M	120.4V	C9OZ 12127-E r/b D00Z 12127-M	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	A,B,F(S/T,A/T, 2/B,Imco)	D0OF 12127-M	120.4Y	D0OZ 12127-M (DA-943-A)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	B,F(A/T,4/B)	C9OF 12127-T	120.4V	C9OZ 12127-T r/b C9OZ 12127-Z	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	B,F(4/B,A/T)	C9OF 12127-Z	120.4V	C9OZ 12127-Z r/b D00Z 12127-R	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	B,F(S/T,4/B,Imco)	C9OF 12127-N	120.4V	C9OZ 12127-G r/b D00Z 12127-N	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	B,F(S/T,4/B,Imco)	D0OF 12127-N	120.4Y	D0OZ 12127-N (DA-945-A)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69	B,F(4/B,A/T,Imco)	D0OF 12127-R	120.4Y	D0OZ 12127-R (DA-984-A)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
70	A,F(2/B,S/T,Imco)	D0AF 12127-H	120.4K	D0AZ 12127-H (DA-994)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
70	F(Shelby GT350) with S/T										
70	A,F(2/B,A/T,Imco)	D0AF 12127-V, D0AF 12127-AC	120.4K	D0AZ 12127-V (DA-1032)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
70	F(Shelby GT350) with A/T										
70	B(2/B,A/T,Imco)	D0OF 12127-F	120.4T	D0OZ 12127-F R/B D00Z 12127-E	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
70	B,F(4/B,S/T,A/T,Imco)	D0OF 12127-Z	120.4AS	D0OZ 12127-G (DA-1012)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	

b - B7A 12106-A (DH-6)
May, 1975

1 - C9AZ 12300-A (DC-13-A)
COPYRIGHT © 1975 — FORD MOTOR COMPANY — DEARBORN, MICHIGAN

FINAL ISSUE

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS					ILLUS. SEC. 120 PAGE
					CAP	CON- DEN- SER	POINTS	REPAIR KIT	ROTOR	
8 CYL. 351 - continued										
70	B(2/B,S/T,Imco)	D00F 12127-E D00F 12127-T	120.4AD	D2ZZ12127-A (DA-1175)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
70/71	F(2/B,S/T,Imco)									
70	B, F(2/B, A/T, Imco)	D00F 12127-U	120.4AA	D00Z 12127-U (DA-1036)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
71	B, F(2/B, A/T)- exc. Calif.									
70/71	B, F(4/B,S/T, Imco)	D00F 12127-V	120.4T	D00Z 12127-V (DA-1037)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	A(2/B, S/T)	D1AF 12127-GA	120.4AG	D1AZ 12127-G (DA-1086)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	A(2/B, A/T)- 351(W)-exc. California	D1AF 12127-HA	120.4AG	D1AZ 12127-H (DA-1085)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	A(2/B, A/T) exc. California	D1AF 12127-TA (C)	120.4AP	D2AZ 12127-K (DA-1180)	b	1	C5AZ 12171-A (DP-77)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
71	A, P/C, Taxi, (2/B, A/T)- California	D1AF 12127-KB	120.4AN	D1AZ 12127-K (DA-1014)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	B, F(2/B, A/T)- California	D1OF 12127-GA	120.4AK	D2ZZ 12127-C (DA-1203)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
71	B, F(4/B, A/T)- except California	D00F 12127-G	120.4T	D00Z 12127-T (DA-1112)	b	1	C5AZ 12171-A (DP-77)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
71	B, F(4/B, A/T)- California	D1OF 12127-LA	120.4AM	D1OZ 12127-L (DA-1061)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	B, F(2/B, A/T) California	D1OF 12127-PA	120.4AJ	D1OZ 12127-P (DA-1213)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	F(4/B, S/T, A/T) (CJ)	D1ZF 12127-BA	120.4AQ	D1ZZ 12127-B (DA-1111) R/B D1ZZ 12127-E or R/B D1ZZ 12127-G	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	12
71	F(4/B, S/T, Imco) "Boss"	D1ZF 12127-DA	120.4AV	D1ZZ 12127-D (DA-1118)	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	12
71	F(4/B, S/T)	D1ZF 12127-EA	120.4AR	D1ZZ 12127-E (DA-1211)	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	12
71	F(4/B, A/T)	D1ZF 12127-FA	120.4AF	D1ZZ 12127-F (DA-1212) R/B D1ZZ 12127-G	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	F(4/B, A/T)- "CJ"	D1ZF 12127-GA	120.4AH	D1ZZ 12127-G	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
72	A, B(2/B, A/T) California	D2MF 12127-GA	120.4BB	D2MY 12127-G	b	1	B8Q 12171-A (DP-12)		B7A 12200-A (DR-5)	11
72	A, B(2/B, A/T), 351(W)	D2AF 12127-PA	120.4BA	D2MY 12127-B (DA-1172)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11
72	F(2/B, A/T)- exc. California	D2AF 12127-KA	120.4AZ	D2AZ 12127-K (DA-1180)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11
72	A, B(2/B, A/T)- 351(C)-exc. Calif.									
72	F(2/B, A/T)- California	D2ZF 12127-CA	120.4AZ	D2ZZ 12127-C (DA-1203)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11
72	A, B(2/B, A/T)- 351(C)-Calif.									
72	F(2/B, S/T)	D2ZF 12127-AA	120.4AZ	D2ZZ 12127-A (DA-1175)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11
72	B, F(4/B, S/T)- "C.T."-exc. Calif.	D2ZF 12127-EA	120.4AV	D2ZZ 12127-E (DA-1205) r/b D3OZ 12127-F	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	12

b - B7A 12106-A (DH-6)

1-C9AZ 12300-A (DC-13-A)

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS					ILLUS. SEC. 120 PAGE
					CAP	CON-DEN-SER	POINTS	REPAIR KIT	ROTOR	
8 CYL. 351 - continued										
72	B, F(4/B, S/T)- "CJ"-Calif.	D2ZF12127-FA	120.4AZ	D2ZZ12127-F (DA-1206)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	11
72	B, F(4/B, A/T)- "CJ"-exc. Calif.	D2ZF12127-GA, GB, GC	120.4AZ	D2ZZ12127-G (DA-1207)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	11
72	B, F(4/B, A/T)- "CJ"-California	D2ZF12127-HA, HB	120.4AZ	D2ZZ12127-H (DA-1208)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	11
72	F(4/B, S/T)- Boss	D2ZF12127-JA	120.4AV	D2ZZ12127-J (DA-1209) r/b D2ZZ 12127-E	b	1	C9AZ12171-A (DP-5)		B7A 12200-A (DR-5)	12
8 CYL. 352										
65	A(S/T)	C5AF12127-A	120.4H	C5AZ12127-A (DA-674)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
65	A(C4, C/M)	C5AF12127-B, C7TF12127-F	120.4H 120.4G	C5AZ12127-W (DA-913)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A(4/B, C/M)- exc. T/E	C4AF12127-M, C5AF12127-BG	120.4N 120.4M	C4AZ12127-M r/b C4AZ 12127-P	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	5
66	A(4/B, C/M)- exc. T/E	C6MF12127-A	120.4H	C4AZ12127-P (DA-911)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A(T/E)	C6AF12127-AG, L, U C6OF12127-G, H	120.4H	C6AZ12127-L (DA-739) Not replaced	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
8 CYL. 390										
65/71	All High Performance Vehicles	C5AF12127-E	120.3D	C5AZ12127-E r/b C0AZ12127-L	b	1	C9AZ12171-C (DP-6)		B7A 12200-A (DR-5)	6
65	A, P/C	C5AF12127-C	120.4H	C5AZ12127-C r/b	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
65	S(C/M-exc. trans. ign.)			C5AZ12127-W						
65	A, P/C	C7TF12127-F	120.4G	C5AZ12127-W (DA-913)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
65	S(C/M-w/or w/o trans. ign.)									
65	S(C/M-with trans. ign.)	C5SF12127-B	120.4P	C5SZ12127-B r/b C5AZ12127-W	c		B8Q 12171-A (DP-12)		B7A 12200-A (DR-5)	6
66	A, B(2/B, 3/4/S/T, & R/A cover with T/E)	C6AF12127-A	120.4H	C6AZ12127-A r/b C7AZ 12127-A	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, B(2/B, 3/4/S/T, T/E)	C6AF12127-K, C6OF12127-E	120.4H	C6AZ12127-K (DA-738) R/B C8AZ 12127-J	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, B(2/B, C/M, C6 & R/A cover with T/E)	C6AF12127-B	120.4H	C7AZ12127-E (DA-784)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, B(2/B, C/M, C6, T/E)	C6AF12127-T, C6OF12127-F	120.4H	C6AZ12127-T (DA-740)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, B(4/B, 3/4/S/T- with T/E)	C6AF12127-L, U C6OF12127-G, H	120.4H	C6AZ12127-L (DA-739)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, B, S(4/B, C/M, C6-with T/E)									
66	A, B(4/B, 3/4/ S/T-exc. T/E)	C6AF12127-C	120.4H	C6AZ12127-C r/b C7AZ 12127-E	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, B, S(4/B, C6, C/M)-exc. T/E	C6AF12127-D, C6MF12127-A	120.4H	C4AZ12127-P (DA-911)	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	B(2/B, 3/4/S/T, T/E)	C6OF12127-E	120.4H	C6OZ12127-E r/b C0AZ12127-L	b	1	B8Q 12171-A (DP-12)	C0TZ12000-A (DK-10)	B7A 12200-A (DR-5)	6

b - B7A 12106-A (DH-6)

1 - C9AZ 12300-A (DC-13A)

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	CAP	CON- DEN- SER	DISTRIBUTOR COMPONENTS				ILLUS. SEC. 120 PAGE
							POINTS	REPAIR KIT	ROTOR		
8 CYL. 390 - continued											
66	B(2/B, C6, T/E)	C6OF 12127-F	120.4H	C6OZ 12127-F r/b C6AZ 12127-T	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
66	B-GT	C6OF 12127-J	120.4H	C6OZ 12127-J (DA-771)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A,B(2/B, 3/S/T- exc. T/E)	C7AF 12127-A, AD	120.4G	C7AZ 12127-A (DA-780)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B(2/B, 3/S/T, T/E)	C7AF 12127-C,Z	120.4G	C8AZ 12127-J (DA-872)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B(2/B, C/M, C6)-exc. T/E	C7AF 12127-B,Y	120.4G	C7AZ 12127-B (DA-781)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B(2/B, C/M, C6)-exc. T/E	C7AF 12127-AG	120.4G	C7AZ 12127-AG (DA-841)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B(4/B, 3/4/ S/T-exc. T/E)	C7AF 12127-E	120.4G	C7AZ 12127-E (DA-784)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B(4/B, C6- exc. T/E)	C7AF 12127-F	120.4G	C7AZ 12127-F r/b C6MY 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	S(exc. T/E)	C7SF 12127-A	120.4G	C7SZ 12127-A r/b C6MY 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B, S(4/B, C6- exc. T/E)	C7MF 12127-G	120.4G	C7SZ 12127-D r/b C6MY 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B(4/B, C6, T/E)	C7AF 12127-H	120.4G	C7AZ 12127-H r/b C7SZ 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B, S(4/B, C6, T/E)	C7SF 12127-B	120.4G	C7SZ 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B, S(4/B, C6, T/E)	C7MF 12127-H	120.4G	C7SZ 12127-H (DA-850)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	B-GT, F(4/B, 3/4/S/T-exc. T/E)	C7OF 12127-H	120.4G	C7OZ 12127-H r/b C7AZ 12127-U	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	B-GT, F(4/B, C6-exc. T/E)	C7AF 12127-U,V	120.4G	C7AZ 12127-U (DA-796)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6	
67	A, B, S(4/B, C6-exc. T/E)	C7MF 12127-A	120.4G	C6MY 12127-B (DA-836)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
67	A, B(2/B, C/M, C6, T/E)	C7AF 12127-D, AA	120.4G	C7AZ 12127-D (DA-783)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
69/71	A(2/B, C6, Imco)										
67	A, B, S(4/B, C6, T/E)	C7AF 12127-L, AC	120.4G	C7AZ 12127-L (DA-790)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68/69	A, B, F(4/B, C6, Imco)										
67	B-GT, F(4/B, C6, 3/4/S/T, T/E)	C7OF 12127-F,G	120.4G	C7OZ 12127-F (DA-807)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68/69	B-GT, F(A/T-w/ T/E)										
68	A(4/B, S/T, T/E)	C8AF 12127-S	120.4C	C8AZ 12127-S (DA-876)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	B-GT, F-GT(4/B, T/E)	C8OF 12127-D	120.4Q	C8OZ 12127-D (DA-881)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	F(2/B, C6-w/Imco)	C8WF 12127-B	120.4C	C8WY 12127-B (DA-906)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	
68	S(4/B, C6, Imco)	C8AF 12127-R	120.4C	C8AZ 12127-R (DA-875)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6	

b - B7A 12106-A (DH-6)

1 - C9AZ 12300-A (DC-13A)

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS					ILLUS. SEC. 120 PAGE
					CAP	CON- DEN- SER	POINTS	REPAIR KIT	ROTOR	
8 CYL. 390 - continued										
68	A, B, F(2/B, S/T, T/E)	C8AF 12127-M	120.4C	C8AZ 12127-M (DA-873)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
70	A(2/B, S/T, Imco)									
68/69	A, B, F(2/B, A/T & Imco)	C8AF 12127-N	120.4C	C8AZ 12127-N r/b C7AZ 12127-D	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
70	A(2/B, A/T, Imco)									
69	A(S/T & Imco)	C9AF 12127-J	120.4C	C9AZ 12127-B (DA-929)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
69	B, F(4/B, S/T, T/E)	C9OF 12127-J	120.4C	C9OZ 12127-J r/b C9AZ 12127-D	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
69	B, F(4/B, S/T w/ Imco)	C9AF 12127-K	120.4G	C9AZ 12127-D (DA-907)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
71	A(2/B, A/T)exc. California	D1AF 12127-LB	120.4C	D1AZ 12127-L (DA-1082)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	A(2/B, A/T)-California	C7AF 12127-AA	120.4G	C7AZ 12127-D (DA-783)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
8 CYL. 400										
71	A(2/B, A/T)-exc. California	D0OF 12127-U	120.4AA	D0OZ 12127-U (DA-1036)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
71	A(2/B, A/T)-California	D1OF 12127-GA	120.4AK	D2ZZ 12127-C (DA-1203)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
72	A, B, S(2/B, A/T)-exc. California	D2AF 12127-RA	120.4AZ	D2AZ 12127-E (DA-1210)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11
72	A, B, S(2/B, A/T)-California	D2AF 12127-FA	120.4AZ	D2AZ 12127-F (DA-1176)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11
8 CYL. 427										
65/67	A, B Special(4/B, 6/B or 8/B)	C5AF 12127-F (with trans.ign.)	120.3E	C5AZ 12127-F R/B C0AZ 12127-L	c		C3AZ 12171-A (DP-71)		B7A 12200-A (DR-5)	6
65	A Special(4/B, S/T)	C5AF 12127-E (exc.trans.ign.)	120.3D	C5AZ 12127-E r/b C0AZ 12127-L	b	1	C9AZ 12171-C (DP-6)	C5ZZ 12000-A (DK-14)	B7A 12200-A (DR-5)	6
65/70	All High Performance Vehicles									
65/67	A, B, Special(4/B, 6/B or 8/B)	C5AF 12127-E	120.3D	C0AZ 12127-L (DA-909)	c		C3AZ 12171-A (DP-71)		B7A 12200-A (DR-5)	6
68	B	C7OF 12127-F, G C8AF 12127-AD	120.4G	C7OZ 12127-F (DA-907)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
68	B, F(4/B, C6, T/E)	C8OF 12127-G	120.4G	C8OZ 12127-G (DA-927)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
8 CYL. 428										
65/70	All High Performance Vehicles	C5AF 12127-E	120.3D	C5AZ 12127-E r/b C0AZ 12127-L	b	1	C9AZ 12171-C (DP-6)	C5ZZ 12000-A (DK-14)	B7A 12200-A (DR-5)	6
66	A(4/S/T, T/E)	C6AF 12127-BA	120.4H	C6AZ 12127-BA r/b C7SZ 12127-H	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A(4/B, S/T, C6-exc. T/E	C6AF 12127-E, F	120.4H	C6AZ 12127-E r/b C4AZ 12127-P	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	S(exc. T/E)-(exc.trans.ign.)									
66	A, S(C6, T/E)	C6AF 12127-L, U C6OF 12127-G, H	120.4H	C6AZ 12127-L (DA-739)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6

b - B7A 12106-A (DH-6)

c - B7AZ 12106-A (DH-146)

1 - C9AZ 12300-A (DC-13-A)

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS					ILLUS. SEC. 120 PAGE
					CAP	CONDENSER	POINTS	REPAIR KIT	ROTOR	
8 CYL. 428 - continued										
66	A, P/C(4/S/T, T/E)	C6AF 12127-M	120.4H	C6AZ 12127-M r/b C6AZ 12127-E or C6AZ 12127-L	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A, S, P/C(C6 & T/E)	C6AF 12127-V	120.4H	C6AZ 12127-V r/b C6AZ 12127-E or C6AZ 12127-L	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	P/C	C6AF 12127-AH	120.4L	C6AZ 12127-AH (DA-756)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A(4/S/T, TE)	C7MF 12127-H	120.4G	C7SZ 12127-H (DA-850)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	S(exc. T/E & exc.trans.ign.)	C6MF 12127-A	120.4H	C4AZ 12127-P (DA-911)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66	A(4/S/T, C6-exc. T/E)									
66	S(exc. T/E & trans. ign.)	C6SF 12127-B	120.4R	C6SZ 12127-B r/b C4AZ 12127-P	b		B8Q 12171-A (DP-12)		B7A 12200-A (DR-5)	6
66	S(T/E-trans.ign.)	C6SF 12127-D	120.4R	C6SZ 12127-D (DA-746)	c		B8Q 12171-A (DP-12)		B7A 12200-A (DR-5)	6
66/67	A(4/S/T, C6-exc. T/E)	C7AF 12127-J	120.4G	C7AZ 12127-J r/b C6MY 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	A, S(4/B, C6, Imco)	C7AF 12127-AC	120.4G	C7AZ 12127-L (DA-790)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	A(C6, T/E)	C7AF 12127-M	120.4G	C7AZ 12127-M r/b C7SZ 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
66/67	A(4/S/T, C6-exc. T/E)	C7MF 12127-A	120.4G	C6MY 12127-B (DA-836)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	P/C(4/S/T, T/E)	C7AF 12127-S	120.4G	C7AZ 12127-S r/b C8AZ 12127-J	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	P/C(C6, T/E)	C7AF 12127-T	120.4G	C7AZ 12127-T r/b C8AZ 12127-J	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	P/C(C6)	C7AF 12127-N, AF	120.4G	C8AZ 12127-J (DA-872)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
67	S(exc. T/E)	C7SF 12127-C	120.4G	C7SZ 12127-C r/b C7AZ 12127-J	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	S(T/E)	C7SF 12127-E	120.4G	C7SZ 12127-E r/b C7SZ 12127-F	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67	S(T/E)	C7SF 12127-F	120.4G	C7SZ 12127-F r/b C6MY 12127-B	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
67/69	B, F(CJ) (A/T & Imco)	C7OZ 12127-F	120.4G	C7OZ 12127-F (DA-807)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
69	A(P/C)(A/T & T/E)									
68	A(4/B, S/T, T/E)	C8AF 12127-T	120.4C	C8AZ 12127-T (DA-877)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
68	A(4/B, C6, Imco)	C8AF 12127-Y	120.4G	C8AZ 12127-Y (DA-905)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6

b - B7A 12106-A (DH-6)

c - B7AZ 12106-A (DH-146)

1 - C9AZ 12300-A (DC-13A)

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS					ILLUS. SEC. 120 PAGE
					CAP	CON-DEN-SER	POINTS	REPAIR KIT	ROTOR	
8 CYL. 428 - continued										
68/69	B, F(C6, S/T, T/E)	C8OF 12127-D	120.4Q	C8OZ 12127-D (DA-881)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
68/69	A, P/C(C6, T/E)	C8AF 12127-J	120.4G	C8AZ 12127-J (DA-872)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
69	B, F(A/T, T/E)	C8OF 12127-J	120.4G	C8OZ 12127-J (DA-970)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
69	B, F(CJ)(S/T WT/E)	C8OF 12127-H	120.4Q	C8OZ 12127-H (DA-969)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
69/70	A(P/C)(4/BA/T T/E)	D0AF 12127-M	120.4C	D0AZ 12127-M (DA-998)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
70	F(CJ)(4/B, S/T T/E)	D0ZF 12127-C	120.4AE	D0ZZ 12127-C (DA-1020)	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	6
70	F(CJ)(4/B, A/T, T/E)GT500	D0ZF 12127-G	120.4G	D0ZZ 12127-D (DA-1021)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
8 CYL. 429										
68/69	S(4/B, A/T, Imco)	C8VF 12127-A	120.4S	C8VY 12127-C (DA-885)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
69/70	A, B(2/B, A/T, Imco)									
70	A, B(4/B, A/T, Imco)									
69	A(P/C)(4/B, A/T, Imco)	C8AF 12127-AD	120.4G	C7OZ 12127-F (DA-807)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
70	A, B(4/B, A/T)	D0AF 12127-Z	120.4S	D0AZ 12127-Z	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
69	B, F Boss(4/B) - Spec. - "Before 2/28/69"	C9AF 12127-U	120.4W	C9AZ 12127-U r/b C9ZZ 12127-D	b		C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	12
69	B, F Boss(4/B) - Spec. - "From 2/28/69"	C9ZF 12127-D	120.4AU	C9ZZ 12127-D (DA-1094)	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	12
69	A(4/B, S/T, Imco)	C8VF 12127-C	120.4T	C9AZ 12127-F (DA-933)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
70	A, B(2/B, 4/B, A/T, T/E, Imco, EV/EM, Imco)									
69/70	A(4/B, S/T, Imco)	C9AF 12127-Y	120.4AD	C9AZ 12127-Y (DA-981)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
70	B(4/B, S/T, T/E)	D0OF 12127-J, D0OF 12127-AA	120.4W 120.4AQ	D0OZ 12127-J (DA-1022)	b	1	C9AZ 12171-A (DP-5)		B7A 12200-A (DR-5)	12
71	F(S/CJ)(4/B, S/T, T/E)									
71	B, F(CJ)(4/B, S/T)									
70	S(4/B, A/T, ev/em)	D0AF 12127-Z	120.4S	D0AZ 12127-Z (DA-1034)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	S(4/B, A/T)									
70/71	B(4/B, A/T, T/E)	D0OF 12127-Y	120.4Z	D0OZ 12127-K (DA-1014)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	F(S/CJ)(4/B, S/T)-w/T/E									
71	A, B(A/T)-exc. California	C8VF 12127-C	120.4T	C9AZ 12127-F (DA-933)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	6
71	A, B(A/T)-California	D1MF 12127-FA	120.4AF	D1MY 12127-F (DA-1069)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	A(P/C)-4/B, A/T	D1AF 12127-NA	120.4AH	D1AZ 12127-N (DA-1080)	b	1	C5AZ 12171-A (DP-77)		B7A 12200-A (DR-5)	6
71	B(CJ)(4/B, A/T)									
71	F(SCJ)(4/B, A/T)									

b - B7A 12106-A (DH-6) 1 - C9AZ 12300-A (DC-13A)

May, 1975

COPYRIGHT © 1975 -

FORD MOTOR COMPANY

- DEARBORN, MICHIGAN

FINAL ISSUE

12127 DISTRIBUTOR APPLICATION CHART - continued

YEAR	MODEL	IDENTIFICATION	PARTS LIST SECTION & NO.	SERVICE REPLACEMENT DISTRIBUTOR	DISTRIBUTOR COMPONENTS						ILLUS. SEC. 120 PAGE
					CAP	CON-DEN-SER	POINTS	REPAIR KIT	ROTOR		
B CYL. 429 - continued											
72	A,B,S(4/B,A/T)-Imco)-Calif.	D2MF 12127-FA	120.4BB	D2AZ 12127-H (DA-1178)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	A,B,S(4/B,A/T)-Imco-exc.Calif.	D2MF 12127-EA	120.4BB	D2AZ 12127-J (DA-1179)	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	A(P/C)(4/B, A/T, Imco)-Calif.	D2AF 12127-MA	120.4BB	D2AZ 12127-M (DA-1182) r/b D2AZ 12127-R	b	1	B8Q 12171-A (DP-12)	C0TZ 12000-A (DK-10)	B7A 12200-A (DR-5)	11	
72	A(P/C)(4/B, A/T)-exc.Calif.	D2AF 12127-NA, NC	120.4BB	D2AZ 12127-N (DA-1224) r/b D2AZ 12127-R	b	1	B8Q 12171-A (DP-12)		B7A 12200-A (DR-5)	11	
72	B(P/C)-4/B										
72	A, B(4/B, A/T)	D2AF 12127-MB	120.4AZ	D2AZ 12127-R (DA-1224-A)	b	1	B8Q 12171-A (DP-12)		B7A 12200-A (DR-5)	11	
72	S(4/B,A/T)-exc.California	D2SF 12127-EA	120.4BB	D2SZ 12127-E	b	1	B8Q 12171-A (DP-12)		B7A 12200-A (DR-5)	11	

8 CYL. 460

72	S(4/B,A/T)- exc. California	D2VF 12127-AA	120.4BB	D2VY 12127-A	b	1	B8Q 12171-A (DP-12)		B7A 12200-B (DR-5)	11
72	S(4/B,A/T)- California	D2VF 12127-BA	120.4BB	D2VY 12127-B	b	1	B8Q 12171-A (DP-12)		B7A 12200-B (DR-5)	11

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12000-11 Refer to Distributor Parts Lists - Section 120, page 1						
12A022 Refer to Distributor Parts Lists - Section 120, page 1						
12A024 IGNITION CABLE - HIGH TENSION - 25 ft. roll - also refer to groups 12259, 12286, 12298, 14296						
66/	B, F, X, U	6	170,200	Radio resistance - linen core	AR	C3AZ 12A024-A
66/	A, Taxi, P/C	6	240		AR	
66/	A, B, F, X (2/B, 4/B P. F.)	8	289		AR	
66/	F Special (4/B)	8	289		AR	
66/	A, B, S (2/B, 4/B)	8	352,390		AR	
66/	A Special (4/B, 8/B)	8	427		AR	
66/	A, S, P/C	8	428		AR	
66/	A, B, F, S, U, X	8	All	Steel core	AR	C3AZ 12A024-B
12A027 AMPLIFIER ASSY. - IGNITION CURRENT						
65/67	A Special (4/B, 8/B)- Trans./ign.	8	427	#C5SF 12A027-B	1	C3TZ 12A027-C
65	S	8	390		1	(DY-64)
65/66	S (Trans./ign.)	8	428		1	
65/66	S	8	390	Bolt-1/4"-20 x 3/4" (amplifier to bracket)	2	20344-S8(B42)
				Lockwasher-1/4"		34805-S8(X62)
				Nut-1/4"-20 lock		34390-S7-8(M92)
12029 COIL ASSY. - IGNITION - LESS MOUNTING STRAP						
65/67	A Special (with 4/B or 8/B carb.)	8	427	12 volt-use with transistorized ignition system	1	C3TZ 12029-A
65/66	S	8	390,428		1	(DG-32)
65/	A, B, F, L, P, S, U, X	4,6, 8	All	12 volt-except with transistorized ignition system	1	B6A 12029-B
65/	A, B, F, P, S, U, X	6&8	All	Nut-No.10-32 (ignition coil terminal)	2	34079-S7(M163)
				Lockwasher-No. 10		34803-S7(X60)
71/	L	4	All	Nut-No.8-32 (ignition coil terminal)	2	34052-S(M155)
12A042 RELAY - IGNITION CURRENT AMPLIFIER						
65/67	A Special (with 4/B or 8/B carb.)	8	427	Use with transistorized ignition system	1	C3TZ 12A042-B
65/67	S	8	390		1	(DY-56)
65/67	A Special (with 4/B or 8/B carb.)	8	427	Screw (relay to mounting plate)-No. 14-10 x 5/8"	2	31498-S8(U253B)
65/67	S	8	390	hex. washer head tapping	2	
b - B7A 12108-A						
c - C947 12300-A						

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12043-4 STRAP - IGNITION COIL MOUNTING						
65/68	A, B, S "Before 2/15/68"	8	352,390, 428		1	B8S 12043-B (DY-52)
65/68	A, B, F, X (2/B, 4/B-P.F.)	8	289,302		1	
65/68	A Special (4/B, 6/B or 8/B carb.)	8	390,406, 427		1	
65/68	A, Taxi, P/C	6	240		1	
68	A, B, F(A/T with T/E)	8	427		1	
65/68	B(except B Special)	8	289,302	Use with 53 amp. Leece Neville alternator	1	
69	F(Boss 4/B special)	8	302,429		1	
72	B, F	8	351		1	
70	F(Boss 4/B)	8	302	(Bracket)	1	D0ZZ 12043-A (DY-90)
65/	B, F, X, U	6	170,200, 250		1	COAF 12043-A
71/	L	4	All			
68/71	A, B, F, S, X	8	351		1	C8TZ 12043-A (DY-70)
71	A	8	390		1	
69/	A, B, F, X, U	6&8	All		1	C9AZ 12043-A (DY-83)
70/71	P	6&8	All		1	D0OZ 12043-A (DY-89)
70/	A, Taxi, P/C	8	302		1	
71/	U	8	302		1	
72	B, F, P	8	302		1	
66/68	S(A/C)	8	390,428		1	C6SZ 12043-A (DY-69)
71/	A	8	400		1	D1AZ 12043-A (DY-95)
72	B	8	400		1	
72	A	8	351		1	
70/	A, B, S	8	429		1	D0VY 12043-B (DY-88)
72	A	8	460		1	D2SZ 12043-A (DY-107)
72	S	8	400		1	
65/	A, S	6&8	All	Bolt (ignition coil mounting strap to cylinder head)-5/16"-18 x 5/8"	2	20326-S7(B49)
				Lockwasher-5/16"	2	34806-S7(X64)
65/67	A, S	6&8	All	Screw (ignition coil mounting strap clamping)-No.10-32 x 5/8"-round head	1	27185-S2(U177A)
68	A, B, F, S, U, X			Screw (attach strap to coil)-No.10-32 x 1 5/8" round head	1	
				Nut-No. 10-32	1	34079-S7(M163)
				Lockwasher-No. 10	1	34803-S7(X60)
72	L			Screw-5/16-18 x 5/8" -attach coil strap to fender side shield	2	378459-S(UU52K)
12045 WIRE ASSY. - IGNITION CURRENT AMPLIFIER						
67	A Special (4/B, 8/B)-except 71	8	427		1	C7AZ 12045-A
65	S	8	390	Used with transistorized ignition system and/or A/C	1	C4SZ 12045-C (DY-61)
66	S (Trans/ign.)	8	428	#C6SB 12045-A	1	C6SZ 12045-A (DY-67)
12A046 RESISTOR and BRACKET ASSY. - IGNITION BALLAST						
65/66	A Special (with 4/B or 8/B carb.)	8	427	Use with transistorized ignition system	1	C3TZ 12A046-C (DY-68)
68	A(4/B, 8/B)P/F	8	427		1	
65	S	8	390		1	
66	S (trans. ign.)	8	428		1	
65/67	A Special (with 4/B or 8/B carb.)	8	427	Screw (resistor & brkt.assy.to mounting plate)-No.14-10 x 5/8" hex.washer head tapping	2	31498-S8(U253B)
65/67	S	8	390		2	
12050 DUAL POINT DISTRIBUTOR KIT COBRA - Refer to Accessories Section						
12A055 FELT - DISTRIBUTOR CAM LUBRICATOR - Also refer to Distributor Parts Lists - Section 120, page 1						
65/68	S	8	390		1	C3TZ 12A055-A
66	A, S	8	428		1	

Identification marking

May, 1975


COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE


YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12A069 WIRE ASSY. - IGNITION COIL GROUND						
65/68	A Special (with 4/B or 8/B carb.)	8	427	6.00" long-16 gauge-make from B6A 14296-C	1	★C2AB 12A069-A
65/68	S	8	390	bulk wire-use with transistorized ign. system)	1	
12072 Refer to Distributor Parts Lists - Section 120, page 1						
12A072 BRACKET - IGNITION CURRENT AMPLIFIER						
65	A Special (with 8/B carb.)	8	427	Used with transistorized ignition system	1	C5AZ 12A072-B
68	A Special (with 4/B & 8/B carb.)	8	427		1	
12073-75 Refer to Distributor Parts Lists - Section 120, page 1						
12A091 VALVE ASSY. - DISTRIBUTOR VACUUM CONTROL						




TYPE 1



TYPE 2



TYPE 3



TYPE 4

P-10003

TYPE 1

67	A, B, F, S(2/B)-T/E, A/C	8	390		1	C7AZ 12A091-A
67	S,P/C(T/E, A/C)	8	428		1	
67	S(A/C Imco)	8	390,428		1	
67	A,P/C(A/C)-T/E & exc. T/E	8	428		1	C7AZ 12A091-C
67	B, F, X(2/B, 4/B P. F.)-T/E, A/C	8	289		1	C7OZ 12A091-A

TYPE 2

68/	A, B, F, S, X(with or without A/C)	8	All	Vacuum -located in thermostat housing	1	C8AZ 12A091-A
68/70	X	6	170,200		1	(DY-126)
69/	U	6	170		1	
69/	F	6	200		1	
71	L (2000 cc) "Before 10/1/70"	4	122		1	
69/	B, F	6	250		1	
69	F Boss (4/B Spec.)	8	302,351		1	
69/	B(CJ), F(CJ)	8	429		1	
70/	P	6	All		1	
71/	L (2000 cc)-exc. Calif. - "From 10/1/70"	4	122	Vacuum-located in thermostat housing	1	D1FZ 12A091-A
						(DY-151-A)
72	P	6	200		1	
72	B, F, P-exc. California	6	200,250		1	
71	L	4	98,122	Connector-attaches to manifold to adapt 12A091	1	E855027-S100
						(AI-02)

TYPE 3

71/	L (2000 cc)-Calif.	4	122	#D12E-B-Black and Red	1	D1FZ 12A091-B
						(DY-128)
72	A, B, F	8	351	#D2AE-AA-Black and Blue	1	D2AZ 12A091-A
72	A, S	8	429		1	(DY-129)
72	B	8	302,429		1	
72	P	6	250	#D2DE-AA-Black and Yellow	1	D2DZ 12A091-A
72	B, F, P (exc. Calif.)- "From 1/3/72"	8	302		1	(DY-116)
72	B, F(Calif. only)	8	351(CJ)	#D2OE-AA-Black and White	1	D2OZ 12A091-A
72	B, F	6	250		1	(DY-130)
72	L (2000 cc)	4	122		1	
71	P	8	302		1	
72	U	6	200		1	

Identification marking

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12A091 VALVE ASSY. - DISTRIBUTOR VACUUM CONTROL - continued						
TYPE 3 - continued						
72	A(exc. Calif.)	8	302	#D2OE-BA-Black and Green-	1	★ D2OZ 12A091-B (DY-115-A)
72	B, F, P (exc. Calif.)- "Before 1/3/72"	8	302	r/b D3FZ 12A091-B (11-74)	1	
72	L(S/T) (1600 cc, 2000 cc)	4	98, 122		1	
72	L (A/T) (2000 cc)-	4	122		1	
72	A, B, F, P (exc. California)	8	302	#D2OE-CA-Black and Red	1	D2OZ 12A091-D (DY-120)
72	A, B	8	351W, 460		1	
TYPE 4						
71/	A, B, F	8	302, 351	Electric and vacuum-located in water jacket	1	D1AZ 12A091-A
71/72	A(P/C)	8	429		1	
72	P	8	302		1	
72	B, P (M/T)	8	302		1	D2SZ 12A091-A (DY-122)
72	B, F (A/T)	8	351		1	
72	B	8	429		1	
12A092-110 Refer to Distributor Parts Lists - Section 120, page 1						
2 BRACKET - IGNITION CABLE MOUNTING						
68	A, B, X	8	302	R. H. -not replaced	1	★C8AZ 12111-A
68	F	8	289	R. H.		
69	B, F(CJ)	8	428		2	C9ZZ 12111-A
69	F Boss (4/B Spec.)	8	429		2	
69	F(Boss)	8	302		2	
70/71	F	8	351		2	
69	F	8	429		7	C9AZ 12111-A
12A111 VALVE and BRACKET ASSY. - DISTRIBUTOR VACUUM ADVANCE CONTROL						
68/	A	6	240		1	C8AZ 12A111-A
69	A, S(less A/C)	8	429		1	C9AZ 12A111-A
68/71	U, X	6	170		1	C8DZ 12A111-A
68	F(A/T with Imco)	8	390		1	
68	U	8	289		1	C8AZ 12A111-C
69/	U(M/T & Imco)	8	302		1	
70/	U(A/T, Imco)	8	302		1	
69	U(M/T & T/E)	8	302		1	
68/	A, U	8	289, 302	Bolt 5/16-18x5/8"	1	C8UZ 12A111-B
				Attach valve and bracket to manifold	1	45963-S2(B227B)
72	B, F(M/T)	8	351 CJ		1	D2ZZ 12A111-A
12113 SEAL - WIRE TERMINAL WEATHER						
65/	A, B, X	6	All	Spark plug wire to distributor	6	A9AZ 12113-A (DZ-407)
65/	A, B, S	8	All	Spark plug wire to distributor	8	
65/	A, B, S	8	352, 390	Ignition coil high tension wire to distributor	1	
65	B (with 4/B carb.)	8	289	Ignition coil high tension wire distributor	1	
65/	A Special (with 4/B or 8/B carb.)	8	427		1	
65	F Special	8	289		1	
65/	A, B, S, X	6&8	All	Insulator (coil to distributor)-use with non radio resistant universal wire kit-"Black"	AR	A9AZ 12113-E
65/	A, B, S, X	6&8	All	Insulator (spark plug)-use with non radio resistant universal wire kit-"Red"	AR	A9AZ 12113-G
12114-119 Refer to Distributor Parts List - Section 120, page 1						
12120 BUSHING - DISTRIBUTOR BASE - LOWER						
68/	A, B, S	8	400, 429	Cast iron-O.D. 1.72"	1	C8SZ 12120-A (MC-201)
68/	A, B, S	8	400, 429	Cast iron-O.D. 1.86"	1	C8VY 12120-A (MC-202)
12120 BUSHING - DISTRIBUTOR HOUSING - LOWER - Refer to Distributor Parts Lists - Section 120, page 1						
12A120 FILTER - DISTRIBUTOR VACUUM CONTROL VALVE						
68/	B, F, X	6&8	All		1	C8AZ 12A120-A
68/	A	8	All		1	
70/	P	6	200, 250		1	

Identification marking

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

SECTION 120

FORD CAR PARTS

See PAGE 1 of this SECTION for
DISTRIBUTOR COMPONENT INFORMATION

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12132 BUSHING - DISTRIBUTOR BASE - Refer to Distributor Parts List - Section 120, page 1						
70/	A, F	8	351	Lower-located in engine block	1	D00Z 12132-B
68/	A, B, S	8	400,429	Upper-cast iron-without flange	1	C8SZ 12132-A (MC-203)
68/	A, B, S	8	400,429	Upper cast iron-with flange	1	C8VY 12132-A (MC-204)
12132 BUSHING - DISTRIBUTOR HOUSING - UPPER - Refer to Distributor Parts Lists - Section 120, page 1						
12A132 DISTRIBUTOR PLATE REPLACEMENT-KIT - Also refer to Distributor Parts Lists - Section 120, page 1						
71/	A, B, F, P, S	8	All	Convert single point to dual points- not replaced (6-74)	1	★ DIAZ 12A132-A (DS-4A)
Consists of						
1-C2FF 12A006-A Spacer		1-C5AZ 12192-A Spring		2-D00Z 12192-A Spring		
1-C0AF 12152-A Plate		1-C5AZ 12192-C Spring		1-FDS 12206-A Conductor		
2-FDS 12171-A Points		1-C5AZ 12192-D Spring		2-34051-S Nut-No.6-32		
1-B7A 12177-A Retainer		2-C5AZ 12192-E Spring		2-34801-S Lockwasher-No.6		
1-FET 12300-A Condenser		2-C5AZ 12192-F Spring		2-57686-S Screw-No.8-32 x 5/8"		
1-C9AZ 12192-A Spring		1-C5VY 12192-A Spring				
12A143 TAB - DISTRIBUTOR VACUUM ADVANCE CONTROL BRACKET LOCK						
69	A, S(4/B, S/T, less A/C)	8	429		1	C9AZ 12A143-A
12144-52 Refer to Distributor Parts Lists - Section 120, page 1						
12A161 HOSE AND GROMMET ASSY.-VACUUM						
70	B, F, P, X (with A/T)	8	302		1	D00Z 12A161-A
	A, B, F (with A/T, S/T)	8	351		1	
	A	8	390		1	
	A, S (with A/T, S/T)	8	429		1	
70/71	A	6	240		1	
71/	B, F	6	250		1	
12A163 - TUBE AND BRACKET ASSY.-VACUUM						
70/71	A(A/T)	6	240		1	D0AZ 12A163-G
71	S	8	429		1	
70	A, F (2/B, A/T)	8	302		1	D0AZ 12A163-B
70	B, F (2/B, A/T)	8	302		1	D00Z 12A163-A
70	B, F	8	351		1	D00Z 12A163-B
71	A(A/T)	8	390		1	D0AZ 12A163-A
71	B, F, P(California only)	6	200,250		1	D1DZ 12A163-A
71	S(California only)	8	429		1	D1VY 12A163-A
70	A			Connector (3/16"-1/8")	AR	383001-S (II-191VG)
12A164 SWITCH ASSY - DISTRIBUTOR MODULATOR AMBIENT						
70	A (with A/T-2/B)	6&8	240,302	Wire 50" long	1	D0AZ 12A164-E
70	A, B (with A/T-2/B)	8	351		1	(SW-1042)
70	A (with S/T & A/T, 2/B)	8	390		1	
70/71	B (with A/T)	8	302		1	
70	X (with A/T-2/B)	8	302		1	
71	A(A/T)	6	240		1	
71	A, F(A/T)	8	302		1	
71	B, F, P	6	250		1	
71	S	8	429		1	
70	F (with A/T)	8	302		1	D0AZ 12A164-B
70	F (with A/T, 2/B, 4/B)	8	351		1	(SW-1041)
72	A, B, F, L, P, S-exc. Nox Emission	6&8	All	Includes wire 26" long	1	D2AZ 12A164-D (SW-1065)
72	A, B, F, L, P, S			Screw-No.8-18" x 3/4"-attach switch to pillar	2	376389-S(UU82D)
71	F			Clip (attach wires, part of switch to inst. panel brace)	2	383207-S(GG271)

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12A168 BLEED ASSY. - DISTRIBUTOR VACUUM AIR						
70/71	A	6	240,		1	D0AZ 12A168-C
70	B, F, X	8	302-2V,		1	
70	B, F, X	8	351-4V,		1	
70/71	A	8	390-2V		1	
71	F, P	6	250		1	
71	S	8	429		1	
72	S-with Nox Emission	8	429		1	
71/	B	6	250		1	
12A170 VALVE ASSY. - DISTRIBUTOR MODULATOR						
72	A	6	All		1	D2AZ 12A170-E
72	S	8	429,460		1	
72	B, F, P -exc. Calif.	6	200,250		1	
72	A, B, F, P, U (A/T)	8	302,		1	
72	A, B(A/T) -exc. Calif.	8	351(W)		1	
72	A, B (P/C) -exc. California	8	429		1	
72	A, B, F	8	351C		1	D2AZ 12A170-D
72	B, F-California only	8	351		1	
72	B		400		1	
72	S(exc. Calif.)	8	400,460		1	
72	L	4	122		1	D2FZ 12A170-A
72	S-California only	8	400,460		1	D2SZ 12A170-A
72	A, B, F			Stud and washer-1/4"-20 x 1/4"-20 x 1 1/2"- attach valve assy. to valve cover	1	383210-S (WW128A)
12171-12189 Refer to Distributor Parts Lists - Section 120, page 1						
12191-12216 Refer to Distributor Parts Lists - Section 120, page 1						
12224 CONNECTOR - DISTRIBUTOR VACUUM PIPE						
71/	L	4	98	5mm dia. hole in one end	2	D1FZ 12224-A
71/	L	4	98	3mm dia. hole in one end	1	D1FZ 12224-B
12226 TUBE - DISTRIBUTOR VACUUM - STEEL NOT SERVICED - Make from 8C 2269-B (unless otherwise noted)						
12226 TUBE - DISTRIBUTOR VACUUM - RUBBER - Unless listed improvise from bulk tubing						
65/	A, B, F, L, P, S, X	4,6, & 8	All	7/64" I.D.-50 ft. long roll	AR	D0PZ 12226-A (KDV-1)
65/	A, B, F, L, P, S, X	4,6, & 8	All	5/32" I.D.-50 ft. long roll	AR	D0PZ 12226-B (KDV-2)
65/	A, B, F, L, P, S, X	4,6, & 8	All	7/32" I.D.-50 ft. long roll	AR	D0PZ 12226-C (KDV-3)
71	L	4	98	Black nylon-21 3/4" long	1	D1FZ 12226-D
71	L	4	98	Black nylon-10 1/4" long	1	D1FZ 12226-E
71/	L	4	98	Connector-elbow-1 1/4" long	2	D1FZ 12226-B
71/	L	4	122	Rubber-12" long with A/C-cut from D0PZ 12226-C	1	★
71/	L	4	98	Cut to length	1	D1FZ 12226-H
65	A, B, F, S, S, Police Interceptor	6&8	All	Connector (tube to distributor)- 3/16" tube-threaded sleeve	1	359546-S8B(II-67)
65/	A, S, X	6&8	All	Nut (distributor vacuum tube)- 3/8"-24	2or3	351112-S(MM109)
68/70	A, B, F, S, U, X	6&8	All	Nipple Dist. Vac.	AR	382488-S(II-2H)
68/	A, B, F, U, X	6&8	All	TEE (3 way)-3/16" tube connect distributor vacuum noses	1	378830-S(II-106H)
68/	A, B, F, S, U, X	6&8	All	Clip-attach tube to rocker arm	1	353547-S2(GG173)
70	F	8	302	Tee (5 way)-3/16" tube	1	384111-S (II-106VE)
71	A, B, F	8	851,400	Nipple-3/8" pipe-3/16" hose	AR	384068-S7(II-26)
72	A, B, F, L, P, S			Strap-adjustable-attach vacuum hose	AR	383313-S(YY6)

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12230-39 Refer to Distributor Parts Lists - Section 120, page 1						
12250 RESISTOR ASSY. - IGNITION COIL						
65/67	A Special (with 4/B or 8/B carb. and transistorized ignition)	8	427	Resistor (ignition coil)-32.00" long-No. 26 gauge black-with resistance of 8.1 ohms	1	C3AZ 12250-A (DY-53)
65/67	S(with transistorized ignition)	8	390		1	
65/67	A, B, S, X (except with transistorized ignition)	6&8	All	Resistor (ignition coil)-61.50" long-wire color code pink with 1.30 to 1.40 ohms resistance No. 20 gauge	1	C0LF 12250-A (DY-37)
68/70	X	6&8	All		1	
65/69	F	6&8	All		1	
68	A, B, S, U	6&8	All		1	
70/	P	6	All		1	
71/	L	4	All		1	
69/70	A, F	6&8	All	Resistor 60" long(1-2)ohms-wire color code pink #C9AB 12250-A	1	C9AZ 12250-A (DY-84)
69/	S	8	All		1	
71/	U	6&8	All		1	
71/	A	6&8	All	Resistor wire color code red with green stripe 60" long	1	D1AZ 12250-A (DY-84A)
69/70	F, X, U	6&8	All	Resistor wire color 60" long(1-2)ohms color code pink #C9OB 12250-A	1	C9OZ 12250-A (DY-85)
69/	B, F		All		1	
71/	L, P				1	
12259 WIRE SET - SPARK PLUG - Also refer to Groups 12A024, 12286, 12298, 14296						
65/66	A Special (with 8/B carb.)	8	427	Rayon core	1	D1AZ 12259-C (WR-3812)
66/69	P/C (exc. T/E)	8	428		1	
67	B, F, S(2/B, 4/B)	8	390		1	
66	A, B, S (2/B, 4/B)-T/E	8	352,390, 428		1	
67	A, S (2/B, 4/B)-T/E	8	390,428		1	
67/68	A & B Specials (4/B, 8/B)	8	427	Rayon-universal	1	D1PZ 12259-P (WR-3162)
68	A, B, F(race package)	8	427		1	
65/68	A, B, F, X	8	289		1	
65/68	B Special, F Special	8	289		1	
65/69	All High Performance Vehicles	8	390,406, 427,428		1	
65/69	B, F, S	8	352,390	Fiberglas core	1	C5AZ 12259-F (WR-3813)
67	B-GT, F (4/B T/E)	8	390		1	
67/68	A, F, S(except GT 500)	8	427,428		1	
67/68	B	8	427		1	
65/70	A	8	352,390		1	
70	A, F	8	428		1	
67/70	A	8	428	Fiberglas core	1	D1AZ 12259-G (WR-3800)
67/68	A, S	8	390		1	
69	B, F	8	428		1	
69/71	F(Boss)	8	302		1	
71	A	8	Spec. 390		1	
65/	A	6	240	Fiberglas core	1	D1AZ 12259-D (WR-3811)
65	B, F, X	8	260	Fiberglas core	1	D1AZ 12259-A (WR-3809)
65/66	B Special, F Special	8	289		1	
65/67	B, F, X(4/B R.F., P.F.)-except T/E	8	289		1	
65/67	A, B, F, U, X(2/B)-except T/E	8	289		1	
68	U(with Imco)	8	289		1	
68	A(with Imco)	8	302		1	
69/	A, B, U, X	8	302		1	
69/71	F(exc. Boss)	8	302		1	
72	F	8	302		1	

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12259 WIRE SET - SPARK PLUG - continued - Also Refer to Groups 12A024, 12286, 12298, 14296						
66/68	A,B,F,U,X(2/B)-T/E	8	289	Linen core	1	C6OZ 12259-B
66/68	F,X(4/B P.F.)-T/E	8	289		1	(WR-3814)
68	B,F,X(with Imco)	8	289,302		1	C8AZ 12259-B
68	A,B,F(with T/E)	8	302		1	D1AZ 12259-H
68	B,F,X,U	8	289		1	(WR-3815)
65/68	B	6	170,200		1	D1AZ 12259-B
65/70	F,X	6	170,200		1	(WR-3802)
70/	P	6	170,200		1	
			250			
69/	B,F	6	250		1	
67/	U	6	170		1	
67/70	U	6	170	Linen core	1	C4TZ 12259-H
69/70	B,F (4/B Special) Boss	8	429		1	D0ZZ 12259-C
69/	A	8	351 W		1	D1OZ 12259-B
69/70	F	8	351 W		1	(WR-3819)
69	B	8	351 W		1	
68/70	S	8	429		1	D1AZ 12259-J
69/71	A,B	8	429		1	WR-3816)
68	F(GT 500)	8	428		1	
72	S	8	400,460		1	
71/72	F,S	8	429		1	
70	B,F	8	351 C		1	
71/72	A,B,F	8	351 C		1	D3AZ 12259-A
71/72	A,B	8	400		1	(WR-3856)
71/	L	4	98		1	D1FZ 12259-A
						(WR-3817)
71/	L	4	122		1	D1FZ 12259-B
						(WR-3818)
71/	P	8	302	Fiberglas	1	D1UZ 12259-A
						(WR-3821)
12264-75 Refer to Distributor Parts Lists - Section 120, page 1						
12276 COVER - DISTRIBUTOR BREAKER						
69/72	A,B,S	8	429,460		1	D0SZ 12276-A
12286 WIRE ASSY. - DISTRIBUTOR TO SPARK PLUG - RADIO RESISTANCE						
- Also refer to Groups 12A024, 12259, 12298 and 14296						
65/70	A,B,S,X	6&8	All	Linen core-90° moulded boot at spark plug end- 180° moulded boot at dist. end-43.75" long - r/b D1AZ 12286-A (3-74)	AR	★ C0AZ 12286-E
65/70	A,B,S,X	6&8	All	Linen core-180° moulded boot at plug end- 60° moulded boot at dist. end-28.50" long- service pkg. includes 1-A9AZ 12113-A boot	AR	C0AZ 12286-B
65/	A,B,F,S,X	6&8	All	Steel core-90° moulded boot at plug end and straight boot at dist. end-54.50" long-service package includes 1-C5TZ 14466-A terminal	AR	C0AZ 12286-G

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12286 WIRE ASSY. - DISTRIBUTOR TO SPARK PLUG - RADIO RESISTANCE - continued -						
Also refer to Groups 12A024, 12259, 12298 and 14296						
65/	A,B,F,S,X	6&8	All	Steel core-110° moulded boot at plug end-90° moulded boot at dist. end-28.00" long-service package includes 1-A9AZ 12113-A boot and 1-C5TZ 14466-A terminal	AR	C0AZ 12286-F
65/	A,B,F,S,X	6&8	All	Steel core-straight boot at plug end-90° moulded boot at distributor end-33.00" long-service package includes 1-A9AZ 12113-A boot and 1-C5TZ 14466-A terminal	AR	C0AZ 12286-H
65/	A,B,F,S,X	6&8	All	Steel core-straight boot at plug end and straight boot at distributor end-24.25" long- service pkg. includes 1-C5TZ 14466-A terminal	AR	C0AZ 12286-J
65/	A,B,F,S,X	6&8	All	Ignition cable (high tension)-not radio resistant- steel core-25 foot bulk roll	AR	C3AZ 12A024-B
65/	A,B,S,X	6&8	All	Ignition cable (high tension)-radio resistance- linen core-25 foot bulk roll	AR	C3AZ 12A024-A
65/71	A,B,F,P,S,X	6&8	All	Rayon core-110° moulded boot at plug end- 90° moulded boot at dist. end-28 1/2" long- service pkg. includes (2) A9AZ 12113-A-boot (2) B8AZ 14466-A terminal	AR	D1AZ 12286-B
71	A,B,F,P,S	6&8	All	Rayon core-90° moulded boot at spark plug end- 180° moulded boot at dist. end-43.75" long	AR	D1AZ 12286-A
71	A,B,F,P,S	6&8	All	Rayon core-180° moulded boot at plug end- 60° moulded boot at dist. end-28.50" long- service pkg. includes 1-A9AZ 12113-A boot	AR	D1AZ 12286-C
72	A,B,F,P,S	8	All	Rayon core-180° moulded boot at spark plug end-26" long	AR	D2AZ 12286-A
72	A,B,F,P,S	8	All	Rayon core-180° moulded boot at spark plug end-28 1/2" long	AR	D2AZ 12286-B
72	A,B,F,P,S	8	All	Rayon core-180° moulded boot at spark plug end-31 1/2" long	AR	D2AZ 12286-C
72	A,B,F,P,S	8	All	Rayon core-110° moulded boot at spark plug end-25 1/2" long	AR	D2AZ 12286-D
72	A,B,F,P,S	8	All	Rayon core-110° moulded boot at spark plug end-29" long	AR	D2AZ 12280-E
72	A,B,F,P	6	All	Rayon core-180° moulded boot at spark plug end-10" long	AR	D2AZ 12286-F
72	A,B,F,P	6	All	Rayon core-180° moulded boot at spark plug end-14 1/2" long	AR	D2AZ 12286-G
72	A,B,F,P	6	All	Rayon core-180° moulded boot at spark plug end-17 1/4" long	AR	D2AZ 12286-H
72	A,B,F,P	6	All	Rayon core-180° moulded boot at spark plug end-24 3/4" long	AR	D2AZ 12286-J

SECTION 120

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12289 INSULATOR - CIRCUIT BREAKER						
65/71	B-(Power back windows)	6	200		1	C5AZ 12289-A
65/71	B (2/B)-Power back windows	8	289		1	
65/71	B(4/B-R. F. or P. F.) -Power back windows	8	289		1	
67	F (Fog lamp)-A/C	6&8	All		1	
68/71	A, B(Power window, top, tailgate)	6&8	All		1	
68/70	X(71)Power back windows	6&8	All		1	
70	F (Power top)	8	All		1	
71	B-with heated back window				1	
12297 SEPARATOR - IGNITION WIRE						
65/	A, B, F, S	8	All	Comb shaped-8 prongs-.09" thick	2	B6A 12297-A
65/	B, F, X, U	6			1	
65/	A, Taxi, P/C	6			1	
65/	A, B, F, L, P, S	6&8		Comb shaped-2.18" long-on rocker arm cover	2	B8Q 12297-A
65/70	X	6&8			2	
71/	L	4	122		1	D1FZ 12297-A
12298 WIRING ASSY. - IGNITION COIL TO DISTRIBUTOR HIGH TENSION -						
Also refer to groups 12A024, 12259, 12286, 14296						
65/68	A, B, S, X(except T/E)	8	352, 390	Radio resistant-13.00" long-not used on B with	1	★C5AZ 12298-A
65/68	A, B, F, X, U	8	289	53 amp. Leece-Neville alternator-linen core	1	
65/66	A Special (with 8/B carb.)	8	427		1	C7TZ 12298-A(7-73)
66	P/C	8	428		1	
65/67	A Special (8/B)	8	427	Steel core	1	★B8TZ 12298-B
65/66	F(2/B, 4/B P. F.)	8	289		1	
65/66	F Special (4/B)	8	289		1	
65	F	8	260	Radio resistant-linen core-10.50" long-	1	★C3AZ 12298-C
65	B Special, F Special	8	289	90° angle coil end	1	
65	B(except B Special)	8	289	Used with 53 amp. Leece-Neville alternator	1	
67	A Special (4/B, 8/B)	8	427	Silicone-13" long	1	8EQ 12298
65/72	A	6	240	Glass core-16" long	1	C4AZ 12298-E
66	A	8	352	Radio resistant-13" long	1	§ D4HZ 12298-A
66/69	A, B, S	8	390		1	
66/68	A Special (8/B)	8	427		1	
66/69	A, S, P/C	8	428		1	
66/68	A, B, F, X(2/B, 4/B-P. F.)-T/E	8	289	Radio resistant-9 1/2" long	1	C6AZ 12298-A
71/	A	8	351(W)	Radio resistant-8" long	1	★ D1AZ 12298-B
68/71	A, B, F, S	8	390	Radio resistant-9" long	1	§ D3VY 12298-A
68	A, B, F	8	427		1	
68/69	A, B, F	8	428		1	
68/	A, B, F, S	8	429		1	
68	F, U, X	8	289		1	
68/70	A, B, F, X	8	302		1	
70	A, (P/C), F(CJ)	8	428		1	
72	S	8	460		1	
65	F Special (4/B carb.)	8	289		1	

SECTION 120

FORD CAR PARTS

See PAGE 1 of this SECTION for
DISTRIBUTOR COMPONENT INFORMATION

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12298 WIRING ASSY. - IGNITION COIL TO DISTRIBUTOR HIGH TENSION - continued - Also refer to Groups 12A024, 12259, 12286, 14296						
71/	B, F, P, U	6	170,200, 250	Radio resistant-11 1/2" long	1	D1UZ 12298-A
69	A,B,X	8	302,351		1	C7TZ 12298-A
69	F-(except Boss)	8	302,351		1	
69	F-Boss "Before 4/14/69"	8	302 Spec.		1	
69	F Boss "From 4/14/69"	8	302 Spec.	13" long	1	\$ D4HZ 12298-A
71/	A	8	400		1	
71/	A, B, F, P, U	8	302,351		1	
72	B,S	8	400		1	
65/70	B,F,U,X	6	170, 200,250	Radio resistant-fiberglas 16.25" long	1	C3OZ 12298-B
70	P	6	All		1	
71/	L	4	122	Radio resistant-15 1/4" long	1	\$ D4FZ 12298-A
71/	L	4	98	Radio resistant-15 1/2" long	1	\$ C6TZ 12298-A
66/67	U	6	170	Steel core-16" long	1	\$ C4UZ 12298-A r/b C3OZ 12298-B (10-74)

12300-90 Refer to Distributor Parts Lists - Section 120, page 1**12405 SPARK PLUG ASSY. - 18MM**

65/	A (for racing only)	6&8	All	BF601-gap setting-.023"/.027"	6or8	C2AZ 12405-A
65/	A (for racing only)	6&8	All	BTF1-gap setting-.023"/.027"	6or8	C2AZ 12405-B
65/	A (for racing only)	6&8	All	BF22-gap setting-.028"/.032"	6or8	C3AZ 12405-A
65/	A (for racing only)	6&8	All	BF12-gap setting-.028"/.032"	6or8	C3AZ 12405-B

12405 SPARK PLUG CHART - 14MM - 18MM

RESTRICTIONS			PART NUMBERS					
YEAR	MODEL & DESCRIPTION	C.I.D.	LIGHT SERVICE		NORMAL SERVICE		H/D SERVICE	
			AUTOLITE	FORD	AUTOLITE	FORD	AUTOLITE	FORD

4 CYLINDER ENGINES

71/	L	98		AGR22	D1FZ 12405-B			
71/	L	122	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A

6 CYLINDER ENGINES

65	A "Before 8/2/65"	240	BTF6	B7A 12405-A	BTF6	B7A 12405-A	BTF6	B7A 12405-A
65/66	A "From 8/2/65 to 9/22/65"	240	BTF6	B7A 12405-A	BTF6	B7A 12405-A	BTF42	C5TZ 12405-A
66/70	A(exc. Taxi & P/C)- "From 9/22/65"	240	BF42	B8A 12405-A	BF42	B8A 12405-A	BF42	B8A 12405-A
66/70	Taxi, P/C	240	BTF6	B7A 12405-A	BTF6	B7A 12405-A	BTF6	B7A 12405-A
65/67	B, F, U, X	170,200	BF92	C2OZ 12405-A	BF82	B7A 12405-B	BF82	B7A 12405-B
68/	B, F, U, X	170,200, 250	BF82	B7A 12405-B	BF82	B7A 12405-B	BF82	B7A 12405-B
70	P	170,200, 250	BF82	B7A 12405-B	BF82	B7A 12405-B	BF82	B7A 12405-B
71/	P	170			BRF82	C1AZ 12405-C		
71/	B, F, P	200,250			BRF82	C1AZ 12405-C		
71/	A(P/C, Taxi)	240			BRF6	B7A 12405-C		
71/	A(Exc. P/C, Taxi)	240			BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A

12405 SPARK PLUG CHART - 14MM - 18MM - continued

RESTRICTIONS			PART NUMBERS					
YEAR	MODEL & DESCRIPTION	C.I.D.	LIGHT SERVICE		NORMAL SERVICE		H/D SERVICE	
			AUTOLITE	FORD	AUTOLITE	FORD	AUTOLITE	FORD
8 CYLINDER ENGINES								
65	F	260	BF42	B8A 12405-A	BF42	B8A 12405-A	BF42	B8A 12405-A
65/69	A, B, F, X, U(2/B, 4/B R. F. or P. F.)	289	BF42	B8A 12405-A	BF42	B8A 12405-A	BTF42	C5TZ 12405-A
65/69	B & F Specials(4/B)	289	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
65	P/C	390	BF42	B8A 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
65/68	A Special(4/B, 6/B, 8/B)	352, 390	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
65/68	A, B, F(2/B, 4/B)	352, 390,	BF42	B8A 12405-A	BF42	B8A 12405-A	BF42	B8A 12405-A
68/69	A, B, F, S(4/B)	427, 428, 429						
35/68	A Special(4/B, 6/B, 8/B)	406, 427	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
66/69	B-GT, F(4/B)	390	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
66/70	P/C	428	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
68/	U	302	BF42	B8A 12405-A	BF42	B8A 12405-A	BF42	B8A 12405-A
68/70	A, B, F, X	302	BF42	B8A 12405-A	BF42	B8A 12405-A	BF42	B8A 12405-A
68/69	A, B, F	427	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
69/70	B(CJ), F(Boss)	302, 429 Spec.	AF32	C9ZZ 12405-A	AF32	C9ZZ 12405-A	AF32	C9ZZ 12405-A
69/70	B(CJ), F(Boss)	302, 429	ARF32	C9PZ 12405-A	ARF32	C9PZ 12405-A	ARF32	C9PZ 12405-A
69/70	A, F	351-2V	BF42	B8A 12405-A	BF42	B8A 12405-A	BF42	B8A 12405-A
69/70	B, F	351-4V, 390, 428	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
69/70	A, B, F	390	BF42	B8A 12405-A	BF42	B8A 12405-A	BF42	B8A 12405-A
69/70	B, F	351	AF42	C9ZZ 12405-B	AF42	C9ZZ 12405-B	ARF42	C9PZ 12405-B
69	A	428	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A	BF32	C0AZ 12405-A
70	B, F " Before 11/5/69"	351	AF32	C9ZZ 12405-A	AF32	C9ZZ 12405-A	ARF32	C9PZ 12405-A
70	B, F " From 11/15/69"	351	AF42	C9ZZ 12405-B	AF42	C9ZZ 12405-B	ARF42	C9PZ 12405-B
70	B(2/B)	351	AF42	C9ZZ 12405-B	AF42	C9ZZ 12405-B	AF42	C9ZZ 12405-B
70	B, F(4/B)	351	AF42	C9ZZ 12405-B	AF42	C9ZZ 12405-B	AF42	C9ZZ 12405-B
70	A, B, S	429	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A
71/	A(P/C, Taxi)-W	302, 351	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A
71	A	302	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A
71/	A	400	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B
71	A, B, F	429-4/B	ARF32	C9PZ 12405-A	ARF32	C9PZ 12405-A	ARF32	C9PZ 12405-A
71/	B, F, P	302-2/B	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A
71	F	302-4/B	ARF32	C9PZ 12405-A	ARF32	C9PZ 12405-A	ARF32	C9PZ 12405-A
71	B, F(2/B, 4/B)	351	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B
72	B(W)	351	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A
72	A, B	429	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A
72	B(P/C)	429	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B
72	A(P/C)	429	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B
72	B, S	400	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B
71/	S	429	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A
71	A	351, 390	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A
72	A, B, F(C)	351	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B	ARF42	C9PZ 12405-B
72	S	460	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A	BRF42	D0AZ 12405-A

SECTION 120

FORD CAR PARTS

See PAGE 1 of this SECTION for
DISTRIBUTOR COMPONENT INFORMATION

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12405 TUNE UP KIT - IGNITION - continued						
MOTORCRAFT						
65	A	6	240	Consists of 1-C9AZ 12171-B (DP-3) points 1-7RA 12300-C (DC-6) cond. 6-B7A 12405-A (BTF-6) spark plugs	1	TKF 5
66/67	A	6	240	Consists of 1-C9AZ 12171-B (DP-3) points 1-7RA 12300-C (DC-6) cond. 6- B8A 12405-A (BF-42) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S.#3384	1	TKF 15
68/70	A	6	240	Consists of 1-C9AZ 12171-B (DP-3) points 1-C9AZ 12300-A (DC-13A) cond. 6-B8A 12405-A (BF-42) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3384	1	TKF 16
71	A	6	240	Consists of 1-C9AZ 12171-B (DP-3) points 1-C9AZ 12300-A (DC-13A) cond. 6-D0AZ 12405-A (BRF-42) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. # 3384	1	TKF 20
65/67	A(exc. 390)			Consists of	1	TKF 1
68	A(428)			1-B8Q 12171-A (DP-12) points	1	
65/68	B(exc. 390 GT)			1-C9AZ 12300-A (DC-13A) cond.	1	
65/67	F(8 cyl. exc.289 Hi Perf. with T/E and 289 (4/B carb.))			8-B8A 12405-A (BF-42) spark plugs	1	
68/70	A(302, 390)				1	
70	B(302)				1	
69	B(351, 390)				1	
68	F (exc. 390 GT)				1	
69/70	F(302, 351, 390) (2/B)				1	
65/68	S				1	
66/	U(8 cyl.)				1	
65/68	X(8 cyl.)				1	
65/67	B(exc. T/E)	6	170,	Consists of	1	TKF 2
65/67	F(exc. T/E)		200	1-C9AZ 12171-B (DP-3) points		
66/67	U(exc. T/E)			1-7RA 12300-C (DC-6) cond.		
65/67	X(exc. T/E)			6-B7A 12405-B (BF-82) spark plugs		
66/70	B(w/T/E & Imco)	6	All	Consists of	1	TKF 6
66/70	F(w/T/E & Imco)			1-C9AZ 12171-B (DP-3) points		
66/	U(w/T/E & Imco)	6	170	1-C9AZ 12300-A (DC-13A) cond.	1	
66/70	X(w/T/E & Imco)	6	250	6-B7A 12405-B (BF-82) spark plugs	1	
70	P	6	All		1	
66/70	A(427, 428) P/C			Consists of	1	TKF 7
66/68	B(390 GT)			1-B8Q 12171-A (DP-12) points	1	
66/67	F(289 Hi Perf. w/ T/E)			1-C9AZ 12300-A (DC-13A) cond.	1	
67	F(289 4/B carb.)			8-C0AZ 12405-A (BF-32) spark plugs	1	
68/69	F(390 GT)				1	
69	B, F(351-4V)				1	
69/70	B(CJ)	8	429	Consists of	1	TKF 13
69/70	F(4/B Boss)	8	302	2-C9AZ 12171-A (DP-5) points 1-C9AZ 12300-A (DC-13A) cond. 8-C9ZZ 12405-A (AF-32) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3384		

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
69	F(CJ)	8	428	Consists of 2-C9AZ 12171-A (DP-5) points 1-C9AZ 12300-A (DC-13A) cond. 8-C0AZ 12405-A (BF-32) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3384	1	TKF 14
70	B(2/B,4/B)	8	351	Consists of	1	TKF 11
70	F(4/B)	8	351	1-B8Q 12171-A (DP-12) points 1-C9AZ 12300-A (DC-13A) cond. 8-C9ZZ 12405-B (AF-42) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3384		
70/	A,B,S	8	429	Consists of	1	TKF 17
71/	A, B, F, P, U	8	302	1-B8Q 12171-A (DP-12) points	1	
71/	A	8	351	1-C9AZ 12300-A (DC-13A) cond.	1	
71	A	8	390	8-D0AZ 12405-A (BRF-42) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S.#3384	1	
71/	A(2/B), B(2/B)	8	400	Consists of	1	TKF 22
71/	B(4/B)	8	351	1-B8Q 12171-A (DP-12) points	1	
71/	F(2/B)	8	351	1-C9AZ 12300-A (DC-13A) cond. 8-C9PZ 12405-B (ARF-42) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3384	1	
71/	A(4/B)	8	429	Consists of	1	TKF 23
71/	B, F(4/B CJ, S/CJ)-A/T	8	429	1-B8Q 12171-A (DP-12) points 1-C9AZ 12300-A (DC-13A) cond. 8-C9PZ 12405-A (ARF-32) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3384	1	
71/	B,F,P	6	170, 200, 250	Consists of 1-C9AZ 12171-B (DP-3) points 1-C9AZ 12300-A (DC-13A) cond. 6-C1AZ 12405-C (BRF-82) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3384	1	TKF 19
71/	F(4/B)	8	302	Consists of	1	TKF 21
71/	B, F(CJ, S/CJ)-S/T	8	429	2-C9AZ 12171-A (DP-5) points 1-C9AZ 12300-A (DC-13A) cond. 8-C9PZ 12405-A (ARF-32) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3384	1	
71/	L	4	98	Consists of 1-B8Q 12171-A (DP-12) points 1-D0RY 12300-A (DCE-238) cond. 4-D1FZ 12405-B (AGR-22) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3930	1	TKF 18
71/	L	4	122	Consists of 1-D1FZ 12171-A (DP-124) points 1-D1FZ 12300-A (DC-88) cond. 4-D0AZ 12405-A (BRF-42) spark plugs 1-Feeler Gauge 1-Lubricant 1-I.S. #3936	1	TKF 24

Identification marking

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

SECTION 120

FORD CAR PARTS

See PAGE 1 of this SECTION for
DISTRIBUTOR COMPONENT INFORMATION

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
12450 GOVERNOR ASSY. - ENGINE						
69/71	F-Boss (S/T)	8	302	#D0ZF 12450-B (6150 RPM)	1	D0ZZ 12450-B
70	B-S/CJ (S/T)	8	429		1	
71	F-S/CJ	8	429		1	
71/	F-Boss	8	351		1	
70/71	F-CJ-S/CJ-(S/T)	8	429	#D0ZF 12450-A (5800 RPM)	1	D0ZZ 12450-A
70/71	B-CJ (S/T)	8	429		1	
70/71	B, F	8	All	Screw 1/4" -14 x 3/4" -attach governor to R.H. suspension housing	3	55914-S(U254-F)
70/71	B, F	8	All	Bolt-3/8"-16 x 1/2-attach ground wire to intake manifold	1	20312-S(B98)
70/71	B, F	8	All	Washer-3/8"	1	34807-S(X66)
12K454 WIRE ASSY. ENGINE GOVERNOR CONTROL VALVE EXTENSION						
71	A(with A/T)	6&8	240,390	#D1AB 12K454-AB	1	D1AZ 12K454-A
72	A(with A/T)	6	240	#D2AB 12K454-AC	1	D2AZ 12K454-A
72	A	8	351,400		1	
72	A(P/C)	8	429		1	
70	B(with A/T)	8	302	#D0OB 12K454-A	1	D0OZ 12K454-A
70	B(with A/T or S/T)	8	351		1	
71	B-California only	6	250	#D1OB 12K454-AC	1	D1OZ 12K454-A
72	B(with A/T)-Calif.only	6&8	All	#D2OB 12K454-AB	1	D2OZ 12K454-B
72	B, F (with A/T)	8	351	#D2OB 12K452-AA	1	D2OZ 12K454-C
71	F	6	250	#D1ZB 12K454-AA	1	D1ZZ 12K454-A
72	F(without A/C)-exc. Calif.	6&8	All	45" long-#D2ZB 12K454-AB	1	D2ZZ 12K454-A
72	F(without A/C)-Calif.only	6&8	All	43" long-#D2ZB 12K454-CB	1	D2ZZ 12K454-C
72	F(with A/C)-exc. Calif.	6&8	All	51" long-#D2ZB 12K454-BB	1	D2ZZ 12K454-B
72	F(with A/C)-Calif.only	6&8	All	54" long-#D2ZB 12K454-DB	1	D2ZZ 12K454-D
72	L(with S/T)-Calif. only	4	98, 122	80" long-attaches to 14401-#D22B 12K454-AA	1	D2FZ 12K454-A
72	L(with S/T, A/T)-Calif. only	4	122	25" long-attaches to 14290-#D22B 12K454-BB	1	D2FZ 12K454-B
72	L(with S/T)-Calif. only	4	98	BC	1	
72	L(with A/T)-Calif. only	4	122	74" long-attaches to 14401-#D22B 12K452-AB	1	D2FZ 12K454-D
71	P(62D)-California only	6	All	#D1DB 12K454-AB	1	D0DZ 12K454-B
72	P(A/T)	6&8	250,302	#D2DB 12K454-AB, AC	1	D2DZ 12K454-A
71	S	8	429	#D1SB 12K454-AC	1	D1SZ 12K454-A
70	X(with A/T)	8	302	#C9DB 12K454-A	1	C9DZ 12K454-A
71/	F			Clip (attach wire to cowl top panel)	4	382033-S(GG303)
12638 WIRE ASSY. - STARTER CIRCUIT JUMPER - Also refer to group 11A103						
65	A(with S/T)	6&8	All	Cut from B6A 14296-C bulk wire-used with back-up lights and 4 speed transmission	1	★C1MF 12638-A
65/66	A (with C/M) "Before 12/13/65"	8	All	Not replaced	1	★C5AZ 12638-A
66	A(C4, C6) "Before 12/13/65"	6&8	All	Not replaced	1	★C5AZ 11A103-A
66	A(C4, C6, C/M) "From 12/13/65"	6&8	All	Not replaced	1	★C5AZ 12638-B
68/69	A(63C, 76B)-with A/T	8		#C8AB 12638-B or C	1	C8AZ 12638-B
66	B (C4)	6	200	Not replaced	1	★C6OZ 12638-B
66	B (2/B, 4/B, R.F. or P.F.)	8	289		1	
66	B(2/B, 4/B)	8	390		1	
68/69	B(63D, E, 65, D, E, 66D, 76D, E) console mounted - C4, C6 A/T	8	390	#C8OB 12638-A, D1OB 12638-AA	1	C8OZ 12638-A
70/71	B (65E)-console mounted	8	351		1	
72	B(w/ A/T)-console - "Before 10/1/71"	6&8	All	#D2OB 12638-AA	1	D2OZ 12638-A
72	B(w/ A/T) "From 10/1/71"	6&8	All	#D2OB 12638-BA	1	D2OZ 12638-B
65/66	F(C4, C6)	6&8	200,289	Not replaced	1	★C5ZZ 12638-B
67	F(tilt steering column)- "Before 2/15/67"	6&8	All	#C7ZB 12638-A - not replaced	1	★C7ZZ 12638-A
	"From 2/15/67"			Refer to Group 3D568		
66	X(C4)	6	200	Not replaced	1	★C6OZ 12638-B
66	X(2/B, 4/B, R.F. or P.F.)	8	289		1	
70/71	S	8	429	#D0SB 12638-A, B, #D1SB 12638-AA	1	D1SZ 12638-A
72	S	8	429	Improvise from bulk wire		★

Identification Marking

FORD CAR PARTS

SECTION 120.1
6 CYL. 170, 200, 240

1

LOADOMATIC DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS		PART NUMBER	LOADOMATIC DISTRIBUTOR												
			DISTRIBUTOR PARTS LIST												
			A	B	C	D	E	F	G	H	1A thru 1M				
CUP - OIL		B6A 10141-A	A	B											
REPAIR KIT - DISTRIBUTOR		A7A 12000-B (DK-2)	A	B	C	D									
Consists of															
(1) C9AZ 12171-B Points		(1) FAA 12200-B Rotor	(1) FET 12300-A Condenser												
			or												
			(1) 7RA 12300-C Condenser												
HOUSING - DISTRIBUTOR TERMINAL (CAP)		7HA 12106 (DH-4)	A	B	C	D									
BUSHING UPPER		C4DZ 12120-A (MC-157)	A	B	C	D									
OILER - DISTRIBUTOR HOUSING		FAA 12135-A			C	D									
GASKET - DISTRIBUTOR BASE		C0DF 12143-A (DZ-4)	A	B											
CLAMP - TERMINAL HOUSING (HOLD DOWN)		7RA 12144 (DZ-337)	2	2	2	2									
RIVET - TERMINAL HOUSING CLAMP		B 12145	2	2	2	2									
SNAP RING - DISTRIBUTOR BREAKER PLATE		7RA 12146 (DZ-10)	A	B	C	D									
PLATE - DISTRIBUTOR BREAKER		C1DF 12151-A (DB-10)	A		C										
		C3UZ 12151-A (DB-163)		B		D									
POINT SET - DISTRIBUTOR ARM & BREAKER-PIVOTLESS		C3DZ 12171-A (DP-70)	A	B	C	D									
Pivot		C9AZ 12171-B (DP-3)	A	B	C	D									
Washer-No. 8		34802-S(X59)	2	2	2	2									
Screw No. 8-32 x 5/16" Fill. head		31037-S7(U-48)	2	2	2	2									
SHAFT and CAM DISTRIBUTOR		C5AZ 12175-B (DF-349)			C	D									
		C4DZ 12175-A (DF-325)	A	B											
WASHER - DISTRIBUTOR DRIVEN GEAR		C5TZ 12179-A (DZ-381)			C	D									
SPRING - Refer to Distributor Identification Charts for Calibration Codes		12191-2													

FORD CAR PARTSSee SECTION 120, PAGE 1 for
PARTS LIST INSTRUCTIONS

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST													1A thru 1M			
		A	B	C	D	E	F	G	H	I	J	K	L	M				
ROTOR ASSY. - DISTRIBUTOR	FAA 12200-B (DR-1)	A	B	C	D													
STOP - Refer to Distributor Identification Charts for Calibration Codes	12202																	
CAM - Refer to Distributor Identification Charts for Calibration Codes	12210																	
RETAINER - DISTRIBUTOR ROTOR	0BA 12213-A (DZ-355)	A	B	C	D													
WIRE ASSY. - PRIMARY TERMINAL	C0DF 12216-A (DW-10)	A	B	C	D													
Nut-No. 6-32	34051-S7(M154)	A	B	C	D													
Lockwasher No. 6	34801-S7(X58)	A	B	C	D													
WIRE ASSY. - DISTRIBUTOR BREAKER GROUND	7RA 12264 (ML-290)	A	B	C	D													
Screw & lockwasher No. 8-32 x 5/16" - fill. head	355067-S7(BB53)	A	B	C	D													
CLAMP - DISTRIBUTOR to CYLINDER HEAD	C3AZ 12270-A (DZ-410)	A	B	C	D													
Screw-5/16"-18 x 1"	20386-S8(B53)	A	B	C	D													
Lockwasher-5/16"	34806-S7(X64)	A	B	C	D													
CONDENSER ASSY. - DISTRIBUTOR	7RA 12300-C (DC-6)	A	B	C	D													
Lockwasher-No. 6	34801-S(X58)	A	B	C	D													
Nut-No. 6-32	34051-S7(M154)	A	B	C	D													
Screw & lockwasher No. 8-32 x 5/16"	355067-S(BB53)	A	B	C	D													
DIAPHRAGM ASSY. - Refer to Distributor Identification Charts for Calibration Codes	12370																	
Screw & lockwasher-No. 8-32 x 3/4"	43395-S8(U75)	2	2															
Nut-tube-3/8"-24 (dist. vacuum tube)	351112-S(MM109)			2	2													
Pin-self-lock-7/16" long	353610-S8(NN126)	A	B	C	D													
GEAR - DISTRIBUTOR DRIVEN	C4DZ 12390-A (DZ-364)	A	B															
	C5TZ 12390-A (DZ-383)			C	D													
Rivet-1/8" x 13/16" (gear to shaft)	61489-S(S10)			C	D													
Pin-1/8" x .672/.702"(gear to shaft)	354132-S(NN97)	A	B															

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

FORD CAR PARTS

SECTION 120.2
6 CYL. 170, 200, 240, 250

I

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST													
		2A thru 2M													
CUP OIL	B6A 10141-A	A	B	C	D	E	F	G	H	J	K	L	M		
REPAIR KIT - DISTRIBUTOR	C5AZ 12000-D (DK-16)	A	B	C	D	E	F	G	H	J	K	L	M		
Consists of															
(1) C9AZ 12171-B Points				(1) D5DZ 12200-A Rotor				(1) C9AZ 12300-A Condenser							
PLUG - DISTRIBUTOR DIAPHRAGM	C7AZ 12A022-A					E	F	G		J					
	C8AZ 12A022-A (DZ-404)								H						
BUTTON-DIST BREAKER PLATE SUPPORT	•D2AZ 12072-A										3	3	3		
SLEEVE - DISTRIBUTOR SHAFT PLATE	C2AZ 12A075-A	A	B	C	D	E	F	G	H	J	K	L	M		
HOUSING - DISTRIBUTOR TERMINAL (CAP)	7HA 12106 (DH-4)	A	B	C	D	E	F	G	H	J	K	L	M		
BUSHING - DISTRIBUTOR HOUSING UPPER	C5AZ 12120-A (MC-175)	A	B	C	D	E	F	G	H	J	K	L	M		
GASKET - DISTRIBUTOR BASE	C0DF 12143-A (DZ-4)	A	B			E	F	G		J	K	L	M		
SEAL - "O" RING DISTRIBUTOR BASE	87055-S94								H						
CLAMP - TERMINAL HOUSING (HOLD DOWN)	7RA 12144 (DZ-337)	2	2	2	2	2	2	2	2	2	2	2	2		
RIVET - TERMINAL HOUSING	B 12145	2	2	2	2	2	2	2	2	2	2	2	2		
RETAINER-DIST.BREAKER PLATE	•D2AZ 12146-A										K	L	M		
PLATE ASSY. - DISTRIBUTOR BREAKER	12151														
Upper	C5TZ 12151-A (DB-170)	A	B	C	D	E	F	G	H	J					
Lower	C5TZ 12151-B (DB-171)	A	B	C	D	E	F	G	H	J					
Less points and condenser	D2PZ 12151-B (DP-186A)										K	L	M		
Upper-plate only	•D2TZ 12151-C										K	L	M		
Lower-plate only	•D2TZ 12151-B										K	L	M		
Washer "C" type	351825-S(XX9)	A	B	C	D	E	F	G	H	J					
Washer -spring 3/16"	372395-S(XX368)	A	B	C	D	E	F	G	H	J					
Washer-flat-3/16"	372396-S(XX78)	A	B	C	D	E	F	G	H	J					
POINT SET - DISTRIBUTOR ARM & BREAKER	C9AZ 12171-B (DP-3)	A	B	C	D	E	F	G	H	J	K	L	M		
Washer-No. 8	34802-S(X59)	2	2	2	2	2	2	2	2	2	2	2	2		
Screw & washer-No. 8-32 x 5/16"	355067-S7(BB53)	2	2	2	2	2	2	2	2	2	2	2	2		
SHAFT - DISTRIBUTOR - includes C8AZ 12179-A thrust washer (upper)	C8TZ 12175-C (DF-367)			C	D										
	D1AZ 12175-A (DF-384)								H						
Includes weights	ø D2DZ 12175-A (DF-366A)	A	B								K				
Includes weights	D2TZ 12175-A (DF-367A)											L			
Includes weights	D2DZ 12175-B (DF-370A)					E	F	G		J			M		
RETAINER - DISTRIBUTOR CAM	B7A 12177-A	A	B	C	D	E	F	G	H	J	K	L	M		
WASHER - DISTRIBUTOR SHAFT THRUST-UPPER	C8AZ 12179-A (DZ-413)	A	B	C	D	E	F	G	H	J	K	L	M		
WASHER - DISTRIBUTOR DRIVEN GEAR	C5TZ 12179-A (DZ-381)			C	D				H						
Washer-5/16" -flat	379039-S(XX112H)			C	D				H						

• Reconditioner only
May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST								2A thru 2M			
		A	B	C	D	E	F	G	H	J	K	L	M
LINK-DIST. BREAKER PLATE	●D2AZ 12A186-A										K	L	M
SPRING-DIST. BREAKER PLATE	●D2AZ 12A187-A										K	L	M
WEIGHT ASSY. - DISTRIBUTOR ADVANCE	C5AZ 12188-A (DZ-382)	2	2	2	2	2	2	2	2	2	2	2	2
Washer "C" type	351825-S(XX9)	2	2	2	2	2	2	2	2	2	2	2	2
SPRING - Refer to Distributor Identification Charts for Calibration Codes	12191-2												
ROTOR ASSY. - DISTRIBUTOR	C5TZ 12200-B (DR-87)	A	B	C	D	E	F	G	H	J	K	L	M
STOP - Refer to Distributor Identification Charts for Calibration Codes	12202												
CAM - Refer to Distributor Identification Charts for Calibration Codes	12210												
WIRE ASSY. - PRIMARY TERMINAL	C1VF 12216-A (DW-12)	A											
	C7VY 12216-A (DW-34)		B		D	E	F	G	H	J	K	L	M
	C5TZ 12216-A (DW-23)			C									
Nut-No. 6-32	34051-S7(M154)	A	B	C	D	E	F	G	H	J	K	L	M
Lockwasher-No. 6	34801-S7(X58)	A	B	C	D	E	F	G	H	J	K	L	M
Screw No. 6-18 x 3/8"	32921-S8(U334G)							G	H	J	K	L	M
WIRE ASSY. - DISTRIBUTOR BREAKER GROUND	D2AZ 12264-A (ML-291)	A	B	C	D	E	F	G	H	J	K	L	M
Screw-No. 8-32 x 5/16"	31037-S7(U48)		B	C	D	E	F	G	H	J	K	L	M
Lockwasher-No. 8	34802-S7(X59)		B	C	D	E	F	G	H	J	K	L	M
Screw and lockwasher-No. 8-32 x 5/16"	355067-S7(BB53)	A	B	C	D	E	F	G	H	J	K	L	M
CLAMP - DISTRIBUTOR TO CYLINDER HEAD	C3AZ 12270-A (DZ-410)	A	B	C	D	E	F	G	H	J	K	L	M
Screw 5/16"-18 x 1"	20386-S8(B53)	A	B	C	D	E	F	G	H	J	K	L	M
Lockwasher-5/16"	34806-S7(X64)	A	B	C	D	E	F	G	H	J	K	L	M
CONDENSER ASSY. - DISTRIBUTOR	C9AZ 12300-A (DC-13A)	A	B	C	D	E	F	G	H	J	K	L	M
Screw No. 8-32 x 5/16"	355067-S7(BB53)	A	B	C	D	E	F	G	H	J	K	L	M
GASKET - DIAPHRAGM VACUUM CONNECTOR	★B7A 12320-A	A	B	C	D	E	F	G	H	J			
DIAPHRAGM ASSY. - Refer to Distributor Identification Charts for Calibration Codes	12370												
Retainer "C" type (diaphragm rod)	351826-S(XX2)	A	B	C	D	E	F	G	H	J			
Washer-flat-1/4" .078" thick (vacuum calibration)	354610-S(XX91)	A	B	C	D	E	F	G	H	J			
Connector-3/16" (vac. tube to dist.)	359546-S8B(II-67)	A	B	C	D	E	F	G	H	J			
Washer-flat-1/4" .009" thick	375482-S(XX85)	A	B	C	D	E	F	G	H	J			
Washer-flat-1/4" .021" thick	375483-S(XX85A)	A	B	C	D	E	F	G	H	J			
Washer-flat-1/4" .041" thick	375484-S(XX85B)	A	B	C	D	E	F	G	H	J			
Screw-No. 8-32 x 1" pan head (diaphragm to dist.)	382331-S2(BB635A)						2	2	2	2			
GEAR - DISTRIBUTOR DRIVEN	C4DZ 12390-A	A	B			E	F	G		J	K		M
	C5TZ 12390-A (DZ-383)			C	D				H			L	
Pin-1/8" x 3/4" (gear to shaft)	353925-S(NN98)			C	D	E	F						
Rivet-1/8" x 13/16" (gear to shaft)	61489-S(S10)	A	B					G	H	J	K	L	M

• Reconditioners only

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

FORD CAR PARTS

SECTION 120.3 1
8 CYL. 289, 352, 406, 427
CENTRIFUGAL ADVANCE

DESCRIPTION AND RESTRICTIONS	PART NUMBER	CENTRIFUGAL ADVANCE												
		DISTRIBUTOR PARTS LIST 3A THRU 3M												
		A	B	C	D	E	F	G	H	J	K	L	M	
CUP - DISTRIBUTOR OIL	B6A 10141-A	A												
REPAIR KIT - DISTRIBUTOR	C5ZZ 12000-A (DK-14)	A	B	C	D									
Consists of														
(2) C9AZ 12171-C Points (1) B7A 12200-A Rotor (1) FET 12300-A Condenser														
or														
(1) 7RA 12300-C Condenser														
HOUSING - DISTRIBUTOR TERMINAL (CAP)	B7A 12106-A (DH-6)	A	B	C	D	E								
BUSHING - DISTRIBUTOR HOUSING	12120													
Upper	B8QH 12120-A (MC-148)	A	B	C	D	E								
Lower	C5AZ 12132-A (MC-176)		B	C	D	E								
GASKET - DISTRIBUTOR BASE	B9TF 12143-A (DZ-3)	A	B	C										
	B8A 12143-A (DZ-1)				D	E								
CLAMP - TERMINAL HOUSING (HOLD DOWN)	B7A 12144-A (DZ-339)	2												
	7RA 12144 (DZ-337)		2	2	2	2								
RIVET - TERMINAL HOUSING (HOLD DOWN CLAMP)	B 12145	2	2	2	2	2								
PLATE - DISTRIBUTOR BREAKER UPPER	C0AF 12152-A (DB-18)	A	B	C	D	E								
POINT SET - DISTRIBUTOR ARM & BREAKER	C9AZ 12171-C (DP-6)	2	2	2	2									
	C3AZ 12171-A (DP-71)					E								
Nut-No. 6-32	34051-S7(M154)	2	2	2	2	2								
Washer-No. 6	34801-S7(X58)	2	2	2	2	2								
Screw-No. 8-32 x 5/16"	355067-S7(BB53)	2	2	2	2	2								
SHAFT - DISTRIBUTOR	B8A 12175-A (DF-6)	A												
Includes C8AZ 12179-A washer -	C5AZ 12175-C (DF-364)		B	C	D	E								
"Before 12/28/70"	D2AZ 12175-D (DF-364-C)		B	C	D	E								
"From 12/28/70"														

CENTRIFUGAL ADVANCE

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 3A THRU 3M												
		A	B	C	D	E	F	G	H	J	K	L	M	
RETAINER - DISTRIBUTOR - CAM	B7A 12177-A	A	B	C	D	E								
WASHER - DRIVEN GEAR	B7A 12179-A	A												
WASHER-DISTRIBUTOR SHAFT THRUST-UPPER	C8AZ 12179-A (DZ-413)		B	C	D	E								
WEIGHT - DISTRIBUTOR ADVANCE	C4TZ 12188-A (DZ-12)	2	2											
	C5AZ 12188-A (DZ-382)			2	2	2								
Ring-3/16" retaining	351285-S(XX9)			2	2	2								
SPRING - Refer to Distributor Identification Charts for Calibration Codes	12191-2													
COLLAR - DISTRIBUTOR SHAFT	7HA 12195	A	B	C	D	E								
ROTOR ASSY. - DISTRIBUTOR	B7A 12200-A (DR-5)	A	B	C	D	E								
STOP - Refer to Distributor Identification Charts for Calibration Codes	12202													
CAM - Refer to Distributor Identification Charts for Calibration Codes	12210													
WIRE ASSY. - PRIMARY TERMINAL	B8Q 12216-A (DW-4)	A	B	C	D									
	C3AZ 12216-A (DW-20)					E								
Nut-No. 6-32	34051-S7(M154)	A	B	C	D	E								
Lockwasher-No. 6	34801-S7(X58)	A	B	C	D	E								
COVER - DISTRIBUTOR	★C3AZ 12239-A (DZ-308)					E								
CLAMP - DISTRIBUTOR TO CYLINDER HEAD	C3AZ 12270-A (DZ-410)	A												
Bolt-5/16"-18 x 1"	20386-S8(B53)	A												
Lockwasher-5/16"	34806-S7(X64)	A												
CONDENSER ASSY. - DISTRIBUTOR	7RA 12300-C (DC-6)	A	B	C	D									
Screw-No. 8-32 x 5/16"	355067-S7(BB53)	2	2	2	2									
GEAR - DISTRIBUTOR DRIVEN	C2OF 12390-A (DZ-362)	A	B	C										
	FAB 12390-C (DZ-367)				D	E								
Rivet-1/8" x 13/16" gear to shaft	61489-S(S10)	A	B	C	D	E								

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

FORD CAR PARTS

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4A THRU 4M												
		A	B	C	D	E	F	G	H	J	K	L	M	
CUP - OIL	B6A 10141-A	A												
REPAIR KIT - DISTRIBUTOR	C0TZ 12000-A (DK-10)	A	B	C	D	E	F	G	H	J		L	M	
Consists of														
(1) B8Q 12171-A Points			(1) B7A 12200-A Rotor			(1) C9AZ 12300-A Condenser								
PLUG - DISTRIBUTOR DIAPHRAGM	C7AZ 12A022-A						F	G						
	C8AZ 12A022-A (DZ-404)		B	C						J	K			
SLEEVE - DISTRIBUTOR SHAFT PLATE	C2AZ 12A075-A		B	C	D		F	G	H	J	K	L	M	
HOUSING - DISTRIBUTOR TERMINAL (CAP)	B7A 12106-A (DH-6)	A	B	C	D	E	F	G	H	J	K	L	M	
BUSHING - DISTRIBUTOR HOUSING	12120													
Upper	B8QH 12120-A (MC-148)	A	B	C	D	E	F	G	H	J		L	M	
	C5AZ 12120-A (MC-175)										K			
Lower	C5AZ 12132-A (MC-176)				D	E	F	G	H			L		
GASKET - DISTRIBUTOR BASE	B9TF 12143-A (DZ-3)	A	B		D		F			J	K			
	B8A 12143-A (DZ-1)			C		E		G	H			L	M	
CLAMP - TERMINAL HOUSING HOLD DOWN	B7A 12144-A (DZ-339)	2												
	7RA 12144 (DZ-337)		2	2	2	2	2	2	2	2	2	2	2	
RIVET - TERMINAL HOUSING HOLD DOWN	B 12145	2	2	2	2	2	2	2	2	2	2	2	2	
PLATE ASSY. - DISTRIBUTOR BREAKER	12151													
Lower	B9AF 12151-A (DB-7)	A	B	C	D	E	F	G	H	J	K	L	M	
Upper	B9AF 12151-B (DB-8)	A	B	C	D	E	F	G	H	J	K	L	M	
Washer-"C" type	351825-S(XX9)	A	B	C	D	E	F	G	H	J				
Washer-spring-3/16"	372395-S(XX368)	A	B	C	D	E	F	G	H	J				
Washer-flat-3/16"	372396-S(XX78)	A	B	C	D	E	F	G	H	J				
POINT SET - DISTRIBUTOR ARM and BREAKER - PIVOT	B8Q 12171-A (DP-12)	A	B	C	D	E	F	G	H	J		L	M	
- Pivotless	C5AZ 12171-A (DP-77)		B	C		E	F	G	H	J	K			
Nut-No. 6-32	34051-S(M154)	A	B	C	D	E	F	G	H	J	K	L	M	
Washer-No. 6	34801-S(X58)	A	B	C	D	E	F	G	H	J	K	L	M	
Screw-No. 8-32 x 5/16"	355067-S(BB53)	2	2	2	2	2	2	2	2	2	2	2	2	
SHAFT - DISTRIBUTOR	B8A 12175-A (DF-6)	A												
Includes C8AZ 12179-A washer	C5AZ 12175-C (DF-364)			C	D	E	F	G	H	J		L	M	
C2AZ 12A075-A sleeve not used with this shaft - "Before 12/28/70"	D2AZ 12175-D (DF-364-C)			C	D	E	F	G	H	J		L	M	
Includes weights	D2AZ 12175-H (DF-374-C)		B											
Includes weights	D2AZ 12175-A (DF-372-C)										K			
Includes weights	D2AZ 12175-B (DF-372-B)										K			

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4A THRU 4M												
		A	B	C	D	E	F	G	H	J	K	L	M	
RETAINER - DISTRIBUTOR CAM	B7A 12177-A	A	B	C	D	E	F	G	H	J	K	L	M	
WASHER - DRIVEN GEAR	B7A 12179-A	A												
WASHER - DISTRIBUTOR SHAFT THRUST - UPPER	C8AZ 12179-A (DZ-413)		B	C	D	E	F	G	H	J	K	L	M	
WEIGHT - DISTRIBUTOR ADVANCE	B7A 12188-A (DZ-11)	2												
	C5AZ 12188-A (DZ-382)		2	2	2	2	2	2	2	2	2	2	2	
SPRING - Refer to Distributor Identification Charts for Calibration Codes	12191-2													
COLLAR - DISTRIBUTOR SHAFT	7HA 12195	A	B	C	D	E	F	G	H	J		L	M	
	C8VY 12195-A										K			
ROTOR ASSY. - DISTRIBUTOR	B7A 12200-A (DR-5)	A	B	C	D	E	F	G	H	J	K	L	M	
STOP - Refer to Distributor Identification Charts for Calibration Codes	12202													
CAM - Refer to Distributor Identification Charts for Calibration Codes	12210													
WIRE ASSY. - PRIMARY TERMINAL	C2OZ 12216-A (DW-17)	A												
	C1VF 12216-A (DW-12)				D	E			H			L	M	
	C7VY 12216-A (DW-34)		B	C			F	G		J	K			
WIRE ASSY. - DISTRIBUTOR BREAKER GRCUND	D2AZ 12264-A (ML-291)	A	B	C	D	E	F	G	H	J	K	L	M	
CLAMP - DISTRIBUTOR TO CYLINDER HEAD	C3AZ 12270-A (DZ-410)	A	B		D	E	F		H	J	K	L	M	
	B8A 12270-A (DZ-409)			C				G				L	M	
CONDENSER ASSY. - DISTRIBUTOR	C9AZ 12300-A (DC-13A)	A	B	C	D	E	F	G	H	J	K	L	M	
Screw-No. 8-32 x 5/16"	355067-S(BB53)	2	2	2	2	2	2	2	2	2				
GASKET - DIAPHRAGM VACUUM CONNECTOR	★B7A 12320-A	A	B	C	D	E	F	G	H	J	K	L	M	
DIAPHRAGM ASSY. - Refer to Distributor Identification Charts for Calibration Codes	12370													
Screw-No. 8-32 x 1 3/16"	354988-S(BB635)	A	B	C	D	E	F	G	H	J				
"C" Retainer (diaphragm rod)	351826-S(XX2)	A	B	C	D	E	F	G	H	J				
GEAR - DISTRIBUTOR DRIVEN	C2OF 12390-A	A	B		D	E	F			J				
	FAB 12390-C (DZ-367)			C				G	H			L	M	
	C9ZZ 12390-A (DZ-412)										K			
Rivet-1/8" x 13/16" gear to shaft	61489-S(S10)	A	B	C	D	E	F	G	H	J				

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

FORD CAR PARTS

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4N THRU 4Z															
		N	P	Q	R	S	T	U	V	W	X	Y	Z				
CUP - OIL	B6A 10141-A	N															
REPAIR KIT - DISTRIBUTOR	C0TZ 12000-A	N		Q		S		U	V	W		Y					
Consists of	(DK-10)																
1-B8Q 12171-A Points	1-B7A 12200-A Rotor																
	1-C9AZ 12300-A Condenser																
PLUG - DISTRIBUTOR DIAPHRAGM	C8AZ 12A022-A (DZ-404)			Q		S	T			W	X		Z				
	C7AZ 12A022-A								V			Y					
FELT - DISTRIBUTOR CAM LUBRICATOR	C3TZ 12A055-A		P		R												
BUTTON-DISTRIBUTOR BREAKER PLATE-SUPPORT	•D2AZ 12072-A							3									
SLEEVE - DISTRIBUTOR SHAFT PLATE	C2AZ 12A075-A			Q	R	S	T		V	W	X	Y	Z				
HOUSING - DISTRIBUTOR TERMINAL (CAP)	B7A 12106-A (DH-6)	N	P	Q		S	T	U	V	W	X	Y	Z				
	B7AZ 12106-A (DH-146)				R												
BUSHING - DISTRIBUTOR HOUSING UPPER	B8QH 12120-A (MC-148)	N	P	Q	R						X						
	C5AZ 12120-A (MC-175)					S	T	U	V	W		Y	Z				
BUSHING - DISTRIBUTOR HOUSING LOWER	C5AZ 12132-A (MC-176)		P		R						X						
GASKET - DISTRIBUTOR BASE	B9TF 12143-A (DZ-3)					S		U	V	W	X	Y					
	B8A 12143-A (DZ-1)	N	P	Q	R		T						Z				
CLAMP TERMINAL HOUSING HOLD DOWN	B7A 12144-A (DZ-339)	2															
	7RA 12144 (DZ-337)		2	2	2	2	2	2	2	2	2	2	2				
RIVET - TERMINAL HOUSING HOLD DOWN CLAMP	B 12145	2	2	2	2	2	2	2	2	2	2	2	2				
RETAINER - DISTRIBUTOR BREAKER PLATE	•D2AZ 12146-A							U									
PLATE ASSY. - DISTRIBUTOR BREAKER	12151																
Lower	B9AF 12151-A (DB-7)	N	P	Q		S	T					Y	Z				
Upper	B9AF 12151-B (DB-8)	N	P	Q	R	S	T		V			Y	Z				
Lower	C1VY 12151-A (DB-158)				R												
Upper-plate only	•D2AZ 12151-C							U									
Lower-plate only	•D2AZ 12151-B							U									
	C9AZ 12151-A (DB-181)									W	X						
	D2PZ 12151-A (DB-187-A)							U									
Screw-No. 8-32 x 3/8" pan hd.	50507-S8(U151)	2	2	2	2	2	2		2	2	2	2	2				
Washer "C"	351825-S(XX9)	N	P	Q	R	S	T		V	W	X	Y	Z				
Washer-3/16" spring	372395-S(XX368)	N	P	Q	R	S	T		V	W	X	Y	Z				
Washer-3/16" flat	372396-S(XX78)	N	P	Q	R	S	T		V	W	X	Y	Z				

• Reconditioners only

SECTION 120.4
ALL 8 CYL. ENGINES
DUAL ADVANCE DISTRIBUTOR

FORD CAR PARTS

See SECTION 120, PAGE 1 for
 PARTS LIST INSTRUCTIONS

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4N THRU 4Z												
		N	P	Q	R	S	T	U	V	W	X	Y	Z	
POINT SET - DISTRIBUTOR ARM and BREAKER	B8Q 12171-A (DP-12)	N		Q	R	S		U	V			Y	Z	
Pivot	C5AZ 12171-A (DP-77)		P				T							
Pivotless														
Pivot	C9AZ 12171-A (DP-5)									2	2			
Screw-No. 8-32 x 5/16" fill. hd.	31037-S(U48)	3	3	3	3	3	3	3	3	3	3	3	3	
Lockwasher-No. 8	34802-S(X59)	3	3	3	3	3	3	3	3	3	3	3	3	
Nut-No. 6-32	34051-S(M154)	N	P	Q	R	S	T	U	V	W	X	Y	Z	
Lockwasher-No. 6	34801-S(X58)	N	P	Q	R	S	T	U	V	W	X	Y	Z	
SHAFT DISTRIBUTOR	B8A 12175-A (DF-6)	N												
Includes C8AZ 12179-A washer - "Before 12/28/70"	C5AZ 12175-C (DF-364)		P	Q	R						X			
C2AZ 12A705-A sleeve not used with this shaft - "From 12/28/70"	D2AZ 12175-D (DF-364-C)	P	Q	R							X			
	D2OZ 12175-B (DF-369-B)					S	T		V	W			Z	
C2AZ 12A075-A sleeve not used with this shaft -	D2AZ 12175-A (DF-372-C)							U				Y		
Washer-5/16" thrust	379039-S(XX112H)	N	P	Q	R	S	T	U	V	W	X	Y	Z	
RETAINER - DISTRIBUTOR CAM	B7A 12177-A	N	P	Q	R	S	T	U	V	W	X	Y	Z	
WASHER - DRIVEN GEAR	B7A 12179-A	N												
WASHER - DISTRIBUTOR SHAFT THRUST - UPPER	C8AZ 12179-A (DZ-413)		P	Q	R	S	T	U	V	W	X	Y	Z	
LINK - DISTRIBUTOR BREAKER PLATE	●D2AZ 12A186-A							U						
RETAINER - DISTRIBUTOR BREAKER PLATE	●D2AZ 12A187-A							U						
WEIGHT - DISTRIBUTOR ADVANCE	B7A 12188-A (DZ-11)	2												
	C5AZ 12188-A (DZ-382)		2	2	2	2	2		2	2	2	2	2	
Ring-3/16" retaining	351825-S(XX9)	2	2	2	2	2	2		2	2	2	2	2	
SPRING - Refer to Distributor Identification Charts for Calibration Codes	12191-2													
COLLAR - DISTRIBUTOR SHAFT	7HA 12195	N	P	Q	R		T				X			
	C8VY 12195-A					S		U	V	W		Y	Z	
Rivet-1/8" x 13/16"	61489-S(S10)	N	P	Q	R	S	T	U	V	W	X	Y	Z	
ROTOR ASSY. - DISTRIBUTOR	B7A 12200-A (DR-5)	N	P	Q	R	S	T	U	V	W	X	Y	Z	
STOP - Refer to Distributor Identification Charts for Calibration Codes	12202													

● Reconditioners only

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

FORD CAR PARTS

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4N THRU 4Z												
		N	P	Q	R	S	T	U	V	W	X	Y	Z	
CAM - Refer to Distributor Identification Charts for Calibration Codes	12210													
WIRE ASSY. - PRIMARY TERMINAL	C1VF 12216-A (DW-12)	N												
	C7VY 12216-A (DW-34)			Q		S	T	U	V			Y	Z	
	C3SZ 12216-A		P		R									
	§ D4AZ 12216-A (DW-38A)									W	X			
Nut-No.6-32	34051-S(M154)	N	P	Q	R	S	T	U	V	W	X	Y	Z	
Lockwasher No. 6	34801-S(X58)	N	P	Q	R	S	T	U	V	W	X	Y	Z	
SCREW - DISTRIBUTOR POINT	D0RY 12230-A							U						
COVER - DISTRIBUTOR DUST	★C3AZ 12239-A (DZ-308)		P		R									
WIRE ASSY. -DISTRIBUTOR BREAKER GROUND	D2AZ 12264-A (ML-291)	N	P	Q	R	S	T	U	V			Y	Z	
	7RA 12264 (ML-290)									W	X			
CLAMP - DISTRIBUTOR TO CYLINDER HEAD	B8A 12270-A (DZ-409)	N	P	Q					V					
	C3AZ 12270-A (DZ-410)					S	T	U		W	X	Y	Z	
CONDENSER ASSY. -DISTRIBUTOR	C9AZ 12300-A (DC-13A)	N		Q		S	T	U	V	W	X	Y	Z	
Screw & washer No. 8-32 x 5/16"	355067-S(BB53)	N		Q		S	T	U	V	W	X	Y	Z	
GASKET - DISTRIBUTOR DIAPHRAGM VACUUM CONNECTOR	★B7A 12320-A	N		Q	R	S	T		V	W	X	Y	Z	
DIAPHRAGM ASSY. - Refer to Distributor Identification Charts for Calibration Codes	12370													
Screw-No. 8-32 x 1"	382331-S (BB635A)	2	2	2	2	2	2		2	2	2	2	2	
Washer-flat-1/4"-.009" calibration	375482-S(XX85)	AR	AR	AR	AR	AR	AR		AR	AR	AR	AR	AR	
-.021" calibration	375483-S(XX85A)	AR	AR	AR	AR	AR	AR		AR	AR	AR	AR	AR	
-.041" calibration	375484-S(XX85B)	AR	AR	AR	AR	AR	AR		AR	AR	AR	AR	AR	
-.78" calibration	354610-S(XX91)	AR	AR	AR	AR	AR	AR		AR	AR	AR	AR	AR	
Retainer "C" washer	351826-S(XX2)	AR	AR	AR	AR	AR	AR		AR	AR	AR	AR	AR	
GEAR - DISTRIBUTOR DRIVEN	FAB 12390-C (DZ-367)	N	P	Q	R									
	C4TZ 12390-A (DZ-365)					S	T			W			Z	
	C9ZZ 12390-A (DZ-412)							U	V			Y		
	C2OF 12390-A (DZ-362)										X			
Rivet-1/8" x 13/16" gear to shaft	61489-S(S10)	N	P	Q	R	S	T	U	V	W	X	Y	Z	

SECTION 120.4
ALL 8 CYL. ENGINES
DUAL ADVANCE DISTRIBUTOR

FORD CAR PARTS

See SECTION 120, PAGE 1 for
 PARTS LIST INSTRUCTIONS

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4AA THRU 4AM												
		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	
REPAIR KIT - DISTRIBUTOR	C0TZ 12000-A (DK-10)	AA		AC										
Consists of														
1-B8Q 12171-A Points	1-B7A 12200-A Rotor	1-C9AZ 12300-A Condenser												
PLUG - DISTRIBUTOR DIAPHRAGM	C7AZ 12A022-A C8AZ 12A022-A (DZ-404)	AA					AF			AJ				
			AB	AC	AD	AE		AG	AH		AK	AL	AM	
SLEEVE - DISTRIBUTOR SHAFT PLATE	C2AZ 12A075-A	AA	AB	AC	AD	AE		AG	AH		AK	AL	AM	
HOUSING - DISTRIBUTOR TERMINAL (CAP)	B7A 12106-A (DH-6)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	
BUSHING - DISTRIBUTOR HOUSING UPPER	C5AZ 12120-A (MC-175) B8QH 12120-A (MC-148)	AA			AD		AF	AG	AH	AJ	AK		AM	
			AB	AC		AE						AL		
GASKET - DISTRIBUTOR BASE	B9TF 12143-A (DZ-3) B8A 12143-A	AA	AB	AC			AF	AG		AJ	AK	AL	AM	
					AD	AE			AH					
CLAMP TERMINAL HOUSING HOLD DOWN	7RA 12144 (DZ-337)	2	2	2	2	2	2	2	2	2	2	2	2	
RIVET - TERMINAL HOUSING HOLD DOWN CLAMP	B 12145	2	2	2	2	2	2	2	2	2	2	2	2	
PLATE ASSY. - DISTRIBUTOR BREAKER	12151													
Lower	B9AF 12151-A (DB-7)	AA	AB	AC	AD		AF	AG	AH	AJ	AK	AL	AM	
Upper	B9AF 12151-B (DB-8) C9AZ 12151-A	AA	AB	AC	AD		AF	AG	AH	AJ	AK	AL	AM	
						AE								
Screw-No.8-32 x 3/8"-pan head	50507-S8(U151)	2	2	2	2	2	AF	2	2	AJ	2	2	2	
Washer-"C" type	351825-S(XX9)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	
Washer-3/16" spring	372395-S(XX368)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	
Washer-3/16" flat	372396-S(XX78)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	
POINT SET - DISTRIBUTOR ARM and BREAKER	B8Q 12171-A (DP-12) C5AZ 12171-A (DP-77) C9AZ 12171-A (DP-5)	AA		AC										
		AA	AB	AC	AD		AF	AG	AH	AJ	AK	AL	AM	
						2								
Screw-No.8-32 x 5/16"-fill.hd.	31037-S(U48)	3	3	3	3	5	AF	3	3	AJ	3	3	3	
Lockwasher-No.8	34802-S(X59)	3	3	3	3	5	AF	3	3	AJ	3	3	3	
Nut-No.6-32	34051-S(M154)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	
Lockwasher-No.6	34801-S(X58)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	
SHAFT DISTRIBUTOR	12175													
	D2OZ 12175-B (DF-369-B)	AA			AD		AF		AH	AJ	AK			
Includes weights	D2AZ 12175-H (DF-374-C)		AB											
"Before 12/28/70"	D2AZ 12175-A (DF-372-C)							AG						
Includes weights	D2AZ 12175-B (DF-372-B)							AG						
C2AZ 12A075-A sleeve not used with this shaft	D1OZ 12175-A (DF-391A)												AM	
"Before 12/28/70"	C5AZ 12175-C (DF-364)			AC		AE						AL		
C2AZ 12A075-A sleeve not used with this shaft	D2AZ 12175-D (DF-364C)			AC		AE						AL		
	"From 12/28/70"													
Washer-5/16" thrust	379039-S(XX112H)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

FORD CAR PARTS

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4AA THRU 4AM											
		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
RETAINER - DISTRIBUTOR CAM	B7A 12177-A	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
WASHER - DISTRIBUTOR SHAFT THRUST - UPPER	C8AZ 12179-A (DZ-413)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
WEIGHT - DISTRIBUTOR ADVANCE	C5AZ 12188-A (DZ-382)	2	2	2	2	2	2	2	2	2	2	2	2
Ring-3/16" retaining	351825-S(XX9)	2	2	2	2	2	2	2	2	2	2	2	2
SPRING - Refer to Distributor Identification Charts for Calibration Codes	12191-2												
COLLAR - DISTRIBUTOR SHAFT	C8VY 12195-A	AA					AF	AG	AH	AJ	AK		AM
	7HA 12195-A		AB	AC	AD	AE						AL	
Rivet-1/8" x 13/16"	61489-S(S10)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
ROTOR ASSY. -DISTRIBUTOR	B7A 12200-A (DR-5)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
STOP - Refer to Distributor Identification Charts for Calibration Codes	12202												
CAM - Refer to Distributor Identification Charts for Calibration Codes	12210												
	C7VY 12216-A (DW-34)	AA	AB	AC	AD		AF	AG	AH	AJ	AK	AL	AM
	D4AZ 12216-A (DW-38A)					AE							
Nut-No.6-32	34051-S(M154)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
Lockwasher-No.6	34801-S(X58)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
WIRE ASSY. -DISTRIBUTOR BREAKER GROUND	D2AZ 12264-A (ML-291)	AA	AB	AC	AD		AF	AG	AH	AJ	AK	AL	AM
	7RA 12264 (ML-290)					AE							
CLAMP - DISTRIBUTOR TO CYLINDER HEAD	C3AZ 12270-A (DZ-410)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
Screw & washer-5/16"-18 x 7/8"	42846-S(U13)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
CONDENSER ASSY. -DISTRIBUTOR	C9AZ 12300-A (DC-13-A)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
Screw & washer-No.8-32 x 5/16"	355067-S7(BB53)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
GASKET - DISTRIBUTOR DIAPHRAGM VACUUM CONNECTOR	*B7A 12320-A	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
DIAPHRAGM ASSY. - Refer to Distributor Identification Charts for Calibration Codes	12370												
Screw-No.8-32 x 1"	382331-S(BB635A)	2	2	2	2	2	2	2	2	2	2	2	2
Washer-flat-1/4"-.009 (calibration)	375482-S(XX85)	AR	AR	AR	AR	AR	AF	AR	AR	AJ	AR	AR	AR
-.021"	375483-S(XX85A)	AR	AR	AR	AR	AR	AF	AR	AR	AJ	AR	AR	AR
-.041"	375484-S(XX85B)	AR	AR	AR	AR	AR	AF	AR	AR	AJ	AR	AR	AR
-.78"	354610-S(XX91)	AR	AR	AR	AR	AR	AF	AR	AR	AJ	AR	AR	AR
Retainer-"C" washer	351826-S(XX2)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM
GEAR - DISTRIBUTOR DRIVEN	C4TZ 12390-A	AA			AD		AF		AH	AJ	AK		AM
	C2OF 12390-A (DZ-362)		AB	AC								AL	
	FAB 12390-C (DZ-367)					AE							
	C9ZZ 12390-A (DZ-412)							AG					
Rivet-1/8" x 13/16"	61489-S(S10)	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM

SECTION 120.4
ALL 8 CYL. ENGINES
DUAL ADVANCE DISTRIBUTOR

FORD CAR PARTS

See SECTION 120, PAGE 1 for
 PARTS LIST INSTRUCTION

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST												4AN THRU 4AZ			
		AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ				
REPAIR KIT - DISTRIBUTOR	C0TZ 12000-A (DK-10)	AN	AP	AQ			AT		AV	AW	AX	AY	AZ				
Consists of																	
1-B8Q 12171-A Points	1-B7A 12200-A Rotor					1-C9AZ 12300-A				Condenser							
PLUG - DISTRIBUTOR DIAPHRAGM	C8AZ 12A022-A (DZ-404)	AN	AP	AQ	AR	AS	AT	AU	AV	AW							
BUTTON - DISTRIBUTOR BREAKER PLATE SUPPORT	●D2AZ 12072-A											3	3	3			
SLEEVE - DISTRIBUTOR SHAFT PLATE	C2AZ 12A075-A	AN	AP	AQ		AS	AT	AU	AV	AW							
HOUSING - DISTRIBUTOR TERMINAL (CAP)	B7A 12106-A (DH-6)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ				
BUSHING - DISTRIBUTOR HOUSING UPPER	C5AZ 12120-A (MC-175)	AN	AP	AQ	AR	AS		AU	AV				AZ				
	B8QH 12120-A (MC-148)						AT			AW	AX	AY					
GASKET - DISTRIBUTOR BASE	B9TF 12143-A (DZ-3)	AN	AP	AQ	AR		AT	AU	AV	AW	AX	AY	AZ				
CLAMP TERMINAL HOUSING HOLD DOWN	7RA 12144	2	2	2	2	2	2	2	2	2	2	2	2				
RIVET - TERMINAL HOUSING HOLD DOWN CLAMP	B 12145	2	2	2	2	2	2	2	2	2	2	2	2				
RETAINER - DISTRIBUTOR BREAKER PLATE	●D2AZ 12146-A										AX	AY	AZ				
PLATE ASSY. - DISTRIBUTOR BREAKER																	
Lower	B9AF 12151-A (DB-7)	AN	AP			AS	AT			AW							
Upper	B9AF 12151-B (DB-8)	AN	AP			AS	AT			AW							
	C9AZ 12151-A (DB-181)			AQ	AR			AU	AV								
	D2PZ 12151-A (DB-187-A)										AX	AY	AZ				
Upper-plate only	●D2AZ 12151-C										AX	AY	AZ				
Lower-plate only	●D2AZ 12151-B										AX	AY	AZ				
Screw-No. 8-32 x 3/8"-pan head	50507-S8(U151)	2	2	2	2	2	2	2	2	2							
Washer-"C" type	351825-S(XX9)	AN	AP	AQ	AR	AS	AT	AU	AV	AW							
Washer-3/16" spring	372395-S(XX368)	AN	AP	AQ	AR	AS	AT	AU	AV	AW							
Washer-3/16" flat	372396-S(XX78)	AN	AP	AQ	AR	AS	AT	AU	AV	AW							

● Reconditioners only

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4AN THRU 4AZ											
		AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
POINT SET - DISTRIBUTOR ARM and BREAKER-PIVOT LESS	C5AZ 12171-A (DP-77)	AN	AP			AS	AT			AW	AX	AY	AZ
PIVOT	C9AZ 12171-A (DP-5)			2	2			2	2				
PIVOT	B8Q 12171-A (DP-12)	AN	AP			AS	AT			AW	AX	AY	AZ
Screw-No. 8-32 x 5/16"-fill. hd.	31037-S(U48)	2	2	4	2	2	2	4	4	2	2	2	2
Lockwasher-No. 8	34802-S(X59)	2	2	4	2	2	2	4	4	2	2	2	2
Nut-No. 6-32	34051-S(M154)	AN	AP	2	AR	AS	AT	2	2	AW	AX	AY	AZ
Lockwasher-No. 6	34801-S(X58)	AN	AP	2	AR	AS	AT	2	2	AW	AX	AY	AZ
SHAFT DISTRIBUTOR	D2OZ 12175-A (DF-369C)								AV				AZ
Includes weights													
C2AZ 12A075-A sleeve not used with this shaft - includes C8AZ 12179-A washer	D2OZ 12175-B (DF-369-B)		AP	AQ	AR	AS		AU					
Includes weights													
	D2AZ 12175-H (DF-374-C)						AT			AW	AX		
	D0AZ 12175-C (DF-380)	AN											
Includes weights													
	D2AZ 12175-C (DF-364-B)											AY	
Washer-5/16" thrust	379039-S(XX112H)	AN	AP	AQ		AS		AU	AV				
RETAINER - DISTRIBUTOR CAM	B7A 12177-A	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
WASHER - DISTRIBUTOR SHAFT THRUST - UPPER	C8AZ 12179-A (DZ-413)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
LINK - DISTRIBUTOR BREAKER PLATE	•D2AZ 12A186-A										AX	AY	AZ
SPRING - DISTRIBUTOR BREAKER PLATE	•D2AZ 12A187-A										AX	AY	AZ
WEIGHT - DISTRIBUTOR ADVANCE	C5AZ 12188-A (DZ-382)	2	2	2	2	2	2			2			
Ring-3/16" retaining	351825-S(XX9)	2	2	2	2	2	2			2			
SPRING - Refer to Distributor Identification Charts for Calibration Codes	12191-2												
COLLAR - DISTRIBUTOR SHAFT	C8VY 12195-A 7HA 12195-A	AN	AP	AQ	AR		AS	AT	AU	AV			AZ
Rivet-1/8" x 13/16"	61489-S(S10)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
ROTOR ASSY. - DISTRIBUTOR	B7A 12200-A (DR-5)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
STOP - Refer to Distributor Identification Charts for Calibration Codes	12202												
CAM - Refer to Distributor Identification Charts for Calibration Codes	12210												

• Reconditioners only

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 4AN THRU 4AZ											
		AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
WIRE ASSY. - PRIMARY TERMINAL	D4AZ 12216-A (DW-38A)			AQ	AR			AU	AV				
	C7VY 12216-A (DW-34)	AN	AP			AS	AT			AW	AX	AY	AZ
Nut-No. 6-32	34051-S(M154)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
Lockwasher-No. 6	34801-S(X58)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
SCREW - DISTRIBUTOR POINT	D0RY 12230-A			4	4			4	4		2	2	2
WIRE ASSY. - DISTRIBUTOR BREAKER GROUND	D2AZ 12264-A (ML-291)	AN	AP			AS	AT			AW	AX	AY	AZ
	7RA 12264 (ML-290)			AQ	AR			AU	AV				
CLAMP - DISTRIBUTOR TO CYLINDER HEAD	C3AZ 12270-A (DZ-410)	AN	AP	AQ	AR		AT	AU	AV	AW	AX	AY	AZ
Screw & washer 5/16-18 x 7/8" - attach dist. clamp to block	42846-S13(U13)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
CONDENSER ASSY. - DISTRIBUTOR	C9AZ 12300-A (DC-13A)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
Screw & washer-No. 8-32 x 5/16"	355067-S7(BB53)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
GASKET - DISTRIBUTOR DIAPHRAGM VACUUM CONNECTOR	*B7A 12320-A	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ
DIAPHRAGM ASSY. - Refer to Distributor Identification Charts for Calibration Codes	12370												
Screw-No. 8-32 x 1"	382331-S(BB635A)	2	2	2	2	2	2	2	2	2			
Washer-flat-1/4"-.009 (calibration)	375482-S(XX85)	AR	AR	AQ	AR	AS	AT	AU	AV	AW			
-.021"	375483-S(XX85A)	AR	AR	AQ	AR	AS	AT	AU	AV	AW			
-.041"	375484-S(XX85B)	AR	AR	AQ	AR	AS	AT	AU	AV	AW			
-.78"	354610-S(XX91)	AR	AR	AQ	AR	AS	AT	AU	AV	AW			
Retainer-"C" washer	351826-S(XX2)	AN	AP	AQ	AR	AS	AT	AU	AV	AW			
GEAR - DISTRIBUTOR DRIVEN	C4TZ 12390-A		AP	AQ	AR	AS		AU	AV				AZ
	C9ZZ 12390-A (DZ-412)	AN											
	C2OF 12390-A (DZ-362)						AT			AW	AX	AY	
Rivet-1/8" x 13/16"	61489-S(S10)	AN	AP	AQ	AR	AS	AT	AU	AV	AW	AX	AY	AZ

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

FORD CAR PARTS

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST												4BA	THRU	4BM
		BA	BB	BC	BD	BE	BF	BG	BH	BJ	BK	BL	BM			
REPAIR KIT - DISTRIBUTOR	C0TZ 12000-A (DK-10)	BA	BB	BC	BD	BE										
Consists of																
B8Q 12171-A Points			B7A 12200-A Rotor			C9AZ 12300-A Condenser										
BUTTON - DIST. BREAKER PLATE - SUPPORT	•D2AZ 12072-A	3	3	3		3										
HOUSING - DISTRIBUTOR TERMINAL (CAP)	B7A 12106-A (DH-6)	BA	BB	BC	BD	BE										
BUSHING - DISTRIBUTOR HOUSING UPPER	C5AZ 12120-A (MC-175)	BA	BB	BC	BD											
	B8QH 12120-A (MC-148)					BE										
GASKET - DISTRIBUTOR BASE	B9TF 12143-A	BA	BB	BC	BD	BE										
CLAMP - TERMINAL HOUSING (HOLD DOWN)	7RA 12144 (DZ-337)	2	2	2	2	2										
RIVET - TERMINAL HOUSING CLAMP	B 12145	2	2	2	2	2										
RETAINER - DISTRIBUTOR BREAKER PLATE	•D2AZ 12146-A	BA	BB	BC		BE										
PLATE ASSY. - DISTRIBUTOR BREAKER	12151															
	D2PZ 12151-A (DB-187-A)	BA	BB	BC		BE										
Upper-plate only	•D2AZ 12151-C	BA	BB	BC		BE										
Lower-plate only	•D2AZ 12151-B	BA	BB	BC		BE										
	C9AZ 12151-A (DB-181)				BD											
POINT SET - DISTRIBUTOR ARM and BREAKER	B8Q 12171-A (DP-12)	BA				BE										
Pivot	C5AZ 12171-A (DP-77)		BB	BC												
Pivotless	C9AZ 12171-A (DP-5)				2											
SHAFT - DISTRIBUTOR -includes weights	D2AZ 12175-F (DF-380-A)	BA														
Includes weights	D2OZ 12175-C (DF-391-B)		BB													
Includes weights	D2AZ 12175-C (DF-364-B)			BC	BD											
	D3OZ 12175-A (*DF-396)					BE										
RETAINER - DISTRIBUTOR CAM	B7A 12177-A	BA	BB	BC	BD	BE										
WASHER - DISTRIBUTOR SHAFT THRUST	C8AZ 12179-A (DZ-413)	BA	BB	BC	BD	BE										
LINK - DISTRIBUTOR BREAKER PLATE	•D2AZ 12A186-A	BA	BB	BC		BE										

• Reconditioners only

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

DUAL ADVANCE DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST															
		BA	BB	BC	BD	BE	BF	BG	BH	BJ	BK	BL	BM	4BA	THRU	4BM	
SPRING - DISTRIBUTOR BREAKER PLATE	• D2AZ 12A187-A	BA	BB	BC	BD	BE											
SPRING - Refer to Distributor Identification Charts for Calibration Codes	12191-2																
COLLAR - DISTRIBUTOR SHAFT	C8VY 12195-A	BA	BB														
	7HA 12195-A			BC	BD	BE											
Rivet 1/8" x 13/16"	61489-S(S10)	BA	BB														
ROTOR ASSY. - DISTRIBUTOR	B7A 12200-A (DR-5)	BA	BB	BC	BD	BE											
STOP - Refer to Distributor Identification Charts for Calibration Codes	12202																
CAM - Refer to Distributor Identification Charts for Calibration Codes	12210																
WIRE ASSY. - PRIMARY TERMINAL																	
	C7VY 12216-A (DW-34)	BA	BB	BC	BD	BE											
Nut - No. 6-32	34051-S(M154)	BA				BE											
Lockwasher No. 6	34801-S(X58)	BA				BE											
SCREW - DISTRIBUTOR POINT	D0RY 12230-A	3	3	3	3	3											
WIRE ASSY. - DISTRIBUTOR BREAKER GROUND	D2AZ 12264-A (ML-291)	BA	BB	BC	BD	BE											
CLAMP - DISTRIBUTOR TO CYLINDER HEAD	C3AZ 12270-A (DZ-410)	BA	BB	BC	BD	BE											
CONDENSER ASSY. - DISTRIBUTOR	C9AZ 12300-A (DC-13A)	BA	BB	BC	BD	BE											
SCREW DISTRIBUTOR CONDENSER	D0RY 12230-A	BA	BB	BC	BD	BE											
DIAPHRAGM ASSY. - Refer to Distributor Identification Charts for Calibration Codes	12370																
GEAR - DISTRIBUTOR DRIVEN	C9ZZ 12390-A (DZ-412)	BA															
	C4TZ 12390-A		BE														
	FAB 12390-C (DZ-367)			BC													
	C2OF 12390-A (DZ-362)				BD	BE											
Rivet 1/8" x 13/16"	61489-S(S10)	BA	BB	BC	BD	BE											

• Reconditioners only

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).

FORD CAR PARTS

SECTION 120.5 1
4 CYL. 98, 122 DISTRIBUTOR

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 5A THRU 5M												
		A	B	C	D	E	F	G	H	J	K	L	M	
CONTACT - CARBON	D1FZ 12011-A		B	C										
PLUG - DISTRIBUTOR DIAPHRAGM	D0RY 12A022-A (DZE-423)	A			D									
BUTTON - DISTRIBUTOR BREAKER PLATE SUPPORT	B9AZ 12072-A					3								
SLEEVE - DISTRIBUTOR SHAFT PLATE	C2AZ 12A075-A D1RY 12A075-A	A			D									
SPRING - PRIMARY GROUND UPPER PLATE TO COVER PLATE	D0RY 12A092-A				D	E								
HOUSING - DISTRIBUTOR TERMINAL (CAP)	D0RY 12106-A (DHE-156) D1FZ 12106-A (DH-157)	A			D	E								
WICK DISTRIBUTOR SHAFT	D0RY 12133-A				D	E								
SEAL - DISTRIBUTOR BASE	D2FZ 12143-A (DZ-443)	A	B	C										
CLAMP - TERMINAL HOUSING HOLD DOWN	7RA 12144 (DZ-337) D1FZ 12144-A (DZ-432) D1RY 12144-A	2												
			2	2										
					2	2								
HOLDER - DISTRIBUTOR HOUSING CLAMP	D1FZ 12144-B (DZ-431)		2	2										
RIVET - TERMINAL HOUSING HOLD DOWN CLAMP	B 12145 D0RY 12145-A	2												
					2									
PLATE - DISTRIBUTOR BREAKER	12151-A													
Upper	D0RY 12151-A (DBE-182)	A			D	E								
Lower	D0RY 12151-C (DBE-184)	A												
Lower	D2FZ 12151-A				D	E								
BREAKER ASSY. - incl. distributor points	D1FZ 12151-A (DBE-185)		B	C										
POINT SET - DISTRIBUTOR ARM & BREAKER - PIVOTLESS	C5AZ 12171-A (DP-77) D1FZ 12171-A (DP-124)	A			D	E								
			B	C										
Screw-No.8-32 x 5/16"	31037-S(U48)	3												
Washer-No.8	34802-S(X59)	3												
RETAINER - DISTRIBUTOR CAM	D0RY 12177-A (DZE-417) D1FZ 12177-A (DZ-435)	A			D	E								
			B	C										

DESCRIPTION AND RESTRICTIONS	PART NUMBER	DISTRIBUTOR PARTS LIST 5A THRU 5M												
		A	B	C	D	E	F	G	H	J	K	L	M	
WASHER - DISTRIBUTOR GEAR THRUST	12179													
Upper	D0RY 12179-A (DZE-421)	A			D	E								
Lower	D0RY 12179-B				D	E								
Upper	D0RY 12179-C				D	E								
	B4A 12179-A				D	E								
WASHER - DISTRIBUTOR CAM RETAINER	D1FZ 12179-A		B	C										
RETAINER - DIAPHRAGM TO DISTRIBUTOR PLATE	D1FZ 12179-B (DZ-433)		B	C										
WEIGHT - DISTRIBUTOR ADVANCE	D0RY 12188-A (DZE-420)	2												
	D1FZ 12188-A (DZ-430)		2	2										
SPRING - Refer to Distributor Identification Charts for calibration codes	12191-2													
ROTOR ASSY. - DISTRIBUTOR	D0RY 12200-B (DRE-91)	A			D	E								
	D1FZ 12200-A (DR-92)		B	C										
STOP - Refer to Distributor Identification Charts for calibration codes	12202													
CAM - Refer to Distributor Identification Charts for calibration codes	12210													
WIRE ASSY. - PRIMARY TERMINAL	D0RY 12216-A (DWE-40)	A												
	D2FZ 12216-A (DWE-43)				D	E								
SCREW - ATTACH POINTS TO PLATE	D1FZ 12230-A (DZ-429)		B	C										
Screw-attach diaphragm to housing	D1FZ 12230-B (DZ-428)		2	2										
Screw-attach distributor cap to distributor housing	D1FZ 12230-C (DZ-427)		2	2										
	D0RY 12230-A (DZE-426)				2									
WIRE ASSY. - DISTRIBUTOR BREAKER GROUND	D2AZ 12264-A (ML-291)	A												
CLAMP - DISTRIBUTOR RETAINING - "Before 2/1/72"	D1FZ 12270-A (DZ-437)		B	C										
"From 2/1/72"	C3AZ 12270-A (DZ-410)		B	C										
Screw & washer-M8 x 25mm	E602550-S82		B	C										
ARM ASSY. - DISTRIBUTOR TIMING	D0RY 12273-A	A			D	E								
CONDENSER - DISTRIBUTOR	D0RY 12300-A (DCE-238)	A			D	E								
	D1FZ 12300-A (DC-88)		B	C										
Screw-No.8-32 x 5/16"	31037-S(U48)	3												
Washer-No.8	34802-S(X59)	3												
GASKET - DISTRIBUTOR DIAPHRAGM VACUUM CONTROL	★ B7A 12320-A	A			D									
DIAPHRAGM ASSEMBLY - Refer to Distributor Identification Charts for calibration codes	12370													
Screw-No.8-32 x 3/8"	50803-S(U150B)	3												
GEAR - DISTRIBUTOR	D0RY 12390-A (DZE-425)	A												
	D1FZ 12390-A (DZ-439)		B											
	D2FZ 12390-A (DZ-444)				D	E								
Rivet-1/8" x 13/16"	61489-S(S10)	A			D	E								

NOTICE: When the parts list suffix is shown in the quantity required column, the quantity is one (1).