

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
A		C - cont'd.	
Actuator (seat belt warning & ignition interlock)	14A554	Clip (fuse panel wiring)	14A173
Actuator assy. (door lock control switch)	14022	Clip (rear lamp ground)	14463
		Clip (window regulator housing retainer)	14570
		Clip (window regulator switch retaining)	14559
		Clip (wiring)	14199
B			
Bezel (seat regulator control switch)	14B690, 14A706	Connector (wire)	14488
		Connector (wiring)	14487
		Connector & sleeve assy. (wiring terminal)	14487
		Connector kit (trailer wiring)	14A347
Block assy. (junction)	14448		
		Contact (console glove compt. lamp)	14A324
Bolt (fuse junction panel)	14A187	Control assy. (door lock vacuum)	14028
Boot (wiring connector sleeve)	14490		
		Cover (ballast resistor mounting plate transistorized ignition)	14A276
Bracket (circuit breaker mounting)	14A066	Cover (battery insulator)	14277
Bracket (instrument panel wiring)	14536	Cover (fuse panel)	14A003
Bracket (rear window regulator control switch mounting)	14A125	Cover (wiring shield)	14A390
Bracket (relay mounting)	14A301		
Bracket (seat regulator control mounting)	14B691, 14A705		
Bracket (seat regulator terminal mounting)	14652	F	
Bracket (wiring connector)	14A206	Fuse holder	14417
Bracket (wiring shield mounting)	14A217	Fuse link (wire)	14526
Bracket assy. (relay mounting)	14A323	Fuse assy. (cigar lighter)	14429
Bracket assy. (window regulator wiring)	14A352		
Bracket assy. (wiring)	14A004		
Breaker assy. (electrical circuit)	14526	G	
Breaker assy. (electrical circuit glass tube)	14526	Gasket (top control circuit breaker mounting)	14A222
Breaker assy. (fusible link wire type fuse)	14526	Gasket (window regulator switch housing)	14A230
		Grommet (wiring)	14603
Bus bar (top control relay)	15A687		
Bus bar (window regulator switch)	14513		
Bus bar assy. (accessory feed)	14A033		
Bushing (terminal)	14603	H	
Button assy. (window regulator control switch)	14530	Hose assy. (oil pressure sending)	14322
		Hose & wiring (door latch vacuum control front door)	14A412
Buzzer kit (exterior lamp warning)	14931	Housing (seat regulator control switch)	14B693
Buzzer kit (exterior warning)	14931	Housing (window regulator switch)	14527-8
		Housing assy. (window regulator switch)	14A122
C			
Cable (battery booster)	14300	I	
Cable (relay to starter motor)	14431	Insert (window regulator multiple switch)	14A307
Cable assy. (battery)	14300-1		
Cable assy. (dash to engine ground)	14303	Insulator (non metallic wiring conduit)	14A240
Cable kit (battery booster)	14300	Insulator (window regulator control switch)	14A016
Case (window regulator switch)	14A317		

INDEX

PART NAME	GROUP NUMBER	PART NAME	GROUP NUMBER
J		S	
Junction block assy. (accessory terminal)	14A725	Seal (tailgate window regulator switch)	14A353
		Shell (wire connector)	14A309
		Shield (eng. compt. wiring harness)	14A088
K		Shield (window regulator control)	14531
KIT - refer to appropriate noun name		Shield (wiring)	14A099, 14A177
For example			
Buzzer kit (exterior lamp warning)	14931	Sleeve (wire insulating)	14455
		Sleeve (wiring connector)	14489
Knob (seat regulator control switch)	14711		
		Socket assy. (instrument cluster)	14A522
L		Socket & wiring assy. (temperature & oil warning lamps)	14522
Lamp & wiring assy. (glove compt.)	14412	Solenoid assy. (seat regulator control)	14A700, 14A720
M		Spacer (bullet type terminal)	14A434
Motor assy. (electric seat regulator)	14547	Spacer (rear window regulator control switch)	14A123
Motor assy. (window regulator)	14553	Spacer (wire connector)	14A468
N		Spring (back window switch control)	14A456
Nut (rear window regulator control switch)	14A124	Support (fuse junction panel upper)	14A148
Nut (seat regulator control switch bezel)	14695		
		Switch (seat regulator control)	14A701
P		Switch assy. (door lock)	14028
Pad (window regulator safety relay)	14A403	Switch assy. (door open warning lamp)	14018
Panel (fuse junction)	14A068	Switch assy. (seat regulator tilt control)	14B696
Panel (relay)	14A481	Switch assy. (top control or tailgate)	14529, 15668
Pin (seat regulator control knob pivot)	14B694	Switch assy. (window regulator control)	14529, 14540, 14632
Plate (ballast resistor mounting)	14A274	Switch & bracket assy. (tailgate window limit)	14A011
Plate (seat regulator switch mounting)	14686	Switch & housing assy. (window regulator control)	14046
Plate (window regulator switch)	14523-4	Switch & wire assy. (glove compt. lamp)	14413
Plate (window regulator switch cover)	14A020, 14A021	Switch & wire assy. (seat belt retractor sensor)	14A501
Plate assy. (ballast resistor mounting transistorized ignition)	14A274	Switch & wiring assy. (window regulator)	14632-3
		Switch & wiring assy. (window regulator control)	14086-7, 14A265-6
R		T	
Relay (automatic seat back latch)	14512	Terminal (battery cable positive)	14450
Relay assy. (seat regulator control)	14546, 14A707	Terminal (bullet type)	14461
		Terminal (electric wiring solderless crimp-on type)	14294
Relay assy. (window & seat regulator control)	14512	Terminal (high tension wire)	14466
Relay assy. (window regulator safety)	14677	Terminal (spark plug)	14453
Retainer (power window switch)	14489	Terminal (wire flag eyelet)	14464
Retainer (wiring harness)	14A163	Terminal (wire flag type)	14468
Retainer assy. (cowl wiring grommet through dash)	14608	Terminal (wire snap-on)	14474
Retainer assy. (wiring harness)	14A282	Tube assy. (fuel pump to carb.)	14588, 9369

INDEX

[illegible]

SECTION 140

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A003 COVER - FUSE PANEL				
67/68	A	Plastic	1	C7SZ 14A003-A
71/	U		1	
69/71	S	Brake skid control	1	D0SZ 14A003-A
72	S	Brake skid control	1	D0VY 14A003-A
14A004 BRACKET ASSY. - WIRING				
69/71	A	Located in front and rear doors with power windows	AR	C9AZ 14A004-A
69/71	A	Screw (attach bracket to inside of door)- No. 8-32 x 1/2" hex. head	4	57075-S2(B330A)
72	A (53, 57)	R.H.-located in front door w/vacuum door locks L.H.	1	D2AZ 14A004-A
72	A		1	D2AZ 14A004-C
		Located in front and rear door with power door locks and windows	AR	D2AZ 14A004-E
14A005 WIRING ASSY. - BODY MAIN				

WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE FOR 1965 and SUBSEQUENT MODELS

The purpose of this guide is to facilitate the identification of the Service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C5SB 14A005-A	★C5SZ 14A005-BJ	C6SB 14A005-AH	★C6SZ 14A005-E
C5SB 14A005-C	★C5SZ 14A005-BL		
C5SB 14A005-E	★C5SZ 14A005-E	C7AB 14A005-A	★C7AZ 14A005-A
C5SB 14A005-G	★C5SZ 14A005-G	C7AB 14A005-B	C7AZ 14A005-B
C5SB 14A005-J	★C5SZ 14A005-B	C7AB 14A005-F	C7AZ 14A005-F
C5SB 14A005-K	★C5SZ 14A005-D	C7AB 14A005-H	C7AZ 14A005-H
C5SB 14A005-L	★C5SZ 14A005-F		
C5SB 14A005-AJ	★C5SZ 14A005-BN	C7SB 14A005-B	★C7SZ 14A005-E
C5SB 14A005-AK	★C5SZ 14A005-BR	C7SB 14A005-C	★C7SZ 14A005-E
C5SB 14A005-AL	★C5SZ 14A005-BS	C7SB 14A005-D	★C7SZ 14A005-E
C5SB 14A005-AM	★C5SZ 14A005-BT	ED-C7SB 14A005-E	★C7SZ 14A005-E
C5SB 14A005-BE	★C5SZ 14A005-BJ	C7SB 14A005-E	C7SZ 14A005-H
C5SB 14A005-BF	★C5SZ 14A005-BK	C7SB 14A005-G	C7SZ 14A005-H
C5SB 14A005-BG	★C5SZ 14A005-BL		
C5SB 14A005-BH	★C5SZ 14A005-BM	C8AB 14A005-A	C8AZ 14A005-C
C5SB 14A005-BJ	★C5SZ 14A005-BJ	C8AB 14A005-B	C8AZ 14A005-D
C5SB 14A005-BK	★C5SZ 14A005-BK	C8AB 14A005-C	C8AZ 14A005-C
C5SB 14A005-BL	★C5SZ 14A005-BL	C8AB 14A005-D	C8AZ 14A005-D
C5SB 14A005-BM	★C5SZ 14A005-BM	C8AB 14A005-E	C8AZ 14A005-C
C5SB 14A005-BN	★C5SZ 14A005-BN	C8AB 14A005-F	C8AZ 14A005-D
C5SB 14A005-BR	★C5SZ 14A005-BR	C8AB 14A005-G	C8AZ 14A005-D
C5SB 14A005-BS	★C5SZ 14A005-BS	C8AB 14A005-H	★C8AZ 14A005-H
C5SB 14A005-BT	★C5SZ 14A005-BT		
		C8SB 14A005-A	★C8SZ 14A005-A
C6SB 14A005-A	★C6SZ 14A005-G	C8SB 14A005-B	★C8SZ 14A005-B
C6SB 14A005-B	★C6SZ 14A005-H	C8SB 14A005-C	★C8SZ 14A005-A
C6SB 14A005-C	★C6SZ 14A005-C	C8SB 14A005-D	★C8SZ 14A005-B
C6SB 14A005-D	★C6SZ 14A005-D	C8SB 14A005-E	★C8SZ 14A005-A
C6SB 14A005-S	★C6SZ 14A005-G	C8SB 14A005-F	★C8SZ 14A005-B
C6SB 14A005-T	★C6SZ 14A005-H	C8SB 14A005-G	★C8SZ 14A005-A
C6SB 14A005-U	★C6SZ 14A005-C	C8SB 14A005-H	★C8SZ 14A005-B
C6SB 14A005-V	★C6SZ 14A005-D	C8SB 14A005-J	★C8SZ 14A005-A
C6SB 14A005-AA	★C6SZ 14A005-E	C8SB 14A005-K	★C8SZ 14A005-B
C6SB 14A005-AB	★C6SZ 14A005-F	C8SB 14A005-N	★C8SZ 14A005-N
C6SB 14A005-AC	★C6SZ 14A005-G	C8SB 14A005-S	★C8SZ 14A005-N
C6SB 14A005-AD	★C6SZ 14A005-H	C8SB 14A005-U	★C8SZ 14A005-N

14A005 WIRING ASSY. - BODY MAIN -continued - See Identification Chart at beginning of Group

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C8SB 14A005-V	★C6SZ 14A005-AA	D2SB 14A005-AD	D2SZ 14A005-F
C8SB 14A005-Y	★C8SZ 14A005-N	D2SB 14A005-AF	D2SZ 14A005-F
C8SB 14A005-AA	★C8SZ 14A005-AA	D2SB 14A005-AG	D2SZ 14A005-F
		D2SB 14A005-AH	D2SZ 14A005-F
C9SB 14A005-E	C9SZ 14A005-S	D2SB 14A005-BD	D2SZ 14A005-G
C9SB 14A005-F	C9SZ 14A005-T	D2SB 14A005-BF	D2SZ 14A005-G
C9SB 14A005-J	C9SZ 14A005-J	D2SB 14A005-BG	D2SZ 14A005-G
C9SB 14A005-K	C9SZ 14A005-T	D2SB 14A005-CD	D2SZ 14A005-H
C9SB 14A005-L	C9SZ 14A005-L	D2SB 14A005-CF	D2SZ 14A005-H
C9SB 14A005-N	C9SZ 14A005-S	D2SB 14A005-CG	D2SZ 14A005-H
C9SB 14A005-R	C9SZ 14A005-T	D2SB 14A005-DD	D2SZ 14A005-J
C9SB 14A005-S	C9SZ 14A005-S	D2SB 14A005-DE	D2SZ 14A005-J
C9SB 14A005-T	C9SZ 14A005-T	D2SB 14A005-DG	D2SZ 14A005-J
C9SB 14A005-U	C9SZ 14A005-J	D2SB 14A005-DH	D2SZ 14A005-J
C9SB 14A005-V	C9SZ 14A005-L	ED-D2SB 14A005-AF	D2SZ 14A005-F
C9SB 14A005-Y	C9SZ 14A005-J	ED-D2SB 14A005-BF	D2SZ 14A005-B
		ED-D2SB 14A005-CF	D2SZ 14A005-H
D2LB 14A005-AC	D2LY 14A005-B	ED-D2SB 14A005-DG	D2SZ 14A005-J

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
- A -				
67	A-without A/C	"Before 1/3/67"	1	★C7AZ 14A005-A
67	A-without A/C	"From 1/3/67"	1	C7AZ 14A005-H
67	A-with A/C	"Before 1/3/67"	1	C7AZ 14A005-B
67	A-with A/C	"From 1/3/67"	1	C7AZ 14A005-F
68	A-with A/C		1	C8AZ 14A005-D
68	A(8 cyl.)-w/o A/C		1	C8AZ 14A005-C
68	A(6 cyl.)-w/o A/C	"Before 5/15/68"		
68	A(6 cyl.)-w/o A/C	"From 5/15/68"	1	★C8AZ 14A005-H
- S -				
67	S	"Before 2/15/67"	1	★C7SZ 14A005-E
67	S	"From 2/15/67"	1	C7SZ 14A005-H
68	S-without automatic temperature control-	"Before 3/1/68"	1	★C8SZ 14A005-A
68	S-without automatic temperature control-	"From 3/1/68"	1	★C8SZ 14A005-N
68	S-with automatic temperature control-	"Before 3/1/68"	1	★C8SZ 14A005-B
68	S-with automatic temperature control-	"From 3/1/68"	1	★C8SZ 14A005-AA
69	S-without automatic temperature control-	"Before 12/2/68"	1	C9SZ 14A005-S
69	S-without automatic temperature control-	"From 12/2/68"	1	C9SZ 14A005-J
69	S-with automatic temperature control-	"Before 12/2/68"	1	C9SZ 14A005-T
69	S-with automatic temperature control-	"From 12/2/68"	1	C9SZ 14A005-L
72	S-w/o power seats		1	D2SZ 14A005-F
72	S-w/power seats w/auto.seat back latch	Driver and passenger power seat	1	D2LY 14A005-B
72	S-w/power seats w/o auto.seat back latch	Driver and passenger power seats	1	D2SZ 14A005-H
72	S-w/power seats w/auto.seat back latch	Drivers power seat	1	D2SZ 14A005-J
72	S-w/power seats w/o auto.seat back latch	Drivers power seat	1	D2SZ 14A005-G
65	S	Clip-attach wiring to cowl panel	AR	★377719-S
		Screw-No.14-14 x 1/2"	AR	31497-S(U254)
		Clip-attach wiring to cowl panel	AR	★376287-S
		Clip	AR	376219-S(GG151)
		Screw-No.10-12 x 1/2"	AR	42127-S(U248C)
69	S	Clip (wiring-attach main body wiring to brake pedal support)	1	382931-S(GG338)

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A011 SWITCH and BRACKET ASSY. - TAILGATE WINDOW LIMIT				
65/67	A(71)	"Before 8/15/66"	1	C5AZ 14A011-A
66/67	B(71), X(71)	"Before 8/15/66"	1	
67/	A(71)	"From 8/15/66"	1	D2AZ 14A011-A
67/	B(71), X(71)	"From 8/15/66"	1	
65	B(71)		1	C3OZ 14A011-A
65	X(59, 71, 78)		1	C0DF 14A011-C
		Screw (switch & bracket to rear corner upper inner pillar)-No. 8-15 x 1/2"	2	*42126-S8
		Lockwasher-No. 8	2	34938-S8(X85)
14018 SWITCH ASSY. - DOOR OPEN WARNING LAMP - Also refer to Group 13713				
65	A(54, 57, 71)	R. H. -door ajar	2	C5AZ 14018-G
65	A(54 Taxi)		2	(SW-696)
65	A(54, 57, 71)	L. H.	2	
65	A(62, 63, 76)	R. H.	1	
65	S	R. H.	1	
66/68	A-with safety package	R. H. -front and rear door	1or2	
66/71	S-with safety package	R. H. -front door	1	
65	A(62, 63, 76)	L. H. -door ajar	1	C5AZ 14018-D
65	A(54 Taxi)		2	
65	S	L. H.	1	
66/67	A-with safety package	"Before 1/16/67" L. H. -front and rear door	1or2	
66/67	S-with safety package	"Before 1/16/67" L. H. -front door	1	
67/68	A-with safety package	"From 1/16/67" L. H. -front and rear door ajar	1or2	C5AZ 14018-H
67/68	S-with safety package -	L. H. -front door	1	(SW-697)
	"From 1/16/67 to 11/6/67"			
69/71	S	L. H.	1	
68	S-with safety package	"From 11/6/67" L. H. -front door ajar	1	C8VY 14018-B
				(SW-808)
67/70	B, F, X-with safety package	R. H.	1	C7ZZ 14018-E
				(SW-698)
		L. H.	1	C7ZZ 14018-F
				(SW-699)
69/70	A, (Taxi, P/C), F	R. H. -front and rear door ajar	1	C9WY 14018-A
				(SW-818)
		L. H. -front and rear door ajar	1	C9WY 14018-B
				(SW-819)
71/	A (Taxi)	R.H. & L.H. -door open warning - r/b D4LY 14018-A (2/75)	4	*D1AZ 14018-A
72	B(Taxi)	R. H. & L. H. - rear door	2	(SW-986)
72	S	R.H. & L.H.	2	
72	S	Used with remote control luggage compartment	1	D2LY 14018-A
				(SW-1085)
68	S	R. H. & L. H. rear door-Refer to Group 13713		
65/69	A, S	Screw-No. 10-24 x 1/2"-attach switch to door lock	2	41308-S(U217)
67/70	B, F, X	Screw-No. 8-32 x 5/16"-attach switch to door lock	2	355067-S(BB53)
70	A, S	Screw-No. 10-24 x 5/8"-attach switch to door lock	AR	357182-S(BB639)
14A020-1 PLATE - WINDOW REGULATOR SWITCH COVER				
68/69	S(57)-without power windows "Before 12/15/68"	Single #C8SB 14A020-B	3	C8SZ 14A020-A
68/69	S(65)-without power windows	Single	1	
70/71	S(57)	Rear doors	2	
69	S(57)-without power windows "From 12/15/68"	Single-R. H. front door #C9SB 14A020-A	1	C9SZ 14A020-A
68/71	S-without power windows	Multiple #C8SB 14A021-B	1	C8SZ 14A021-A
72	S-without power windows or power seats	R. H. -front door	1	D2SZ 14A020-A
72	S-w/o power windows or power seats	L. H. -front door	1	D2SZ 14A021-B
70/71	S(57)-without power windows or seats	R. H. -front door arm rest	1	D0SZ 14A020-A
70/71	S(65)-without power windows or seats	R. H. -front door arm rest	1	D0SZ 14A020-B

* Identification marking

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

FORD CAR PARTS

SECTION 140

SECTION 140		DESCRIPTION	QTY.	PART NUMBER
YEAR	MODEL			
14022 ACTUATOR ASSY. - DOOR LOCK CONTROL SWITCH - Also refer to Group 13A786				
65/66	A-with safety package	Strap (actuator wiring to reinf. quarter panel door or rail roof side inner rear)	1	C5AZ 14022-C
65/66	A-with safety package		AR	376914-S(YY2)
14A027 WIRING ASSY. - WINDOW REGULATOR REAR SWITCH FEED				
69/70	A(71)	#C9AB 14A304-A, B, D0AB 14A304-A	1	C9AZ 14A027-A
69/70	A-with power windows	"Before 12/10/69" R. H. to L. H. rear door #C9AB 14A027-B	1	C9AZ 14A027-B
70	A-with power windows	"From 12/10/69" R. H. to L. H. rear door #ED D0AB 14A027-B, C, D0AB 14A027-C	1	D0AZ 14A027-B
71/	A(53, 54, 57, 71)	R.H. to L.H. rear door #D1AB 14A027-AB	1	D1AZ 14A027-A
71/	A(71)	Power window-w or w/o D1AB 14A304-BD backlite washer	1	D1AZ 14A027-C
68	A(71)	#C8AB 14A304-A, D0OB 14A304-A, D1OB 14A304-AA	1	C8AZ 14A027-A
68/71	B(71)		1	
68/70	X(71)		1	
72	B(71)	#D2OB 14A304-AA	1	D3OZ 14A027-A
71	A	Clip-attach wiring to front floor cross member	3	378674-S(GG150H)
71	B(71)	Screw-No. 8-12 x 1/2" -attach wiring to rear of instrument cluster	2	383938-G(UU52V)
14028 CONTROL ASSY. - DOOR LOCK - VACUUM				
65/66	A-with safety package	Less actuator - 14022	1	C5AZ 14028-A
67	A-with safety package and power windows	Safety convenience panel mounted #C7AB 62218A78-D	1	C7AZ 14028-C
68	A		1	C8AZ 14028-A
69	A	#C9AB 62218A78-A	1	C9AZ 14028-A
70	A	#C9AB 62218A78-B	1	D0AZ 14028-A
65	S		1	C4SZ 14028-B
66	S(63A, 76)-with safety package		1	
66	S(63C, D)		1	C6SZ 14028-A
67	S-with safety package	#C7SB 65218A78-E	1	C7SZ 14028-D
68/69	S	#C8SB 65218A78-B	1	C8SZ 14028-B
65/66	A	Screw-No. 6-20 x 1/2"-control to convenience panel	2	52784-S(U361A)
14028 SWITCH ASSY. - DOOR LOCK				
71	A(65, 76)	"Before 3/23/71" R.H. #D1AB 14017-AB, AD, AE	1	D1AZ 14028-A
		L.H. #D1AB 14963-AB, AD, AE	1	D1AZ 14028-B
71	A(65, 76)	"From 3/23/71" R.H. #D1AB 14017-AF	1	D1AZ 14028-G
		L.H. #D1AB 14963-AF	1	D1AZ 14028-H
71	A(54, 71)	R.H. #D1AB 14017-BB, BC	1	D1AZ 14028-C
		L.H. #D1AB 14963-BB, BC	1	D1AZ 14028-D
71	A(53, 57)	R.H. #D1AB 14017-CB, CC	1	D1AZ 14028-E
		L.H. #D1AB 14963-CB, CC	1	D1AZ 14028-F
72	A(65, 76)	R.H.-w/threaded shaft #D2AB 14017-EA	1	D2AZ 14028-J
		L.H. #D2AB 14963-EA	1	D2AZ 14028-K
72	A(53, 57)	R.H.-w/threaded shaft #D2AB 14017-CB	1	D2AZ 14028-E
		L.H. #D2AB 14963-CB	1	D2AZ 14028-F
72	A(54, 71)	R.H.-w/threaded shaft #D2AB 14017-BA	1	D2AZ 14028-C
		L.H.-w/threaded shaft #D2AB 14963-BA	1	D2AZ 14028-D
72	A(71)-with power tailgate lock	L. H. -side only	1	
72	B(53, 71)	R. H. #D2OB 14017-AB	1	D2OZ 14028-E
		L. H. #D2OB 14963-AB	1	D2OZ 14028-D
72	B(63, 65)	R.H. & L.H. #D2OB 14017-BA	2	D2OZ 14028-C
70/71	S	L.H. front door #D1VB 14A460-A, D0VB 14A460-A	1	D1VY 14028-A
72	S(w/single key lock system)	R.H. #D2SB 14017-AB	1	D2SZ 14028-A
		L.H. #D2SB 14963-AB	1	D2SZ 14028-B
72	S(except single key lock system)	R.H. & L.H.-w/threaded shaft #D2SB 14017-BB	2	D2SZ 14028-C
14A032 WIRING & JUNCTION BLOCK ASSY. INSTRUMENT PANEL - Refer to Groups 11A647 & 14401				

FORD CAR PARTS

5

SECTION 140

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A033 BUS BAR ASSY. - ACCESSORY FEED				
68/70	X	Accessory post	AR	C8OZ 14A033-C
69/	A(Taxi), F	Accessory post	AR	
70/	P, L		1	
68/71	B		1	
65/66	F, X	With 2 fuse holder-offset	AR	C5DZ 14A033-A
68/	A, B, F, X	Nut-No. 8-32-attach 14A318 to bus bar	1	34653-S(M106X)
65/66	S	With 4 fuse holders (battery)	1	C3SZ 14A033-B
65/66	S	With 6 fuse holders (accessory)	1	C4SZ 14A033-A
67/71	S		1	C4VY 14A033-A
14046 SWITCH & HOUSING ASSY. - WINDOW REGULATOR CONTROL - Refer to Group 14529				
14064 WIRE ASSY. - TACHOMETER LAMP				
70	B			
71	B(302,351)	#D00B 14064-A, B, C	1	D0OZ 14064-A
14K064 WIRE ASSY. - TEMPERATURE SENDER TO INDICATOR				
69	F(351)	#D10B 14064-AA	1	D1OZ 14064-A
14A066 BRACKET - CIRCUIT BREAKER MOUNTING - Unless indicated, improvise from steel stock				
65/66	A-with Select Aire A/C		1	C5AZ 14A066-C
66	B, X-with Select Aire A/C		1	
67/69	S		1	
65/70	X(59, 71)	Tailgate window	1	C7SZ 14A066-A
67/71	B(71)	Electric windows or seats	1	C1AZ 14A066-A
65/71	B(71)	Tailgate window	1	
65/71	A(71)	Tailgate window	1	
65/70	A(76), X(76)	Top control	1	
65/71	F(76)	Top control	1	
65/	A	Electric windows or seats	1	
70	F-with automatic seat back latch and/or power windows		1	
70/	B-with power windows, heated back window		1	
14A068 PANEL - FUSE JUNCTION				
65/66	A		1	C6AZ 14A068-A
66	U		1	
67/68	A		1	C7AZ 14A068-B
67	U	"Before Ser. A56, 001"	1	C7TZ 14A068-C
67	U	"From Ser. A56, 001"	1	C6TZ 14A068-E
68/71	B		1	C8OZ 14A068-A
69/	A		1	
70/72	P, L		1	
68/70	X		1	
69/70	F		1	
65/66	F-with alternator	"Before 2/1/66"	1	C5DZ 14A068-A
65/66	B, X	"Before 2/1/66"	1	
66/67	B, F, X	"From 2/1/66"	1	C6OZ 14A068-A
68	F		1	
72	B	"Before 11/1/71"	1	
72	B	"From 11/1/71"	1	D2OZ 14A068-A
71/	F	Includes (1) D2OZ 14417-A holder & terminal	1	D2OZ 14A068-B
72	S	Includes (1) D2OZ 14417-A holder & terminal	1	D1ZZ 14A068-A
65/66	S		1	D2SZ 14A068-A
67/71	S		1	C4SZ 14A068-A
68/	U		1	C6VY 14A068-C
			1	C8TZ 14A068-A
65/66	A	Screw (panel to dash panel)-No. 10-12 x 1 1/4"	2	379180-S2(UU81C)
68/	U	Flatwasher-No. 10	2	*351262-S8
		Nut-(junction block and instrument panel wiring to L. H. air vent duct)-No. 10-24	2	34053-S8(M156)
		Lockwasher - No. 10	2	34903-S8(X96)
67/	A	Flatwasher - No. 10	1	44716-S8(X15)
65/66	S	Screw-No. 10-12 x 2" (attach panel to cowl panel)	2	377192-S2(UU51X)
		Screw (panel to R. H. cowl side)-No. 10-12 x 1/2"	2	42161-S8(U252A)

Identification marking
May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
	14A081	WIRING - REAR QUARTER - WINDOW REGULATOR - Refer to Group 14632-3		
	14086-7	SWITCH and WIRING - WINDOW REGULATOR CONTROL - Refer to Group 14632-3		
	14A099	SHIELD - WIRING - UNLESS LISTED IMPROVISE - Also refer to Group 14A177 & Body Group 20770		
	- A -			
65/66	A-with electric seat	Electric seat (6 way) wiring	1	C3MY 14A099-A
65/66	A-with electric windows or safety package	R.H. -front door-steel-not replaced	1	★C5AZ 14A099-J
65/66	A(57F, 63, 76)-door mounted courtesy lamps		1	
65/66	A(54 Taxi)		1	
67/68	A(57F, 63, 76B)		1	
67/68	A(54C, 57F, 63, 76B)-door mounted courtesy lamps		1	
67/68	A(54A,B,E, 62, 57B, 76A)-w/safety package		1	
67	A(54A, 57B, 71A, B, C, E, 76A)-with electric windows		1	
67	A(54B, E-New York taxi)		1	
65/66	A-with electric windows or safety package	L.H. -front door-steel	1	C5AZ 14A099-K
65/66	A(57F, 63, 76)-door mounted courtesy lamps		1	
65/66	A(54 Taxi)		1	
67/68	A(54C, 57F, 63, 76B)-door mounted courtesy lamps		1	
67/68	A(54A, B, E, 62, 57B, 71)-w/safety package		1	
67/68	A(54A, 57B, 71A, B, C, E, 76A)-with electric windows		1	
67	A(54B, E-New York taxi)		1	
69	A-with electric windows and safety convenience package		1	
65/66	A(54, 57, 71)-with electric windows with or without safety package	R.H. -rear door-steel	1	C5AZ 14A099-L
65	A(57F)-door mounted courtesy lamps		1	
67	A(54C, 57F)-without safety package or power window with manual vents		1	
67/68	A(54B, E-New York taxi)		1	
68	A-power window with manual vents		1	
65/66	A(54, 57, 71)-with electric windows with or without safety package	L.H. -rear door-steel	1	C5AZ 14A099-N
65	A(57F)-door mounted courtesy lamps		1	
67	A(54C, 57F)-without safety package or power windows with manual vents		1	
67	A(54B, E-New York taxi)		1	
68	A(54B, E)-New York Taxi		1	
68	A-power window		1	
66	A(54, 57B, 57F, 71)-with safety package	R.H. -rear door-steel	1	C6AZ 14A099-A
67/68	A(54C, 57F)-with safety package or power window with manual vent		1	
67/68	A(54, 57B, 71)- w/elect.window & safety pkg.		1	
66	A(54, 57B, 57F, 71)-with safety package	L.H. -rear door-steel	1	C6AZ 14A099-C
67/68	A(54C, 57F)-with safety package or power window with manual vent		1	
67/68	A(54, 57B, 71)-w/elect. window & safety pkg.		1	
69	A(63, 65, 76)	R.H. -w/pwr. windows located at qtr. window	1	C9MY 14A099-A
		L.H.	1	C9MY 14A099-B
69/70	A(53, 54, 57, 71)	R.H. -with power windows or vacuum door locks located at rear door	1	C9AZ 14A099-A
		L.H.	1	C9AZ 14A099-B
69	A	R.H. -with power windows or power locks- located at front door	1	C9AZ 14A099-C
		L.H.	1	C9AZ 14A099-D
69/	A	12" long	1	D0AZ 14A099-G
69/	A	L.H. -side of steering column	1	C9AZ 14A099-F
70	A(heated back lite)	15" long	2	D0AZ 14A099-A

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A099 SHIELD - WIRING - continued - UNLESS LISTED IMPROVISE				
- Also refer to Group 14A177 & Body Group 20770				
- A -				
70	A	R. H. -front door-located inside door to shield 14630 wiring	1	D0VY 14A099-P
70	A	L. H. -front door-located inside door to shield 14631 wiring	1	D0VY 14A099-R
71/	A(53,54,57,71)-with power windows or power door locks	R.H.-located in rear door	1	D1AZ 14A099-C
		L.H.	1	D1AZ 14A099-E
71/	A-with heated back window	14" long	1	D1AZ 14A099-D
- B -				
68/69	B(54,71)-with power windows	R. H. and L. H. -located on front door inner panel	2	C8OZ 14A099-A
68/69	B(54,71)-with power windows	R. H. -located on rear door	1	C8OZ 14A099-C
		L. H.	1	C8OZ 14A099-D
68/71	B-with power windows	R. H. -located on front door inner panel	1	C8OZ 14A099-B
		L. H.	1	C8OZ 14A099-E
70/71	B	R. H. and L. H. -rear door	2	D0OZ 14A099-C
70/	B-with auto/seat back latch	R. H.	1	D0OZ 14A099-J
		L. H.	1	D0OZ 14A099-K
70/	B	Located at instrument panel to cover 14401	1	D0OZ 14A099-F
70	B	Located at instrument panel at steering column	1	D0OZ 14A099-G
71	B-with heated back window	13" long	1	D0VY 14A099-M
71	B-with heated back window	14" long	1	D1AZ 14A099-D
71	B	Located at instrument panel lower brace	1	D1OZ 14A099-A
72	B-with power windows	R.H.-located in front door	1	D2OZ 14A099-A
		L.H.	1	D2OZ 14A099-F
72	B-with power windows	R. H. -located in rear door -part of 14028	1	D2OZ 14A099-J
		L. H.	1	D2OZ 14A099-K
72	B-with power door locks or power windows	R.H. & L.H.	2	D2OZ 14A099-C
72	B "Before 7/3/72"	10" long-located at lower instrument panel flange	1	D2OZ 14A099-D
72	B "From 7/3/72"	10" long-located at lower instrument panel flange	1	D3OZ 14A099-D
72	B	Located at lower instrument panel flange with hole for w/shield wiper switch	1	D2OZ 14A099-E
72	B "Before 11/8/71"	Use with 3 speed manual trans.	1	D2AZ 14A099-C
72	B "From 11/8/71"	Use with 3 speed manual trans.	1	D2AZ 14A099-D
72	B	Use with 4 speed manual trans.	1	D2OZ 14A099-H
- F -				
65/66	F	Used on vehicles having ammeter and oil pressure gauges	1	C5ZZ 14A099-A
70	F	Located at underside of instrument panel	1	D0ZZ 14A099-A
71/	F-w/power windows	Located at quarter window wiring	2	D1ZZ 14A099-B
71/	F	Located under instrument panel center	1	D1ZZ 14A099-C
71/	F	Located under instrument panel R.H. & L.H. ends	2	D1ZZ 14A099-D
71	F-with power windows	R.H.-cowl	1	D1ZZ 14A099-E
71/	F-with power windows	L.H.-cowl	1	D1ZZ 14A099-F
72	F "Before 11/8/71"	Use with 3 speed manual trans.	1	D2AZ 14A099-C
72	F "From 11/8/71"	Use with 3 speed manual trans.	1	D2AZ 14A099-D
72	F	Use with 4 speed manual trans.	1	D2OZ 14A099-H
- L -				
71/	L	Located at instrument panel	1	D1FZ 14A099-A
72	L(64)-with heated back lite	Located on back window lift assy.	2	D2FZ 14A099-A
- P -				
70	P "Before 5/26/69"	R.H.-22 3/4" long-rear of instrument panel	1	D0DZ 14A099-A
70/72	P "From 5/26/69 to 3/1/72"	R.H.-rear of instrument panel	1	D0DZ 14A099-G
72	P "From 3/1/72"	R.H.-rear of instrument panel	1	D2DZ 14A099-A
72	P	Use with 3 speed manual trans.	1	D2AZ 14A099-D
72	P	Located at instrument panel at seat belt actuator	1	D2DZ 14A099-B

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A099 SHIELD - WIRING - continued - UNLESS LISTED IMPROVISE - Also refer to Group 14A177 & Body Group 20770				
- S -				
65/66	S	Attaches to rear seat riser at trans. tunnel-Nylon	1	C5SZ 14A099-K
65/66	S	7.00" long	1	C4SZ 14A099-K
65/66	S	1.76" long-located at R. H. fender support to retain basic 14290 wiring	1	C4SZ 14A099-T
65	S	Located at No. 3 floor cross member	2	C4SZ 14A099-A
66	S(63)		2	
66	S(76)-with power windows & vent windows		2	
65/66	S	48.90" long-located on console-R. H. side	1	C5SZ 14A099-E
65/66	S-with A/C	8.00" long-located on A/C evaporator-Nylon	1	C5SZ 14A099-C
66	S	33.00" long-located at front fender & apron support	1	C4SZ 14A099-J
67/71	S(57)	Rear door window regulator wiring shield	2	C7SZ 14A099-A
67/68	S	"Before 9/1/66" 9.00" long located L. H. side instrument panel -lower-cut from C5SZ 14A099-E	1	★C7SB 14A099-D
67/68	S	"From 9/1/66" 7.30" long-located L. H. side instrument panel -lower-cut from C5SZ 14A099-E	1	★C7SB 14A099-T
67/68	S	10.00" long-located upper instrument panel-cut from C5SZ 14A099-E	1	★C7SB 14A099-G
68/71	S	Attaches to front floor pan-19" long-curved	1	C8SZ 14A099-G
68/69	S	Attaches to front floor pan-57" long	1	★C8SZ 14A099-A
68/71	S	Attaches to front floor pan-11 3/4" long	1	C8SZ 14A099-C
69	S	Attaches to R. H. hood hinge	1	★C9SZ 14A099-C
69/71	S-with heated back window	Cut to size-13" long	1	D0VY 14A099-M
70/71	S	Located at brake pedal support	1	D0SZ 14A099-F
70/71	S	Located at steering column lower brace	1	D0SZ 14A099-G
70	S	Located at front floor pan-55" long	1	D0SZ 14A099-K
70/71	S	Steel-located at parking brake control	1	C9LY 14A099-A
71	S-with heated back window	14" long	1	D1AZ 14A099-D
72	S	R.H. & L.H.	2	D2LY 14A099-A
72	S	Plastic located at instrument panel to cover 14401	1	D2SZ 14A099-A
72	S	11" long curved located at instrument panel	1	D2SZ 14A099-B
72	S	"L" shaped nylon located at instrument panel	1	D2SZ 14A099-C
72	S	16 1/4" long located at R.H. side of instrument panel-includes hole for glove compt. lamp	1	D2SZ 14A099-D
72	S	"L" shaped plastic located at dash panel at cowl side panel to cover 14A005	1	D2SZ 14A099-E
72	S	31" long plastic located at front floor cross member to cover 14A005	1	D2SZ 14A099-F
72	S	"S" shaped plastic located at front floor cross member has 1/2" slot for attaching seat back latch wiring	1	D2SZ 14A099-G
72	S	Plastic located at brake pedal support brace	1	D2SZ 14A099-K
65/66	A	Screw-No. 10-12 x 1/2"	4	42127-S8(U248C)
66	B, X	Shield to inside front door panel	1	
65/66	F	Shield to steering column bracket	1	
65/66	S	Shield to frt. body pillar upper-inner)-L. H.	1	
65/66	S	Shield to No. 3 upper floor cross member	AR	
65/66	S	Shield to brake pedal support	2	
65/66	S	Shield to front fender apron & rad. support	5	
65/66	S	Shield and washer 44719-S8 to floor side reinforcement to rear R.H. & L.H. side member	2	
65/66	S	Shield to front body upper inner pillar	2	
65/66	S	Shield to front fender extension	2	
65/66	S	Shield to console panel lower edge retainer	1	
66	S	Shield to air conditioner evaporator	2	
68	B	Screw (attach shield to front or rear door panel)-No. 10-12 x 5/8"	2	42134-S8(U249)
71	B	Screw-No. 8-18 x 3/8" attach shield to seat back frame	2	42119-S(U246)
70	A	Screw-1/4"-14 x 1/2" (attach shield to floor pan)	AR	55981-S(U254E)

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A099 SHIELD - WIRING - continued - UNLESS LISTED IMPROVISE - Also refer to Group 14A177 & Body Group 20770				
67/	F(289, 390)	Screw (attach shield to floor pan)-No. 8-18 x 3/4"	2	376389-S101 (UU82D)
65/	A	Attach shield to rear door	2	
65/	S	Flatwasher-1/4"	2	44719-S8(X17)
65/	S	Clip & stud assembly-No. 10-24	2	372719-S100(BB643)
65/	S	Clip (shield to front floor pan)	7	*377681-S2
70	S	Screw (attach 14A099 to floor pan)-No. 8-18 x 3/8"	AR	379560-S (UU89CA)
69/	A	Screw No. 8-15 x 1/2"-attach wiring shield to front door, rear door, and seat cushion	4	52012-S(U202)
72	S	Clip No.8-18-attach shield to inst.panel	AR	381953-S(GG376)
14A122 HOUSING ASSY. - WINDOW REGULATOR SWITCH - Also refer to Groups 10852, 14A124 & 15A670				
69/70	A(71)-retractable back window	Located at instrument panel (paint to match)	1	C9AZ 14A122-A
69/70	A(76)-top control		1	
14A124 NUT-REAR WINDOW REGULATOR CONTROL SWITCH				
66/67	X(71)-retractable back window		1	C6DZ 14A124-A
66/67	B(71)-with swing away tailgate-elec. back wdw.		1	
66/67	B(76)-top control		1	
14A125 BRACKET - REAR WINDOW REGULATOR CONTROL SWITCH MOUNTING				
68	A(71C, D, H, J)	With power tail gate window	1	C8AZ 14A125-A
14A148 SUPPORT - FUSE JUNCTION PANEL - UPPER				
71	F	"Before 6/25/71"	1	D1ZZ 14A148-A
71/	F	"From 6/25/71"	1	D1ZZ 14A148-B
71/	L	Steel-attaches to brake pedal support	1	D1FZ 14A148-A
14A163 RETAINER - WIRING HARNESS - Unless listed, improvise locally				
65/66	A(except C/M, C4, F/M/2)	Used with rear lamp wiring at stop lamp switch	1	*C5AZ 14A163-A
65/66	A	To secure wiring to cowl side panel-not req'd. on units built after 9/6/65 - not replaced	2	*C5AZ 14A163-B
65/66	B	Nylon-not replaced	3	*C2OZ 14A163-A
66/68	A	To secure wiring in rocker panel	AR	C6AZ 14A163-A
67/70	A	To secure wire at headlamp dimmer switch	1	C7AZ 14A163-A
68/	S, F		1	
67/68	A	To attach glove & courtesy lamp leads to plate	AR	C7AZ 14A163-C
68	A, B, S, X	To attach rear seat speaker and stereo wires to pillar and package tray	AR	
68	B(54, 63, 65), X(54, 62)	Rear window defogger	1	
68	F-with safety package		AR	
68	F(63)-except with safety package	Used with rear window defogger	5	
68	F(65)-except with safety package	Used with rear window defogger	3	
68	S	Rear window defogger	1	
69/70	F(GT350/500)	Luggage compartment lamp wiring to door	1	
69/70	S	Use to retain sun roof wiring	2	
69	A(71)	Attach wiring to tailgate hinge	1	C9AZ 14A163-D
70/	A(71)	Used to retain power back lite wiring	1	D0AZ 14A163-J
72	B(71)		1	
70	A	Attaches 14630, 14631 wiring inside front doors	2	D0VY 14A163-G
71/	B, P			
71	F	"Before 6/25/71"	1	D1AZ 14A163-A
71	F	"From 6/25/71"	1	D1ZZ 14A163-L
71	S	"Before 2/8/71"	1	D1SZ 14A163-A
71	S	"From 2/8/71"	1	384742-S(GG166D)
72	B	Retain ignition switch	2	D0VY 14A163-F
72	S		2	
72	B(8 cyl. 351W)	Attach 14289 to valve cover	1	D2OZ 14A163-E

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
	14A163 RETAINER - WIRING HARNESS - continued	- Unless listed, improvise locally		
65/69	B(54A-Taxi)	Used with roof light wiring	2	C3SZ 14A163-B
65/69	B-with 4 speed trans.	Used with backup lamp wiring	2	
65/69	B(71)	Used with tailgate window regulator	AR	
65/66	B(except 71)	Used with fuel gauge sending wire	1	
65/69	B, X(54, 62, 63)	Used with rear lamp wiring	2	
66	B(63C, D, 76C, D)	Used with arm rest courtesy lamps	AR	
67	B(63C, D, 66D, 76C, D)	With door mounted courtesy lamp	4	
67	B(71), X(71)	Used with rear lamp wiring	2	
67	B(66, 71)	Used with fuel tank sending wire	1	
67	B(63C, 66D, 76C)	Used with console wiring	1	
66/68	F(76)	Used with power top wiring	4	
67	F	Use to attach engine compt, lamp wire and/or speed control wiring to dash flange in engine compt.	AR	
67/70	F	Used w/console & safety convenience pkg.wiring	1	
68/70	S	Rear seat speaker at pkg. tray	3	
66/	U	Used with horn wiring	1	
67/	U(8 cyl. 289)	Attach No.3 wire of 14289 to radiator surge tank bracket	1	
65/70	X(except 66, S/D, S/W)	Used with backup lamp wiring	1	
69	F	Used with speed control	1	
71/	U	Used to retain 14401 under instrument panel	1	
69	B	Attach 14401 to instrument panel	4	C8LY 14A163-A
69	X	Attach 14290 to fender apron	4	
67/68	F	Nylon-not replaced	AR	★C7ZZ 14A163-A
67/69	F-with 3 speed S/T	"Before 10/1/68" Steel	2	C7ZZ 14A163-B
67/69	F-with 4 speed S/T		1	
69	F-with 3 speed S/T	"From 10/1/68"	AR	C9ZZ 14A163-A
69	F-with 4 speed S/T		AR	
71/	F, L-with 3 speed S/T		2	
71/	P-with 3 speed S/T	Attach 15520 switch and wiring to housing	2	
70/	F-with 4 speed S/T		1	D0ZZ 14A163-A
71/	F	Located at radio mounting bracket	1	D1ZZ 14A163-K
71/	F	Located at cowl side panel	2	D1ZZ 14A163-AA
71	L	Located at instrument panel reinforcement	AR	D1FZ 14A163-A
71/	L	Steel	1	D1FZ 14A163-B
71/	A, F, L	Nylon -attaches 13A719 to dome lamp	1	D1FZ 14A163-C
65/69	S	Used with door warning lamp wiring	2	C3SZ 14A163-B
65/66	S(76)	Used with rear lamp wiring	2or3	
65/69	A	Used with rear door electric window regulator	AR	
65/66	A	Used with dash panel to headlamp junction wiring	1or2	
65/69	A	Used with luggage compartment lamp wiring	AR	
65/69	A(71)		1	
65/69	A		2or4	
65/66	A-with moveable steering column	Used with starter circuit jumper wiring	2	
65/66	A	Used with backup lamp wiring	2	
65/69	A(71)		4	
65/69	A	Used with frt.door electric wdw. or safety package	1or2	
65/69	A	Used with cigar lighter lead of instrument panel wiring	1	
65/69	A(76)	Used with top control relay to circuit breaker wiring at wheelhouse flange	2or3	
65/69	A(54B, E)-New York Taxi	Used with R. H. or L. H. open door warning wiring	AR	
65/69	A-with Safety Package		AR	
65/69	A(63C, 76B)	Used with transmission control selector indicator lamp wiring	2	
66	A(57)	Used with hose vent regulator damper motor to wheelhouse	1	
68	A(54, 57, 62, 63, 71, 76)	Front seat wiring	3	
67	S-with A/C	Retains wiring assy. to A/C distribution chamber not replaced	1	★C7SZ 14A163-C
69	S	1 1/2" x 1/2" used with power windows-connector to switch	AR	C9VY 14A163-A
69	S(57)-with vac. door locks	R. H. -front door	1	C9VY 14A163-B

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A163 RETAINER - WIRING HARNESS - continued - Unless listed, improvise locally				
72	S-with brake skid control	Steel	1	D2LY 14A163-B
72	B,S	20 1/2" long-nylon (chain link type)	1	D2OZ 14A163-D
72	S	Steel-fastens to bumper bar at side shield	AR	D2LY 14A163-C
68	S	With rear lamp monitor	8	C8WY 14A163-B
68	A(except 71, 76)	Retains fuel sender wire to rear seat strainer	2	
68	A	To attach 14405 to quarter panel rear	AR	
68/69	S	To attach rear lamp extension wire to quarter panel	AR	
		To attach luggage comp. lamp wiring to deck lid and upper back panel	AR	
68/	U	Attach windshield wiper motor wiring to windshield header	AR	
69	A, S	Defogger wiring to package tray	AR	
70	P	To attach 14290 wiring to fender apron	2	
70	F-with speed control	Attached at front fender apron	1	
71	F	Attach wiring 14406 to fuel tank flange	2	
71	A(71)	Attach 14529 and wiring to tailgate panel	2	D2AZ 14A163-D
70/71	B	Used to attach hidden headlamp vacuum hose to radiator support	AR	
71	F	Used to attach park lamp wiring to 13008	2	
71	F	Attach wiring 14290 to fender side shield	AR	
72	S	Attach parking brake hose to brake pedal support	1	
72	S	Attach 14630-1 wiring to inner panel	2	
72	A(429), P/C, B(429)	Located on engine	1	
72	F(351), Boss	Located on engine	1	
72	A(429), P/C, B(429)	Located on L.H. valve cover	1	D2AZ 14A163-F
72	A, B(302, 351, 400)	Located on engine	2	D2AZ 14A163-G
72	F(351)-except Boss	Located on engine	1	D2ZZ 14A163-A
72	F(351)-Boss	Located on engine	1	
72	L-with heated backlite	Located in luggage comp. on hinge support	2	D2FZ 14A163-A
70/	A(71)	Screw No. 8-15 x 1/2" attach C8WY 14A163B to tailgate panel	2	52012-S(U202)
71	A, B, F, P, S	Screw-1/4"-20 x 3/4" hex. washer head Attach retainer to 3676	AR	383184-S (UU52AD)
14A173 CLIP - FUSE PANEL WIRING				
65/66	S	Used with electric window wiring lead in 14401 assembly at No. 3 upper floor cross member	1or2	CISF 14A173-A
65/66	X-with 4 speed trans. or F/M	Used with back up lamp wiring	2or3	
65/66	X(8 cyl.)		2	
65/66	F	Used with console courtesy lamp feed wire	1	
65/66	F	Used with back up lamp switch feed wire	1	
65/66	F	Used w/trans. control selector indicator lamp wire	1	
65/66	S	Screw (attaches clip to No. 3 upper floor cross member)	1	42127-S8(U248C)
14A187 BOLT - FUSE JUNCTION PANEL				
68/71	B, F	1/4"-20 x 3 1/4" long	1	C8OZ 14A187-A
69/	A		1	
70/71	L, P		1	
68/70	X		1	
72	B	1/4"-20 x 2 21/32" long	1	D2OZ 14A187-A
14199 CLIP - WIRING				
71/	L-with 4 speed manual trans.	Located on trans.	1	D1FZ 14199-A
14A200 WIRING ASSY. - WINDOW REGULATOR SAFETY RELAY TO WINDOW REGULATOR SWITCH - Also refer to Groups 14678 & 15A669				
67/68	A(54, 57, 62, 63, 76)	Used with electric windows	1	C7AZ 14A200-A
67/68	A(71)	Used with electric windows and tailgate	1	
69	A(71)	"Before 6/1/69"	1	C9AZ 14A200-A
69	A	"Before 6/1/69"	1	
69	A(71)	"From 6/1/69"	1	C9AZ 14A200-C
69	A	"From 6/1/69"	1	
70	A-with power windows or tailgate		1	D0AZ 14A200-A

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A200 WIRING ASSY. - WINDOW REGULATOR SAFETY RELAY TO WINDOW REGULATOR SWITCH -				
continued -Also refer to Groups 14678 & 15A669				
68/69	B(71), X(71)-with power tailgate		1	C8OZ 14A200-A
68/69	B(54, 65, 71, 76)-with power windows		1	
70	B, X-with power windows or tailgate or auto/seat back latch		1	D0OZ 14A200-A
70	A(71)	Screw 1/4"-14 x 1/2" (attach wiring to brake pedal support)	AR	55981-S (U254E)
71/72	A-with power windows	Also used with power backlite, electric luggage compt. opener & engine compt. lamp #D2AB 14A200-AA	1	D2AZ 14A200-A
71	B	Used w/pwr.window, htd.backlite, pwr.seats	1	D1OZ 14A200-A
72	B(exc. 53, 71 Police or Taxi)-w/o power windows and/or power tailgate--w/o trailer towing pkg.	#D2OB 14A435-AD	1	D2OZ 14A200-D
72	B(exc. 53, 71 Police or Taxi)-w/power windows and/or power tailgate--w/o trailer towing pkg.	#D2OB 14A200-AC	1	D2OZ 14A200-A
72	B(exc. 53, 71 Police or Taxi)-w/o power windows and/or power tailgate--w/trailer towing pkg.	#D2OB 14A435-BD	1	D2OZ 14A200-C
72	B(exc. 53, 71 Police or Taxi)-w/power windows and/or power tailgate--w/trailer towing pkg.	#D2OB 14A200-BC	1	D2OZ 14A200-B
72	B(53, 71 Police or Taxi)-w/o power windows and/or power tailgate--w/trailer towing pkg.	#D2OB 14A435-CA CC	1	D2OZ 14A200-F
72	B(53, 71 Police or Taxi)-w/power windows and/or power tailgate	#D2OB 14A200-CA CC	1	D2OZ 14A200-E
71/72	F-with power windows "Before 12/1/71"		1	D1ZZ 14A200-A
72	F-with power windows "From 12/1/71 to 6/15/72"		1	D2ZZ 14A200-A
72	F-w/power windows w/o heated backlite-"From 6/15/72"		1	
72	F-w/power windows and heated backlite-"From 6/15/72"		1	D3ZZ 14A200-A
72	F-w/o power windows and/or auto.seat back latch w/heated backlite "From 6/15/72"		1	D3ZZ 14A200-B
72	F-w/o power windows with auto. seat back latch and heated backlite "From 6/15/72"		1	D3ZZ 14A200-C
70	B	Strap(attach wiring to fender apron)	2	376914-S(YY2)
71	B	Clip (attach wiring to dash panel)	2	384007-S(GG369)
71/	F	Clip-attach wiring to L. H. air duct	1	372172-S(GG228)
		Clip-attach wiring to cowl top panel	4	382033-S(GG303)
		Clip-attach wiring to instrument panel bracket	1	383207-S(GG271)
14A206 BRACKET - WIRING CONNECTOR				
71	A	With power windows	6	D1AZ 14A206-A
14A217 BRACKET - WIRING SHIELD MOUNTING				
68/69	S	Improvise		
70/71	S		2	D0LY 14A217-A
14A230 GASKET - WINDOW REGULATOR SWITCH HOUSING - Improvise from rubber material				
14A240 INSULATOR - NON-METALLIC WIRING CONDUIT				
		3/8" I.D. x 15 ft. roll	AR	C1AZ 14A240-A
		3/16" I.D. x 15 ft. roll	AR	C1AZ 14A240-B
14A265-6 SWITCH and WIRING - WINDOW REGULATOR CONTROL - Refer to Group 14632-3				
14A276 COVER - BALLAST RESISTOR MOUNTING PLATE				
65/66	A	Transistorized ignition - not required on units built after 12/13/65	1	C4TZ 14A276-A
65	S		1	
14277 COVER - BATTERY INSULATOR				
69	B, F(428CJ)	Vinyl	1	C9ZZ 14277-A
69	F(429 Boss)		1	
14A282 RETAINER ASSY. - WIRING HARNESS				
68	A	Located on L. H. side of dash panel-not repl.	1	★C7AZ 14A282-B
71/	A	Located at steering column	1	D1AZ 14A282-A
68	A	Screw-1/4"-14 x 5/8" (attach retainer to instrument panel)	4	381922-S2(UU52A)
68	A	Plug button (attaches wiring to retainer)	1	382374-S(PP13CB)

14289 WIRE ASSY. - DASH TO ENGINE GAUGE FEED

WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE FOR 1965 and SUBSEQUENT MODELS

The purpose of this guide is to facilitate the identification of the Service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C4OB 14289-A	★C4OZ 14289-A	C9DB 14289-A	C9DZ 14289-A
C4OB 14289-B	C4OZ 14289-C	C9OB 14289-A	C9OZ 14289-A
C4ZB 14289-A	C5ZZ 14289-A	C9TB 14289-A	D0BZ 14289-A
C4ZB 14289-B	C5ZZ 14289-B	C9ZB 14289-A	C9ZZ 14289-A
		C9ZB 14289-D	D0AZ 14289-A
C5AB 14289-A	★C5AZ 14289-A	C9ZB 14289-F	D0AZ 14289-A
C5AB 14289-B	C5AZ 14289-B	C9ZB 14289-G	D0ZZ 14289-E
C5AB 14289-C	C5AZ 14289-C	C9ZB 14289-H	D0ZZ 14289-E
C5AB 14289-E	★C5AZ 14289-E		
C5AB 14289-F	★C5AZ 14289-D	D0AB 14289-A	D0AZ 14289-A
C5AB 14289-J	C5AZ 14289-B	D0AB 14289-B	D0AZ 14289-B
C5AB 14289-K	★C5AZ 14289-E	D0AB 14289-C	D0AZ 14289-C
C5AB 14289-L	★C5AZ 14289-D	D0BB 14289-A	D0BZ 14289-A
C5AB 14289-N	C5AZ 14289-A	D0BB 14289-B	D0BZ 14289-B
C5DB 14289-A	★C5DZ 14289-A	D0DB 14289-A	D0DZ 14289-C
C5DB 14289-B	★C5DZ 14289-C	D0DB 14289-B	D0OZ 14289-A
C5DB 14289-C	★C5DZ 14289-C	D0DB 14289-C	D0DZ 14289-C
C5OB 14289-A	C4OZ 14289-C	D0ZB 14289-B	D0ZZ 14289-A
C5ZB 14289-A	★C5ZZ 14289-F	D0ZB 14289-E	D0ZZ 14289-E
C5ZB 14289-B	C5ZZ 14289-G	D0ZB 14289-F	D0ZZ 14289-E
C5ZB 14289-C	★C5ZZ 14289-H		
C5ZB 14289-D	C5ZZ 14289-J	D1AB 14289-AA	D1AZ 14289-A
C5ZB 14289-E	C5ZZ 14289-G	D1AB 14289-BA	D1AZ 14289-B
C5ZB 14289-F	★C5ZZ 14289-F	D1AB 14289-CA	D1AZ 14289-C
C5ZB 14289-G	C5ZZ 14289-G	D1AB 14289-DB	D1AZ 14289-D
		D1AB 14289-EA	D1AZ 14289-E
C6AB 14289-A	★C6AZ 14289-A	D1AB 14289-FC	D1AZ 14289-F
C6AB 14289-B	C5AZ 14289-J	D1AB 14289-GB	D1AZ 14289-G
C6AB 14289-C	C5AZ 14289-K	D1BB 14289-AA	D1TZ 14289-A
C6AB 14289-E	★C6AZ 14289-E	D1OB 14289-AA	D1AZ 14289-B
C6AB 14289-F	★C6AZ 14289-F	D1OB 14289-BA	D0DZ 14289-C
C6AB 14289-H	★C6AZ 14289-H	D1OB 14289-CB	D1OZ 14289-C
C6AB 14289-J	C6AZ 14289-J	D1TB 14289-AA	D1TZ 14289-A
C6AB 14289-K	C6AZ 14289-K	D1ZB 14289-AA	D0ZZ 14289-E
C6AB 14289-L	★C6AZ 14289-L		
C6DB 14289-A	C6DZ 14289-A	D2AB 14289-AE	D2AZ 14289-A
C6DB 14289-A	C6DZ 14289-B	D2AB 14289-AF	D2AZ 14289-A
C6OB 14289-A	★C6OZ 14289-A	D2AB 14289-BD	D2AZ 14289-B
C6OB 14289-B	C6OZ 14289-B	D2AB 14289-BE	D2AZ 14289-B
C6OB 14289-C	C6OZ 14289-C	D2AB 14289-BH	D2AZ 14289-J
C6TB 14289-C	★C6TZ 14289-C	D2AB 14289-CC	D2AZ 14289-C
C6TB 14289-D	C6TZ 14289-D	D2AB 14289-DB	D2AZ 14289-D
C6ZB 14289-A	C6ZZ 14289-A	D2AB 14289-ED	D2AZ 14289-E
C6ZB 14289-B	C6ZZ 14289-B	D2AB 14289-FC	D2AZ 14289-F
		D2AB 14289-FD	D2AZ 14289-F
C7DB 14289-A	C7DZ 14289-A	D2AB 14289-GE	D2AZ 14289-G
C7DB 14289-B	C7DZ 14289-B	D2AB 14289-HD	D2AZ 14289-H
C7GB 14289-A	C7ZZ 14289-A	D2DB 14289-AE	D2DZ 14289-A
C7OB 14289-D	C7OZ 14289-D	D2DB 14289-BC	D2DZ 14289-B
C7OB 14289-E	C7OZ 14289-E	D2MB 14289-AB	D2MY 14289-A
C7OB 14289-F	C7OZ 14289-F	D2MB 14289-BB	D2MY 14289-B
C7TB 14289-BG	C7TZ 14289-BG	D2OB 14289-DB	D2OZ 14289-D
C7TB 14289-BF	D0BZ 14289-B	D2OB 14289-EA	D2OZ 14289-E
		D2OB 14289-GA	D2OZ 14289-G
C8DB 14289-A	C8DZ 14289-A	D2ZB 14289-AA	D2ZZ 14289-A
C8DB 14289-B	C8DZ 14289-B		
C8GB 14289-A	C8GY 14289-A	D4TB 14289-PA	D4TZ 14289-P

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14289 WIRE ASSY. - DASH TO ENGINE GAUGE FEED				
- A -				
65	A(8 cyl. 289)	"Before 6/14/65"	1	C5AZ 14289-B
65/66	A(8 cyl. 289)	"From 6/14/65 to 2/1/66"	1	C5AZ 14289-J
66	A(8 cyl. 289)	"From 2/1/66"	1	C6AZ 14289-J
65	A(8 cyl. 352, 390)	"Before 6/14/65"	1	C5AZ 14289-C
65/66	A(8 cyl. 352, 390, 428)	"From 6/14/65 to 2/1/66"	1	C5AZ 14289-K
66	A(8 cyl. 352, 390, 428)	"From 2/1/66"	1	C6AZ 14289-K
67/69	A	Refer to Basic Group 14398		
70	A(6 cyl. 240)		1	D0AZ 14289-C
70	A(8 cyl. 302-2V, 351-2V)		1	D0OZ 14289-A
70	A(8 cyl. 390, 428)		1	D0AZ 14289-A
70	A(8 cyl. 429)		1	D0AZ 14289-B
71	A(6 cyl. 240)		1	D1AZ 14289-A
71	A(8 cyl. 302, 351 "W")-without A. T. C.		1	D1AZ 14289-B
71	A(8 cyl. 302, 351 "W")-with A. T. C.		1	D1AZ 14289-E
71	A(8 cyl. 390)		1	D1AZ 14289-C
71	A(8 cyl. 400)-without A. T. C.		1	D1OZ 14289-C
71	A(8 cyl. 351 "C")-without A. T. C.		1	
71	A(8 cyl. 400)-with A. T. C.		1	D1AZ 14289-F
71	A(8 cyl. 351 "C")-with A. T. C.		1	
71	A(8 cyl. 429)-without A. T. C.		1	D1AZ 14289-D
71	A(8 cyl. 429)-with A. T. C.		1	D1AZ 14289-G
72	A(6 cyl. 240)-with C4 trans.		1	D2AZ 14289-D
72	A(6 cyl. 240)-with CM trans.		1	D2AZ 14289-H
72	A(8 cyl. 302)	"Before 10/22/71"	1	D2AZ 14289-B
72	A(8 cyl. 351W)-without A. T. C.		1	
72	A(8 cyl. 302)	"From 10/22/71"	1	D2AZ 14289-J
72	A(8 cyl. 351W)-with A. T. C.		1	D2AZ 14289-E
72	A(8 cyl. 351C, 400)-with A. T. C.		1	D2AZ 14289-F
72	A(8 cyl. 400-2V)-without A. T. C.-California		1	D2AZ 14289-C
72	A(8 cyl. 400-2V)-without A. T. C.-exc. Calif.		1	D2OZ 14289-D
72	A(8 cyl. 351C)-without A. T. C.		1	
72	A(8 cyl. 429 exc. P/I)-without A. T. C.		1	D2AZ 14289-A
72	A(8 cyl. 429 exc. P/I)-with A. T. C.		1	D2AZ 14289-G
72	A(8 cyl. 429 P/I)-without A. T. C.		1	D2MY 14289-A
72	A(8 cyl. 429 P/I)-with A. T. C.		1	D2MY 14289-B
- B -				
65	B(8 cyl.)		1	C4OZ 14289-C
66	B(8 cyl. 289)		1	C6OZ 14289-B
66	B(8 cyl. 390)		1	C6OZ 14289-C
67/68	B(6 cyl.)		1	C7OZ 14289-D
67/68	B(8 cyl. 390, 427, 428)		1	C7OZ 14289-F
67	B(8 cyl. 289)		1	C7OZ 14289-E
68	B(8 cyl. 289, 302)	"Before 1/2/68"	1	
68	B(8 cyl. 289, 302)	"From 1/2/68"	1	C8DZ 14289-A
69	B(8 cyl. 302, 351)	"Before 11/18/68"	1	C9OZ 14289-A
69	B(8 cyl. 302, 351)	"From 11/18/68"	1	C9DZ 14289-A
69	B(6 cyl.)		1	C8DZ 14289-B
69	B(8 cyl. 390, 427, 428 CJ)		1	C8GY 14289-A
70/71	B(6 cyl.)		1	D0DZ 14289-C
70	B(8 cyl. 302)		1	D0OZ 14289-A
70	B(8 cyl. 351)		1	D0ZZ 14289-A
70	B(8 cyl. 429)		1	D0AZ 14289-B
71	B(8 cyl. 302)		1	D1AZ 14289-B
71	B(8 cyl. 351)		1	D1OZ 14289-C
71	B(8 cyl. 429)		1	D1AZ 14289-D
72	B(6 cyl. 250)		1	D2ZZ 14289-A
72	B(8 cyl. 302)	"Before 10/22/71"	1	D2AZ 14289-B
72	B(8 cyl. 302)	"From 10/22/71"	1	D2AZ 14289-J
72	B(8 cyl. 351-4V CJ)	"Before 9/15/71"	1	D2AZ 14289-C
72	B(8 cyl. 400-2V)-California		1	
72	B(8 cyl. 351C-2V)-w/electronic spark control-	"From 2/7/72"	1	

FORD CAR PARTS

SECTION 140

15

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14289 WIRE ASSY. - DASH TO ENGINE GAUGE FEED - continued				
- B -				
72	B(8 cyl. 400-2V) - except California		1	D2OZ 14289-D
72	B(8 cyl. 351-2V) - "Before 2/7/72"		1	
72	B(8 cyl. 351-4V CJ) "From 9/15/71"		1	
72	B(8 cyl. 351C-2V) -w/o electronic spark control "From 2/7/72"		1	
72	B(8 cyl. 351W-2V) "From 2/7/72"		1	D2OZ 14289-E
72	B(8 cyl. 429 exc. P/I)		1	D2AZ 14289-A
72	B(8 cyl. 429 P/I) -without A. T. C.		1	D2MY 14289-A
72	B(8 cyl. 429 P/I) -with A. T. C.		1	D2MY 14289-B
- F -				
65	F(65A, 76A) -6 cyl.		1	C5ZZ 14289-A
65	F(8 cyl.) -with generator		1	C5ZZ 14289-B
65	F(63A, 65A, C, 76A, C) -8 cyl. -with alternator		1	C5ZZ 14289-G
65	F(63B, 65B, 76B) -8 cyl.		1	C5ZZ 14289-J
65	F(63A, 65A, C, 76A, C) -8 cyl. -with ammeter & oil pressure gauges		1	
66	F(6 cyl.)		1	C6ZZ 14289-A
66	F(8 cyl.) -with heavy duty wiring		1	C6ZZ 14289-B
67	F(8 cyl. 289)		1	C6DZ 14289-B
68	F(8 cyl. 289, 302) "Before 4/8/68"		1	
68	F(8 cyl. 289, 302) "From 4/8/68"		1	
67/68	F(6 cyl.)		1	C8DZ 14289-A
67/68	F(8 cyl. 390, 427, 428)		1	C7DZ 14289-A
69	F(8 cyl. 390, 428)		1	C7ZZ 14289-A
70	F(8 cyl. 428CJ)		1	D0AZ 14289-A
69	F(8 cyl. 429)		1	
69	F(8 cyl. 302 Boss)		1	
70	F(65A, B) -8 cyl. 302-4V -with tachometer		1	D0ZZ 14289-E
71	F(8 cyl. 302-4V) -w/ or w/o gauges		1	
70	F(63A, B) -8 cyl. 302-4V Boss		1	
69	F(6 cyl.)		1	
70/71	F(6 cyl.)		1	C9ZZ 14289-A
69/70	F(8 cyl. 351-2V (W))		1	D0DZ 14289-C
69/70	F(8 cyl. 302-2V)		1	D0OZ 14289-A
70	F(8 cyl. 351-4V)		1	
70	F(8 cyl. 351-2V (C))		1	D0ZZ 14289-A
71	F(8 cyl. 302-2V)		1	
71	F(8 cyl. 351)		1	D1AZ 14289-B
71	F(8 cyl. 429)		1	D1OZ 14289-C
72	F(6 cyl. 250)		1	D1AZ 14289-D
72	F(8 cyl. 302) "Before 10/22/71"		1	D2ZZ 14289-A
72	F(8 cyl. 302) "From 10/22/71"		1	D2AZ 14289-B
72	F(8 cyl. 351-4V Boss) "Before 2/1/72"		1	D2AZ 14289-J
72	F(8 cyl. 351-4V CJ) "Before 9/15/71"		1	D2AZ 14289-C
72	F(8 cyl. 351-4V Boss) "From 2/1/72"		1	
72	F(8 cyl. 351-2V)		1	D2OZ 14289-G
72	F(8 cyl. 351-4V CJ) "From 9/15/71"		1	D2OZ 14289-D
- P -				
70/	P(6 cyl.)		1	D0DZ 14289-C
71	P(8 cyl.)		1	D1AZ 14289-B
72	P(8 cyl.) "Before 10/22/71"		1	D2DZ 14289-A
72	P(8 cyl.) "From 10/22/71"		1	D2DZ 14289-B
- U -				
66	U(8 cyl.)		1	C6TZ 14289-D
67/68	U(8 cyl.)		1	C7TZ 14289-BG
67/	U(6 cyl. 170)	Pkg. contains (1) - D0DB 10B886-A wire for use on past models	1	D0BZ 14289-B
69/70	U(8 cyl. 302)	Pkg. contains (1) - D0LB 10B886-A wire for use on past models	1	D4TZ 14289-P
71/72	U(8 cyl. 302)		1	D1TZ 14289-A

May, 1975

COPYRIGHT © 1975 --

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14289 WIRE ASSY. - DASH TO ENGINE GAUGE FEED - continued				
- X -				
66	X(6 cyl.)		1	C6DZ 14289-A
66	X(8 cyl.)		1	C6DZ 14289-B
67	X(6 cyl.)		1	C7DZ 14289-A
67	X(8 cyl.)		1	C7DZ 14289-B
68	X(8 cyl.)		1	C8DZ 14289-A
68/70	X(6 cyl.)		1	C8DZ 14289-B
69/70	X(8 cyl. 302)		1	C9DZ 14289-A
65	A	Clip (wiring to instrument panel or dash panel)	AR	*376931-S
65	A	"Before 6/14/65" Clip (wiring to R. H. front fender)	1	358350-S(GG172)
65/66	A	"From 6/14/65" Clip (wiring to R. H. front fender-apron)	1	377987-S(GG256)
68	B, X	Clip (wiring to dash panel)	AR	
65/	A, B, F, S, X	Adjustable strap (wire hold down)-Nylon	AR	376914-S(YY2)
65/	A-with 60 amp. alternator	Clip (wiring to R. H. front fender apron)	2	371645-S100 (GG210M)
65/	A (6 cyl.)	Clip (wiring to mounting bolt that attaches valve push rod chamber cover to engine)	2	353547-S2(GG173)
65/70	X	Clip (wiring to ignition coil strap)	1	
65/	A, S	Clip (wiring & coil to distributor low tension wire to L. H. cylinder head with bolt that attaches ignition coil strap)	1	
65/	A, S	Clip (wiring to bolt that attaches valve rocker arm cover to cylinder head)	3	
65/	B		3	
65/	F		3	
65	F	Clip (wiring and ignition coil screw to engine)	1	
66	A	Clip (wiring to dash panel)	6	380896-S(GG252)
68	A	Screw-1/4"-14 x 3/4"	AR	55914-S2(U254F)
65	F	Clip (wiring to fender to apron brace)	2	*372303-S100
65	X	Clip (wiring to dash panel)	AR	372866-S100 (GG89)
71	U	Clip (wiring to dash panel)	2	381645-S(GG261)
70	A, B, S	Screw No. 8-15 x 1/2" attach ground wire of 14289 to radiator support	1	52012-S(U202)
71	A, B	Bolt-3/8"-16 x 1/2" attach ground wire to engine	1	20312-S7(B75)
71	A, B	Bolt-7/16"-14 x 1/2" attach ground wire engine gauge feed to block	1	20314-S(B98)

14290 WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION

**WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE
FOR 1965 and SUBSEQUENT MODELS**

The purpose of this guide is to facilitate the identification of the Service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C4ZB 14290-A	C5ZZ 14290-B	C5DB 14290-B	C5DZ 14290-A
C4ZB 14290-B	C5ZZ 14290-B	C5DB 14290-C	C5DZ 14290-A
C5AB 14290-A	C5AZ 14290-D	C5OB 14290-A	C5OZ 14290-A
C5AB 14290-C	*C5AZ 14290-E	C5OB 14290-B	*C5OZ 14290-B
C5AB 14290-D	C5AZ 14290-D	C5OB 14290-C	C5OZ 14290-A
C5AB 14290-E	*C5AZ 14290-E	C5OB 14290-D	*C5OZ 14290-B
C5AB 14290-F	C5AZ 14290-D	C5OB 14290-E	*C5OZ 14290-E

14290 WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION - continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C5SB 14290-E	★C5SZ 14290-S	C8OB 14290-A	C8OZ 14290-F
C5SB 14290-F	C5SZ 14290-T	C8OB 14290-C	C8OZ 14290-F
C5SB 14290-G	★C5SZ 14290-N	C8OB 14290-D	C8OZ 14290-F
C5SB 14290-H	★C5SZ 14290-R	C8OB 14290-E	C8OZ 14290-F
C5SB 14290-J	★C5SZ 14290-S	C8OB 14290-F	C8OZ 14290-F
C5SB 14290-K	C5SZ 14290-T	C8SB 14290-A	C8SZ 14290-E
C5SB 14290-L	★C5SZ 14290-N	C8SB 14290-B	C8SZ 14290-E
C5SB 14290-M	★C5SZ 14290-R	C8SB 14290-C	C8SZ 14290-E
C5SB 14290-N	★C5SZ 14290-N	C8SB 14290-E	C8SZ 14290-E
C5SB 14290-R	★C5SZ 14290-R		
C5SB 14290-S	★C5SZ 14290-S	C8TB 14290-F	C8TZ 14290-AE
C5SB 14290-T	C5SZ 14290-T	C8TB 14290-K	C8TZ 14290-AE
C5ZB 14290-B	C5ZZ 14290-D	C8TB 14290-M	C8TZ 14290-AE
C5ZB 14290-D	C5ZZ 14290-C	C8TB 14290-Y	C8TZ 14290-AE
C5ZB 14290-E	C5ZZ 14290-C	C8TB 14290-AD	C8TZ 14290-AD
		C8TB 14290-AE	C8TZ 14290-AE
C6AB 14290-A	C6AZ 14290-A	C8ZB 14290-A	C8ZZ 14290-A
C6AB 14290-B	★C6AZ 14290-B	C8ZB 14290-B	★C8ZZ 14290-B
C6AB 14290-E	★C6AZ 14290-E	C8ZB 14290-C	C8ZZ 14290-C
C6AB 14290-H	C6AZ 14290-H	C8ZB 14290-D	C8ZZ 14290-D
C6AB 14290-J	★C6AZ 14290-J	C8ZB 14290-E	C8ZZ 14290-A
C6AB 14290-K	C6AZ 14290-A	C8ZB 14290-F	★C8ZZ 14290-B
C6OB 14290-A	C6OZ 14290-E	C8ZB 14290-G	C8ZZ 14290-C
C6OB 14290-B	★C6OZ 14290-F	C8ZB 14290-H	C8ZZ 14290-D
C6OB 14290-C	C6OZ 14290-E		
C6OB 14290-D	★C6OZ 14290-F	C9AB 14290-J	C9AZ 14290-A
C6SB 14290-A	★C6SZ 14290-E	ED-C9AB 14290-J	C9AZ 14290-A
C6SB 14290-B	C6SZ 14290-C	C9DB 14290-C	C9DZ 14290-A
C6SB 14290-C	C6SZ 14290-C	C9DB 14290-D	C9DZ 14290-A
C6SB 14290-E	★C6SZ 14290-E	C9DB 14290-E	C9DZ 14290-E
ED-C6SB 14290-F	C6SZ 14290-C	C9DB 14290-F	C9DZ 14290-F
C6TB 14290-A	C6TZ 14290-D	C9OB 14290-C	C9OZ 14290-A
C6TB 14290-D	C6TZ 14290-D	C9OB 14290-D	★C9OZ 14290-B
C6TB 14290-E	C6TZ 14290-E	C9OB 14290-E	C9OZ 14290-E
C6TB 14290-H	★C6TZ 14290-H	C9OB 14290-F	★C9OZ 14290-F
C6TB 14290-J	C6TZ 14290-J	C9OB 14290-G	C9OZ 14290-G
C6ZB 14290-A	C6ZZ 14290-A	C9OB 14290-H	C9OZ 14290-H
C6ZB 14290-B	C6ZZ 14290-B		
		C9SB 14290-C	C9SZ 14290-B
C7AB 14290-A	C7AZ 14290-A	C9SB 14290-D	C9SZ 14290-D
C7AB 14290-AD	C7ZZ 14290-AD	C9SB 14290-E	C9SZ 14290-E
C7OB 14290-A	C7OZ 14290-A	C9SB 14290-F	C9SZ 14290-F
C7OB 14290-C	C6OZ 14290-E	C9SB 14290-G	C9SZ 14290-E
C7OB 14290-D	C6OZ 14290-F	C9SB 14290-H	C9SZ 14290-F
C7SB 14290-D	C7SZ 14290-A	C9SB 14290-J	C9SZ 14290-F
C7SB 14290-F	C7SZ 14290-A	C9SB 14290-K	C9SZ 14290-E
C7SB 14290-G	C7SZ 14290-A	C9TB 14290-F	C9TZ 14290-A
C7TB 14290-H	C7TZ 14290-L	C9TB 14290-G	C9TZ 14290-B
C7TB 14290-K	C7TZ 14290-K	C9ZB 14290-H	C9ZZ 14290-R
C7TB 14290-L	C7TZ 14290-L	C9ZB 14290-J	C9ZZ 14290-S
C7ZB 14290-S	C7ZZ 14290-AG	ED-C9ZB 14290-K	C9ZZ 14290-R
C7ZB 14290-T	C7ZZ 14290-AD	ED-C9ZB 14290-L	C9ZZ 14290-S
C7ZB 14290-U	★C7ZZ 14290-AJ	C9ZB 14290-M	C9ZZ 14290-R
C7ZB 14290-V	C7ZZ 14290-AF	C9ZB 14290-N	C9ZZ 14290-S
C7ZB 14290-Y	C7ZZ 14290-AG	C9ZB 14290-R	C9ZZ 14290-R
C7ZB 14290-Z	C7ZZ 14290-AD	C9ZB 14290-S	C9ZZ 14290-S
C7ZB 14290-AB	C7ZZ 14290-AF		
C7ZB 14290-AC	C7ZZ 14290-AG	D0AB 14290-J	D0AZ 14290-L
C7ZB 14290-AD	C7ZZ 14290-AD	D0AB 14290-K	D0AZ 14290-A
C7ZB 14290-AE	★C7ZZ 14290-AJ	D0AB 14290-L	D0AZ 14290-L
C7ZB 14290-AF	C7ZZ 14290-AF	D0BB 14290-E	D0BZ 14290-A
		D0BB 14290-F	D0BZ 14290-B
		D0DB 14290-E	D0DZ 14290-F
C8AB 14290-A	C8AZ 14290-A	ED-D0DB 14290-E	D0DZ 14290-E
C8AB 14290-B	C8AZ 14290-A	ED-D0DB 14290-L	D0DZ 14290-J
C8AB 14290-C	C8AZ 14290-A	D0DB 14290-N	D0DZ 14290-N
C8DB 14290-A	C8DZ 14290-A	D0OB 14290-F	D0OZ 14290-A
C8DB 14290-B	C8DZ 14290-A	D0OB 14290-J	D0OZ 14290-A
C8DB 14290-C	C8DZ 14290-A	D0OB 14290-L	D0OZ 14290-L
C8DB 14290-D	C8DZ 14290-A	ED-D0OB 14290-L	D0OZ 14290-L
C8DB 14290-E	C8DZ 14290-A	ED-D0OB 14290-N	D0OZ 14290-L

LOOM MARKING OR TAG NUMBER		SERVICE WIRING PART NUMBER		LOOM MARKING OR TAG NUMBER		SERVICE WIRING PART NUMBER	
14290 WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION - continued							
D0SB 14290-F		D0SZ 14290-A		D2AB 14290-AB		D2AZ 14290-A	
D0SB 14290-G		D0SZ 14290-B		D2AB 14290-BB		D2AZ 14290-B	
D0SB 14290-H		D0SZ 14290-H		D2DB 14290-AC		D2DZ 14290-A	
D0SB 14290-J		D0SZ 14290-L		D2DB 14290-AD		D3DZ 14290-A	
D0SB 14290-K		D0SZ 14290-K		D2DB 14290-BC		D2DZ 14290-D	
D0SB 14290-L		D0SZ 14290-L		D2DB 14290-BD		D2DZ 14290-D	
D0ZB 14290-L		D0ZZ 14290-A		D2OB 14290-AF		D2OZ 14290-C	
D0ZB 14290-M		D0ZZ 14290-K		D2OB 14290-AG		D2OZ 14290-C	
D0ZB 14290-N		D0ZZ 14290-N		D2OB 14290-AH		D2OZ 14290-C	
				D2SB 14290-AF		D2SZ 14290-A	
DIAB 14290-AF		DIAZ 14290-A		ED-D2SB 14290-AH		D2SZ 14290-C	
DIAB 14290-AG		DIAZ 14290-A		D2SB 14290-AJ		D2SZ 14290-E	
DIAB 14290-AH		DIAZ 14290-A		D2SB 14290-BF		D2SZ 14290-B	
DIAB 14290-BH		DIAZ 14290-B		ED-D2SB 14290-BH		D2SZ 14290-D	
DIAB 14290-BJ		DIAZ 14290-B		D2SB 14290-BJ		D2SZ 14290-F	
DIAB 14290-BK		DIAZ 14290-B		D2ZB 14290-BB		D2ZZ 14290-B	
D1DB 14290-AC		D1DZ 14290-A		D2ZB 14290-BC		D2ZZ 14290-F	
D1DB 14290-AE		D1DZ 14290-A		D2ZB 14290-BD		D2ZZ 14290-K	
D1DB 14290-BC		D1DZ 14290-B		D2ZB 14290-CB		D2ZZ 14290-C	
D1DB 14290-BF		D1DZ 14290-B		D2ZB 14290-CC		D2ZZ 14290-G	
D1OB 14290-AF		D1OZ 14290-A		D2ZB 14290-CD		D2ZZ 14290-L	
D1OB 14290-AG		D1OZ 14290-A		D2ZB 14290-DB		D2ZZ 14290-D	
D1SB 14290-AC		D1SZ 14290-A		D2ZB 14290-DC		D2ZZ 14290-M	
D1SB 14290-BC		D1SZ 14290-B		D2ZB 14290-DD		D2ZZ 14290-M	
D1ZB 14290-AH		D1ZZ 14290-A		D2ZB 14290-EB		D2ZZ 14290-E	
D1ZB 14290-AJ		D1ZZ 14290-A		D2ZB 14290-EC		D2ZZ 14290-J	
ED-D1ZB 14290-AK		D1ZZ 14290-A		D2ZB 14290-ED		D2ZZ 14290-N	
D1ZB 14290-AL		D1ZZ 14290-A					
D1ZB 14290-BG		D1ZZ 14290-B		D22B 14290-AB		D2FZ 14290-A	
D1ZB 14290-BH		D1ZZ 14290-B		D22B 14290-AC		D2FZ 14290-D	
ED-D1ZB 14290-BJ		D1ZZ 14290-B		D22B 14290-AE		D2FZ 14290-D	
D1ZB 14290-BK		D1ZZ 14290-B		D22B 14290-AF		D2FZ 14290-G	
D1ZB 14290-CG		D1ZZ 14290-C		D22B 14290-AG		D2FZ 14290-G	
D1ZB 14290-CH		D1ZZ 14290-C		D22B 14290-BB		D2FZ 14290-B	
ED-D1ZB 14290-CJ		D1ZZ 14290-C		D22B 14290-BC		D2FZ 14290-E	
D1ZB 14290-CK		D1ZZ 14290-C		D22B 14290-BE		D2FZ 14290-E	
ED-D1ZB 14290-DH		D1ZZ 14290-D		D22B 14290-BF		D2FZ 14290-H	
D1ZB 14290-DK		D1ZZ 14290-D		D22B 14290-BG		D2FZ 14290-H	
D1ZB 14290-DL		D1ZZ 14290-D		D22B 14290-BH		D2FZ 14290-N	
				D22B 14290-CB		D2FZ 14290-C	
D12B 14290-AG		D1FZ 14290-A		D22B 14290-CC		D2FZ 14290-J	
D12B 14290-AH		D1FZ 14290-A		D22B 14290-CE		D2FZ 14290-J	
D12B 14290-AK		D1FZ 14290-A		D22B 14290-CF		D2FZ 14290-J	
ED-D12B 14290-AK		D1FZ 14290-A		D22B 14290-CG		D2FZ 14290-J	
ED-D12B 14290-AM		D1FZ 14290-A		D22B 14290-CH		D3FZ 14290-D	
ED-D12B 14290-BH		D1FZ 14290-E		D22B 14290-DB		D3FZ 14290-F	
D12B 14290-BJ		D1FZ 14290-E		D22B 14290-EB		D2FZ 14290-L	
D12B 14290-BL		D1FZ 14290-E		D22B 14290-EC		D2FZ 14290-P	
D12B 14290-BM		D1FZ 14290-E		ED1-D22B 14290-AB		D2FZ 14290-A	
ED-D12B 14290-BM		D1FZ 14290-E		ED1-D22B 14290-BB		D2FZ 14290-B	
ED-D12B 14290-BP		D1FZ 14290-E		ED1-D22B 14290-CB		D2FZ 14290-C	
D12B 14290-CG		D1FZ 14290-D					
ED-D12B 14290-CG		D1FZ 14290-D		D3DB 14290-AE		D3DZ 14290-A	
D12B 14290-CH		D1FZ 14290-D		ED-D32B 14290-AF		D3FZ 14290-A	
D12B 14290-CK		D1FZ 14290-D					
D12B 14290-CL		D1FZ 14290-D		S9MS 14L290-A		C9ZZ 14290-E	
ED-D12B 14290-CL		D1FZ 14290-D		C9ZX 15A211-A		C9ZZ 14290-E	
ED-D12B 14290-CN		D1FZ 14290-D					

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14290 WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION				
- A -				
65	A(except transistorized ignition)		1	C5AZ 14290-D
65	A-with transistorized ignition	Not replaced	1	★C5AZ 14290-E
66	A(8 cyl. 427) "Before 1/3/66"	Not replaced	1	★C6AZ 14290-B
66	A(8 cyl. 427) "From 1/3/66 to 2/1/66"	Not replaced	1	★C6AZ 14290-E
66	A(8 cyl.427) "From 2/1/66"	Not replaced	1	★C6AZ 14290-J

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14290 WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION - continued				
- A -				
66	A(except 8 cyl. 427)	"Before 2/1/66"	1	C6AZ 14290-A
66	A(except 8 cyl. 427)	"From 2/1/66"	1	C6AZ 14290-H
67	A		1	C7AZ 14290-A
68	A		1	C8AZ 14290-A
69	A		1	C9AZ 14290-A
70	A(except 54C, 57F, 63C, 65A, 71A, E, 76B)		1	D0AZ 14290-A
70	A(54C, 57F, 63C, 65A, 71A, E, 76B)		1	D0AZ 14290-L
71	A-without cornering lights		1	D1AZ 14290-A
71	A-with cornering lights		1	D1AZ 14290-B
72	A-without cornering lights		1	D2AZ 14290-A
72	A-with cornering lights		1	D2AZ 14290-B
- B -				
65	B-with 40 amp. Ford alternator		1	C5OZ 14290-A
65	B-with 52 amp. Ford or 53 amp. Leece-Neville alternator	Not replaced	1	★C5OZ 14290-B
65	B-with 52 amp. Ford or 53 amp. Leece-Neville alternator	Not replaced	1	★C5OZ 14290-E
66	B-except 53 amp. Leece-Neville alternator		1	C6OZ 14290-E
67	B(54, 62, 63B, C, 66, 71, 76B, C)-except with 53 amp. Leece-Neville alternator		1	
66/67	B-with 53 amp. Leece-Neville alternator	Not replaced	1	★C6OZ 14290-F
67	B(63D, 76D)-except with 53 amp Leece-Neville alternator		1	C7OZ 14290-A
68	B		1	C8OZ 14290-F
69	B(w/o intermittent wipers) "Before 11/18/68"		1	C9OZ 14290-A
69	B(w/o intermittent wipers)-		1	C9OZ 14290-E
	"From 11/18/68 to 4/1/69"			
69	B(w/o intermittent wipers) "From 4/1/69"		1	C9OZ 14290-G
69	B(with intermittent wipers) "Before 11/18/68"	Not replaced	1	★C9OZ 14290-B
69	B(with intermittent wipers)-	Not replaced	1	★C9OZ 14290-F
	"From 11/18/68 to 4/1/69"			
69	B(with intermittent wipers) "From 4/1/69"		1	C9OZ 14290-H
70	B	"Before 11/1/69"	1	D0OZ 14290-A
70	B	"From 11/1/69"	1	D0OZ 14290-L
71	B		1	D1OZ 14290-A
72	B		1	D2OZ 14290-C
- F -				
65	F-with generator		1	C5ZZ 14290-B
65	F(63A, 65A, C, 76A, C)-with alternator & charge or oil indicator warning lamps		1	C5ZZ 14290-C
65	F(63B, 65B, 76B)		1	C5ZZ 14290-D
65	F(63A, 65A, C, 76A, C)-8 cyl. -with ammeter & oil pressure gauges			
66	F	"Before 11/15/65"	1	C6ZZ 14290-A
66	F	"From 11/15/65"	1	C6ZZ 14290-B
67	F(exc. GT)-exc. w/tachometer		1	C7ZZ 14290-AG
67	F(except GT)-with tachometer		1	C7ZZ 14290-AD
67	F(GT 350/500)	Not replaced	1	★S7MS 14290-A
67	F(GT)-without tachometer	Not replaced	1	★C7ZZ 14290-AJ
67	F(GT)-with tachometer		1	C7ZZ 14290-AF
68	F(except GT)- without tachometer		1	C8ZZ 14290-A
68	F(except GT)-with tachometer	Not replaced	1	★C8ZZ 14290-B
68	F(GT, 65GT C/S). without tachometer		1	C8ZZ 14290-C
68	F(GT, 65GT C/S)-with tachometer		1	C8ZZ 14290-D
69	F-without tachometer		1	C9ZZ 14290-S
69	F-with tachometer		1	C9ZZ 14290-R
69	F(GT 350/500)	Instrument panel to fog lamp	1	C9ZZ 14290-E
70	F(except 63C)		1	D0ZZ 14290-A
70	F(63C)	"Before 10/15/69"	1	D0ZZ 14290-R
70	F(63C)	"From 10/15/69"	1	D0ZZ 14290-N

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14290 WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION - continued				
- F -				
71	F(63D)-8 cyl. 302-2V -w/o instrument pkg.- "Before 10/1/70"		1	D1ZZ 14290-B
71	F(65,76)-w/o instrument pkg.		1	
71	F(63D,65D,F,76D) exc. 8 cyl. 351 Boss eng. w/o instrument pkg., sports interior pkg. or special value pkg. "From 10/1/70"		1	
71	F(63D)-8 cyl. 302-2V -w/instrument pkg. -		1	D1ZZ 14290-C
71	F(65,76)-w/instrument pkg. "Before 10/1/70"		1	
71	F(63D,65D,F,76D) exc. 8 cyl. 351 Boss eng. - w/instrument pkg. or sports interior pkg.- "From 10/1/70"		1	
71	F(63D)-8 cyl. 302-4V -w/o instrument pkg. -		1	D1ZZ 14290-D
71	F(63R)-w/o instrument pkg. "Before 10/1/70"		1	
71	F(63D,65D) exc. 8 cyl. 351 Boss eng. - w/special value pkg.		1	
71	F(63R)-w/o instrument pkg. or sports interior pkg. "From 10/1/70"		1	
71	F(63D)-8 cyl. 302-4V -w/instrument pkg. - "Before 10/1/70"		1	D1ZZ 14290-A
71	F(63R)-w/instrument pkg.		1	
71	F(63D)-8 cyl. 351 Boss engine		1	
71	F(63R)-w/instrument pkg. or sports interior pkg. "From 10/1/70"		1	
72	F(63D,65D,F,76D)-except 8 cyl. 351 boss eng. w/o instrument pkg., sports interior pkg. or special value pkg. "Before 12/1/71"		1	D2ZZ 14290-C
72	F(63D,65D,76D)-exc. 8 cyl. 351 Boss engine w/o instrument pkg. sports interior pkg. or special valve pkg. "From 12/1/71"		1	D2ZZ 14290-L
72	F(63D,65D,F,76D)-with instrument package- "Before 12/1/71"		1	D2ZZ 14290-D
72	F(65D)-exc. 8 cyl. 351 Boss engine w/sports interior pkg. w/o instrument pkg. or special value pkg. "Before 12/1/71"		1	
72	F(63D,65D,F,76D)-w/instrument pkg. - "From 12/1/71"		1	D2ZZ 14290-M
72	F(65D)-exc. 8 cyl. 351 Boss engine w/sports interior pkg. w/o instrument pkg. or special valve pkg. "From 12/1/71"		1	
72	F(65D)-8 cyl. 351 Boss with instrument package or special value package "Before 12/1/71"		1	D2ZZ 14290-B
72	F(63D)-w/instrument pkg. or sports interior pkg. or special value pkg. "Before 12/1/71"		1	
72	F(63R) with instrument package or sports interior package "Before 12/1/71"		1	
72	F(76D)-with sports interior package and instrument package "Before 12/1/71"		1	
72	F(65D)-8 cyl. 351 Boss w/instrument pkg. or special valve pkg. "From 12/1/71"		1	D2ZZ 14290-K
72	F(63D)-w/instrument pkg. or sports interior pkg. or special valve pkg. "From 12/1/71"		1	
72	F(63R)-w/instrument pkg. or sports interior pkg. "From 12/1/71"		1	
72	F(76D)-w/sports interior pkg. & instrument pkg. "From 12/1/71"		1	
72	F(63D,R)-exc. 8 cyl. 351 Boss engine w/special value pkg. w/o instrument pkg. or sports interior pkg. "Before 12/1/71"		1	D2ZZ 14290-E
72	F(65D)-with special value package without instrument package "Before 12/1/71"		1	
72	F(76D)-with sports interior package- "Before 12/1/71"		1	

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14290 WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION - continued				
- F -				
72	F(63D,R)-exc. 8 cyl. 351 Boss engine w/special valve pkg. w/o instrument pkg. or sports interior pkg.	"From 12/1/71"	1	D2ZZ 14290-N
72	F(65D)-w/special valve pkg. w/o instrument pkg.	"From 12/1/71"	1	
72	F(76D)-w/sports interior pkg. -	"From 12/1/71"	1	
- L -				
71	L(4 cyl. 98)-w/o A/C		1	D1FZ 14290-D
71	L(4 cyl. 122)-without A/C		1	D1FZ 14290-A
71	L-with A/C		1	D1FZ 14290-E
72	L(4 cyl. 98)-w/o A/C	"Before 11/1/71"	1	D2FZ 14290-C
72	L(4 cyl. 98)-w/o A/C -	"From 11/1/71 to 7/3/72"	1	D2FZ 14290-J
72	L(4 cyl. 98)-w/o A/C	"From 7/3/72"	1	D3FZ 14290-A
72	L(4 cyl. 122)-w/o A/C	"Before 11/1/71"	1	D2FZ 14290-A
72	L(4 cyl. 122)-w/o A/C -	"From 11/1/71 to 1/3/72"	1	D2FZ 14290-D
72	L(4 cyl. 122)-w/o A/C	"From 1/3/72"	1	D2FZ 14290-G
72	L(4 cyl. 122)-w/A/C - "From 1/3/72 to 5/1/72"	With Non-emission	1	D2FZ 14290-H
72	L-with A/C	"Before 11/1/71"	1	D2FZ 14290-B
72	L-with A/C	"From 12/1/71 to 1/3/72"	1	D2FZ 14290-E
72	L(4 cyl. 122)-without A/C	Without Nox-emission	1	D3FZ 14290-F
72	L(4 cyl. 122)-with A/C	Without Nox-emission	1	D2FZ 14290-L
72	L(4 cyl. 122)-with A/C	With Nox-emission	1	D2FZ 14290-N
- P -				
70	P-w/o locking strg. col.	"Before 4/14/69"	1	D0DZ 14290-E
70	P-w/o locking steering column -	"From 4/14/69 to 8/1/69"	1	D0DZ 14290-F
70	P-w/o locking strg. col.	"From 8/1/69"	1	D0DZ 14290-J
70	P-with locking steering column		1	D0DZ 14290-N
71	P (except 62D)		1	D1DZ 14290-A
71	P(62D)		1	D1DZ 14290-B
72	P(54A, 62A)	Without grille lamps	1	D3DZ 14290-A
72	P(62D)		1	D2DZ 14290-D
72	P(54A, 62A)	With grille lamps	1	
- S -				
65	S(except A/C or transistorized ignition)	Not replaced	1	★C5SZ 14290-S
65	S-with A/C-except transistorized ignition		1	C5SZ 14290-T
65	S-with A/C & transistorized ignition	Not replaced	1	★C5SZ 14290-R
65	S(except A/C)-with transistorized ignition	Not replaced	1	★C5SZ 14290-N
66	S-except transistorized ignition	Not replaced	1	★C6SZ 14290-E
66	S-with transistorized ignition	Not replaced	1	★C6SZ 14290-C
67	S		1	C7SZ 14290-A
68	S		1	C8SZ 14290-E
69	S-without heated back lite	"Before 10/15/68"	1	C9SZ 14290-B
69	S-without heated back lite	"From 10/15/68"	1	C9SZ 14290-E
69	S-with heated back lite	"Before 10/15/68"	1	C9SZ 14290-D
69	S-with heated back lite	"From 10/15/68"	1	C9SZ 14290-F
70	S(except 65A, B-Fiera)	"Before 11/1/69"	1	D0SZ 14290-A
70	S(exc. 65A, B-Fiera)	"From 11/1/69 to 1/5/70"	1	D0SZ 14290-H
70	S(except 65A, B-Fiera)	"From 1/5/70"	1	D0SZ 14290-K
70	S(65A, B-Fiera)	"Before 1/5/70"	1	D0SZ 14290-B
70	S(65A, B-Fiera)	"From 1/5/70"	1	D0SZ 14290-L
71	S (exc. 65A, B-Fiera)		1	D1SZ 14290-A
71	S(65A, B-Fiera)		1	D1SZ 14290-B
72	S-without cornering lights		1	D2SZ 14290-E
72	S-with cornering lights		1	D2SZ 14290-F


YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14290 WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION - continued				
- U -				
66	U	"Before Ser.788,001"	1	C6TZ 14290-D
66	U	"From Ser.788,001 to 830,001"	1	C6TZ 14290-E
66	U-w/38 or 45 amp. alt.	"From Ser.830,001"	1	★C6TZ 14290-H
66	U-with 55 amp. alternator	Not replaced	1	C6TZ 14290-J
67	U-w/38 or 45 amp. alt.		1	C7TZ 14290-K
67	U-with 55 amp.		1	C7TZ 14290-L
68	U-with 38 or 42 amp. alt.		1	C8TZ 14290-AE
68	U-with 55 amp. alt.w/oil and ammeter gauges		1	C8TZ 14290-AD
69	U-except 55 amp. alternator		1	C9TZ 14290-A
69	U-with 55 amp. alternator		1	C9TZ 14290-B
70	U-with 55 amp. alt.	"Before Ser.H10,001"	1	D0BZ 14290-B
70	U-with 38 or 45 amp. alternator		1	D0BZ 14290-A
70	U-with 55 amp. alt.	"From Ser.H10,001"	1	
71/	U	Part of 14401		
- X -				
65	X(6 cyl.)		1	★C5DZ 14290-A
65	X(8 cyl.)		1	
66/67	X		1	C6OZ 14290-E
68	X		1	C8DZ 14290-A
69	X	"Before 4/1/69"	1	C9DZ 14290-A
69	X	"From 4/1/69"	1	C9DZ 14290-E
70	X		1	C9DZ 14290-F
65	A-with transistorized ignition	Nut (wiring to junction block)-No. 10-24	1	34053-S8(M156)
65/	A	Nut (wiring to L. H. front fender)	1	
		Lockwasher-No. 10	1	34803-S7(X60)
		Lockwasher-No. 10	2	34939-S8(X86)
65/	A	Clip (wiring to L. H. front fender)	1	358350-S(GG172)
		Flat washer-No. 10	1	44713-S8(X13)
65/67	A-with transistorized ignition	Nut (wiring to junction block)-1/4"-20	1	33795-S7(M49)
		Lockwasher-1/4"	1	34805-S8(X62)
70	A	Clip(attach wiring to front fender)	AR	383182-S(GG359)
65/	A,B,S	Adjustable strap (wire hold down)-Black Nylon	AR	376914-S(YY2)
65	F	Attach 14290 to fender shield and radiator	AR	
66/70	U	cross member		
65	B	Clip(wiring to accel. bar bracket on dash panel)	1	353547-S2(GG173)
70	B	Screw-1/4"-14 x 1/2" (attach wiring to fender	AR	55981-S(U254E)
66/70	U	apron)		
65/	A	Screw (wiring to radiator support)-No. 10-12 x 1/2"	2	42127-S8(U248)
65/	B	Screw(wiring to frt.fender apron & rad.support)	2	
66	B,X	Screw (wiring to front fender apron-front)	AR	
		376219-S to L. H. front fender apron)-		
65/	S	Screw (wiring, windshield wiper hose and clip	1	
65/	S(76)	Screw (377792-S or 376219-S) to R.H. front fender	3	
		apron)		
65/	S(63)	Screw (wiring and clip 376189-S or 376219-S to	5or6	
65/67	S(76)	R. H. & L. H. front fender apron)	2or3	
65/	S	Screw (wiring and clip 376219-S or 378904-S to	1or2	
		R. H. front fender extension)		
65/	S	Screw (wiring and clip 376189-S to L. H. front	2	
		fender extension)		
65/	S-with or without A/C electric windows or	Screw (wiring and clip 376189-S or 376219-S to	3or5	
	speed control device	dash panel)		
65/	S-with electric windows	Screw (wiring, front window regulator wiring and	1	
		clip 376219-S or 377722-S to dash panel)		
65/	S-with A/C	Screw (wiring, blower switch feed wiring and	1	
		clip 376219-S or 377722-S to dash panel)		
65/	S-with speed control device	Screw (wiring, speed control wiring and clip	1	
		376219-S to dash panel)		
65/	S	Screw (wiring and clip 376189-S, 376219-S or	1or2	
		377722-S to R.H. or L.H. rear of front fender apron)		
65/	S	Screw (wiring and rear lamp wiring or air	2or4	
		conditioner blower feed wire and clip 376189-S		
		or 377722-S to R. H. or L. H. front fender apron		
		cowl side upper member)		
		Lockwasher-No. 10	2	34939-S8(X86)

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14290	WIRE ASSY. - DASH PANEL TO HEADLAMP JUNCTION - continued			
70	F(63C)	Clip(attach wiring to radiator support)	AR	383207-S(GG271)
71	B,P,S	Attach wiring to fender side shield or radiator support	AR	
70	B	Rivet-1/4"(attach clip to front cross member)	AR	383142-S(SS45A)
65/	F	Nut (wiring and battery relay cable to starter solenoid)-5/16"-24	1	33798-S8(M62)
		Lockwasher-5/16"	1	34806-S7(X64)
70/	A,S	Screw-No.8-18 x 1/2" attach ground wire of 14290 to radiator support	AR	52012-S(U202)
65/	F	Lockwasher-1/4"	1	34940-S7(X88)
65/	F	Screw (wiring to radiator support)	1	31497-S8(U254)
68	F	Clip (attach wiring to cross member)	4	382350-S(GG300)
68	F	Clip (attach wiring to side cowl panel)	2	382184-S100
70	F, P		AR	(GG304)
70	F	Clip (attach wiring to front cross member)	AR	383104-S(GG300A)
70	P	Clip (attach wiring to front support)	AR	382931-S(GG338)
71	P,S	Clip (attach wiring to radiator support)	AR	
66/69	S	Clip (attach wiring to front fender)	AR	376188-S(GG147M)
70	P		AR	
70	P	Clip (attach wiring to radiator support)	AR	
70	P	Screw-No.8-15 x 1/2"(attach clip to frt.fender)	AR	52012-S(U202)
		Lockwasher-1/4"	1	34805-S8(X62)
65/	S	Clip-nylon	AR	376219-S(GG151)
65/	S-with transistorized ignition	Nut (wiring to junction block)-1/4"-20	1	33795-S7(M49)
66	S(except transistorized ignition)	Nut (wiring & fuse assy. to junction block)	1	
65/	S-with transistorized ignition	Nut (wiring to junction block)-No. 10-24	1	34053-S8(M156)
66	S(except transistorized ignition)	Nut (wiring & fuse assy. to junction block)	1	
		Lockwasher-No. 10	1	34803-S7(X60)
66	S	Screw (wiring & wiring assy. headlamp-leads & regulator assy. to extension front fender apron to radiator support)-No. 14-10 x 5/8"	1	31498-S8(U253B)
		Lockwasher-No. 10	1	34940-S7(X88)
67	U	Clip (attach wiring to dash panel)	1	376896-S(GG268)
14294	WIRE TERMINAL - KIT			
65/66	A, B, F, S, X, U		AR	C4AZ 14294-A
14294	TERMINAL - ELECTRIC WIRING - SOLDERLESS CRIMP - ON TYPE			
		Eyelet-No.10 stud-for No.16,18,20 & 22 gauge wire	AR	B9A 14294-A
		Eyelet-No.6 stud-for No.14 & 16 gauge wire	AR	B9A 14294-B
		Eyelet-No.10 stud-for No.14 & 16 gauge wire	AR	B9A 14294-C
		Eyelet-1/4" stud-for No.14 & 16 gauge wire	AR	B9A 14294-D
		Eyelet-No.10 stud-for 8 gauge wire	AR	C5AZ 14294-A
		Eyelet-No.10 stud-for No.10 & 12 gauge wire	AR	B9A 14294-F
		Eyelet-1/4" stud-for No.10 & 12 gauge wire	AR	B9A 14294-G
		Eyelet-3/8" stud-for No.10 & 12 gauge wire	AR	B9A 14294-H
		Faston tab-for No.14,16 gauge wire	AR	C5AZ 14294-C
		Snap on-male-for No.14,16 & 18 gauge wire	AR	B9A 14294-J
		Bullet type-(uninsulated bullet)-for No.14,16 & 18 gauge wire	AR	B9A 14294-K
		Snap on-female-for No.14,16 & 18 gauge wire	AR	B9A 14294-L
		Bullet type (insulated bullet)-for No.14 & 16 gauge wire	AR	B9A 14294-M
		Bullet type (insulated)-for No.14,16 gauge wire	AR	C5AZ 14294-B
		Eyelet-1/2" stud-for No.14,16 & 18 gauge wire	1	C5ZZ 14294-A
		Eyelet-3/8" stud-for No.14,16 & 18 gauge wire	1	C6OZ 14294-A
71	L	Eyelet No. 18 or 20 gauge wire	AR	D1FZ 14294-A
14296	WIRE - Also refer to Groups 12284 & 12286			
		Primary-No.8 gauge-50 ft. spool	AR	B3A 14296-A
		Primary-No.12 gauge-100 ft. spool	AR	B6A 14296-A
		Primary-No.14 gauge-100 ft. spool	AR	B6A 14296-B
		Primary-No.16 gauge-100 ft. spool	AR	B6A 14296-C
		High tension-No.16 gauge-100 ft. spool	AR	8A 14296-A
		Ignition 7MM 100 ft. spool	AR	8A 14296-B
		Plug wire-100 ft. spool	AR	D2PZ 14296-A

SECTION 140

FORD CAR PARTS

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14300 CABLE KIT - BATTERY BOOSTER				
65/	A, B, F, P, S, U, X	6 gauge-8 foot	1	C9PZ 14300-A
65/	A, B, F, P, S, U, X	6 gauge-12 foot	1	C9PZ 14300-B
14300 CABLE ASSY. - BATTERY UNIVERSAL TYPE				



P-9098

Battery cable terminals (battery end) are universal and may be used on either the positive or negative battery post. Battery cable length is determined by distance between hole centers.

LENGTH (inches)	WIRE GAUGE	IDENTIFICATION MARKING	SERVICE PART NUMBER	LENGTH (inches)	WIRE GAUGE	IDENTIFICATION MARKING	SERVICE PART NUMBER
10	4	D1PF 14300-AGA	D1PZ 14300-AG(WC-8118)	34	1	D1PF 14300-SA	D1PZ 14300-S(6341)
10	6	D1PF 14300-AA	D1PZ 14300-A(7106)	40	1	D1PF 14300-TA	D1PZ 14300-T(6401)
12.50	1	D1PF 14300-MA	D1PZ 14300-M(6121)	41	4	D1PF 14300-JA	D1PZ 14300-J(7414)
13	4	D1PF 14300-DA	D1PZ 14300-D(7134)	48	4	D1PF 14300-KA	D1PZ 14300-K(7484)
16	4	D1PF 14300-EA	D1PZ 14300-E(7164)	53	1	D1PF 14300-UA	D1PZ 14300-U(6531)
16.50	1	D1PF 14300-NA	D1PZ 14300-N(6161)	56	4	D1PF 14300-LA	D1PZ 14300-L(7564)
19	4	D1PF 14300-FA	D1PZ 14300-F(7194)	56	4	D2SF 14300-AC	D1PZ 14300-E(7164)
20	6	D1PF 14300-BA	D1PZ 14300-B(7206)	and D1PZ 14431-E(7514)			
21	1	D1PF 14300-PA	D1PZ 14300-P(6211)				
23	4	D1PF 14300-GA	D1PZ 14300-G(7234)	65	1	D1PF 14300-VA	D1PZ 14300-V(6651)
24	6	D1PF 14300-CA	D1PZ 14300-C(7246)	75	1	D1PF 14300-XA	D1PZ 14300-X(6751)
27	1	D1PF 14300-RA	D1PZ 14300-R(6271)	104	6	D1PF 14300-AFA	D1PZ 14300-AF(WC-8085)
30	4	D1PF 14300-HA	D1PZ 14300-H(7304)				

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
14300-1 CABLE ASSY. - BATTERY						
BATTERY TO STARTER RELAY						
65/70	A, B	6&8	All	Universal-10" long (6 gauge)	1	D1PZ 14300-A
66/70	X	6&8	All		1	(7106)
70/	P	6&8	All		1	
71/	A	6&8	240,302,390		1	
71	A	8	351		1	
72	A	8	351W		1	
71	B	6&8	250,302		1	
71/	L	4	All		1	
71/	U	6&8	All		1	
71/	F	6&8	250,302		1	
70	S	"Before 8/3/69"	8 All	Universal-56" long (4 gauge)	1	D1PZ 14300-L (7564)
65/70	F	6&8	All	Universal-13" long (4 gauge)	1	D1PZ 14300-D (7134)
67/69	S	8	All		1	
70/71	S	8	All	Battery to junction block on fender	1	
71	A	8	400,429		1	
71	B, F	8	351,429		1	
65	X	6&8	All	Universal-16" long (4 gauge)	1	D1PZ 14300-E (7164)
66	B	8	390		1	
72	B	6&8	All		1	
72	S-California	8	400	Battery to junction block on fender	1	
72	S	8	429,460	Battery to junction block on fender	1	
66/70	U	6&8	All		1	

FORD CAR PARTS

SECTION 140

25

YEAR	MODEL	CYL.	C.I.D.	DESCRIPTION	QTY.	PART NUMBER
14300-1 CABLE ASSY. - BATTERY - continued						
BATTERY TO STARTER RELAY - continued						
65/66	S	8	All	14.50" long	1	C4SZ 14300-A
72	A	8	351C, 400,429	Universal-10" long (4 gauge)	1	D1PZ 14300-AG (WC-8118)
72	F	8	351		1	
72	S-exc. California	8	400	Battery to junction block on fender	1	
69	B-with trunk mounted battery	8	428 CJ	206" long	1	C9OZ 14300-A (WC-8027)
65	F(GT-350)	8	All	186" long	1	S1MS 14300-A (WC-8024)
69	F-with trunk mounted battery	8	428 CJ	173" long	1	C9ZZ 14300-A (WC-8028)
69	F-Boss-with trunk mounted battery	8	429		1	
BATTERY TO GROUND						
65	X-exc. with A/C	6	All	Universal-16" long (4 gauge)	1	D1PZ 14300-E
65	B, F	6	All		1	(7164)
65	X-with A/C	6	All	23" long	1	D1PZ 14300-G
67/70	S	8	All		1	
65/66	S	8	All	Universal-30" long (4 gauge)	1	D1PZ 14300-H
66/71	A	6	All		1	(7304)
69/70	A	8	390,428		1	
69/	A	8	302,351		1	
69/	A	8	400		1	
69/	A	8	429		1	
65/66	B	8	All		1	
67/69	B-exc. with 70 amp. H/D battery	6&8	All		1	
70	B	6&8	All		1	
72	B	6&8	All		1	
66	F	6	All		1	
65/66	F	8	All		1	
72	S	8	400,429		1	
66/70	U	6	All		1	
65/70	X	6&8	All		1	
67/69	B-with 70 amp. H/D battery	6&8	All	Universal-41" long (4 gauge)	1	D1PZ 14300-J
67/69	F	6&8	All		1	(7414)
70/71	B	6&8	All	42" long	1	D0OZ 14301-D
70/	P	6&8	All		1	(WC-8041-A)
70	F	6&8	All		1	
70	F	8	428		1	
71	F	8	351,429		1	
72	F	6&8	All		1	
70/71	F	6	All	44" long	1	D0ZZ 14301-C
70	F	8	302,351		1	(WC-8048)
71	F	8	302		1	
67/70	U	8	All	Universal-24" long (6 gauge)	1	D1PZ 14300-C
71	A	8	390		1	(7246)
65	A	6&8	All		1	
67/71	S	8	429	Universal-23" long (4 gauge)	1	D1PZ 14300-G
						(7234)
71/	L	4	All	27 1/2" long	1	D1FZ 14301-B
						(WC-8082-A)
71/72	U	6&8	All	26" long	1	D2BZ 14301-A
						(WC-8122-A)
69	B, F-with trunk mounted battery	8	428 CJ	Universal-16 1/2" long (1 gauge)	1	D1PZ 14300-N
69	F-Boss-with trunk mounted battery	8	429		1	(WC-6161)
YEAR MODEL DESCRIPTION QTY. PART NUMBER						
65/	A, B, F, S, X			Bolt (cable to battery terminal)-5/16"-18 x 1 1/4"	2 or 4	23017-S16(B296)
				Nut-5/16"-18	2 or 4	33797-S16(M51)
				Nut (cable to starter relay terminal)-5/16"-24	1	33798-S8(M62)
				Lockwasher-5/16"	1 or 2	34806-S7(X64)
65/	A (8 cyl. 352, 390, 406), S			Bolt (ground cable to bracket)-3/8"-16 x 7/8"	1	20368-S8(B79)
65/	A (6 cyl.)			Bolt (cable to cylinder block)	1	

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14300-1 CABLE ASSY. - BATTERY - continued				
65/	A (8 cyl. 352, 390, 406)	Nut-3/8"-16	1	33799-S7(M52)
65/	F(6 cyl.)	(cable to engine head)	1	
65/	A,B(6 & 8 cyl.)	Lockwasher-3/8"	1	34807-S8(X66)
65/	A,B(8 cyl. 352, 390, 406), F(6 cyl.)	Lockwasher-3/8"	1	351487-S(XX291)
67/	A,B,F,X,U	Nut & washer (attach cable to solenoid)-5/16-18	1	381561-S36 (MM295AD)
65/	B(6 cyl.)-with A/C	Bolt(relay cable to compressor mounting bracket)-5/16"-18 x 1"	1	20386-S8(B53)
65/	B(6 cyl.)-with A/C, P(6 cyl.)	Nut-5/16"-18 (battery terminal)	1	33797-S6(M51)
		Flat washer-5/16"	1	44722-S8(X19)
71/	A	Bolt sq.hd. (attach cable to battery terminal)-1/4"-20 x 1 3/8"	1	383849-S2 (BB842G)
71/	A	Nut 1/4"-20	1	383848-S2 (MM30FX)
65/	A(8 cyl. 260, 289, 406, 427 Special)	Bolt (ground cable to cyl. block)-7/16"-14 x 7/8"	1	304668-S8(B100A)
65/70	X	Adjustable strap (ground cable to R. H. front suspension housing)-Nylon	1	376914-S(YY2)
65/	B,S(8 cyl.)		1	
66/	A, F		1	
70/	B, F	Attach cable to front fender apron	AR	
65/	B(8 cyl.)	Lockwasher-7/16"	1	★34943-S8
70	B, F, S	Screw (cable to ground)-1/4"-14 x 1/2"	1	55981-S(U254E)
70/	B, F, S	Bolt (cable to engine)-7/16"-14 x 7/8"	1	357450-S(BB172)
71	L	Attach cable to block	1	
71	A, B, U	Bolt (cable to block)-3/8"-16 x 1/2"	1	20312-S(B75)
71	A, B	Washer (cable to block)-3/8"	1	351487-S(XX291)
71/	B, F, L, P(6 cyl.)	Bolt (cable to block)-3/8"-16 x 1 1/8"	1	373162-S (BB563A)
66	B(6 cyl.), F(6 cyl.), X(6 cyl.)	Bolt (ground cable to engine)-3/8"-16 x 1/2"	1	20312-S7(B75)
70	P(6 cyl.)		1	
65/	B, X(6 cyl.)	Bolt (ground cable to engine)-5/16"-24 x 3/8"	1	★20303-S8
65/	B, X(6 cyl.)	Lockwasher-5/16"	1	★34941-S7
65/	F(8 cyl.)	Bolt(cable to cylinder block)-7/16"-14 x 3/4"	1	★20350-S7
		Lockwasher-7/16"	1	34808-S8(X67)
70	P	Bolt(cable to ground)-5/16"-18 x 1 1/4"	1	20426-S(BB55)
72	F		1	
65/66	S	Lockwasher-1/2"	1	★34944-S
65/66	S	Screw(cable to R. H. front side inner member)-5/16"-24 x 5/8"	1	359605-S8(BB590)
68	S			
71/	L	Nut & washer (attach cable to solenoid)-3/8"-16	1	382136-S (MM295AG)
		Screw & washer (attach 14301 to block)-M10 x 16 (metric coarse)	AR	N602568-S51M (AB67)
71/	L(122-2000 cc)	Bolt (attach cable to trans.washer)-M10 x 25MM	1	N602570-S51 (AB70)
			1	374222-S(XX348)
72	L(122-2000 cc)	Screw & washer (attach 14301 to engine)-M10 x 16MM	1	N602206-S51 (AB23)
14A301 BRACKET - RELAY MOUNTING				
71	A	Located on instrument panel lower flange	1	D1AZ 14A301-B
72	A		1	D2AZ 14A301-A
72	B	Used with visibility group	1	D2OZ 14A301-A
69/70	F	Used w/turn signal & emergency warning flasher	1	C9ZZ 14A301-A
70	F		1	D0ZZ 14A301-A
71	F	Located under instrument panel at glove compt. door	1	D1ZZ 14A301-A
72	F	"Before 6/15/72"	1	D2ZZ 14A301-A
72	F	"From 6/15/72"	1	D3ZZ 14A301-A
71	F	Nut-No. 8 spring (attach brkt. to instru. panel)	AR	382655-S(MM273D)
71	F	Screw-No.8-15 x 5/8"	AR	52554-S8(U230)
65/66	S		1	C5SZ 14A301-C
67	S	Not replaced	1	★C7SZ 14A301-B
72	S		1	D2SZ 14A301-A
65/66	S	Screw(brkt. to brake pedal suppt.)No.14-14 x 1/2"	2or4	31497-S8(U254)
		Washer(bracket to brake pedal support)-1/4"	2or4	34940-S(X88)
14A302 WIRING HARNESS & CIRCUIT BREAKER ASSY. - BODY MAIN - Refer to Group 14A005				

SECTION 140

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14303 CABLE ASSY. - DASH TO ENGINE GROUND				
65/67	A(8 cyl. 289)	13 1/2"-cut from B3A 14296-A wire	1	★FEV 14303-B
67	B(6 cyl.), X(6 cyl.)		1	
65/67	A(8 cyl. -except 289 & 427 8/B Special)	15 1/2" long-cut from B3A 14296-A wire	1	★FEV 14303-C
65	A(6 cyl.) "Before 12/14/64"		1	
65/67	A(6 cyl.) "From 12/14/64"	15 1/2" long-cut from B3A 14296-A wire	1	★C5AB 14303-A
65/67	A(8 cyl. 427 8/B Special)	10" long-use DIPZ 14431-A	1	★FDA 14303-A
65	X(6 cyl.)		1	
67/68	B(8 cyl. 289), X(8 cyl. 289), F(8 cyl. 289-2V & 4V)		1	
65/67	F(6 cyl.) "Before 1/9/67"		1	
66/67	F(8 cyl.)		1	
67/71	F(6 cyl.) "From 1/9/67"	12.0"-use DIPZ 14431-A	1	★C7ZB 14303-A
65/66	B(6 cyl.)	12.0" long-cut from B3A 14296-A wire	1	★FEV 14303-A
66	X(6 cyl.)		1	
68	B(6 & 8 cyl.), X(6 & 8 cyl.)		1	
65/66	B(8 cyl.), X(8 cyl.)	7 1/2" long-use DIPZ 14431-A	1	★FDD 14303-A
65	F(8 cyl.)		1	
67/69	B(8 cyl. 390 & 427)		1	
68	A, B, S, U, X	Dash to engine-use DIPZ 14431-A	1	★C1VF 14303-A
66/70	A, B, F, S, U	Dash to engine ground -12" long (4 gauges)	1	DIPZ 14303-A
65/70	A	Screw(ground strap to dash)-No. 14-14 x 1/2"	1	31497-S8(U254)
65/70	A, S, X	Lockwasher-1/4"	1	34940-S7(X88)
65/70	A(8 cyl.), X	Bolt(strap to intake manifold)-5/16"-18 x 1/2"	1	20310-S8(B48)
65/70	A(8 cyl.), X	Lockwasher-5/16"	1	34806-S7(X64)
71	A	Bolt(attach ground cable to block)-7/16"-14 x 1/2"	1	20314-S(B98)
71	A	Washer-7/16"	1	374222-S(XX348)

14305 WIRING ASSY. - GENERATOR OR ALTERNATOR TO VOLTAGE REGULATOR

WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE FOR 1965 and SUBSEQUENT MODELS

The purpose of this guide is to facilitate the identification of the Service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C4ZB 14305-A	★C5ZZ 14305-A	C6AB 14305-F	C6AZ 14305-F
C4ZB 14305-B	C5ZZ 14305-B	C6AB 14305-G	C6AZ 14305-G
		C6AB 14305-H	C6AZ 14305-H
C5AB 14305-A	C5AZ 14305-N	C6AB 14305-J	★C6AZ 14305-J
C5AB 14305-C	C5AZ 14305-N	C6AB 14305-K	★C6AZ 14305-K
C5AB 14305-H	C5AZ 14305-H	C6AB 14305-M	★C6AZ 14305-M
C5AB 14305-J	★C6AZ 14305-J	C6AB 14305-AL	C6AZ 14305-F
C5AB 14305-K	C5AZ 14305-F		
C5AB 14305-L	C5AZ 14305-N	C6OB 14305-A	C6OZ 14305-C
C5AB 14305-M	C5AZ 14305-N	C6OB 14305-B	C6OZ 14305-D
C5DB 14305-A	C5DZ 14305-A	C6OB 14305-C	C6OZ 14305-C
C5DB 14305-B	C5DZ 14305-B	C6OB 14305-D	C6OZ 14305-D
C5GB 14305-A	C5GY 14305-B	C6OB 14305-E	★C6OZ 14305-E
C5GB 14305-C	C5GY 14305-B	C6OB 14305-F	★C6OZ 14305-F
		C6OB 14305-G	C6OZ 14305-D
C6AB 14305-A	C5AZ 14305-N	C6OB 14305-H	C6OZ 14305-D
C6AB 14305-B	C5AZ 14305-P	C6OB 14305-J	C6OZ 14305-D
C6AB 14305-C	C5AZ 14305-N	C6OB 14305-K	C6OZ 14305-C
C6AB 14305-D	C5AZ 14305-P		
C6AB 14305-E	C6AZ 14305-E	C6SB 14305-A	C6SZ 14305-A

14305 WIRING ASSY. - GENERATOR OR ALTERNATOR TO VOLTAGE REGULATOR - continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C6TB 14305-AU	D0BZ 14305-A	C8ZB 14305-A	C7ZZ 14305-A
C6TB 14305-BD	C6TZ 14305-DL	C8ZB 14305-B	C7ZZ 14305-H
C6TB 14305-BT	C6TZ 14305-DL	C8ZB 14305-C	C7ZZ 14305-J
C6TB 14305-CD	D0BZ 14305-A	C8ZB 14305-F	C7ZZ 14305-H
C6TB 14305-CE	C6TZ 14305-DL	C8ZB 14305-E	C7ZZ 14305-J
C6TB 14305-CL	C6TZ 14305-DL		
C6ZB 14305-A	C6ZZ 14305-A	C9AB 14305-M	C9WY 14305-G
C6ZB 14305-B	C6ZZ 14305-B	C9AB 14305-S	C9AZ 14305-G
		C9AB 14305-U	C9AZ 14305-G
C7AB 14305-A	C7AZ 14305-B	C9AB 14305-V	C9AZ 14305-B
C7AB 14305-B	C7AZ 14305-B	C9AB 14305-Y	C9AZ 14305-B
C7AB 14305-C	C7AZ 14305-D	C9AB 14305-Z	C9AZ 14305-D
C7AB 14305-D	C7AZ 14305-D	C9AB 14305-AA	C9AZ 14305-D
C7AB 14305-E	C7AZ 14305-F	C9AB 14305-AB	C9AZ 14305-F
C7AB 14305-F	C7AZ 14305-F	C9AB 14305-AC	C9AZ 14305-F
C7AB 14305-K	C7AZ 14305-F	C9AB 14305-AD	C9AZ 14305-B
C7AB 14305-G	★C7AZ 14305-G	C9AB 14305-AF	C9AZ 14305-D
C7OB 14305-A	C7OZ 14305-L	C9AB 14305-AG	C9AZ 14305-D
C7OB 14305-B	C7OZ 14305-L	C9AB 14305-AH	C9AZ 14305-F
C7OB 14305-C	C7OZ 14305-K	C9AB 14305-AJ	C9AZ 14305-F
C7OB 14305-D	C7OZ 14305-K	C9AB 14305-AK	C9AZ 14305-G
C7OB 14305-E	C7OZ 14305-J	C9AB 14305-AL	C9AZ 14305-G
C7OB 14305-F	C7OZ 14305-J	C9AB 14305-AM	C9AZ 14305-H
C7SB 14305-A	C7SZ 14305-A	C9AB 14305-AN	C9AZ 14305-AR
C7TB 14305-AS	C6TZ 14305-BG	C9AB 14305-AR	C9AZ 14305-AR
C7TB 14305-AT	C6TZ 14305-DL	C9AB 14305-AS	C9AZ 14305-BH
C7ZB 14305-A	C7ZZ 14305-A	C9AB 14305-AT	C9AZ 14305-BH
C7ZB 14305-B	C7ZZ 14305-B	C9AB 14305-AU	C9AZ 14305-BC
C7ZB 14305-C	C7ZZ 14305-H	C9AB 14305-AV	C9AZ 14305-BC
C7ZB 14305-D	C7ZZ 14305-G	C9AB 14305-AY	C9AZ 14305-AY
C7ZB 14305-E	C7ZZ 14305-E	C9AB 14305-AZ	C9AZ 14305-BF
		C9AB 14305-BA	C9AZ 14305-BF
C8AB 14305-A	C8AZ 14305-B	C9AB 14305-BB	C9AZ 14305-BJ
C8AB 14305-B	C8AZ 14305-B	C9AB 14305-BC	C9AZ 14305-BC
C8AB 14305-C	C8AZ 14305-D	C9AB 14305-BD	C9AZ 14305-BC
C8AB 14305-D	C8AZ 14305-D	C9AB 14305-BE	C9AZ 14305-BF
C8AB 14305-E	C8AZ 14305-F	C9AB 14305-BF	C9AZ 14305-BF
C8AB 14305-F	C8AZ 14305-F	C9AB 14305-BG	C9AZ 14305-BH
C8AB 14305-G	C8AZ 14305-G	C9AB 14305-BH	C9AZ 14305-BH
C8AB 14305-K	★C8AZ 14305-K	C9AB 14305-BJ	C9AZ 14305-BJ
C8AB 14305-L	C8AZ 14305-B	C9AB 14305-BK	C9AZ 14305-BK
C8AB 14305-M	C8AZ 14305-B		
C8AB 14305-N	C8AZ 14305-D	C9OB 14305-A	C7OZ 14305-L
C8AB 14305-R	C8AZ 14305-D	C9OB 14305-B	C7OZ 14305-L
C8AB 14305-S	C8AZ 14305-F	C9OB 14305-C	C7OZ 14305-K
C8AB 14305-T	C8AZ 14305-F	C9OB 14305-D	C7OZ 14305-K
C8AB 14305-U	C8AZ 14305-G	C9OB 14305-E	C7OZ 14305-J
C8AB 14305-V	★C8AZ 14305-K	C9OB 14305-F	C7OZ 14305-L
C8AB 14305-Y	★C8AZ 14305-K	C9OB 14305-G	C7OZ 14305-L
C8AB 14305-AA	C8AZ 14305-F	C9OB 14305-H	C7OZ 14305-K
		C9OB 14305-J	C7OZ 14305-K
C8OB 14305-A	C7OZ 14305-J	C9OB 14305-K	C7OZ 14305-J
C8OB 14305-B	C7OZ 14305-J	C9OB 14305-L	C7OZ 14305-L
C8OB 14305-C	C7OZ 14305-L	C9OB 14305-M	C9OZ 14305-M
C8OB 14305-D	C7OZ 14305-L	C9OB 14305-N	C9OZ 14305-R
C8OB 14305-E	C7OZ 14305-K	C9OB 14305-R	C9OZ 14305-R
C8OB 14305-F	C7OZ 14305-K	C9OB 14305-S	C9OZ 14305-S
C8OB 14305-H	C7OZ 14305-J	C9SB 14305-A	C9SZ 14305-A
C8SB 14305-B	C8SZ 14305-B	C9SB 14305-B	C9SZ 14305-A
C8SB 14305-D	C8SZ 14305-B	C9SB 14305-C	C9SZ 14305-C
C8TB 14305-AE	D0BZ 14305-A	C9SB 14305-D	C9SZ 14305-A
C8TB 14305-AF	C6TZ 14305-DL	C9SB 14305-E	C9SZ 14305-C
C8TB 14305-BD	D0BZ 14305-A	C9TB 14305-N	C6TZ 14305-DL
C8TB 14305-BE	C6TZ 14305-DL	C9TB 14305-R	C6TZ 14305-DL
C8WB 14305-C	C7ZZ 14305-B	C9TB 14305-AF	C6TZ 14305-DL
C8WB 14305-D	C7ZZ 14305-E	C9TB 14305-AT	D0BZ 14305-A

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C9WB 14305-D	C9WY 14305-G	D2OB 14305-CC	D2OZ 14305-C
C9WB 14305-F	C9WY 14305-G	D2OB 14305-CD	D2OZ 14305-C
C9WB 14305-G	C9WY 14305-G	D2OB 14305-CG	D2OZ 14305-J
C9ZB 14305-J	C9ZZ 14305-S	ED-D2OB 14305-CG	D2OZ 14305-J
C9ZB 14305-K	C9ZZ 14305-S	D2OB 14305-CH	D2OZ 14305-L
C9ZB 14305-L	C9ZZ 14305-S	ED-D2OB 14305-CH	D2OZ 14305-L
C9ZB 14305-R	C9ZZ 14305-S	D2OB 14305-DE	D2OZ 14305-D
C9ZB 14305-S	C9ZZ 14305-S	D2OB 14305-DF	D2OZ 14305-D
		D2OB 14305-DG	D2OZ 14305-D
D0AB 14305-A	D0AZ 14305-A	ED-D2OB 14305-DG	D2OZ 14305-D
D0AB 14305-B	D0AZ 14305-P	D2OB 14305-DH	D2OZ 14305-N
D0AB 14305-D	D0AZ 14305-D	ED-D2OB 14305-DH	D2OZ 14305-N
D0AB 14305-E	D0AZ 14305-D		
D0AB 14305-F	D0AZ 14305-P	D2OB 14305-EE	D2OZ 14305-E
D0AB 14305-G	D0AZ 14305-P	D2OB 14305-EF	D2OZ 14305-E
D0AB 14305-M	D0AZ 14305-P	D2OB 14305-EG	D2OZ 14305-E
D0AB 14305-N	D0AZ 14305-P	D2OB 14305-EH	D2OZ 14305-E
D0AB 14305-P	D0AZ 14305-P	ED-D2OB 14305-EH	D2OZ 14305-E
D0AB 14305-R	D0AZ 14305-P	D2OB 14305-FA	D2OZ 14305-F
		D2OB 14305-FB	D2OZ 14305-F
D0BB 14305-A	D0BZ 14305-A	D2OB 14305-FC	D2OZ 14305-N
D0BB 14305-B	D0BZ 14305-C	ED-D2OB 14305-FC	D2OZ 14305-N
D0BB 14305-C	D0BZ 14305-C	D2OB 14305-GA	D2OZ 14305-G
D0DB 14305-B	D0DZ 14305-B	D2OB 14305-GB	D2OZ 14305-G
D0DB 14305-G	D0DZ 14305-H	D2OB 14305-GC	D2OZ 14305-M
D0DB 14305-H	D0DZ 14305-H	ED-D2OB 14305-GC	D2OZ 14305-M
D0DB 14305-J	D0DZ 14305-H	D2OB 14305-HA	D3OZ 14305-L
D0DB 14305-K	D0DZ 14305-H	ED-D2OB 14305-HA	D3OZ 14305-L
D0DB 14305-L	D0DZ 14305-M		
D0DB 14305-M	D0DZ 14305-M	D2ZB 14305-AA	D2ZZ 14305-C
D0WB 14305-B	D0WY 14305-A	D2ZB 14305-AB	D3DZ 14305-B(8 cyl.) or D3DZ 14305-D(6 cyl.)
D0WB 14305-C	D0WY 14305-C	D2ZB 14305-BA	D2ZZ 14305-B
D0ZB 14305-B	D0ZZ 14305-C	D2ZB 14305-BB	D2ZZ 14305-E
D0ZB 14305-G	D0ZZ 14305-C	D2ZB 14305-BC	D3ZZ 14305-E
D0ZB 14305-H	D0ZZ 14305-C	D2ZB 14305-CA	D2ZZ 14305-C
		D2ZB 14305-CB	D3DZ 14305-B(8 cyl.) or D3DZ 14305-D(6 cyl.)
D1AB 14305-BA	D1AZ 14305-D	D2ZB 14305-DA	D2ZZ 14305-H
D1AB 14305-CB	D1AZ 14305-D	D2ZB 14305-EA	D2ZZ 14305-G
D1AB 14305-CC	D1AZ 14305-D	D2ZB 14305-AA	D2FZ 14305-B
D1AB 14305-DB	D1AZ 14305-D	D2ZB 14305-AB	D2FZ 14305-B
D1AB 14305-DC	D1AZ 14305-D	D2ZB 14305-AC	D2FZ 14305-C
D1AB 14305-EB	D1AZ 14305-E	D2ZB 14305-BA	D2FZ 14305-D
D1AB 14305-EC	D1AZ 14305-E		
D1BB 14305-AB	D2BZ 14305-A	D3DB 14305-BC	D3DZ 14305-B
		D3DB 14305-DB	D3DZ 14305-D
D1OB 14305-AB	D1OZ 14305-B	D3OB 14305-AC	D3OZ 14305-A
D1OB 14305-AC	D1OZ 14305-B	D3OB 14305-AD	D3OZ 14305-A
D1OB 14305-BC	D1OZ 14305-B	D3OB 14305-BC	D3OZ 14305-B
D1ZB 14305-BC	D1ZZ 14305-B	D3OB 14305-BD	D3OZ 14305-B
D1ZB 14305-BD	D1ZZ 14305-B	D3OB 14305-CC	D3OZ 14305-C
D1ZB 14305-AB	D1FZ 14305-A	D3OB 14305-CD	D3OZ 14305-C
D12B 14305-AC	D1FZ 14305-A	D3OB 14305-HA	D2OZ 14305-N
		ED-D3OB 14305-HC	D3OZ 14305-H
D2AB 14305-CA	D2AZ 14305-H	D3OB 14305-JA	D2OZ 14305-M
D2AB 14305-CB	D2AZ 14305-H		
D2AB 14305-DA	D2AZ 14305-H	D3ZB 14305-AC	D3ZZ 14305-A
D2AB 14305-DB	D2AZ 14305-H	D3ZB 14305-BC	D3ZZ 14305-B
D2AB 14305-EA	D2AZ 14305-E	D3ZB 14305-CC	D3ZZ 14305-C
D2AB 14305-FA	D2AZ 14305-F	D3ZB 14305-AA	D2FZ 14305-C
D2AB 14305-GA	D2AZ 14305-G	D3ZB 14305-BA	D2FZ 14305-D
D2BB 14305-AA	D2BZ 14305-A		
D2OB 14305-AC	D3OZ 14305-L		
D2OB 14305-AD	D3OZ 14305-L		
D2OB 14305-AG	D3OZ 14305-L		
D2OB 14305-AH	D2OZ 14305-K		
ED-D2OB 14305-AH	D2OZ 14305-K		

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14305 WIRING ASSY. - GENERATOR OR ALTERNATOR TO VOLTAGE REGULATOR				
- A -				
65/66	A(6 cyl.)	"Before 2/1/66"	Used with 53 amp. Leece-Neville alternator	1 ★C5AZ 14305-E
66/67	A(6 cyl.)	"From 2/1/66"	Used with 53 amp. Leece-Neville alternator	1 ★C6AZ 14305-J
65/66	A(8 cyl.)	"Before 2/1/66"	Used with 53 amp. Leece-Neville alternator	1 C5AZ 14305-F
66/67	A(8 cyl.)	"From 2/1/66"	Used with 53 amp. Leece-Neville alternator	1 ★C6AZ 14305-K
65/66	A(8 cyl.)	"Before 2/1/66"	Used with 60 amp. Leece-Neville alternator	1 ★C5AZ 14305-H
66/67	A(8 cyl.)	"From 2/1/66"	Used with 60 amp. Leece-Neville alternator	1 ★C6AZ 14305-M
65/66	A(6 cyl.)	"Before 2/1/66"	Used with 42 or 55 amp. Ford alternator	1 C5AZ 14305-N
66	A(6 cyl.)	"From 2/1/66"	Used with 42 or 55 amp. Ford alternator	1 C6AZ 14305-E
65/66	A(8 cyl.)	"Before 2/1/66"	Used with 42 or 55 amp. Ford alternator	1 C5AZ 14305-P
66	A(8 cyl. 289)	"From 2/1/66"	Used with 42 or 55 amp. Ford alternator	1 C6AZ 14305-F
66	A(8 cyl. 352, 390, 427, 428)-except with A/C or T/E	"From 2/1/66"	Used with 42 or 55 amp. Ford alternator	1 C6AZ 14305-G
66	A(8 cyl. 352, 390, 427, 428)-with A/C or T/E-	"From 2/1/66"	Used with 42 or 55 amp. Ford alternator	1 C6AZ 14305-H
67	A(6 cyl.)		Used with 42 or 55 amp. Ford alternator	1 C7AZ 14305-B
67	A(8 cyl. 289)		Used with 42 or 55 amp. Ford alternator	1 C7AZ 14305-D
67	A(8 cyl. 390, 427, 428)		Used with 42 or 55 amp. Ford alternator	1 C7AZ 14305-F
67	A(8 cyl. 289, 390, 428)		Used with 65 amp. Ford alternator	1 ★C7AZ 14305-G
68	A(6 cyl.)		Use with 42 or 55 amp. Ford alternator	1 C8AZ 14305-B
68	A(8 cyl. 302)		Use with 42 or 55 amp. Ford alternator	1 C8AZ 14305-D
68	A(8 cyl. 390, 427, 428)		Use with 42 or 55 amp. Ford alternator	1 C8AZ 14305-F
68	A(8 cyl.)		Use with 65 amp. Ford alternator	1 C8AZ 14305-G
68	A(8 cyl.)		Use with 65 amp. Leece-Neville alternator	1 C8AZ 14305-K
69	A(6 cyl. 240)	"Before 11/15/68"	Use with 42 or 55 amp. Ford alternator	1 C9AZ 14305-B
69	A(6 cyl. 240)	"From 11/15/68 to 4/1/69"	Use with 42 or 55 amp. Ford alternator	1 C9AZ 14305-AR
69	A(6 cyl. 240)	"From 4/1/69"	Use with 42, 55 amp. Ford alternator	1 C9AZ 14305-BF
69	A(8 cyl. 302, 351)	"Before 2/3/69"	Use with 42 or 55 amp. Ford alternator	1 C9AZ 14305-D
69	A(8 cyl. 302, 351)	"From 2/3/69"	Use with 42, 55 amp. Ford alternator	1 C9AZ 14305-BH
69	A(8 cyl. 390, 428, 429)	"Before 2/3/69"	Use with 42 or 55 amp. Ford alternator	1 C9AZ 14305-F
69	A(8 cyl. 390, 428, 429)	"From 2/3/69"	Used with 42, 55 amp. Ford alternator	1 C9AZ 14305-BC
69	A(8 cyl.)	"Before 4/1/69"	Use with 65 amp. Ford alternator	1 C9AZ 14305-G
69	A(8 cyl.)	"From 4/1/69"	Use with 65 amp. Ford alternator	1 C9AZ 14305-BJ
69	A(8 cyl. exc. 302)	"Before 2/3/69"	Use w/65 amp. L/N alternator	1 C9AZ 14305-H
69	A(8 cyl. exc. 302)	"From 2/3/69"	Use w/65 amp. L/N alternator	1 C9AZ 14305-AY
70	A(6 cyl. 240)		Use with 42 or 55 amp. Ford alternator	1 D0AZ 14305-D
70	A(8 cyl.)		Use with 42 or 55 amp. Ford alternator	1 D0AZ 14305-P
70	A(8 cyl.)		Use with 65 amp. Leece-Neville alternator	1 C9AZ 14305-BK
70	A(8 cyl.)		Use with 65 amp. Ford alt.	1 D0AZ 14305-A
71	A(6 & 8 cyl.)		Use with 42, 55, 61 amp. Ford alternator	1 D1AZ 14305-D
71	A(8 cyl.)		Use with 70 amp. Ford alternator	1 D1AZ 14305-E
72	A(6 & 8 cyl. 240, 302, 351, 400)		Use with 42, 55 or 61 amp. Ford alternator	1 D2AZ 14305-H
72	A(8 cyl. 429)		Use with 42, 55 or 61 amp. Ford alternator	1 D2AZ 14305-G
72	A(8 cyl. 400)		Use with 70 amp. Ford alternator	1 D2AZ 14305-E
72	A(8 cyl. 429)		Use with 70 amp. Ford alternator	1 D2AZ 14305-F
- B -				
65	B(6 cyl.)		Used with 42, 52 amp. Ford alternator	1 ★C5OZ 14305-C
65	B(6 cyl.)			1 ★CC5OF 14305-A
65	B(6 cyl.)		Used with 53 amp. Leece-Neville alternator	1 ★C5OZ 14305-E
65	B(8 cyl.)		Used with 42, 52 amp. Ford alternator	1 C5OZ 14305-D
65	B(8 cyl.)		Used with 53 amp. Leece-Neville alternator	1 ★C5OZ 14305-F
66	B(6 cyl.)		Used with 42 or 52 amp. Ford alternator	1 C6OZ 14305-C
66	B(8 cyl.)		Used with 38 or 52 amp. Ford alternator	1 ★C6OZ 14305-D
66/67	B(6 cyl.)		Used with 53 amp. Leece-Neville alternator	1 ★C6OZ 14305-E
66/67	B(8 cyl.)		Used with 53 amp. Leece-Neville alternator	1 ★C6OZ 14305-F
67/69	B(6 cyl.)	"Before 4/1/69"	Used with 42 or 55 amp. alternator	1 C7OZ 14305-L
69	B(6 cyl.)	"From 4/1/69"	Used with 42, 55 amp. Ford alternator	1 C9OZ 14305-M
67/69	B(8 cyl. 390, 427, 428)	"Before 4/1/69"	Used with 42 or 55 amp. Ford alternator	1 C7OZ 14305-J
69	B(8 cyl. 390, 428)	"From 4/1/69"	Used with 42, 55 amp. Ford alternator	1 C9OZ 14305-S
67/69	B(8 cyl. 289, 302, 351)	"Before 4/1/69"	Used with 42 or 55 amp. Ford alternator	1 C7OZ 14305-K
69	B(8 cyl. 289, 302, 351)	"From 4/1/69"	Used with 42, 55 amp. Ford alternator	1 C9OZ 14305-R
70	B	"Before 4/15/70"	Used with 38, 42, 55 amp. Ford alternator	1 D0DZ 14305-H
70	B	"From 4/15/70"	Used with 38, 42, 55 amp. Ford alternator	1 D0DZ 14305-M
71	B		Use with 38, 42, 55, 61 amp. Ford alt.	1 D1OZ 14305-B

★ Canada only

* Tape and insulate unused leads

☆ U. S. only

SECTION 140

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14305 WIRING ASSY. - GENERATOR OR ALTERNATOR TO VOLTAGE REGULATOR - continued				
- B -				
72	B(exc.63 w/heated backlite)-w/Rallye instrument cluster "Before 11/1/71"	Use with 42, 55, 61 amp. Ford alternator	1	D2OZ 14305-C
72	B(exc.63 w/heated backlite)-w/Rallye instrument cluster "From 11/1/71 to 1/3/72"	Use with 42, 55, 61 amp. Ford alternator	1	D2OZ 14305-J
72	B(exc.63 w/heated backlite)-w/o Rallye instrument cluster "Before 1/3/72"	Use with 42, 55, 61 amp. Ford alternator	1	D3OZ 14305-L
72	B(63-w/heated backlite)-w/o Rallye instrument cluster "Before 1/3/72"		1	D2OZ 14305-D
72	B(63-w/heated backlite)-w/Rallye instrument cluster "Before 1/3/72"		1	D2OZ 14305-E
72	B-w/o Rallye instrument cluster - "Before 1/3/72"	Use with 70 amp. Ford alternator	1	D2OZ 14305-F
72	B-w/Rallye instrument cluster - "Before 1/3/72"	Use with 70 amp. Ford alternator	1	D2OZ 14305-G
72	B(exc. P/C & Taxi)-6 & 8 cyl. 302, 351-2V, 400, 429-w/o Rallye instrument cluster- "From 1/3/72 to 7/3/72"	Use with 42 amp. Ford alternator	1	D2OZ 14305-K
72	B(exc. P/C & Taxi)-6 & 8 cyl. 302, 351-2V, 400, 429-w/o Rallye instrument cluster- "From 7/3/72"	Use with 42 amp. Ford alternator	1	D3OZ 14305-A
72	B(exc. P/C & Taxi)-8 cyl. 302, 351-2V, 400, 429-with Rallye instrument cluster- "From 1/3/72 to 7/3/72"	Use with 42 amp. Ford alternator	1	D2OZ 14305-L
72	B(exc. P/C & Taxi)-8 cyl. -w/o A/C, heated backlite or trailer towing pkg. --with Rallye instrument cluster- "From 1/3/72 to 7/3/72"	Use with 55 amp. Ford alternator	1	
72	B(exc. P/C & Taxi)-8 cyl. 302, 351-2V, 400, 429 with Rallye instrument cluster- "From 7/3/72"	Use with 42 amp. Ford alternator	1	D3OZ 14305-C
72	B(exc. P/C & Taxi)-8 cyl. w/o A/C, heated backlite or trailer towing pkg. with Rallye instrument cluster- "From 7/3/72"	Use with 55 amp. Ford alternator	1	
72	B(exc. P/C & Taxi)-6 & 8 cyl. 302, 351-2V, 400, 429 with A/C and/or trailer towing pkg. --w/o Rallye instrument cluster- "From 1/3/72 to 7/3/72"	Use with 55 amp. Ford alternator	1	D3OZ 14305-L
72	B(8 cyl. 351-4V CJ)-w/o A/C, heated backlite, or trailer towing pkg. --w/o Rallye instrument cluster "From 1/3/72 to 7/3/72"	Use with 55 amp. Ford alternator	1	
72	B(exc. P/C & Taxi)-6 & 8 cyl. 302, 351-2V, 400, 429 w/A/C and/or trailer towing pkg. w/o Rallye instrument cluster "From 7/3/72"	Use with 55 amp. Ford alternator	1	D3OZ 14305-B
72	B(8 cyl. 351-4V CJ)-w/o A/C, heated backlite or trailer towing pkg. w/o Rallye instrument cluster "From 7/3/72"	Use with 55 amp. Ford alternator	1	
72	B(P/C & Taxi)-6 & 8 cyl. 302, 429--w/o Rallye instrument cluster-"From 1/3/72 to 7/3/72"	Use with 61 or 70 amp. Ford alternator	1	D2OZ 14305-N
72	B(8 cyl.)--w/o Rallye instrument cluster- "From 1/3/72 to 7/3/72"	Use with 70 amp. Ford alternator	1	
72	B(8 cyl. 302, 351-2V, 400)-w/o Rallye instrument cluster "From 7/3/72"	Use with 70 amp. Ford alternator	1	D3OZ 14305-D
72	B(8 cyl. 302, 351-2V, 400, 429)--with Rallye instrument cluster-"From 1/3/72 to 7/3/72"	Use with 70 amp. Ford alternator	1	D2OZ 14305-M
72	B(8 cyl. 302, 351-2V, 400, 429)-with Rallye instrument cluster "From 7/3/72"	Use with 70 amp. Ford alternator	1	D3OZ 14305-E
- F -				
65	F(6 cyl.)-with generator		1	★C5ZZ 14305-A
65	F(8 cyl.)-with generator		1	C5ZZ 14305-B
65	F(6 cyl.)-with alternator-except luxury trim		1	C5DZ 14305-A
65	F(8 cyl.)-with alternator-except luxury trim		1	C5DZ 14305-B
65	F(6 & 8 cyl.)-with luxury trim		1	ΔC5GY 14305-B

Δ Fold & tape excess wiring when using on units with 6 cylinder engines

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14305 WIRING ASSY. - GENERATOR OR ALTERNATOR TO VOLTAGE REGULATOR - continued				
- F -				
66	F(6 cyl.)		1	C6ZZ 14305-A
66	F(8 cyl.)	Heavy duty wiring	1	C6ZZ 14305-B
67/68	F(6 cyl.)		1	C7ZZ 14305-A
67	F(8 cyl. 289)-without tachometer		1	C7ZZ 14305-B
68	F(289,302)-without tachometer		1	
67	F(8 cyl. 289)-with tachometer		1	C7ZZ 14305-E
68	F(289,302)-with tachometer		1	
67/68	F(8 cyl. 390,427,428)-without tachometer		1	C7ZZ 14305-H
67/68	F(8 cyl. 390,427,428)-with tachometer		1	C7ZZ 14305-J
69	F(8 cyl. 302,351,390,428)-with tachometer		1	C9WY 14305-G
69	F-6 cyl., Boss(8 cyl.429)-with tachometer		1	
69	F(8 cyl. 302,351,390,428)-without tachometer		1	C9ZZ 14305-S
69	F-Boss (8 cyl.429)-without tachometer		1	
70	F(8 cyl.302-2V,351-2V,4V,428-4V CJ)- "Before 5/15/70"	With tachometer	1	D0WY 14305-A
70	F(8 cyl.302-2V,351-2V,4V,428-4V CJ)- "From 5/15/70"	With tachometer	1	D0WY 14305-C
70	F(6 & 8 cyl.)	Without tachometer	1	D0ZZ 14305-C
71	F(63D,65,76)-w/o instrument group - "Before 10/1/70"		1	D1OZ 14305-B
71	F(63R)-w/o instrument pkg.-"From 10/1/70"		1	
71	F(63R) "Before 10/1/70"		1	D1ZZ 14305-B
71	F(63D,65,76)-with instrument pkg.- "Before 10/1/70"		1	
71	F(63D,R,65D,F,76D)-with instrument pkg.- "From 10/1/70"		1	
71	F(63D,R)-with sports interior pkg.- "From 10/1/70"		1	
71	F(63D)-with 8 cyl. 351 Boss engine- "From 10/1/70"		1	
72	F-with instrument pkg. "Before 12/1/71"		1	D2ZZ 14305-B
72	F-with instrument pkg. - "From 12/1/71 to 1/3/72"	Use with 38,42,55,61 amp. Ford alternator	1	D2ZZ 14305-E
72	F-with instrument pkg. "From 1/3/72"	Use with 38,42,55,61 amp. Ford alternator	1	D3ZZ 14305-E
72	F-without instrument pkg. "Before 12/1/71"	Use with 38,42,55,61 amp. Ford alternator	1	D2ZZ 14305-C
72	F(8 cyl.)-without instrument pkg.- "From 12/1/71"	Use with 38,42,55,61 amp. Ford alternator	1	D3DZ 14305-B
72	F(6 cyl.)-without instrument pkg. - "From 12/1/71"	Use with 38,42,55,61 amp. Ford alternator	1	D3DZ 14305-D
72	F-without instrument pkg. "Before 7/3/72"	Use with 70 amp. Ford alternator	1	D2ZZ 14305-G
72	F-without instrument pkg. "From 7/3/72"	Use with 70 amp. Ford alternator	1	D3ZZ 14305-C
72	F-with instrument pkg. "Before 7/3/72"	Use with 70 amp. Ford alternator	1	D2ZZ 14305-H
72	F-with instrument pkg. "From 7/3/72"	Use with 70 amp. Ford alternator	1	D3ZZ 14305-B
- L -				
71/72	L(122-2000cc) "Before 12/1/71"		1	D1FZ 14305-A
72	L(122-2000cc) "Before 12/1/71 to 7/3/72"		1	D2FZ 14305-B
72	L(4 cyl. 122)-with A/C and heated backlite- "From 7/3/72"		1	D2FZ 14305-C
72	L(4 cyl. 122)-without A/C or heated backlite- "From 7/3/72"		1	D2FZ 14305-D
- P -				
70	P "Before 7/28/69"		1	D0DZ 14305-B
70	P "From 7/28/69 to 4/15/70"	Use with 38,42 or 55 amp. Ford alternator	1	D0DZ 14305-H
70	P "From 4/15/70"	Use with 38,42,55 amp. Ford alternator	1	D0DZ 14305-M
71	P "From 4/15/70"	Use with 38,42,61 amp. Ford alternator	1	D1OZ 14305-B
72	P "Before 12/1/71"		1	D2ZZ 14305-C
72	P(6 cyl. 250) "From 12/1/71"		1	D3DZ 14305-D
72	P(8 cyl. 302) "From 12/1/71"		1	D3DZ 14305-B
- S -				
65	S-without A/C	Not replaced	1	★C5SZ 14305-A
65	S-with A/C		1	C5SZ 14305-B
66	S		1	C6SZ 14305-A

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14305	WIRING ASSY. - GENERATOR OR ALTERNATOR TO VOLTAGE REGULATOR - continued			
	- S -			
67	S		1	C7SZ 14305-A
68	S(390, 429)-with or without A/C		1	C8SZ 14305-B
69	S-without heated back lite		1	C9SZ 14305-A
69	S-with heated back lite		1	C9SZ 14305-C
	- U -			
66/70	U	Used with 38, 45 or 55 amp. Ford alternator	1	D0BZ 14305-C
71/72	U	Used with 38, 45 or 55 amp. Ford alternator	1	D2BZ 14305-A
	- X -			
65	X(6 cyl.)		1	☆ C5DZ 14305-A
65	X(6 cyl.)		1	★ CC5DF 14305-A
65	X(8 cyl.)		1	C5DZ 14305-B
66	X(6 cyl.)	Used with 42 amp. Ford alt.	1	C6OZ 14305-C
66	X(8 cyl.)		1	C6OZ 14305-D
67/68	X(6 cyl.)	Used with 42 or 55 amp. Ford alternator	1	C7OZ 14305-B
69	X(6 cyl.) "Before 4/1/69"	Used with 42, 55 amp. Ford alternator	1	C7OZ 14305-L
69/70	X(6 cyl.) "From 4/1/69"	Used with 42, 55 amp. Ford alternator	1	C9OZ 14305-M
67/69	X(8 cyl.) "Before 4/1/69"	Used with 42, 55 amp. Ford alternator	1	C7OZ 14305-K
69/70	X(8 cyl.) "From 4/1/69"	Used with 42, 55 amp. Ford alternator	1	C9OZ 14305-R
65/	A	Nut -1/4" -20	AR	33795-S7(M49)
65/	A, F	Lockwasher-1/4"	AR	34805-S8(X62)
65/	A-with P/S	Clip(alternator wiring to frt. frame cross member)	1	372046-S100 (GG186)
65/	A (6 cyl.)	Screw(alternator wiring to engine)-3/8"-16 x 3/4"	1	43265-S8(U16)
65/	A, U	Strap (alternator wiring to front frame cross member or L.H. front fender apron)	AR	376914-S(Y2)
65/	S	Strap (alternator wiring to R.H. front fender apron, rad. support or frt. frame cross member)	AR	
65/70	X	Clip (attach alternator wiring to stud)	AR	382963-S100
65/	B, F	Clip (attach 14305 to 10346)	1	(GG213J)
69	A, B, F, S, U, X	Clip (attach wire to fender apron)	1	382931-S(GG338)
70	P, B, S	Clip (wiring to alternator)	1	356628-S(GG175)
70	P	Screw (wiring and generator regulator to radiator support)-No. 14-14 x 3/4"	1	42143-S8(U255)
65	B-with 53 amp. alternator	Lockwasher-1/4"	2	34940-S8(X88)
65	F	Nut (wiring to alternator)-No. 10-32	1	34079-S8(M163)
65	F	Nut (wiring to alternator)-1/4"-28	1	34081-S7(M164)
65/	F	Lockwasher-No.10	1	34803-S36(X60)
65/	S	Screw (wiring & clip 376189-S or 376219-S to L. H. fender apron front fender apron & radiator support or to R.H. & L.H. front susp. lower arm strut mtg. brkt. reinforcement)-No.10-12 x 1/2"	AR	42127-S8(U248C)
68	B, X(427, 428)	Clip(attach wiring to front fender)	AR	383207-S(GG271)
71	F	Nut No. 10-24 (attach wiring to alternator)	AR	383255-S (MM296AC)
71	A, B, F, L, P, U	Nut 1/4"-20 (attach wiring to alternator)	AR	383256-S (MM296AE)
71	A, B, F, L, P	Clip	AR	376219-S(GG151)
65/	S	Bolt (wiring to engine)-3/8"-16 x 1/2"	1	20312-S7-S(B75)
68	B(390, 427, 428)	Bolt (wiring to engine)	1	
65/70	X(6 cyl.)		1	
66	B(6 cyl.)		1	
68	F(428)		1	
	14A307 INSERT - WINDOW REGULATOR MULTIPLE SWITCH HOUSING			
65	S-except with power vent windows	Aluminum-applique ("lettering-LF-RF-LR-RR")	1	C4SZ 14A307-A
66	S(63A, 76)-except with power vent windows	Aluminum-applique ("lettering-LV-RV-LF-RF-LR-RR")	1	C5SZ 14A307-A
65	S-with power vent windows	Chrome -die casting	1	C6SZ 14A307-A
66	S(63A, 76)-with power vent windows	Aluminum-applique ("lettering-LV-RV-LF-RF")	1	C6SZ 14A307-B
66	S(63C)-with power vent windows			
66	S(63C)-with power vent windows			
	14A309 SHELL - WIRE CONNECTOR			
65/	A, B, F, S, U, X	Black nylon-male	AR	C6AZ 14A309-A
70/	P	Black nylon-female	AR	C6AZ 14A309-B
65/	A, B, F, S, U, X	Nylon-female-used in 14A005 body main wiring assy.-not replaced	AR	★ C7AZ 14A309-B
67	A			

★ Canada only

☆ U. S. only

May, 1975

COPYRIGHT © 1975 -

FORD MOTOR
COMPANY

- DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A309 SHELL - WIRE CONNECTOR - continued				
67/72	A	Nylon-female mates with C6AZ 14A309-A or D0AZ 14A309-A	AR	C7AZ 14A309-A
	B		AR	
68/69/71	A, B, S, X B, X	Nylon-used in 14A005-body main wiring assy. Used in 14290 wiring to brake switch	1	C8AZ 14A309-A
69/71	A	Brass	1	C9AZ 14A309-D
	F		1	
69/71	A	Nylon (round male)-(1) 12 gauge wire	AR	C9AZ 14A309-B
	A	Nylon (round female)-(1) 12 gauge wire	AR	C9AZ 14A309-C
	A	Nylon connects to windshield wiper switch	1	C9AZ 14A309-A
70/72	A	Nylon-female	AR	D0AZ 14A309-A
	B	Nylon	AR	C7OZ 14A309-A
	L		1	
70/72	P		AR	D3AZ 14A309-C
	S-with sun roof		1	
72	A, B, S	Nylon attaches 14401 to 17A553	1	D2AZ 14A309-A
14313 WIRE ASSY. - IGNITION FEED				
68/69/70	A, B, F, S, U, X P (non-locking column)	Replacement wiring and connector	1 1	C9AZ 14313-A
14A313 WIRING ASSY. - SEAT BELT WARNING INDICATOR LAMP - Unless listed, improvise from B6A 14296-C wire				
65/66	S		1	C5SZ 14A313-C
66	B, X	"Before 11/15/65" Improvise-cut from B6A 14296-C bulk wire	1	★
66/67	B, X	"From 11/15/65" #C6OB 14A313-D-not replaced	1	★C6OZ 14A313-A
66	F	"Before 11/15/65" Improvise-cut from B6A 14296-C bulk wire	1	★
66	F	"From 11/15/65" #C6ZB 14A313-D-not replaced	1	★C6ZZ 14A313-A
72	P(manual trans.)	Extension-#D2DB 14A515-AA	1	D2DZ 14A313-A
14A317 CASE - WINDOW REGULATOR SWITCH				
66	S(63C)-with power windows		1	C6SZ 14A317-A
14A318 WIRE ASSY. - ACCESSORY FEED - Unless listed, improvise from B6A 14296-C wire				
68/69/70/71/65/66/70/71	A, Taxi, P/C, E, X(with A/C and spot light, rear lite power windows, defogger) F P A, B, L B(54, 62, 71), F, X A, B, P F	#C8OB 14A318-A, C9ZB 14A318-A Seat belt, parking brake warning, swing away steering column, speed control, rear window defogger 15" long Nut-No.8-32 (attach wire to 14A033 post) Clip(attach wire to inst. panel)	1 1 1 1 1 AR	C9ZZ 14A318-A C5DZ 14A318-A 34653-S(M106X) 383207-S(GG271)
14322 HOSE ASSY. - OIL PRESSURE SENDING				
65/66	F(GT350)	Used with 80 pound gauge	1	S1MS 14322-B
14A323 BRACKET ASSY. - RELAY MOUNTING				
65/66	A-with safety package		1	C5AZ 14A323-C
65/66	A	Screw No.8-18 x 3/4" attach bracket to inst. panel	1	376389-S(UU82D)
14334 WIRE ASSY. - INTERIOR LAMP FEED - Improvise from B6A 14296-C wire - Also refer to Group 13A709				
65	X(63)	Clip (wiring to mounting support and bracket)	AR	356687-S32(GG28)
65	X(63)	Clip (wiring to roof side inner rear lower rail)	1	372046-S100
65	X	Clip (wiring to L.H. pillar & cowl side assy. front body)	1	
14A346 WIRE ASSY. - TRAILER BATTERY FEED				
71/72/72/72	A A S S	#D1AB 14A346-AA #D2AB 14A346-AB "Before 11/1/71" #D2SB 14A346-AA "From 11/1/71" #D2SB 14A346-AB, AC, AD, AE	1 1 1 1	D1AZ 14A346-A D2AZ 14A346-A D2SZ 14A346-A D2SZ 14A346-B
14A347 TRAILER WIRING CONNECTOR KIT				
67/70/	A, B, F, S, X P		1 1	C7AZ 14A347-A
Consists of				
1-C6RA 13A496-A Bracket		2-34656-S	Nut & washer	2-36822-S Bolt
1-C8PJ 14487-A Connector assy.		2-34657-S	Nut & washer	2-44713-S Washer
2-20324-S Bolt				
14A348 WIRE ASSY. - TRAILER BRAKE CONTROL SWITCH				
71/72	A A, B, S	#D1AB 14A348-A #D2AB 14A348-BA	1 1	D1AZ 14A348-A D2AZ 14A348-B
14A352 BRACKET ASSY. - WINDOW REGULATOR WIRING				
66/71/66/69/66/70	B(71)-with power back window A(71)-with power back window X(71)-with power back window		1 1 1	C6AZ 14A352-A

Identification marking

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A353 SEAL - TAIL GATE WINDOW REGULATOR SWITCH				
65/	A(71), B(71), X(71)-with power back window		1	C5AZ 14A353-E
14A390 COVER - WIRING SHIELD				
68/71	S	57" long-attaches to front floor pan	1	C8SZ 14A390-A
72	S	R.H.-with power seats or power windows L.H.	1	D2LY 14A390-A
72	B	R.H. & L.H. with power windows located in front door	2	D2OZ 14A390-A
72	S	Plastic located on dash panel at cowl side panel mates with D2SZ 14A099-E	1	D2SZ 14A390-A
72	S	Plastic located at front floor cross member mates with D2SZ 14A099-F	1	D2SZ 14A390-B
72	S	Plastic located at front floor cross member mates with D2SZ 14A099-G	1	D2SZ 14A390-C

14398 WIRING ASSY.- DASH PANEL TO ENGINE

WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE FOR 1965 and SUBSEQUENT MODELS

The purpose of this guide is to facilitate the identification of the service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM WIRING OR TAG NUMBER	SERVICE MARKING PART NUMBER
C7AB 14398-F	C7AZ 14398-D	D2OB 14398-KD	D2OZ 14398-C
C7AB 14398-G	★C7AZ 14398-L	D2OB 14398-KE	D2OZ 14398-C
C7AB 14398-H	★C7AZ 14398-H	D2OB 14398-LD	D2OZ 14398-D
C7AB 14398-J	C7AZ 14398-J	D2OB 14398-LE	D2OZ 14398-D
C7AB 14398-K	C7AZ 14398-D	D2SB 14398-AG	D2SZ 14398-A
C7AB 14398-L	★C7AZ 14398-L	D2SB 14398-BG	D2SZ 14398-B
C7SB 14398-B	C7SZ 14398-B	D2SB 14398-BH	D2SZ 14398-J
C8SB 14398-A	C8SZ 14398-A	ED-D2SB 14398-BK	D2SZ 14398-J
C8SB 14398-C	C8SZ 14398-B	ED1-D2SB 14398-BK	D2SZ 14398-J
C9AB 14398-D	C9AZ 14398-A	D2SB 14398-BM	D2SZ 14398-M
C9AB 14398-E	C9AZ 14398-B	D2SB 14398-BN	D2SZ 14398-M
C9AB 14398-F	C9AZ 14398-F	ED-D2SB 14398-BP	D2SZ 14398-M
C9AB 14398-G	C9AZ 14398-G	ED-D2SB 14398-CA	D2SZ 14398-P
C9AB 14398-H	C9AZ 14398-H	D2SB 14398-CE	D2SZ 14398-C
C9AB 14398-J	C9AZ 14398-J	D2SB 14398-CF	D2SZ 14398-C
C9SB 14398-B	C9SZ 14398-B	D2SB 14398-DE	D2SZ 14398-D
D0SB 14398-E	D0SZ 14398-P	D2SB 14398-DF	D2SZ 14398-D
D0SB 14398-F	D0SZ 14398-M	D2SB 14398-DG	D2SZ 14398-K
D0SB 14398-L	D0SZ 14398-L	ED-D2SB 14398-DJ	D2SZ 14398-K
D0SB 14398-M	D0SZ 14398-M	ED1-D2SB 14398-DJ	D2SZ 14398-K
D0SB 14398-P	D0SZ 14398-P	D2SB 14398-DL	D2SZ 14398-N
D0SB 14398-R	D0SZ 14398-R	D2SB 14398-DM	D2SZ 14398-N
D0SB 14398-S	D0SZ 14398-S	ED-D2SB 14398-DN	D2SZ 14398-N
D0SB 14398-T	D0SZ 14398-S	D2SB 14398-EG	D2SZ 14398-E
D0SB 14398-U	D0SZ 14398-P	D2SB 14398-FG	D2SZ 14398-F
D0SB 14398-X	D0SZ 14398-S	D2SB 14398-FH	D2SZ 14398-L
D0SB 14398-V	D0SZ 14398-S	D2SB 14398-FL	D2SZ 14398-P
D1SB 14398-BE	D1SZ 14398-B	D2SB 14398-FM	D2SZ 14398-P
D1SB 14398-BF	D1SZ 14398-B	D2SB 14398-GE	D2SZ 14398-G
D1SB 14398-CA	D1SZ 14398-C	D2SB 14398-HF	D2SZ 14398-H
D1SB 14398-CB	D1SB 14398-C	D2SB 14398-HG	D2SZ 14398-H
D2OB 14398-AE	D2OZ 14398-A	D2SB 14398-HJ	D2SZ 14398-R
D2OB 14398-HD	D2OZ 14398-A	D2SB 14398-HK	D2SZ 14398-R
D2OB 14398-HE	D2OZ 14398-A	ED-D2SB 14398-HL	D2SZ 14398-R
D2OB 14398-JD	D2OZ 14398-B		
D2OB 14398-JE	D2OZ 14398-B		

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14398 WIRING ASSY. - DASH PANEL TO ENGINE				
67/68	A(6 cyl.)		1	★C7AZ 14398-H
67/68	A(8 cyl. 289)		1	C7AZ 14398-J
68	A(302)		1	
67	A(8 cyl. 427)		1	★C7AZ 14398-L
67/68	A(8 cyl. 390, 428)		1	C7AZ 14398-D
68	A(427)	Used with hydraulic tappets	1	
69	A(6 cyl.)	"Before 11/15/68"	1	C9AZ 14398-A
69	A(6 cyl.)	"From 11/15/68"	1	C9AZ 14398-G
69	A(8 cyl. 390, 428, 429)	"Before 2/3/69"	1	C9AZ 14398-B
69	A(8 cyl. 390, 428, 429)	"From 2/3/69"	1	C9AZ 14398-H
69	A(8 cyl. 302, 351)	"Before 2/3/69"	1	C9AZ 14398-F
69	A(8 cyl. 302, 351)	"From 2/3/69"	1	C9AZ 14398-J
72	B-without tachometer and/or hidden wipers		1	D2OZ 14398-A
72	B-with tachometer without hidden wipers		1	D2OZ 14398-B
72	B-without tachometer with hidden wipers		1	D2OZ 14398-C
72	B-with tachometer with hidden wipers		1	D2OZ 14398-D
67	S		1	C7SZ 14398-B
68	S(390)		1	C8SZ 14398-A
68/69	S(429)		1	C9SZ 14398-B
70	S-w/o heated backlite	"Before 9/15/69"	1	D0SZ 14398-L
70	S-w/o heated backlite-	From 9/15/69 to 12/1/69"	1	D0SZ 14398-R
70	S-w/o heated backlite	"From 12/1/69"	1	D0SZ 14398-S
70	S-with heated backlite	"Before 12/1/69"	1	D0SZ 14398-M
70	S-with heated backlite	"From 12/1/69"	1	D0SZ 14398-P
71	S-without heated backlite		1	D1SZ 14398-C
71	S-with heated backlite		1	D1SZ 14398-B
72	S(400)-without A.T.C. and/or heated backlite		1	D2SZ 14398-A
72	S(400)-without A.T.C. with heated backlite		1	D2SZ 14398-C
72	S(400)-with A.T.C. without heated backlite		1	D2SZ 14398-E
72	S(400)-with A.T.C. with heated backlite		1	D2SZ 14398-G
72	S(429)-without A.T.C. and/or heated backlite-		1	D2SZ 14398-B
		"Before 11/1/71"		
72	S(429)-without A.T.C. and/or heated backlite-		1	D2SZ 14398-J
		"From 11/1/71 to 4/5/72"		
72	S(460)-without A.T.C. and/or heated backlite-		1	
		"Before 4/5/72"		
72	S(429)-without A.T.C. with heated backlite-		1	D2SZ 14398-D
		"Before 11/1/71"		
72	S(429)-without A.T.C. with heated backlite -		1	D2SZ 14398-K
		"From 11/1/71 to 4/5/72"		
72	S(460)-without A.T.C. with heated backlite-		1	
		"Before 4/5/72"		
72	S(429)-with A.T.C. without heated backlite-		1	D2SZ 14398-F
		"Before 11/1/71"		
72	S(429)-with A.T.C. without heated backlite-		1	D2SZ 14398-L
		"From 11/1/71 to 4/5/72"		
72	S(460)-with A.T.C. without heated backlite -		1	
		"Before 4/5/72"		
72	S(429, 460)-with A.T.C. and heated backlite-		1	D2SZ 14398-H
		"Before 4/5/72"		
72	S(429, 460)-without A.T.C. and/or heated backlite		1	D2SZ 14398-M
		"From 4/5/72"		
72	S(429, 460)-without A.T.C. with heated backlite-		1	D2SZ 14398-N
		"From 4/5/72"		
72	S(429, 460)with A.T.C. without heated backlite-		1	D2SZ 14398-P
		"From 4/5/72"		
72	S(429, 460)-with A.T.C. and heated backlite-		1	D2SZ 14398-R
		"From 4/5/72"		
71	S	Nut No. 10-24 (attach wiring to alternator)	AR	383255-S(MM296-AC)
71	S	Nut 1/4"-20 (attach wiring to alternator)	AR	383256-S(MM296AE)
70	S	Clip (attach wiring to power steering bracket)	1	374532-S(GG335)

14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL

WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE FOR 1965 and SUBSEQUENT MODELS

The purpose of this guide is to facilitate the identification of the Service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C4ZB 14401-A	★C5ZZ 14401-E	C6DB 14401-D	★C6DZ 14401-F
C4ZB 14401-B	C5ZZ 14401-F	C6DB 14401-E	★C6DZ 14401-F
C4ZB 14401-E	★C5ZZ 14401-E	C6DB 14401-F	★C6DZ 14401-E
C4ZB 14401-F	C5ZZ 14401-F	C6DB 14401-G	★C6DZ 14401-F
		C6DB 14401-H	★C6DZ 14401-E
C5AB 14401-F	C5AZ 14401-N	C6DB 14401-J	★C6DZ 14401-F
C5AB 14401-H	C5AZ 14401-L	C6DB 14401-Z	★C6DZ 14401-Z
C5AB 14401-J	★C5AZ 14401-M	C6DB 14401-AA	★C6DZ 14401-AA
C5AB 14401-L	C5AZ 14401-L	C6OB 14401-A	★C6OZ 14401-C
C5AB 14401-M	★C5AZ 14401-M	C6OB 14401-C	C6OZ 14401-D
C5AB 14401-N	C5AZ 14401-N	C6OB 14401-F	★C6OZ 14401-C
C5DB 14401-E	★C5DZ 14401-A	C6OB 14401-G	C6OZ 14401-D
C5DB 14401-F	★C5DZ 14401-B	C6OB 14401-Z	C6OZ 14401-Z
C5OB 14401-A	C5OZ 14401-E	C6OB 14401-AA	C6OZ 14401-AA
C5OB 14401-B	★C5OZ 14401-F	C6SB 14401-A	★C6SZ 14401-E
C5OB 14401-E	C5OZ 14401-E	C6SB 14401-B	★C6SZ 14401-F
C5OB 14401-F	★C5OZ 14401-F	C6SB 14401-C	★C6SZ 14401-E
C5SB 14401-A	★C5SZ 14401-A	C6SB 14401-D	★C6SZ 14401-F
C5SB 14401-B	C5SZ 14401-B	C6SB 14401-E	★C6SZ 14401-E
C5SB 14401-C	★C5SZ 14401-C	C6SB 14401-F	★C6SZ 14401-F
C5SB 14401-D	★C5SZ 14401-D	C6TB 14401-C	C6TZ 14401-AU
C5ZB 14401-E	C5ZZ 14401-M	C6TB 14401-AU	C6TZ 14401-AU
C5ZB 14401-F	C5ZZ 14401-M	C6TB 14401-DV	★C6TZ 14401-DV
C5ZB 14401-G	C5ZZ 14401-G	C6TB 14401-DY	C6TZ 14401-DY
C5ZB 14401-J	C5ZZ 14401-M	C6ZB 14401-B	C6ZZ 14401-F
C5ZB 14401-K	C5ZZ 14401-M	C6ZB 14401-C	C6ZZ 14401-F
C5ZB 14401-L	C5ZZ 14401-M	C6ZB 14401-F	C6ZZ 14401-F
C5ZB 14401-M	C5ZZ 14401-M		
C5ZB 14401-N	C5ZZ 14401-N	C7AB 14401-C	C7AZ 14401-A
		C7AB 14401-D	★C7AZ 14401-B
C6AB 14401-A	C6AZ 14401-A	C7AB 14401-S	C7AZ 14401-S
C6AB 14401-B	C6AZ 14401-B	C7AB 14401-T	C7AZ 14401-T
C6AB 14401-C	★C6AZ 14401-C	C7DB 14401-A	C7DZ 14401-C
C6AB 14401-AK	C6AZ 14401-AN	C7DB 14401-B	★C7DZ 14401-D
C6AB 14401-AL	C6AZ 14401-AR	C7DB 14401-C	C7DZ 14401-C
C6AB 14401-AM	★C6AZ 14401-AS	C7DB 14401-D	★C7DZ 14401-D
C6AB 14401-AN	C6AZ 14401-AN	C7OB 14401-C	C7OZ 14401-E
C6AB 14401-AR	C6AZ 14401-AR	C7OB 14401-D	C7OZ 14401-F
C6AB 14401-AS	★C6AZ 14401-AS	C7OB 14401-E	C7OZ 14401-E
C6AB 14401-AT	C6AZ 14401-AN	C7OB 14401-F	C7OZ 14401-F
C6AB 14401-AU	C6AZ 14401-AR	C7SB 14401-C	★C7SZ 14401-A
C6AB 14401-AV	★C6AZ 14401-AS	C7SB 14401-E	★C7SZ 14401-F
C6AB 14401-AY	C6AZ 14401-AN	C7SB 14401-F	★C7SZ 14401-F
ED1-C6AB 14401-AK	C6AZ 14401-AN	C7TB 14401-BE	★C7TZ 14401-CB
ED2-C6AB 14401-AK	C6AZ 14401-AN	C7TB 14401-DH	★C7TZ 14401-CA
EDA-C6AB 14401-AK	C6AZ 14401-AN	C7TB 14401-DJ	★C7TZ 14401-CB
ED1-C6AB 14401-AL	C6AZ 14401-AR	C7TB 14401-DV	C7TZ 14401-DV
ED2-C6AB 14401-AL	C6AZ 14401-AR	C7TB 14401-DY	★C7TZ 14401-DY
EDA-C6AB 14401-AL	C6AZ 14401-AR	C7ZB 14401-J	C7ZZ 14401-AK
ED1-C6AB 14401-AM	★C6AZ 14401-AS	C7ZB 14401-K	C7ZZ 14401-AL
ED2-C6AB 14401-AM	★C6AZ 14401-AS	C7ZB 14401-L	★C7ZZ 14401-G
EDA-C6AB 14401-AM	★C6AZ 14401-AS	C7ZB 14401-M	★C7ZZ 14401-H
		C7ZB 14401-AA	C7ZZ 14401-AK
C6DB 14401-A	★C6DZ 14401-E	C7ZB 14401-AB	C7ZZ 14401-AL
C6DB 14401-C	★C6DZ 14401-E		

14401 WIRING ASSY - INSTRUMENT PANEL TO DASH PANEL continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C7ZB 14401-AC	★C7ZZ 14401-AC	C8ZB 14401-A	C8ZZ 14401-C
C7ZB 14401-AD	★C7ZZ 14401-AD	C8ZB 14401-B	C8ZZ 14401-D
C7ZB 14401-AK	C7ZZ 14401-AK	C8ZB 14401-C	C8ZZ 14401-C
C7ZB 14401-AL	C7ZZ 14401-AL	C8ZB 14401-D	C8ZZ 14401-D
C7ZB 14401-AM	★C7ZZ 14401-AM	C8ZB 14401-E	C8ZZ 14401-C
C7ZB 14401-AN	★C7ZZ 14401-AN	C8ZB 14401-F	C8ZZ 14401-D
		C8ZB 14401-G	C8ZZ 14401-C
C8AB 14401-A	C8AZ 14401-M	C8ZB 14401-H	C8ZZ 14401-D
C8AB 14401-B	C8AZ 14401-AC	C8ZB 14401-J	C8ZZ 14401-C
C8AB 14401-D	C8AZ 14401-M	C8ZB 14401-K	C8ZZ 14401-D
C8AB 14401-E	C8AZ 14401-AC	C8ZB 14401-L	C8ZZ 14401-C
C8AB 14401-F	C8AZ 14401-M	C8ZB 14401-M	C8ZZ 14401-D
C8AB 14401-G	C8AZ 14401-AC	C8ZB 14401-N	C8ZZ 14401-D
C8AB 14401-J	C8AZ 14401-M	C8ZB 14401-R	C8ZZ 14401-D
C8AB 14401-K	C8AZ 14401-AC	C8ZB 14401-S	C8ZZ 14401-C
C8AB 14401-L	C8AZ 14401-AC	C8ZB 14401-T	C8ZZ 14401-D
C8AB 14401-M	C8AZ 14401-M	C8ZB 14401-U	C8ZZ 14401-C
C8AB 14401-Y	C8AZ 14401-M	C8ZB 14401-V	C8ZZ 14401-D
C8AB 14401-Z	C8AZ 14401-AC	C8ZB 14401-Y	C8ZZ 14401-C
C8AB 14401-AA	C8AZ 14401-M	C8ZB 14401-Z	C8ZZ 14401-D
C8AB 14401-AB	C8AZ 14401-AC	C8ZB 14401-AA	C8ZZ 14401-C
C8AB 14401-AC	C8AZ 14401-AC	C8ZB 14401-AB	C8ZZ 14401-D
C8AB 14401-AF	★C8AZ 14401-AF	C8ZB 14401-AC	C8ZZ 14401-C
C8DB 14401-A	C8DZ 14401-A	C8ZB 14401-AD	C8ZZ 14401-D
C8DB 14401-B	C8DZ 14401-A	C8ZB 14401-AE	C8ZZ 14401-C
C8DB 14401-C	C8DZ 14401-A	C8ZB 14401-AF	C8ZZ 14401-D
C8DB 14401-D	C8DZ 14401-A	C8ZB 14401-AG	C8ZZ 14401-C
C8DB 14401-E	C8DZ 14401-A	C8ZB 14401-AH	C8ZZ 14401-D
C8DB 14401-F	C8DZ 14401-A	C8ZB 14401-AJ	C8ZZ 14401-C
C8DB 14401-J	C8DZ 14401-A	C8ZB 14401-AK	C8ZZ 14401-D
C8DB 14401-K	C8DZ 14401-A	C8ZB 14401-AL	C8ZZ 14401-C
C8DB 14401-L	C8DZ 14401-A	C8ZB 14401-AM	C8ZZ 14401-C
C8DB 14401-M	C8DZ 14401-A	C8ZB 14401-AN	C8ZZ 14401-D
C8DB 14401-N	C8DZ 14401-A	C8ZB 14401-AR	C8ZZ 14401-D
ED-C8DB 14401-H	C8DZ 14401-A	C8ZB 14401-AS	C8ZZ 14401-C
C8OB 14401-A	C8OZ 14401-A	C8ZB 14401-AT	C8ZZ 14401-D
C8OB 14401-B	C8OZ 14401-A	C8ZB 14401-AU	C8ZZ 14401-C
C8OB 14401-C	C8OZ 14401-A	C8ZB 14401-AV	C8ZZ 14401-D
C8OB 14401-F	C8OZ 14401-A	ED-C8ZB 14401-AU	C8ZZ 14401-C
C8OB 14401-G	C8OZ 14401-A		
C8OB 14401-L	C8OZ 14401-A	C9AB 14401-BD	★C9AZ 14401-DF
C8OB 14401-M	C8OZ 14401-A	C9AB 14401-BF	C9AZ 14401-DD
C8OB 14401-N	C8OZ 14401-A	C9AB 14401-BG	C9AZ 14401-DH
C8OB 14401-R	C8OZ 14401-A	C9AB 14401-BH	★C9AZ 14401-DF
C8OB 14401-S	C8OZ 14401-A	C9AB 14401-CN	C9AZ 14401-DG
ED-C8OB 14401-K	C8OZ 14401-A	C9AB 14401-CR	C9AZ 14401-DC
ED-C8OB 14401-M	C8OZ 14401-A	C9AB 14401-CS	C9AZ 14401-BE
C8SB 14401-A	★C8SZ 14401-A	C9AB 14401-DC	C9AZ 14401-DC
C8SB 14401-B	★C8SZ 14401-B	C9AB 14401-DD	C9AZ 14401-DD
C8SB 14401-C	★C8SZ 14401-A	C9AB 14401-DE	C9AZ 14401-DE
C8SB 14401-D	★C8SZ 14401-B	C9AB 14401-DF	★C9AZ 14401-DF
C8SB 14401-E	★C8SZ 14401-A	C9AB 14401-DG	C9AZ 14401-DG
C8SB 14401-F	★C8SZ 14401-B	C9AB 14401-DH	C9AZ 14401-DH
C8SB 14401-S	★C8SZ 14401-AD	C9AB 14401-DJ	C9AZ 14401-BE
C8SB 14401-T	★C8SZ 14401-AE	C9AB 14401-DK	C9AZ 14401-DC
C8SB 14401-U	★C8SZ 14401-G	C9AB 14401-DL	C9AZ 14401-DG
C8SB 14401-AB	★C8SZ 14401-G	C9AB 14401-DP	C9AZ 14401-DD
C8SB 14401-AC	★C8SZ 14401-H	C9AB 14401-DT	★C9AZ 14401-DF
C8SB 14401-AD	★C8SZ 14401-AD	ED-C9AB 14401-AV	★C9AZ 14401-DF
C8SB 14401-AE	★C8SZ 14401-AE	ED-C9AB 14401-AY	C9AZ 14401-DG
ED-C8SB 14401-L	★C8SZ 14401-G	ED-C9AB 14401-AZ	C9AZ 14401-DD
ED-C8SB 14401-M	★C8SZ 14401-H	ED-C9AB 14401-BA	C9AZ 14401-DC
ED-C8SB 14401-N	★C8SZ 14401-AD	ED-C9AB 14401-BB	C9AZ 14401-DH
ED-C8SB 14401-R	★C8SZ 14401-AE	ED-C9AB 14401-BC	C9AZ 14401-BE
C8TB 14401-T	★C8TZ 14401-DC	ED-C9AB 14401-BD	★C9AZ 14401-DF
C8TB 14401-U	★C8TZ 14401-DC	ED-C9AB 14401-BN	C9AZ 14401-DH
C8TB 14401-AM	★C8TZ 14401-DC	ED-C9AB 14401-BS	C9AZ 14401-DD
C8TB 14401-AN	★C8TZ 14401-DC	ED-C9AB 14401-BY	C9AZ 14401-DH
C8TB 14401-DB	C8TZ 14401-DB	ED-C9AB 14401-BV	C9AZ 14401-DD
C8TB 14401-DC	★C8TZ 14401-DC		

14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C9DB 14401-C	C9DZ 14401-E	D0AB 14401-L	D0AZ 14401-BU
C9DB 14401-D	C9DZ 14401-E	D0AB 14401-BK	D0AZ 14401-A
C9DB 14401-E	C9DZ 14401-E	D0AB 14401-BL	D0AZ 14401-B
C9DB 14401-F	C9DZ 14401-E	D0AB 14401-BM	D0AZ 14401-BU
C9OB 14401-G	C9OZ 14401-J	D0AB 14401-BN	D0AZ 14401-D
C9OB 14401-H	C9OZ 14401-K	D0AB 14401-BR	D0AZ 14401-BR
C9OB 14401-K	C9OZ 14401-K	D0AB 14401-BS	D0AZ 14401-BS
C9OB 14401-L	C9OZ 14401-J	D0AB 14401-BT	D0AZ 14401-BT
C9OB 14401-M	C9OZ 14401-K	D0AB 14401-BU	D0AZ 14401-BU
C9OB 14401-N	C9OZ 14401-K	D0AB 14401-CA	D0AZ 14401-BR
C9OB 14401-P	C9OZ 14401-J	D0AB 14401-CB	D0AZ 14401-BS
C9OB 14401-R	C9OZ 14401-K	D0AB 14401-CC	D0AZ 14401-BT
C9OB 14401-S	C9OZ 14401-J	D0AB 14401-CD	D0AZ 14401-BU
C9SB 14401-G	C9SZ 14401-A	ED-D0AB 14401-CA	D0AZ 14401-BR
C9SB 14401-H	C9SZ 14401-B	ED-D0AB 14401-CB	D0AZ 14401-BS
C9SB 14401-J	C9SZ 14401-J	ED-D0AB 14401-CC	D0AZ 14401-BT
C9SB 14401-K	C9SZ 14401-K	ED-D0AB 14401-CD	D0AZ 14401-BU
C9SB 14401-L	C9SZ 14401-K	ED-D0AB 14401-CE	D0AZ 14401-BR
C9SB 14401-M	C9SZ 14401-J	ED-D0AB 14401-CF	D0AZ 14401-BS
C9SB 14401-R	C9SZ 14401-R	ED-D0AB 14401-CG	D0AZ 14401-BT
C9SB 14401-S	C9SZ 14401-S	ED-D0AB 14401-CH	D0AZ 14401-BU
C9SB 14401-T	C9SZ 14401-R	D0BB 14401-C	D0BZ 14401-A
C9SB 14401-U	C9SZ 14401-S	D0BB 14401-D	D0BZ 14401-B
C9SB 14401-V	C9SZ 14401-J	D0BE 14401-E	D0BZ 14401-E
C9SB 14401-Y	C9SZ 14401-S	D0DB 14401-D	D0DZ 14401-D
C9SB 14401-Z	C9SZ 14401-A	D0DB 14401-G	D0DZ 14401-G
C9SB 14401-AA	C9SZ 14401-B	D0DB 14401-K	D0DZ 14401-D
C9SB 14401-AB	C9SZ 14401-J	D0DB 14401-R	D0DZ 14401-R
C9SB 14401-AC	C9SZ 14401-K	D0DB 14401-AA	D0DZ 14401-G
C9SB 14401-AD	C9SZ 14401-R	D0DB 14401-AC	D0DZ 14401-R
C9SB 14401-AE	C9SZ 14401-S	D0DB 14401-AL	D0DZ 14401-AL
C9TB 14401-AY	C9TZ 14401-AY	D0DB 14401-AU	D0DZ 14401-AL
C9TB 14401-AZ	C9TZ 14401-AZ	D0DB 14401-BC	D0DZ 14401-AL
ED-C9TB 14401-AY	C9TZ 14401-A	D0DB 14401-CG	D0DZ 14401-AL
ED-C9TB 14401-AZ	C9TZ 14401-B	D0DB 14401-CH	D0DZ 14401-AL
C9ZB 14401-AB	C9ZZ 14401-A	D0DB 14401-CJ	D0DZ 14401-AL
C9ZB 14401-AC	C9ZZ 14401-B	D0OB 14401-H	D0CZ 14401-A
C9ZB 14401-AD	C9ZZ 14401-C	D0OB 14401-K	D0OZ 14401-A
C9ZB 14401-AE	C9ZZ 14401-A	D0OB 14401-M	D0OZ 14401-A
C9ZB 14401-AF	C9ZZ 14401-B	D0OB 14401-P	D0OZ 14401-A
C9ZB 14401-AG	C9ZZ 14401-C	D0OB 14401-R	D0OZ 14401-N
C9ZB 14401-AH	C9ZZ 14401-A	D0OB 14401-T	D0OZ 14401-N
C9ZB 14401-AJ	C9ZZ 14401-B	D0SB 14401-N	D0SZ 14401-A
C9ZB 14401-AL	C9ZZ 14401-AL	D0SB 14401-R	D0SZ 14401-B
C9ZB 14401-AK	C9ZZ 14401-C	D0SB 14401-S	D0SZ 14401-C
C9ZB 14401-AM	★C9ZZ 14401-AM	D0SB 14401-T	D0SZ 14401-D
C9ZB 14401-AN	★C9ZZ 14401-AM	D0SB 14401-AH	D0SZ 14401-A
C9ZB 14401-AR	C9ZZ 14401-AL	D0SB 14401-AJ	D0SZ 14401-B
C9ZB 14401-AS	★C9ZZ 14401-AM	D0SB 14401-AK	D0SZ 14401-C
C9ZB 14401-AT	C9ZZ 14401-AN	D0SB 14401-AL	D0SZ 14401-D
C9ZB 14401-BB	C9ZZ 14401-BB	D0SB 14401-AX	D0SZ 14401-A
C9ZB 14401-BC	C9ZZ 14401-BC	D0SB 14401-AY	D0SZ 14401-B
C9ZB 14401-BD	C9ZZ 14401-BD	D0SB 14401-AZ	D0SZ 14401-C
C9ZB 14401-BE	C9ZZ 14401-BE	D0SB 14401-BA	D0SZ 14401-D
C9ZB 14401-BF	C9ZZ 14401-AL	D0SB 14401-BN	D0SZ 14401-BN
C9ZB 14401-BJ	C9ZZ 14401-A	D0SB 14401-BP	D0SZ 14401-BP
C9ZB 14401-BK	C9ZZ 14401-B	D0SB 14401-BU	D0SZ 14401-BU
C9ZB 14401-BL	C9ZZ 14401-C	D0SB 14401-BV	D0SZ 14401-BS
C9ZB 14401-BM	★C9ZZ 14401-AM	D0SB 14401-CA	D0SZ 14401-CA
C9ZB 14401-BN	★C9ZZ 14401-AM	D0SB 14401-CB	D0SZ 14401-CB
C9ZB 14401-BP	C9ZZ 14401-BB	ED-D0SB 14401-AS	D0SZ 14401-A
C9ZB 14401-BR	C9ZZ 14401-BC	ED-D0SB 14401-AT	D0SZ 14401-B
C9ZB 14401-BS	C9ZZ 14401-BD	ED-D0SB 14401-AU	D0SZ 14401-C
C9ZB 14401-BT	C9ZZ 14401-BE	ED-D0SB 14401-AV	D0SZ 14401-D
		ED-D0SB 14401-CA	D0SZ 14401-BY
		ED-D0SB 14401-CB	D0SZ 14401-BX
D0AB 14401-G	D0AZ 14401-A	ED1-D0SB 14401-CD	D0SZ 14401-BZ
D0AB 14401-H	D0AZ 14401-B	D0ZB 14401-BB	D0ZZ 14401-BS
D0AB 14401-K	D0AZ 14401-D	D0ZB 14401-BC	D0ZZ 14401-B

14401 WIRING ASSY - INSTRUMENT PANEL TO DASH PANEL - continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
D0ZB 14401-BD	D0ZZ 14401-C	D2DB 14401-AE	D2DZ 14401-A
D0ZB 14401-BT	D0ZZ 14401-K	D2DB 14401-AF	D2DZ 14401-C
D0ZB 14401-BU	D0ZZ 14401-J	D2DB 14401-AG	D2DZ 14401-C
D0ZB 14401-BY	D0ZZ 14401-BM	D2DB 14401-BE	D2DZ 14401-D
D0ZB 14401-BZ	D0ZZ 14401-BN	D2DB 14401-BF	D2DZ 14401-D
D0ZB 14401-CA	D0ZZ 14401-BS	D2DB 14401-BG	D2DZ 14401-D
D0ZB 14401-CD	D0ZZ 14401-BX	D2OB 14401-AG	D2OZ 14401-A
D0ZB 14401-CE	D0ZZ 14401-BV	D2OB 14401-AL	D2OZ 14401-E
D0ZB 14401-CF	D0ZZ 14401-BM	D2OB 14401-AM	D2OZ 14401-E
D0ZB 14401-CG	D0ZZ 14401-BN	D2OB 14401-AN	D2OZ 14401-E
D0ZB 14401-CH	D0ZZ 14401-BS	D2OB 14401-AP	D2OZ 14401-J
D0ZB 14401-CJ	D0ZZ 14401-BX	D2OB 14401-BG	D2OZ 14401-H
D0ZB 14401-CK	D0ZZ 14401-BV	D2OB 14401-BL	D2OZ 14401-F
		D2OB 14401-BM	D2OZ 14401-F
D1AB 14401-AM	D1AZ 14401-A	D2OB 14401-BN	D2OZ 14401-F
D1AB 14401-AP	D1AZ 14401-G	D2OB 14401-BP	D2OZ 14401-K
D1AB 14401-AS	D1AZ 14401-K	D2OB 14401-CD	D2OZ 14401-C
D1AB 14401-BM	D1AZ 14401-H	D2OB 14401-CH	D2OZ 14401-G
D1AB 14401-BP	D1AZ 14401-H	D2OB 14401-CJ	D2OZ 14401-G
ED1-D1AB 14401-AP	D1AZ 14401-G	D2OB 14401-CK	D2OZ 14401-G
ED1-D1AB 14401-BP	D1AZ 14401-H	D2OB 14401-CL	D2OZ 14401-L
D1AB 14401-BS	D1AZ 14401-L	D2OB 14401-DD	D2OZ 14401-D
D1AB 14401-EM	D1AZ 14401-E	D2OB 14401-DJ	D2OZ 14401-H
D1AB 14401-EP	D1AZ 14401-J	D2OB 14401-DK	D2OZ 14401-H
D1AB 14401-ES	D1AZ 14401-M	D2OB 14401-DL	D2OZ 14401-M
D1BB 14401-AB	D1BZ 14401-A	ED-D2OB 14401-BK	D2OZ 14401-H
D1DB 14401-AC	D1DZ 14401-C	ED-D2OB 14401-DG	D2OZ 14401-D
D1DB 14401-AD	D1DZ 14401-C	D2SB 14401-AL	D2SZ 14401-E
D1DB 14401-BD	D1DZ 14401-B	D2SB 14401-AR	D2SZ 14401-E
D1DB 14401-BE	D1DZ 14401-D	D2SB 14401-AS	D2SZ 14401-E
D1DB 14401-BF	D1DZ 14401-E	D2SB 14401-BL	D2SZ 14401-F
ED-D1DB 14401-BF	D1DZ 14401-D	D2SB 14401-BR	D2SZ 14401-F
D1OB 14401-AF	D1OZ 14401-A	D2SB 14401-BS	D2SZ 14401-F
D1OB 14401-AG	D1OZ 14401-B	D2SB 14401-CK	D2SZ 14401-G
D1SB 14401-AK	D1SZ 14401-C	D2SB 14401-CN	D2SZ 14401-G
D1SB 14401-AL	D1SZ 14401-C	D2SB 14401-CP	D2SZ 14401-G
D1SB 14401-BK	D1SZ 14401-D	D2SB 14401-DK	D2SZ 14401-H
D1SB 14401-BL	D1SZ 14401-D	D2SB 14401-DN	D2SZ 14401-H
D1ZB 14401-AH	D1ZZ 14401-N	D2SB 14401-DP	D2SZ 14401-H
D1ZB 14401-AJ	D1ZZ 14401-N	ED-D2SB 14401-AL	D2SZ 14401-A
D1ZB 14401-AK	D1ZZ 14401-N	ED2-D2SB 14401-AP	D2SZ 14401-A
D1ZB 14401-BH	D1ZZ 14401-B	ED-D2SB 14401-BL	D2SZ 14401-B
D1ZB 14401-BJ	D1ZZ 14401-H	ED-D2SB 14401-CK	D2SZ 14401-C
D1ZB 14401-CH	D1ZZ 14401-C	ED-D2SB 14401-DK	D2SZ 14401-D
D1ZB 14401-CJ	D1ZZ 14401-J	ED2-D2SB 14401-BP	D2SZ 14401-B
D1ZB 14401-CL	D1ZZ 14401-P	ED2-D2SB 14401-CM	D2SZ 14401-C
D1ZB 14401-DH	D1ZZ 14401-D	ED2-D2SB 14401-DM	D2SZ 14401-D
D1ZB 14401-DZ	D1ZZ 14401-K	D2ZB 14401-AB	D2ZZ 14401-A
D1ZB 14401-EH	D1ZZ 14401-E	D2ZB 14401-AE	D2ZZ 14401-E
D1ZB 14401-EJ	D1ZZ 14401-L	D2ZB 14401-AF	D2ZZ 14401-E
D1ZB 14401-EK	D1ZZ 14401-R	D2ZB 14401-BB	D2ZZ 14401-B
D1ZB 14401-FH	D1ZZ 14401-F	D2ZB 14401-BD	D2ZZ 14401-D
D1ZB 14401-FJ	D1ZZ 14401-M	D2ZB 14401-BE	D2ZZ 14401-F
D1ZB 14401-FK	D1ZZ 14401-Q	D2ZB 14401-CA	D2ZZ 14401-G
D12B 14401-AH	D1FZ 14401-D	D2ZB 14401-CE	D2FZ 14401-A
D12B 14401-AJ	D1FZ 14401-D	D2ZB 14401-CD	D2FZ 14401-G
D12B 14401-AK	D1FZ 14401-H	D2ZB 14401-CE	D2FZ 14401-G
D12B 14401-BH	D1FZ 14401-H	D2ZB 14401-DE	D2FZ 14401-B
D12B 14401-BJ	D1FZ 14401-E	D2ZB 14401-DF	D2FZ 14401-B
D12B 14401-BK	D1FZ 14401-H	D2ZB 14401-DG	D2FZ 14401-H
D12B 14401-CH	D1FZ 14401-J	D2ZB 14401-DC	D2FZ 14401-J
D12B 14401-CJ	D1FZ 14401-J	D2ZB 14401-DE	D2FZ 14401-J
D12B 14401-CK	D1FZ 14401-J	D2ZB 14401-EC	D2FZ 14401-E
		D2ZB 14401-EF	D2FZ 14401-F
D2AB 14401-AD	D2AZ 14401-A	D2ZB 14401-EG	D2FZ 14401-M
D2AB 14401-AE	D2AZ 14401-A	D2ZB 14401-FA	D2FZ 14401-K
D2AB 14401-BD	D2AZ 14401-B		
D2AB 14401-BE	D2AZ 14401-B		
D2AB 14401-CD	D2AZ 14401-C		
D2AB 14401-CE	D2AZ 14401-C		

14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
D22B 14401-GA	D2FZ 14401-L	ED-C9AB 14444-AD	C9AZ 14401-DC
D22B 14401-GB	★D2FZ 14401-N	ED-C9AB 14444-AF	C9AZ 14401-DG
ED-D3BB 14401-AD	D3BZ 14401-A	ED-C9AB 14444-AL	C9AZ 14401-DH
S9MS 14L401-A	C9ZZ 14401-D	ED-C9AB 14444-AM	C9AZ 14401-BD
C9ZX 14A411-A	C9ZZ 14401-D	ED-C9AB 14444-AT	C9AZ 14401-DD
		ED-C9AB 14444-AV	C9AZ 14401-DH
C8AB 14444-A	C8AZ 14401-M	ED-C9AB 14444-AY	C9AZ 14401-DH
C8AB 14444-B	C8AZ 14401-AC	ED-C9AB 14444-AZ	C9AZ 14401-DH
C8AB 14444-AC	C8AZ 14401-AC	ED-C9AB 14444-CG	★C9AZ 14401-DF
ED-C8DB 14444-A	C8DZ 14401-A	ED-C9AB 14444-CH	C9AZ 14401-DH
ED-C8DB 14444-B	C8DZ 14401-A	ED-C9AB 14444-CJ	C9AZ 14401-DG
C8OB 14444-A	C8OZ 14401-A	ED-C9AB 14444-CK	C9AZ 14401-DE
C8SB 14444-C	C8SZ 14401-B	ED-C9AB 14444-CL	C9AZ 14401-DD
C8SB 14444-D	C8SZ 14401-AE	ED-C9AB 14444-CM	C9AZ 14401-DC
C8SB 14444-E	C8SZ 14401-A	C9DB 14444-D	C9DZ 14401-E
C8SB 14444-F	C8SZ 14401-AD	C9OB 14444-G	C9OZ 14401-J
C8SB 14444-G	C8SZ 14401-G	C9OB 14444-H	C9OZ 14401-K
C8SB 14444-H	C8SZ 14401-H	C9SB 14444-G	C9SZ 14401-S
C8SB 14444-S	C8SZ 14401-AD	C9SB 14444-H	C9SZ 14401-R
C8SB 14444-T	C8SZ 14401-AE	C9SB 14444-J	C9SZ 14401-S
C8SB 14444-AD	C8SZ 14401-AD	C9SB 14444-L	C9SZ 14401-J
C8SB 14444-AE	C8SZ 14401-AE	C9SB 14444-M	C9SZ 14401-S
C8ZB 14444-A	C8ZZ 14401-C	C9ZB 14444-D	C9ZZ 14401-A
C8ZB 14444-B	C8ZZ 14401-C	C9ZB 14444-E	C9ZZ 14401-B
C8ZB 14444-C	C8ZZ 14401-D	C9ZB 14444-F	C9ZZ 14401-C
C8ZB 14444-D	C8ZZ 14401-D	C9ZB 14444-G	C9ZZ 14401-A
		C9ZB 14444-H	C9ZZ 14401-B
C9AB 14444-AA	★C9AZ 14401-DF	C9ZB 14444-J	C9ZZ 14401-C
C9AB 14444-AB	C9AZ 14401-DD	C9ZB 14444-K	C9ZZ 14401-AL
C9AB 14444-AC	C9AZ 14401-DH	C9ZB 14444-L	★C9ZZ 14401-AM
C9AB 14444-BU	C9AZ 14401-DG	C9ZB 14444-M	C9ZZ 14401-AN
C9AB 14444-BV	C9AZ 14401-DC	C9ZB 14444-AA	C9ZZ 14401-BB
C9AB 14444-BY	C9AZ 14401-BE	C9ZB 14444-AB	C9ZZ 14401-BC
ED-C9AB 14444-N	★C9AZ 14401-DF	C9ZB 14444-AC	C9ZZ 14401-BD
ED-C9AB 14444-R	C9AZ 14401-DG	C9ZB 14444-AD	C9ZZ 14401-BE
ED-C9AB 14444-S	C9AZ 14401-DD	D0DB 14444-B	D0DZ 14401-G
ED-C9AB 14444-T	C9AZ 14401-DC	D0DB 14444-E	D0DZ 14401-R
ED-C9AB 14444-U	C9AZ 14401-DH	D0DB 14444-G	D0DZ 14401-G
ED-C9AB 14444-Y	C9AZ 14401-BD	D0DB 14444-J	D0DZ 14401-R

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
------	-------	-------------	------	-------------

14401 WIRING ASSY - INSTRUMENT PANEL TO DASH PANEL - continued -

See Identification Chart at beginning of Group

- A -

65	A-with A/C	"Before 6/14/65"		1	C5AZ 14401-N
65/66	A-with A/C	"From 6/14/65 to 2/1/66"		1	C6AZ 14401-B
66	A-with A/C	"From 2/1/66"	Includes (4) C6AB 13A724-B jumper wires	1	C6AZ 14401-AR
65	A(exc.A/C or trans.ign.)	"Before 6/14/65"		1	C5AZ 14401-L
65/66	A(except A/C or transistorized ignition -	"From 6/14/65 to 2/1/66"		1	C6AZ 14401-A
66	A(except A/C or trans.ign.)	"From 2/1/66"	Includes (4) C6AB 13A724-B jumper wires	1	C6AZ 14401-AN
65	A(8 cyl. 427)-with transistorized ignition-	"Before 6/14/65"	Not replaced	1	★C5AZ 14401-M
65/66	A(8 cyl. 427)-with transistorized ignition-	"From 6/14/65 to 2/1/66"	Not replaced	1	★ C6AZ 14401-C
66	A(8 cyl.427)-with trans.ign.	"From 2/1/66"	Includes (4) C6AB 13A274-B jumper wires-	1	★ C6AZ 14401-AS
			not replaced		
67	A-except A/C	"Before 1/3/67"		1	C7AZ 14401-A
67	A-except A/C	"From 1/3/67"		1	C7AZ 14401-S
67	A-with A/C	"Before 1/3/67"	Not replaced	1	★C7AZ 14401-B
67	A-with A/C	"From 1/3/67"		1	C7AZ 14401-T
68	A(8 cyl.)-exc. A/C			1	C8AZ 14401-M
68	A(6 cyl.)-exc. A/C	"Before 5/15/68"		1	
68	A(6 cyl.)-exc. A/C	"From 5/15/68"	Not replaced	1	★C8AZ 14401-AF
68	A-with A/C			1	C8AZ 14401-AC
69	A(6 cyl.)-exc. A/C		With intermittent wipers	1	C9AZ 14401-DG
69	A(8 cyl.)-exc. A/C		With intermittent wipers	1	C9AZ 14401-DC
69	A(with A/C)	"Before 4/15/69"	With intermittent wipers	1	C9AZ 14401-BE
69	A(8 cyl.)-with A/C	"From 4/15/69"	With intermittent wipers	1	C9AZ 14401-DE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued -				
See Identification Chart at beginning of Group				
- A -				
69	A(6 cyl.)-exc.A/C	Without intermittent wipers -not replaced	1	★C9AZ 14401-DF
69	A(8 cyl.)-exc.A/C	Without intermittent wipers	1	C9AZ 14401-DD
69	A(with A/C)	Without intermittent wipers	1	C9AZ 14401-DH
70	A-exc.A/C	"Before 11/1/69"	1	D0AZ 14401-A
70	A-exc.A/C	"From 11/1/69"	1	D0AZ 14401-BR
70	A-with A/C	"Before 11/1/69"	1	D0AZ 14401-B
70	A-with A/C	"From 11/1/69"	1	D0AZ 14401-BS
70	A-exc.A/C	"Before 11/1/69"	1	D0AZ 14401-D
70	A-exc.A/C	"From 11/1/69"	1	D0AZ 14401-BT
70	A-with A/C	With intermittent wipers	1	D0AZ 14401-BU
71	A-except A/C	"Before 3/1/71"	1	D1AZ 14401-A
71	A-except A/C	"From 3/1/71 to 4/15/71"	1	D1AZ 14401-G
71	A-exc.A/C	"From 4/15/71"	1	D1AZ 14401-K
71	A-with A/C - (manual control)-	"Before 4/15/71"	1	D1AZ 14401-H
71	A-with A/C - (manual control)-	"From 4/15/71"	1	D1AZ 14401-L
71	A-with A/T/C	"Before 3/1/71"	1	D1AZ 14401-E
71	A-with A/T/C	"From 3/1/71 to 4/15/71"	1	D1AZ 14401-J
71	A-with A/T/C	"From 4/15/71"	1	D1AZ 14401-M
72	A-without A/C		1	D2AZ 14401-A
72	A-with A/C - (manual control)		1	D2AZ 14401-B
72	A-with A/T/C		1	D2AZ 14401-C
- B -				
65	B-with single speed wipers		1	★ C5OZ 14401-E
65	B-with 2 speed wipers	Not replaced	1	★ C5OZ 14401-F
65	B-with single speed wipers		1	★CC50F 14401-A
65	B-with 2 speed wipers		1	★CC50F 14401-B
66	B-with single speed wipers	"Before 2/1/66"	1	★C6OZ 14401-C
66	B-with single speed wipers	"From 2/1/66"	1	C6OZ 14401-Z
66	B-with 2 speed wipers	"Before 2/1/66"	1	C6OZ 14401-D
66	B-with 2 speed wipers	"From 2/1/66"	1	C6OZ 14401-AA
67	B-except A/C		1	C7OZ 14401-E
67	B-with A/C		1	C7OZ 14401-F
68	B		1	C8OZ 14401-A
69	B-w/o intermittent wipers		1	C9OZ 14401-J
69	B-with intermittent wipers		1	C9OZ 14401-K
70	B	"Before 11/1/69"	1	D0OZ 14401-A
70	B	"From 11/1/69"	1	D0OZ 14401-N
71	B		1	D1OZ 14401-B
72	B-w/o A/C and/or intermittent wipers		1	D2OZ 14401-A
72	B-w/o A/C and/or intermittent wipers	"Before 11/1/71"	1	D2OZ 14401-E
72	B-w/o A/C and/or intermittent wipers	"From 11/1/71 to 1/3/72"	1	D2OZ 14401-J
72	B-w/o A/C and/or intermittent wipers-	"From 1/3/72"	1	D2OZ 14401-C
72	B-w/o A/C-with intermittent wipers	"Before 11/1/71"	1	D2OZ 14401-G
72	B-w/o A/C with intermittent wipers	"From 11/1/71 to 1/3/72"	1	D2OZ 14401-L
72	B-w/o A/C with intermittent wipers-	"From 1/3/72"	1	D2OZ 14401-B
72	B-with A/C-w/o intermittent wipers	"Before 11/1/71"	1	D2OZ 14401-F
72	B-with A/C w/o intermittent wipers	"From 11/1/71 to 1/3/72"	1	D2OZ 14401-K
72	B-with A/C w/o intermittent wipers-	"From 1/3/72"	1	D2OZ 14401-D
72	B-w/A/C-with intermittent wipers-	"Before 11/1/71"	1	D2OZ 14401-H
72	B-w/A/C-with intermittent wipers-	"From 11/1/71 to 1/3/72"	1	D2OZ 14401-M
72	B-with A/C with intermittent wipers-	"From 1/3/72"	1	D2OZ 14401-M

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued -				
See Identification Chart at beginning of Group				
- F -				
65	F - with single speed wipers-with generator	Not replaced	1	★C5ZZ 14401-E
65	F - with 2 speed wipers-with generator	Not replaced	1	★C5ZZ 14401-F
65	F (except 63B, 65B, 76B)-with single or 2 speed wipers "Before 4/1/65"	Must be used with basic 17B587 wiring-not used with fog lamp	1	C5ZZ 14401-M
65	F (except 63B, 65B, 76)-with single speed or 2 speed wipers "From 4/1/65"	Must be used with basic 17B587 wiring-not used with fog lamps	1	C5ZZ 14401-N
65	F(63B, 65B, 76B)	When used on units with 2 speed heater blower motor, basic 18A336 is required	1	C5ZZ 14401-G
66	F		1	C6ZZ 14401-F
67	F(except GT)-exc. w/tach.		1	C7ZZ 14401-AK
67	F(except GT)-with tach.		1	C7ZZ 14401-AL
67	F(GT)-exc. with tach. "Before 1/3/67"	Not replaced	1	★C7ZZ 14401-G
67	F(GT)-except with tachometer- "From 1/3/67 to 4/15/67"	Not replaced	1	★C7ZZ 14401-AC
67	F(GT)-exc. with tach. "From 4/15/67"	Not replaced	1	★C7ZZ 14401-AM
67	F(GT)-with tachometer "Before 1/3/67"	Replaced by C7ZZ 14401-AD(2/74)	1	★C7ZZ 14401-H
67	F(GT)- with tachometer - "From 1/3/67 to 4/15/67"	Not replaced	1	★C7ZZ 14401-AD
67	F(GT)-with tach. "From 4/15/67"	Not replaced	1	★C7ZZ 14401-AN
68	F(65 GT/CS)-with tachometer		1	
68	F-with or without fog lamps less tachometer		1	★C8ZZ 14401-C
68	F(65 GT/CS)-without tachometer		1	
68	F-with or without fog lamps with tachometer		1	★C8ZZ 14401-D
69	F-exc. A/C or tachometer "Before 4/15/69"	Except (302-4V Boss)	1	C9ZZ 14401-A
69	F-exc. A/C or tachometer "From 4/15/69"	Except (302-4V Boss)	1	C9ZZ 14401-AI
69	F-less tachometer "From 4/15/69 to 5/19/69"	With (302-4V Boss)	1	C9ZZ 14401-BC
69	F-less tachometer "From 5/19/69"	With (302-4V Boss)	1	C9ZZ 14401-BE
69	F-with tachometer, with or without A/C - "Before 4/15/69"	Except (302-4V Boss)	1	C9ZZ 14401-B
69	F (with tachometer, with or without A/C - "From 4/15/69"	Except (302-4V Boss)-not replaced	1	★C9ZZ 14401-AM
69	F-with A/C w/o tachometer "Before 4/15/69"	Except (302-4V-Boss)	1	C9ZZ 14401-C
69	F-with A/C w/o tachometer "From 4/15/69"	Except (302-4V-Boss)	1	C9ZZ 14401-AN
69	F-with tachometer "From 4/15/69 to 5/19/69"	With (302-4V Boss)	1	C9ZZ 14401-BB
69	F-with tachometer "From 5/19/69"	With (302-4V Boss)	1	C9ZZ 14401-BD
69	F(GT 350/500)	"Auxiliary"	1	C9ZZ 14401-D
70	F(63A, B, 65, 76)-w/o A/C or tachometer		1	D0ZZ 14401-BS
70	F(63A, B65, 76)-w/o A/C with tachometer - "Before 11/1/69"		1	D0ZZ 14401-B
70	F(63A, B, 65, 76)-w/o A/C with tachometer- "From 11/1/69"		1	D0ZZ 14401-BM
70	F(63A, B, 65, 76)-with A/C without tachometer- "Before 11/1/69"		1	D0ZZ 14401-C
70	F(63A, B, 65, 76)-with A/C w/o tachometer- "From 11/1/69"		1	D0ZZ 14401-BN
70	F(63C)-without tachometer "Before 11/1/69"		1	D0ZZ 14401-K
70	F(63C)-without tachometer "From 11/1/69"		1	D0ZZ 14401-BV
70	F(63C)-with tachometer "Before 11/1/69"		1	D0ZZ 14401-J
70	F(63C)-with tachometer "From 11/1/69"		1	D0ZZ 14401-BX
71	F(63)(exc. 351 Boss)-w/o instrument pkg., sports interior pkg. or A/C		1	D1ZZ 14401-N
71	F(65, 76)-w/o instrument pkg. or A/C		1	
71	F(63D, 65, 76)-without A/C with instrument pkg. "Before 10/1/70"		1	D1ZZ 14401-E
71	F(63)(exc. 351 Boss)-w/sports interior pkg., and/or instrument pkg. w/o A/C - "From 10/1/70 to 11/1/70"		1	
71	F(63D)(351 Boss)- "From 10/1/70 to 11/1/70"		1	
71	F(65, 76)-w/instrument pkg. w/o A/C - "From 10/1/70 to 11/1/70"		1	

* Fold and insulate unused leads
May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued-				
See Identification Chart at beginning of Group				
- F -				
71	F(63)(exc.351 Boss)-w/sports interior pkg., and/or instrument pkg. w/o A/C-	"From 11/1/70"	1	D1ZZ 14401-H
71	F(63D)(351 Boss)-	"From 11/1/70"	1	
71	F(65,76)-w/instrument pkg.w/o A/C-	"From 11/1/70"	1	
71	F(63D,65,76)-with A/C w/o instrument pkg.- "Before 10/1/70"		1	D1ZZ 14401-C
71	F(63)(exc.351 Boss)-w/o instrument pkg., and/or sports interior pkg. w/ A/C-	"From 10/1/70 to 11/1/70"	1	D1ZZ 14401-C
71	F(65,76)-w/o instrument pkg., w/ A/C-	"From 10/1/70 to 11/1/70"	1	
71	F(63)(exc.351 Boss)-w/o instrument pkg., and/or sports interior pkg. w/ A/C-	"From 11/1/70 to 3/1/71"	1	D1ZZ 14401-J
71	F(65,76)-w/o instrument pkg., w/ A/C-	"From 11/1/70 to 3/1/71"	1	
71	F(63)(exc. 351 Boss)-w/o instrument pkg. and/or sports interior pkg. -with A/C -	"From 3/1/71"	1	D1ZZ 14401-P
71	F(65,76)-w/o instrument pkg. -with A/C -	"From 3/1/71"	1	
71	F(63D,65,76)-with A/C with instrument pkg. - "Before 10/1/70"		1	D1ZZ 14401-E
71	F(63)(exc.351 Boss)-w/ instrument pkg., sports interior pkg. w/ A/C-	"From 10/1/70 to 11/1/70"	1	
71	F(65,76)-w/ instrument pkg. w/ A/C-	"From 10/1/70 to 11/1/70"	1	
71	F(63)(exc.351 Boss)-w/ instrument pkg., sports interior pkg. w/ A/C-	"From 11/1/70 to 3/1/71"	1	D1ZZ 14401-L
71	F(65,76)-w/instrument pkg. w/ A/C-	"From 11/1/70 to 3/1/71"	1	
71	F(63)(exc. 351 Boss)-w/instrument pkg., sports interior pkg. -w/A/C "From 3/1/71"		1	D1ZZ 14401-R
71	F(65,76)-w/instrument pkg., with A/C -	"From 3/1/71"	1	
71	F(63R)-without A/C	"Before 10/1/70"	1	D1ZZ 14401-D
71	F(63)(exc.351 Boss)-w/ sports interior pkg., w/o A/C-	"From 10/1/70 to 11/1/70"	1	
71	F(63)(exc.351 Boss)-w/ sports interior pkg., w/o A/C	"From 11/1/70"	1	D1ZZ 14401-K
71	F(63R)-with A/C	"Before 10/1/70"	1	D1ZZ 14401-F
71	F(63)(exc.351 Boss)-w/ sports interior pkg., w/ A/C-	"From 10/1/70 to 11/1/70"	1	
71	F(63)(exc.351 Boss)-w/ sports interior pkg. w/ A/C-	"From 11/1/70 to 3/1/71"	1	D1ZZ 14401-M
71	F(63)(exc. 351 Boss)-w/sports interior pkg.- "From 3/1/71"		1	D1ZZ 14401-Q
72	F-w/o tachometer	"Before 12/1/72"	1	D2ZZ 14401-A
72	F-w/o tachometer	"From 12/1/72"	1	D2ZZ 14401-E
72	F-with tachometer	"Before 12/1/71"	1	D2ZZ 14401-B
72	F-with tachometer	"From 12/1/71 to 1/3/72"	1	D2ZZ 14401-D
72	F-with tachometer	"From 1/3/72"	1	D2ZZ 14401-F
- L -				
71	L(exc. A/C, radio or sports appearance group)		1	D1FZ 14401-D
71	L(with A/C)		1	D1FZ 14401-J

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued -				
See Identification Chart at beginning of Group				
- L -				
71	L(exc. A/C, with radio and/or sports appearance group) "Before 7/12/71"		1	D1FZ 14401-H
71/72	L(exc. A/C, with radio and/or sports appearance group) "From 7/12/71"		1	D2FZ 14401-A
72	L-w/o A/C and/or rallye pkg.	Without ignition restraint system	1	D2FZ 14401-J
72	L-w/o A/C and/or rallye pkg.	With ignition restraint system	1	D2FZ 14401-K
72	L-w/A/C-without rallye pkg.- "Before 12/1/71"		1	D2FZ 14401-E
72	L-w/A/C-without rallye pkg.- "From 12/1/71"	Without ignition restraint system	1	D2FZ 14401-F
72	L-with A/C -without rallye pkg.	With ignition restraint system	1	D2FZ 14401-L
- P -				
70	P-without locking column "Before 4/14/69"		1	D0DZ 14401-D
70	P-without locking column except A/C - "From 4/14/69"		1	D0DZ 14401-G
70	P-without locking column with A/C - "From 4/14/69"		1	D0DZ 14401-R
70	P-with locking steering column		1	D0DZ 14401-AL
71	P(54A, 62A)		1	D1DZ 14401-C
71	P(62D) "Before 10/27/70"		1	D1DZ 14401-B
71	P(62D) "From 10/27/70 to 1/4/71"		1	D1DZ 14401-D
71	P(62D) "From 1/4/71"		1	D1DZ 14401-E
72	P(54A, 62A) "Before 1/3/72"	Without grille lamps	1	D2DZ 14401-A
72	P(54A, 62A) "From 1/3/72"	Without grille lamps	1	D2DZ 14401-C
72	P(54A, 62A, D)	With grille lamps	1	D2DZ 14401-D
- S -				
65	S (except transistorized ignition)-with A/C		1	C5SZ 14401-B
66	S-with trans. ignition		1	C6SZ 14401-F
69	S-exc. A/T/C "Before 10/15/68"		1	C9SZ 14401-A
69	S-exc. A/T/C "From 10/15/68 to 1/6/69"		1	C9SZ 14401-J
69	S-except A/T/C without brake skid control- "From 1/6/69"		1	
69	S-exc. A/T/C with brake skid control- "From 1/6/69"		1	C9SZ 14401-S
69	S-with A/T/C "Before 10/15/68"		1	C9SZ 14401-B
69	S-with A/T/C "From 10/15/68 to 1/6/69"		1	C9SZ 14401-K
69	S-with A/T/C without brake skid control- "From 1/6/69"		1	
69	S-with A/T/C with brake skid control- "From 1/6/69"		1	C9SZ 14401-R
70	S-without A/T/C	Without intermittent wipers	1	D0SZ 14401-A
70	S-with A/T/C	Without intermittent wipers	1	D0SZ 14401-B
70	S-without A/T/C	With intermittent wipers	1	D0SZ 14401-C
70	S-with A/T/C	With intermittent wipers	1	D0SZ 14401-D
70	S-without A/T/C "Before 12/1/69"	With hydro wipers	1	D0SZ 14401-BN
70	S-without A/T/C "From 12/1/69 to 1/19/70"	With hydro wipers	1	D0SZ 14401-BS
70	S-without A/T/C "From 1/19/70 to 3/16/70"	With hydro wipers	1	D0SZ 14401-BX
70	S-without A/T/C "From 3/16/70 to 5/1/70"	With hydro wipers	1	D0SZ 14401-BZ
70	S-without A/T/C "From 5/1/70"	With hydro wipers	1	D0SZ 14401-CB
70	S-with A/T/C "Before 12/1/69"	With hydro wipers	1	D0SZ 14401-BP
70	S-with A/T/C "From 12/1/69 to 1/19/70"	With hydro wipers	1	D0SZ 14401-BU
70	S-with A/T/C "From 1/19/70 to 3/16/70"	With hydro wipers	1	D0SZ 14401-BY
70	S-with A/T/C "From 3/16/70"	With hydro wipers	1	D0SZ 14401-CA
71	S-without A/T/C		1	D1SZ 14401-C
71	S-with A/T/C		1	D1SZ 14401-D
72	S-without A/T/C - except California - "Before 11/1/71"		1	D2SZ 14401-A
72	S-without A/T/C - except California - "From 11/1/71"		1	D2SZ 14401-E
72	S-without A/T/C - California - "Before 11/1/71"		1	D2SZ 14401-C
72	S-without A/T/C - California - "From 11/1/71"		1	D2SZ 14401-G

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued -				
See Identification Chart at beginning of Group				
- S -				
72	S-with A/T/C - except California - "Before 11/1/71"		1	D2SZ 14401-B
72	S with A/T/C - except California - "From 11/1/71"		1	D2SZ 14401-F
72	S-with A/T/C - California "Before 11/1/71"		1	D2SZ 14401-D
72	S-with A/T/C - California "From 11/1/71"		1	D2SZ 14401-H
- U -				
66	U		1	C6TZ 14401-AU
66	U	Used with 55 amp. Ford alternator	1	C6TZ 14401-DY
67	U	"Before Ser. A42,001" Used with 38 or 45 amp. Ford alternator	1	★C7TZ 14401-CA
67	U	"From Ser. A42,001" Used with 38 or 45 amp. Ford alternator	1	C7TZ 14401-DV
67	U	"Before Ser. A42,001" Used with 55 amp. Ford alternator	1	★C7TZ 14401-CB
67	U	"From Ser. A42,001" Used with 55 amp. Ford alternator	1	★C7TZ 14401-DY
68	U	Used with 38 or 45 amp. Ford alternator	1	C8TZ 14401-DB
68	U	Used with 55 amp. Ford alternator	1	★C8TZ 14401-DC
69	U	"Before Ser. E24,001" Used with 38 or 45 amp. alternator	1	C9TZ 14401-A
69	U	"From Ser. E24,001" Used with 38 or 45 amp. Ford alternator	1	C9TZ 14401-AY
69	U	"Before Ser. E24,001" Used with 55 amp. Ford alternator	1	C9TZ 14401-B
69	U	"From Ser. E24,001" Used with 55 amp. Ford alternator	1	C9TZ 14401-AZ
70	U	"Before Ser. H50,001" Used with 38 or 45 amp. Ford alternator	1	D0BZ 14401-A
70	U	"Before Ser. H50,001" Used with 55 amp. Ford alternator	1	D0BZ 14401-B
70	U	"From Ser. H50,001" Used with 38, 45 or 55 amp. alternator	1	D0BZ 14401-E
71/72	U	"Before Ser. P60,001"	1	D1BZ 14401-A
72	U	"From Ser. P60,001"	1	D3BZ 14401-A
- X -				
67	X-except A/C		1	C7DZ 14401-C
67	X-with A/C	Not replaced	1	★C7DZ 14401-D
68	X		1	C8DZ 14401-A
69/70	X		1	C9DZ 14401-E
65/	A	Screw (wiring to instr. cluster)-No. 8-32 x 3/8"	1	★40904-S8
65/	A	Screw(wiring & clip 377691-S to instrument panel) No. 10-12 x 1/2"	1	42127-S8(U248C)
65/	S	Screw (wiring to instrument panel)	1	
65/	A, S	Lockwasher - No. 10	AR	34903-S8 (X96)
65/	A	Screw (wiring and clip 377846-S to brake pedal support)-No. 10-16 x 3/8"	1	42120-S8(U248)
65/	A	Clip(wiring instr. panel)-	1	★377691-S7
65/	A	Clip(wiring & junction block to instrument panel)	1	★376801-S
65	A	Screw (wiring and clip 370805-S100 to side cowl panel)-No. 10-16 x 3/8"	1	42120-S8(U248)
65/	A	Nut (wiring and clip 377692-S to instrument cluster)-No. 10-24	2	34053-S8(M156)
65/	A	Clip	AR	★377846-S
65/	A	Clip	2	★377692-S
65/	A	Flat washer-No. 10	3	44713-S8(X13)
65	A	"Before 3/1/65" Nut (wiring and clip 379962-S to instrument panel)-No. 8-32	3	45253-S7-8(M176)
65/66	A	"From 3/1/65" Nut (wiring and clip 379962-S to instrument panel)-No. 10-24	3	359606-S8 (MM291A)
65/66	A	Clip	3	379962-S(GG257)
66	A	Clip (wiring to R. H. & L. H. inner cowl panel)	4	★370805-S100
66	B, X-with S/T or O/D	Clip (wiring to steering column bracket)	1	
69	A	Clip (wiring to side cowl panel)	1	358350-S(GG172)
71	A	Clip (attach wiring to heater)	AR	384007-S(GG369)
70	A	Screw (wiring to starter)-No. 8-15 x 1/2"	1	52012-S(U202)
70/	A	Screw (attach wiring to windshield wiper motor at dash panel)-No. 8-18 x 1/2"	AR	
70	B	Attach wiring to air register control	AR	
70	A	Clip (wiring to starter solenoid)	1	376219-S(GG151)
71	A	Clip (attach wiring to instrument panel)	1	
70/	A	Screw-1/4-14 x 1/2" (wiring to instrument panel)	AR	55981-S(U254E)
70/	A	Clip (wiring to stop lamp switch)	AR	383182-S(GG359)

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued -				
See Identification Chart at beginning of Group				
70/	A	Clip (wiring to instrument panel)	AR	382932-S(GG338C)
71	A	Clip (attach wiring to brake pedal support)	AR	384386-S(GG271A)
71	A	Clip-No. 8-18 (attach wiring to instrument panel)	AR	384246-S(GG339A)
70/	A	Strap (attach wiring to cluster)	AR	383313-S(YY6)
71	A	Clip (wiring to dash panel)	AR	372172-S(GG228)
65	B	Screw (wiring & junction block to instrument cluster)-No. 8-18 x 3/8"	1or2	52720-S8(U380)
65	B-with A/C	Screw (wiring & junction block to lower flange of instrument panel)-No. 10-32 x 3/4"	2	*50535-S8
65	B	Screw (wiring and clip 376189-S to panel-dash)	1	42120-S8(U248)
65	B-with A/C	Clip (wiring to instr. panel lower flange)	2	*377846-S
65	B-except A/C	Clip	2	*376118-S
65	B	Clip	1	*376189-S
65/	B	Lockwasher-No. 10	1	34903-S8(X96)
70	B	Screw-No. 8-15 x 1"(attach wiring to brake suppt.)	AR	42151-S(U247)
65/	B	Clip(wiring & junction block to cowl top inner panel)	1	*370805-S100
65/	A	Clip (wiring to cowl side panel)	1	
65/	B	Nut(wiring and clip 370805-S to cowl top inner panel) No. 10-24	1	34053-S8(M156)
66	B, X	"Before 3/1/66"		
		Nut (wiring and clip 380725-S to vacuum booster) -5/16"-18 x 1/2"	2	33797-S7(M50)
66	B, X	"Before 3/1/66"		
		Clip	2	*380725-S
66	B, X	"From 3/1/66"		
		Clip	1	*377943-S
66	B, X			
		Clip	1	*380752-S
66	B, X			
		Clip (wiring to speaker opening in instrument panel)-attach with existing parts	2	*380755-S
66	B, X-with S/T or O/D			
		Screw (wiring and clip 370805-S100 to steering column bracket)-No. 10-12 x 1/2"	1	42127-S8(U248C)
66	B, X	"From 3/1/66"		
		Screw (wiring, windshield washer hose & clip 377943-S to cowl top panel)	1	
66	B, X			
		Screw (wiring and clip 380752-S to instrument panel)	1	
66/	B, X			
		Strap	AR	376914-S(YY2)
68/	B, X			
		Clip (wiring to inst. panel bracket)	AR	382033-S100 (GG303)
70	B			
		Clip (wiring to brake pedal support)	AR	382194-S(GG305)
65/	B			
		Nut (wiring to ignition switch)-No. 10-32	1	34079-S7(M163)
71	B			
		Screw-No. 10-12 x 5/8"(attach clock ground wire)	1	42014-S(U240)
		Lockwasher-No. 10	AR	34939-S8(X86)
		Flat washer-No. 10	1	44713-S8(X13)
71	B			
		Clip (attach wiring to dash panel)	AR	372172-S(GG228)
65	F(except 76-with power top)			
65	F	"Before 9/29/64"		
		Clip (wiring to instrument panel brace)	3	*377986-S
		Nut (wiring and clip 377904-S to cowl top inner panel)-No. 10-24	1	34053-S8(M156)
65/	F	"From 9/29/64"		
		Nut (wiring & shield to cowl top)	1	
65/	F			
		Lockwasher-No. 10	1	34903-S8(X96)
65/	F			
		Screw (wiring to instrument panel brace)- No. 10-12 x 1/2"	1	52727-S8(U382)
65/	F	"From 9/29/64"		
		Screw (wiring and clip 370805-S100 to vent air outlet duct)-No. 8-18 x 3/8"	1	376378-S101(UU97)
65/	F			
		Screw (wiring & clip 370805-S100 to cowl top inner panel)	AR	42127-S8(U248C)
65	F	"Before 9/29/64"		
		Clip	1	*377904-S
65/	F	"From 9/29/64"		
		Clip	1	*370805-S100
65/	F			
		Clip (wiring to wiper motor bracket)	1	372047-S100
66	F			
		Clip (wiring to R. H. cowl side panel)	1	(GG217)
66	F			
		Wiring to L. H. cowl side panel)	1	*377986-S
65/	F			
		Clip (wiring to instrument panel lower flange)	4	*376118-S
66	F			
		Clip (wiring to brake pedal support)	1	

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued				
See Identification Chart at beginning of Group				
67	F	Clip (wiring to cowl top panel)	1	352369-S100(GG26)
68	F	Clip (wiring to cowl top panel)	1	382193-S100 (GG293)
70/	F	Clip (wiring to instrument panel)	AR	383207-S(GG271)
70	F	Clip (wiring to cowl panel)	AR	382184-S(GG304)
70	F	Clip (wiring to instrument panel)	2	382185-S(GG283)
71	F	Clip(attach wiring to fender apron)	2	383477-S(GG271C)
71	F	Clip (attach wiring to instrument panel)	AR	382033-S(GG303)
71	F	Clip (attach wiring to fuse panel)	AR	358350-S(GG172)
70	P	Nut 1/4"-20 (wiring to clip)	AR	33795-S(M49)
70	P	Clip (wiring to brake pedal support)	AR	377599-S(GG262)
70	P	Clip (wiring to roof side)	AR	382931-S(GG338)
70/	P	Clip (wiring to dash panel)	AR	372172-S(GG228)
65	S	Clip (wiring to instrument cluster)	2	★372888-S100
65/	S	Lockwasher-1/4"	1	34940-S7(X88)
65/	S	Screw(wiring to brake pedal suppt.)-1/4"-20 x 5/8"	1	★39894-S
65/	S	Strap (wiring harness retaining)	2	376914-S(YY2)
65/	S	Bolt & clip (wiring to instrument panel)- No. 10-24	3	372719-S100 (BB643)
65/	S	Nut (wiring to instrument panel)-No. 10-24	3	45243-S7-8(M178)
65	S	"Before 11/20/64" Clip (wiring to instrument cluster)	4	★378610-S
65/	S	"From 11/20/64" Clip (wiring to instrument cluster)	4	★380319-S
65/	S	Clip (wiring to instrument panel)	3	★377719-S
70	S	Clip (wiring to instrument panel)	8	384008-S100 (GG368)
70/	S	Clip (attach wiring to instrument panel)	AR	383312-S(GG271B)
70	S	Screw-No.8-15 x 5/8"(attach ground wire of 14401 to instrument panel)	2	52554-S(U230)
70	S	Clip(attach wiring to instrument panel)	3	376219-S(GG151)
71	S	Clip-attach wiring to 01508 brake support	1	372172-S(GG228)
71	S	Clip (attach wiring to fender apron)	2	383207-S(GG271)
66/	U	Strap(attach wiring to fender shield)	AR	376914-S(YY2)
68	U	Clip (wiring to lower instrument panel)	1	380668-S100 (GG221A)
68	U	Nut 1/4" -20 (Clip to wiring to lower instrument panel)	1	45234-S7(M179)
69	U	Strap(attach wiring to speedometer cable)	1	383313-S(YY6)
71	U	Screw-1/4"-20 x 3/4"(attach wiring to lower instrument panel)	AR	38294-S(U141)
71	U	Nut-1/4"-20(attach wiring to lower instru.panel)	AR	33920-S(M25)
71	U	Screw-No.8-32 x 13/16"(attach wiring to instrument panel)	AR	354988-S(BB635)
71	U	Nut-No.8-32(attach wiring to instrument panel)	AR	34052-S(M155)
71	U	Screw-No.8-15 x 1/2"(wiring to dash panel)	8	52012-S(U202)
71	U	Clip(wiring to fuse panel)	1	376219-S(GG151)
71	U	Screw-1/4"-14 x 1/2"(attach clip to shield)	AR	55981-S(J254E)
71	U	Nut-No.10-24(wiring to fuse panel)	1	34053-S(M156)
71	U	Strap-adjustable(attach wiring to shield)	AR	382175-S(GG289)
71/	U	Clip(attach wiring to instrument cluster)	AR	381921-S(GG330)
71/	U	Clip(attach wiring to lower instrument panel)	AR	
65/70	X	Clip (wiring to instrument cluster)	2	353547-S2(GG173)
65/70	X	Clip (wiring to instrument cluster)	2	372861-S100(GG68)
65	X	Screw (wiring and clip 370805-S100 to brake pedal support)-No. 10-12 x 1/2"	1	42127-S8(U248C)
65/66	X	Clip	1	★370805-S100
65	X	Clip	1	★370409-S100
65/70	X	Nut (wiring and clip 370409-S100 or 370805-S100 to cowl top inner panel)-No. 10-24	1	34053-S8(M156)
65/70	X	Lockwasher-No. 10	1	34903-S8(X96)
14A403 PAD - WINDOW REGULATOR SAFETY RELAY				
67/	S-with power windows	Rubber	1	C7SZ 14A403-A

14401 WIRING ASSY. - INSTRUMENT PANEL TO DASH PANEL - continued

See Identification Chart at beginning of Group

14405 WIRING ASSY. - REAR LAMP

WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE FOR 1965 and SUBSEQUENT MODELS

The purpose of this guide is to facilitate the identification of the Service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
S8ZS 13A449-A	C8ZZ 14405-C	C6OB 14405-C	C6OZ 14405-B
C9SX 13A455-A	C9ZZ 14405-J	C6OB 14405-E	★C6OZ 14405-F
C4ZB 14405-B	★C5ZZ 14405-B	C6OB 14405-F	★C6OZ 14405-F
		C6OB 14405-H	★C6OZ 14405-F
C5AB 14405-H	★C5AZ 14405-B	C6SB 14405-A	★C6SZ 14405-A
C5AB 14405-K	★C5AZ 14405-E	C6SB 14405-D	★C6SZ 14405-D
C5AB 14405-M	★C5AZ 14405-C	C6SB 14405-S	★C6SZ 14405-S
C5AB 14405-N	★C5AZ 14405-F	C6SB 14405-V	★C6SZ 14405-V
C5DB 14405-AG	★C5DZ 14405-AH	C6TB 14405-B	★C6TZ 14405-C
C5DB 14405-AH	★C5DZ 14405-AH	C6TB 14405-C	★C6TZ 14405-C
C5DB 14405-AJ	★C5DZ 14405-AM	C6ZB 14405-J	★C6ZZ 14405-J
C5DB 14405-AK	★C5DZ 14405-AM	C6ZB 14405-K	★C6ZZ 14405-K
C5DB 14405-AL	★C5DZ 14405-AM	ED-C6ZB 14405-D	★C6ZZ 14405-K
C5DB 14405-AM	★C5DZ 14405-AM		
C5OB 14405-F	★C5OZ 14405-B	★C7AB 14405-H	★C7AZ 14405-A
C5OB 14405-H	★C5OZ 14405-D	C7AB 14405-J	★C7AZ 14405-B
C5SB 14405-G	★C5SZ 14405-A	C7AB 14405-K	★C7AZ 14405-C
C5SB 14405-H	★C5SZ 14405-B	C7AB 14405-L	★C7AZ 14405-D
C5SB 14405-J	★C5SZ 14405-C	C7AB 14405-M	★C7AZ 14405-M
C5SB 14405-K	★C5SZ 14405-D	C7AB 14405-N	★C7AZ 14405-N
C5SB 14405-L	★C5SZ 14405-L	C7DB 14405-A	★C7DZ 14405-A
C5SB 14405-M	★C5SZ 14405-M	C7OB 14405-A	★C7OZ 14405-A
C5SB 14405-S	★C5SZ 14405-S	C7OB 14405-B	C7OZ 14405-B
C5SB 14405-T	★C5SZ 14405-T	C7OB 14405-G	★C7OZ 14405-A
C5SB 14405-U	★C5SZ 14405-U	C7OB 14405-H	C7OZ 14405-B
C5SB 14405-V	★C5SZ 14405-V	C7SB 14405-C	★C7SZ 14405-B
C5ZB 14405-F	★C5ZZ 14405-D	C7SB 14405-G	★C7SZ 14405-G
C5ZB 14405-K	★C5ZZ 14405-C	C7TB 14405-V	C7TZ 14405-N
		C7ZB 14405-A	★C7ZZ 14405-K
C6AB 14405-B	★C6AZ 14405-B	C7ZB 14405-B	★C7ZZ 14405-K
C6AB 14405-C	C6AZ 14405-E	C7ZB 14405-C	★C7ZZ 14405-C
C6AB 14405-D	★C6AZ 14405-D	C7ZB 14405-D	★C7ZZ 14405-D
C6AB 14405-E	C6AZ 14405-E	C7ZB 14405-J	★C7ZZ 14405-J
C6AB 14405-F	★C6AZ 14405-F	C7ZB 14405-K	★C7ZZ 14405-K
C6AB 14405-G	C6AZ 14405-E		
C6AB 14405-H	★C6AZ 14405-H	C8AB 14405-A	★C8AZ 14405-AZ
C6AB 14405-J	C6AZ 14405-E	C8AB 14405-B	C8AZ 14405-B
C6AB 14405-L	C6AZ 14405-M	C8AB 14405-C	★C8AZ 14405-AV
C6AB 14405-M	C6AZ 14405-M	C8AB 14405-D	★C8AZ 14405-D
C6AB 14405-U	C6AZ 14405-E	C8AB 14405-E	★C8AZ 14405-E
C6AB 14405-V	C6AZ 14405-E	C8AB 14405-F	★C8AZ 14405-F
C6AB 14405-Y	★C6AZ 14405-B	C8AB 14405-G	★C8AZ 14405-AV
ED-C6AB 14405-AB	★C6AZ 14405-F	C8AB 14405-H	★C8AZ 14405-D
ED-C6AB 14405-AC	★C6AZ 14405-H	C8AB 14405-J	★C8AZ 14405-AZ
C6DB 14405-A	C6DZ 14405-J	C8AB 14405-K	C8AZ 14405-B
C6DB 14405-B	C6DZ 14405-J	C8AB 14405-L	★C8AZ 14405-E
C6DB 14405-E	★C6DZ 14405-F	C8AB 14405-M	★C8AZ 14405-AZ
C6DB 14405-F	★C6DZ 14405-F	C8AB 14405-N	★C8AZ 14405-F
C6DB 14405-G	C6DZ 14405-J	C8AB 14405-R	★C8AZ 14405-AV
C6DB 14405-H	★C6DZ 14405-F	C8AB 14405-S	★C8AZ 14405-D
C6DB 14405-J	C6DZ 14405-J	C8AB 14405-T	C8AZ 14405-B
C6OB 14405-A	C6OZ 14405-B	C8AB 14405-U	★C8AZ 14405-E
C6OB 14405-B	C6OZ 14405-B	C8AB 14405-V	★C8AZ 14405-AZ
		C8AB 14405-Y	★C8AZ 14405-F

14405 WIRING ASSY. - REAR LAMP - continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C8AB 14405-Z	★C8AZ 14405-AV	C9WB 14405-R	C9WY 14405-B
C8AB 14405-AA	★C8AZ 14405-D	C9ZB 14405-C	C9ZZ 14405-A
C8AB 14405-AB	C8AZ 14405-B	C9ZB 14405-D	C9ZZ 14405-B
C8AB 14405-AC	★C8AZ 14405-E	C9ZB 14405-E	C9ZZ 14405-A
C8AB 14405-AD	★C8AZ 14405-AZ	C9ZB 14405-F	C9ZZ 14405-B
C8AB 14405-AL	★C8AZ 14405-F		
C8AB 14405-AM	★C8AZ 14405-AV	D0AB 14405-Z	D0AZ 14405-AD
C8AB 14405-AR	C8AZ 14405-B	D0AB 14405-AA	D0AZ 14405-D
C8AB 14405-AS	★C8AZ 14405-E	D0AB 14405-AD	D0AZ 14405-AD
C8AB 14405-AT	★C8AZ 14405-AZ	D0AB 14405-AE	D0AZ 14405-AE
C8AB 14405-AU	★C8AZ 14405-AU	D0AB 14405-AH	D0AZ 14405-A
C8AB 14405-AV	★C8AZ 14405-AV	D0AB 14405-AJ	D0AZ 14405-B
C8AB 14405-AY	★C8AZ 14405-AY	D0AB 14405-AK	D0AZ 14405-A
C8AB 14405-AZ	★C8AZ 14405-AZ	D0AB 14405-AL	D0AZ 14405-B
C8DB 14405-A	★C8DZ 14405-L	D0AB 14405-AP	D0AZ 14405-AE
C8DB 14405-B	★C8DZ 14405-M	D0AB 14405-AR	D0AZ 14405-AD
C8DB 14405-J	★C8DZ 14405-L	D0AB 14405-AX	D0AZ 14405-B
C8DB 14405-K	C8DZ 14405-B	D0AB 14405-AY	D0AZ 14405-A
C8DB 14405-L	★C8DZ 14405-L	ED-D0AB 14405-AS	D0AZ 14405-B
C8DB 14405-M	★C8DZ 14405-M	ED-D0AB 14405-AT	D0AZ 14405-A
C8OB 14405-A	★C8OZ 14405-C	D0BB 14405-A	D0BZ 14405-A
C8OB 14405-B	★C8OZ 14405-D	D0DB 14405-G	D0DZ 14405-G
C8OB 14405-C	★C8OZ 14405-C	D0DB 14405-H	D0DZ 14405-G
C8OB 14405-D	★C8OZ 14405-D	ED-D0DB 14405-B	D0DZ 14405-C
C8OB 14405-E	★C8OZ 14405-E	ED-D0DB 14405-F	D0DZ 14405-C
C8OB 14405-F	★C8OZ 14405-F	ED-D0DB 14405-G	D0DZ 14405-C
C8OB 14405-G	★C8OZ 14405-C	D0OB 14405-L	D0OZ 14405-S
C8OB 14405-H	★C8OZ 14405-D	D0OB 14405-P	D0OZ 14405-B
C8OB 14405-J	★C8OZ 14405-F	D0OB 14405-S	D0OZ 14405-S
C8OB 14405-K	★C8OZ 14405-C	D0OB 14405-T	D0OZ 14405-B
C8OB 14405-L	★C8OZ 14405-D	D0OB 14405-U	D0OZ 14405-S
C8OB 14405-M	★C8OZ 14405-E	D0SB 14405-N	D0SZ 14405-Y
C8OB 14405-N	★C8OZ 14405-C	D0SB 14405-P	D0SZ 14405-Z
C8OB 14405-R	★C8OZ 14405-D	D0SB 14405-R	D0SZ 14405-AA
C8OB 14405-S	★C8OZ 14405-F	D0SB 14405-S	D0SZ 14405-AB
C8OB 14405-U	★C8OZ 14405-C	D0SB 14405-Y	D0SZ 14405-Y
C8OB 14405-Z	★C8OZ 14405-D	D0SB 14405-Z	D0SZ 14405-Z
C8SB 14405-A	★C8SZ 14405-A	D0SB 14405-AA	D0SZ 14405-AA
C8SB 14405-B	★C8SZ 14405-A	D0SB 14405-AB	D0SZ 14405-AB
C8SB 14405-G	★C8SZ 14405-G	D0SB 14405-AC	D0SZ 14405-AC
C8TB 14405-CM	C7TZ 14405-N	D0SB 14405-AE	D0SZ 14405-AE
C8ZB 14405-A	★C8ZZ 14405-A	D0SB 14405-AF	D0SZ 14405-AF
C8ZB 14405-B	★C8ZZ 14405-F	D0SB 14405-AH	D0SZ 14405-AD
C8ZB 14405-C	★C8ZZ 14405-A	D0SB 14405-AJ	D0SZ 14405-AF
C8ZB 14405-D	★C8ZZ 14405-F	D0SB 14405-AK	D0SZ 14405-AE
C8ZB 14405-E	★C8ZZ 14405-E	ED-D0SB 14405-AL	D0SZ 14405-AD
C8ZB 14405-F	★C8ZZ 14405-F	ED-D0SB 14405-AM	D0SZ 14405-AC
C8ZX 14405-A	★C8ZZ 14405-C	D0ZB 14405-V	D0ZZ 14405-U
		D0ZB 14405-X	D0ZZ 14405-U
		ED-D0ZB 14405-S	D0ZZ 14405-B
		ED-D0ZB 14405-T	D0ZZ 14405-U
C9AB 14405-A	C9AZ 14405-L	D1AB 14405-AB	D1AZ 14405-A
C9AB 14405-B	C9AZ 14405-M	D1AB 14405-BB	D1AZ 14405-B
C9AB 14405-C	C9AZ 14405-C	D1AB 14405-CD	D1AZ 14405-C
C9AB 14405-D	C9AZ 14405-D	D1AB 14405-DB	D1AZ 14405-D
C9AB 14405-J	C9AZ 14405-C	D1AB 14405-EB	D1AZ 14405-E
C9AB 14405-K	C9AZ 14405-D	D1AB 14405-FC	D1AZ 14405-F
C9AB 14405-L	C9AZ 14405-L	D1BB 14405-AA	D1BZ 14405-A
C9AB 14405-M	C9AZ 14405-M	D1DB 14405-BA	D1DZ 14405-B
C9AB 14405-S	C9AZ 14405-C	D1OB 14405-AA	D1OZ 14405-A
C9AB 14405-T	C9AZ 14405-D	D1OB 14405-BA	D1OZ 14405-B
ED-C9AB 14405-N	C9AZ 14405-L	D1SB 14405-EC	D1SZ 14405-L
ED-C9AB 14405-R	C9AZ 14405-M	D1SB 14405-ED	D1SZ 14405-L
C9DB 14405-B	C9DZ 14405-A	D1SB 14405-FC	D1SZ 14405-M
C9OB 14405-F	C9OZ 14405-F	D1SB 14405-FD	D1SZ 14405-M
C9OB 14405-G	C9OZ 14405-G	D1SB 14405-GB	D1SZ 14405-G
C9OB 14405-H	C9OZ 14405-C	D1SB 14405-GC	D1SZ 14405-G
C9OB 14405-K	C9OZ 14405-K	D1SB 14405-HB	D1SZ 14405-C
C9OB 14405-L	C9OZ 14405-C	D1SB 14405-HC	D1SZ 14405-H
C9SB 14405-B	C9SZ 14405-A	D1SB 14405-JB	D1SZ 14405-J
C9SB 14405-C	C9SZ 14405-C		
C9SB 14405-E	C9SZ 14405-E		
C9SB 14405-F	C9SZ 14405-E		
ED-C9SB 14405-E	C9SZ 14405-E		

14405 WIRING ASSY. - REAR LAMP - continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
D1SB 14405-JC	D1SZ 14405-J	D2OB 14405-CD	D2OZ 14405-C
D1SB 14405-KB	D1SZ 14405-B	D2OB 14405-CE	D2OZ 14405-C
D1SB 14405-KC	D1SZ 14405-K	D2OB 14405-DD	D2OZ 14405-D
D1ZB 14405-AD	D1ZZ 14405-B	D2OB 14405-EE	D2OZ 14405-E
D1ZB 14405-AF	D1ZZ 14405-A	D2OB 14405-EF	D2OZ 14405-E
D1ZB 14405-AG	D1ZZ 14405-C	D2OB 14405-FF	D2OZ 14405-F
D1ZB 14405-AD	D1FZ 14405-A	D2OB 14405-GH	D2OZ 14405-G
D1ZB 14405-BC	D1FZ 14405-B	D2OB 14405-GL	D2OZ 14405-J
		D2OB 14405-GM	D2OZ 14405-J
D2AB 14405-AB	D2AZ 14405-A	D2SB 14405-AC	D2SZ 14405-A
D2AB 14405-AD	D2AZ 14405-A	D2SB 14405-AF	D2SZ 14405-B
D2AB 14405-CC	D2AZ 14405-C	D2SB 14405-BA	D2SZ 14405-C
D2AB 14405-CE	D2AZ 14405-C	D2SB 14405-BB	D2SZ 14405-C
D2AB 14405-DA	D2AZ 14405-D		
D2AB 14405-DC	D2AZ 14405-D	D22B 14405-AB	D2FZ 14405-A
D2AB 14405-EA	D2AZ 14405-E	ED-D22B 14405-AB	D2FZ 14405-A
D2AB 14405-EC	D2AZ 14405-E	D22B 14405-AD	D2FZ 14405-C
D2AB 14405-FA	D2AZ 14405-F	D22B 14405-BA	D2FZ 14405-B
D2AB 14405-GA	D2AZ 14405-G		
D2AB 14405-HA	D2AZ 14405-H	D3BB 14405-AA	D3BZ 14405-A
D2AB 14405-JA	D2AZ 14405-J	D3DB 14405-AA	D3DZ 14405-A
D2DB 14405-AA	D2DZ 14405-A	D3SB 14405-AA	D3SZ 14405-A
D2OB 14405-AF	D2OZ 14405-A	D3SB 14405-BA	D3SZ 14405-B
D2OB 14405-AJ	D2OZ 14405-H		
D2OB 14405-AK	D2OZ 14405-H	S9MS 14L405-A	C9ZZ 14405-J

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14405 WIRING ASSY. - REAR LAMP - continued				
	- A -			
66	A(71A, E)	"Before 1/17/66"	1	*C6AZ 14405-E
66	A(71B, C, D)-except with 3 speed trans. & back up lamps-	"Before 1/17/66"	1	
66	A(71A, B, C, D, E)	"From 1/17/66"	1	*C6AZ 14405-M
68	A(54, 57, 62, 63, 65)-exc. safety convenience panel		1	C8AZ 14405-AZ
68	A(54, 57, 62, 63, 65)-w/safety convenience panel	Not replaced	1	*C8AZ 14405-AV
68	A(71)-except safety convenience panel		1	C8AZ 14405-B
68	A(71)-with safety convenience panel	Not replaced	1	*C8AZ 14405-D
68	A(76)-except safety convenience panel-	Not replaced	1	*C8AZ 14405-E
	"Before 4/1/68"			
68	A(76)-except safety convenience panel-	Not replaced	1	*C8AZ 14405-AY
	"From 4/1/68"			
68	A(76)-with safety convenience panel -	Not replaced	1	*C8AZ 14405-F
	"Before 4/1/68"			
68	A(76)-with safety convenience panel-	Not replaced	1	*C8AZ 14405-AU
	"From 4/1/68"			
69	A(exc. 71)-exc. safety convenience panel		1	C9AZ 14405-L
69	A(71)-except safety convenience panel		1	C9AZ 14405-C
69	A(exc. 71)-with safety convenience panel		1	C9AZ 14405-M
69	A(76)-with or without safety convenience panel		1	
69	A(71)-with safety convenience panel		1	C9AZ 14405-D
70	A(exc. 71)-without safety convenience package		1	D0AZ 14405-A
70	A(exc. 71)-with safety convenience package		1	D0AZ 14405-B
70	A(71)-with safety convenience package -		1	D0AZ 14405-D
	"Before 10/15/69"			
70	A(71)-with safety convenience package -		1	D0AZ 14405-AE
	"From 10/15/69"			
70	A(71)-without safety convenience package		1	D0AZ 14405-AD
71	A(53H, K, 57H, K, 65H, K, 76H) -exc. trailer pkg.		1	D1AZ 14405-B
71	A(53H, K, 57H, K, 65H, K, 76H) -w/trailer pkg.		1	D1AZ 14405-E
71	A(54B, D, F, 57F, 65F) -except trailer package		1	D1AZ 14405-A
71	A(54D, F, 57F, 65F) -with trailer package		1	D1AZ 14405-D
71	A(71)-except trailer package		1	D1AZ 14405-C
71	A(71)-with trailer package		1	D1AZ 14405-F

* Tape and insulate unused leads

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14405 WIRING ASSY. - REAR LAMP - continued				
- A -				
72	A(53,54,57,65,76)-except 429 P/C "Before 10/1/71"		1	D2AZ 14405-F
72	A(53,54,57,65,76)-exc. 429 P/C "From 10/1/71"		1	D2AZ 14405-A
72	A(71)-except 429 P/C "Before 10/1/71"		1	D2AZ 14405-G
72	A(71)-exc. 429 P/C "From 10/1/71"		1	D2AZ 14405-C
72	A(54,57,65)-429 P/C "Before 10/1/71"		1	D2AZ 14405-H
72	A(54,57,65)-429 P/C "From 10/1/71"		1	D2AZ 14405-D
72	A(71)-429 P/C "Before 10/1/71"		1	D2AZ 14405-J
72	A(71)-429 P/C "From 10/1/71"		1	D2AZ 14405-E
- B -				
67	B(54,62,63,76)		1	C7OZ 14405-A
67	B(66,71)	Not replaced	1	★ C7OZ 14405-B
68	B(54,65,76)-w/ or w/o safety convenience pkg.	Not replaced	1	★*C8OZ 14405-C
68	B(66,71)-w/ or w/o safety convenience pkg.	Not replaced	1	★*C8OZ 14405-D
68	B(63)-except safety convenience package	Not replaced	1	★C8OZ 14405-E
68/69	B(63)-with safety convenience package	Not replaced	1	★C8OZ 14405-F
69	B(54,65,76)		1	C9OZ 14405-C
69	B(63)-except safety convenience package		1	C9OZ 14405-F
69	B(66,71)		1	C9OZ 14405-G
70	B(exc. 66,71)		1	D0OZ 14405-S
70	B(66,71)		1	D0OZ 14405-B
71	B(except 66,71)		1	D1OZ 14405-B
71	B(66,71)		1	D1OZ 14405-A
72	B(53,63,65)-w/o trailer towing package - "Before 11/1/71"		1	D2OZ 14405-A
72	B(53,63,65) w/o trailer towing package - "From 11/1/71"		1	D2OZ 14405-H
72	B(53,63,65) with trailer towing package - "Before 11/1/71"		1	D2OZ 14405-G
72	B(53,63,65) w/trailer towing package - "From 11/1/71"		1	D2OZ 14405-J
72	B(71) w/o trailer towing package		1	D2OZ 14405-C
72	B(71) with trailer towing package		1	D2OZ 14405-E
72	B(97) w/o trailer towing package		1	D2OZ 14405-D
72	B(97) with trailer towing package		1	D2OZ 14405-F
- F -				
68	F-except overhead console "Before 11/1/67"	Courtesy lamp to switch-fuel gauge to sender	1	C8ZZ 14405-A
68	F-except overhead console or safety convenience panel "From 11/1/67"	Courtesy lamp to switch-fuel gauge to sender	1	C8ZZ 14405-E
68	F-with overhead console and/or safety convenience panel	Courtesy lamp to switch to fuse panel-fuel gauge sender to gauge to warning relay-defogger switch to defogger motor	1	C8ZZ 14405-F
68	F(63A, C, 65A, C)-with rear window defogger, and/or safety convenience panel			
68	F	For rear lamp wiring Refer to Group 13410		
68	F(65)GT-CS		1	C8ZZ 14405-C
69	F-except safety convenience package		1	C9ZZ 14405-A
69	F-with safety convenience package		1	C9ZZ 14405-B
67	F(GT350/500)	R.H. & L.H.	2	S7MS 14405-A
69	F(GT350/500)-ground		1	C9ZZ 14405-J
69	F(GT350/500)		1	C9WY 14405-B
70	F(6 & 8 cyl. 302-4V Boss 351-390-4V, 428CJ) with visibility light group "Before 12/15/69"		1	D0ZZ 14405-B
70	F "From 12/15/69"		1	D0ZZ 14405-U
71	F "Before 11/1/70"		1	D1ZZ 14405-A
71/72	F "From 11/1/70 to 10/18/71"		1	D1ZZ 14405-B
72	F "From 10/18/71"	Includes (1) D1ZZ 15B411-A wire	1	D1ZZ 14405-C
- L -				
71/72	L(62) "Before 11/1/71"		1	D1FZ 14405-A
72	L(62) "From 11/1/71"		1	D2FZ 14405-B
71/	L(64)		1	D1FZ 14405-B
72	L(73)		1	D3FZ 14405-B

* Tape & insulate unused leads

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14405 WIRING ASSY. - REAR LAMP - continued				
- P -				
70	P	"Before 10/1/69"	1	D0DZ 14405-C
70	P	"From 10/1/69"	1	D0DZ 14405-G
71	P		1	D1DZ 14405-B
72	P	"Before 6/15/72"	1	D2DZ 14405-A
72	P	"From 6/15/72"	1	D3DZ 14405-A
- S -				
67	S	"Before 1/3/67"	1	C7SZ 14405-B
67	S	"From 1/3/67"	1	C7SZ 14405-G
68	S	Not replaced	1	★C8SZ 14405-A
69	S-with auxiliary stop lamps	Not replaced	1	★C8SZ 14405-G
69	S-w/o aux. stop lamps "Before 10/15/68"		1	C9SZ 14405-A
69	S(without auxiliary stop lamps)- "From 10/15/68 to 11/18/68"		1	C9SZ 14405-C
69	S-w/o aux. stop lamps "From 11/18/68"		1	C9SZ 14405-E
70	S(57) -w/o brake skid control "Before 5/1/70"		1	D0SZ 14405-Z
70	S(57)-w/o brake skid control "From 5/1/70"		1	D0SZ 14405-AF
70	S(57)-w/brake skid control "Before 3/16/70"		1	D0SZ 14405-AB
70	S(57)-w/brake skid control "From 3/16/70"		1	D0SZ 14405-AD
70	S(65)-w/o brake skid control "Before 5/1/70"		1	D0SZ 14405-Y
70	S(65)-w/o brake skid control "From 5/1/70"		1	D0SZ 14405-AE
70	S(65)-w/brake skid control "Before 3/16/70"		1	D0SZ 14405-AA
70	S(65)-w/brake skid control "From 3/16/70"		1	D0SZ 14405-AC
71	S(65A, C)-without brake skid control-with power windows		1	D1SZ 14405-J
71	S(65)-without brake skid control-without power windows		1	D1SZ 14405-L
71	S(65A, C)-with brake skid control-with power windows "Before 10/15/70"		1	D1SZ 14405-C
71	S(65A, C)-with brake skid control-with power windows "From 10/15/70"		1	D1SZ 14405-H
71	S(65)-with brake skid control-without power windows		1	D1SZ 14405-M
71	S(57)-w/o brake skid control "Before 10/15/70"		1	D1SZ 14405-B
71	S(57)-w/o brake skid control "From 10/15/70"		1	D1SZ 14405-K
71	S(57)-w/brake skid control		1	D1SZ 14405-G
72	S "Before 11/1/71"		1	D2SZ 14405-A
72	S-w/o trailer towing pkg.- "From 11/1/71 to 4/1/72"		1	D2SZ 14405-B
72	S-w/o trailer towing pkg. "From 4/1/72"		1	D3SZ 14405-A
72	S-w/trailer towing pkg. "Before 4/1/72"		1	D2SZ 14405-C
72	S-w/trailer towing pkg. "From 4/1/72"		1	D3SZ 14405-B
- U -				
67/69	U		1	C7TZ 14405-N
70	U		1	D0BZ 14405-A
71/72	U	"Before Ser.P40,001"	1	D1BZ 14405-A
72	U	"From Ser.P40,001"	1	D3BZ 14405-A
- X -				
66	X(54, 62)		1	C6DZ 14405-J
66	X(66, 71)	Used with or without backup lamps-not replaced	1	★C6DZ 14405-F
67	X(54, 62)		1	C7DZ 14405-A
67	X(71)	Not replaced	1	★C7OZ 14405-B
68	X(54, 62)-except safety convenience panel	Not replaced	1	★C8DZ 14405-I
68	X(54, 62)-with safety convenience panel	Not replaced	1	★C8DZ 14405-M
68	X(71)	Not replaced	1	★C8OZ 14405-D
69/70	X(exc. 71)		1	C9DZ 14405-A
69/70	X(71)		1	C9OZ 14405-G
69	A(71)	Clip-wiring attach rear lamp wiring to rear quarter panel (L. H. side)	AR	382931-S(GG338)
71	P	Clip (attach wiring to roof side rail)	2	

* Tape & insulate unused leads

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14405 WIRING ASSY. - REAR LAMP - continued				
70	A(71)	Clip(wiring to L. H. quarter rail)	3	383207-S(GG271)
65	F	Clip (wiring to cowl side pillar)	3	372047-S100(GG217)
65	F	Screw (wiring and clip)	2	42127-S8(U248C)
66	S			
71	A(71),B	Screw-No.8-5 x 1/2" (attach locator on wiring to quarter pillar lower back panel and rear seat riser)	AR	52012-S(U202)
70/	B	Attach ground wire of 14405 to lower back panel	AR	
70/	F	Attach ground wire to luggage compartment striker bracket	AR	
70/	S	Attach ground wire to luggage compartment striker bracket	AR	
65	F	Clip	2	★377846-S
65	F	Nut (wiring and clip 377766-S to existing L. H. moulding stud)-1/4"-20	1	33795-S7(M49)
65	F	Clip	1	★377766-S
65/	A-with 4 speed trans.	Clip (wiring and rear window regulator switch feed wiring with screw that attaches to cover of front floor pan)	2	358350-S(GG172)
70	F	Clip (wiring to rear of wheelhouse)	AR	380753-S(GG248)
70	F(76)	Clip (wiring to belt rail to wheelhouse)	2	
70/	A(71) ,B(71)	Clip (wiring to quarter pillar)	2	
70	B	Clip (attach 14405 wiring to tail lamp)	AR	382031-S(GG280)
70/	A	Clip (attach 14405 wiring to floor pan)	2	376219-S(GG151)
70	S	Attach 14405 wiring to lower back panel	AR	
70	B(71)	Screw (attach wiring and retainer to tail gate hinge lower)-1/4"-14 x 1/2"	1	55981-S(U254E)
65/	A(except 71)	Clip (wiring with nut that attaches rear lamp to lower back panel)	2	353547-S2(GG173)
65	F	Clip (wiring with screw that attaches fuel tank to center floor pan)	2	
65	F	Clip (wiring to flange of center floor pan)	2	372046-S100
69	F	Luggage compartment lamp to upper back panel	1	(GG186)
65/	B,F,S,X ,U	Strap (wiring to lower back panel)	1	376914-S(YY2)
66	S	Clip (wiring to lower back panel)	AR	376188-S(GG147M)
67	B(except 71),X	Clip (wiring to lower rear panel)	2	379485-S(GG263)
71	A(71)	Clip (wiring to floor pan at fuel sender)	2	379042-S(GG143A)
65/70	X	Clip (wiring to L.H. body rocker panel)	5	372860-S100(GG42)
65/70	X	Clip (wiring to L. H. cowl side inner panel or	AR	372047-S100
70/	U	or rear quarter wheel housing)	AR	(GG217)
65/	B(except 71)	Clip (wiring to fuel filler housing)	1	372864-S100
65	F	Clip (wiring to L. H. side member)	4	(GG91)
71	A(71)	Screw-No.8-18 x 3/4" (attach locator to floor)	2	376389-S100
71	A	Attach fuel tank lead wire to floor pan	1	(UU82D)
71	L	Screw No.10-16 x 1/2" attach wire 14405 to lower back panel	AR	★377847-S
70	B, F	Clip (wiring to floor pan)	AR	381645-S(GG261)
70	B(65)	Clip (wiring to quarter window regulator panel)	2	381954-S(GG299)
71	B	Clip (attach wiring to rear quarter panel)	AR	
70	B(66)	Clip (wiring to pillar)	2	382033-S(GG303)
71	B(66)	Clip (attach wiring to rear quarter pillar)	2	
70	B(76)	Clip (wiring to wheel house)	2	380753-S(GG248)
70	S	Screw-No. 8-18 x 3/8" (attach 14405 to wheel house)	AR	379560-S(UU89CA)
66	A(71)	Clip (attach wiring to wheel house)	AR	377987-S(GG256)
67	A,B	Washer No.10 (ground 14405 to lower back panel)	1	34939-S(X86)
		Screw-No. 10-12 x 1/2" (ground 14405 to lower back panel)	1	42127-S(U248C)
67	B(except 71)	Clip (attach 14405 to lower back panel)	AR	377359-S(GG236)
70/	B,U	Strap(attach 14405 to side rail)	AR	376914-S(YY2)
71	L,P	Clip (attach wiring to rear floor pan and to quarter panel at rear lamps)	AR	381645-S(GG261)
71	L	Clip (attach wiring to cowl panel)	1	382931-S(GG338)

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14405 WIRING ASSY. - REAR LAMP - continued				
71	S	Clip (attach wiring to luggage compt.side board)	AR	376219-S(GG151)
71	S	Clip (attach wiring to rear lamp body)	AR	372861-S(GG68)
71	S	Clip (attach wiring to luggage compt.side board)	AR	381954-S(GG299)
71	U	Screw-5/16"-18 x 1/2" (attach 14405 to side rail)	AR	40923-S(U364)
71/	U	Clip (attach wiring to L.H. front side rail)	5	373829-S(GG267)
14406 WIRING ASSY. - FUEL TANK SENDER - Unless listed-improvise from B6A 14296-C wire				
- A -				
67/68	A(71)-except with safety package	#C6AB 14406-A	1	C7AZ 14406-A
- B -				
67	B(66, 71)	#C6OB 14406-B	1	C7OZ 14406-B
69/71	B(66, 71)		1	
72	B(exc. 71, 97)	#D2OB 14406-BD	1	D2OZ 14406-B
- F -				
71/	F	#ED-D1ZB 14406-AD, D1ZB 14406-AC, AD, AE	1	D1ZZ 14406-B
- L -				
71/	L(exc. 73)	#ED1-D12B 14406-AC, AD	1	D1FZ 14406-B
- P -				
71/	P	#ED-D1DB 14406-AB, AC, D1DB 14406-AB	1	D1DZ 14406-B
- S -				
68	S-without safety convenience package	#C8SB 14406-A, B-not replaced	1	★C8SZ 14406-A
68	S-with safety convenience package	#C8LB 14406-A, C8SB 14406-C	1	C8SZ 14406-B
72	S	#D2SB 14406-BB	1	D2SZ 14406-B
- U -				
66/67	U	Used w/nylon aux. gas tank-#C6TB 14406-G	1	C7TZ 14406-G
68/70	U-with ammeter and oil pressure gauges	#C8TB 14406-A-used with 11 gallon tank	1	C8TZ 14406-A
71/	U	#D1BB 14406-AA	1	D1BZ 14406-A
- X -				
67	X (71)	#C6OB 14406-B	1	C7OZ 14406-B
69/70	X (71)		1	
71	B	Clip (attach wire to fuel tank)	4	372047-S(GG217)
		Clip (attach wire to rear floor pan)	2	381645-S(GG261)
14408 WIRE ASSY. - REAR LAMP EXTENSION				
72	L(73)	#D22B 14408-AB	1	D3FZ 14408-A
69	S(65)	"Before 10/15/68" #C9SB 14408-J-not replaced	1	★C9SZ 14408-C
69	S(57)	"Before 10/15/68" #C9SB 14408-L,S,#C9SB 14408-M,AD-	1	★C9SZ 14408-S
69	S(65)	"From 10/15/68" fold & tape unused leads-not replaced	1	
70	S	#D0SB 14408-A,B,D	1	D0SZ 14408-B
71	S	"Before 10/15/70" #D1SB 14408-BA	1	D1SZ 14408-A
71	S	"From 10/15/70" #D1SB 14408-BB	1	D1SZ 14408-B
14A411 WIRING ASSY. - MAIN JUMPER				
69	A	Used to repair damaged wiring at fuse panel terminal	1	C9AZ 14A411-A
70	S	Connects 14401 to 14398-#D0SB 14A411-A, B	1	D0SZ 14A411-B
14412 LAMP & WIRING ASSY. - GLOVE COMPARTMENT				
65/66	S		1	C4SZ 14412-B
65	F	Console glove compartment	1	
67/70	S	Glove compartment at instrument panel	1	C6VY 14412-A
69/70	F	#C9WB 14412-A	1	C9WY 14412-A
71/	S	#D1SB 14412-A1A	1	D1SZ 14412-A
72	B-with console		1	
65	F	Screw (wire and clip 377929-S to console panel)-No. 10-12 x 1/2"	2	42127-S8(U248C)
65	F	Clip	2	★377929-S
14A412 WIRING ASSY. - DOOR LOCK SOLENOID				
67	S-with safety package "From 10/31/66"	Used with vacuum door lock control	1	★C7SZ 14A412-A
14A412 HOSE and WIRING ASSY. - DOOR LATCH VACUUM CONTROL				
71	A(53, 54, 57, 71)	R. H. #D1AB 54220A12-AC, AD	1	D1AZ 14A412-A
		L. H. #D1AB 54220A13-AC, AD	1	D1AZ 14A412-C
71	A(65, 76)	R. H. #D1AB 65220A12-AC, AD	1	D1AZ 14A412-B
		L. H. #D1AB 65220A13-AC, AD	1	D1AZ 14A412-D
72	A(53, 54, 57, 71)	R. H. #D2AB 54220A12-AC	1	D2AZ 14A412-E
		L. H. #D2AB 54220A13-AC	1	D2AZ 14A412-G
72	A(65, 76)	R. H. #D2AB 65220A12-AC	1	D2AZ 14A412-H
		L. H. #D2AB 65220A13-AC	1	D2AZ 14A412-J

Identification marking
May, 1975

COPYRIGHT © 1975—

FORD MOTOR
COMPANY

—DEARBORN, MICHIGAN

FINAL ISSUE

SECTION 144

FORD CAR PARTS

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A412 WIRE ASSY. - DOOR LOCK LEAD				
72	A(71)	"Before 3/15/72"	154" long #D2AB 14025-BC,BD	1 D2AZ 14A412-B
72	A(71)	"From 3/15/72"	180" long #D2AB 14025-BE (connects 14028 to tailgate lock)	1 D2AZ 14A412-K
72	B(53, 71)	"Before 2/1/72"	R. H. & L. H. front door #D2OB 14024-AA	2 D2OZ 14A412-A
72	B(53, 71)	"From 2/1/72"	R. H. & L. H. front doors #D2OB 14024-AB	2 D2OZ 14A412-M
72	B(53, 71)		R. H.-lead-front door-26" long-#D2OB 14A491-BA	1 D2OZ 14A412-G
			L. H.-lead-front door-26" long-#D2OB 14A492-BA	1 D2OZ 14A412-H
72	B(63, 65)		R. H. & L. H. front door #D2OB 14024-BA	2 D2OZ 14A412-B
72	B(63, 65)		R. H. -lead- front door -24" long #D2OB 14A491-AA	1 D2OZ 14A412-E
			L. H. -lead-front door-24" long #D2OB 14A492-AA	1 D2OZ 14A412-F
72	B(53, 71)		R. H. rear door #D2OB 14026-AA	1 D2OZ 14A412-C
			L. H. rear door #D2OB 14027-AA	1 D2OZ 14A412-D
72	B(53, 71)		R. H. -lead-rear door-27" long #D2OB 14A491-CA	1 D2OZ 14A412-J
			L. H. -lead-rear door-27" long #D2OB 14A492-CA	1 D2OZ 14A412-K
72	B(71)		Tailgate-lead-23" long #D2OF 14A523-AA	1 D2OZ 14A412-L
72	S		R. H.-19" long #D2SB 14A491-AB	1 D2SZ 14A412-B
			L. H.-19" long #D2SB 14A492-AB	1 D2SZ 14A412-C
72	S		R. H. extension #D2SB 14A494-AB	1 D2SZ 14A412-D
			L. H. extension #D2SB 14A495-AB	1 D2SZ 14A412-E
72	S		Feed-from 14526 to 14A005-4" long	1 D2SZ 14A412-F
72	S		Feed-from 14526 to 14512 relay-4" long	1 D2SZ 14A412-G
14413 SWITCH and WIRE ASSY. - GLOVE COMPARTMENT LAMP				
70	A, B, P			1 D0OZ 14413-A
71/	A			1 D1AZ 14413-A
72	B-without console			1
65	B			1 C3AZ 14413-B
65/69	A			1
65/68	F	Instrument panel glove compartment	1	
66/69	B, X			1 D0OZ 14413-A
71	B			1 D1OZ 14413-A
69/	F			1 C9WY 14413-B
67/71	S			1 C6VY 14413-A
72	S-with console			1 D1WY 14413-A
72	B-with console			1
69	A	Cap 3/16" I.D.-cut off 5/16" and cement to actuator	1	380614-S(DD3)
14417 HOLDER FUSE				
66	A, B, F, S, U, X	Straight base-for 20 gauge wire (steel)	AR	C6AZ 14417-A
67	F		AR	
66	A, B, F, S, U, X	30° base-for 20 gauge wire (steel)	AR	C6AZ 14417-B
67	A		AR	
70	A	With hang on A/C (steel)	1	D0AZ 14417-A
71/	L	With clock	1	
72	B	Single fuse type	1	D2OZ 14417-A
72	S	Use with 14 or 16 gauge wire-(1) wire	2	D2SZ 14417-A
72	S	Use with 18 or 20 gauge wire-(1) wire	1	D2SZ 14417-B
72	S	Use with 14, 16 or 18 gauge wire-(2) wires	1	D2SZ 14417-C
72	S	Use with 16, 18 or 20 gauge wire-(2) wires	1	D2SZ 14417-D
14429 FUSE ASSY. - CIGAR LIGHTER				
65/66	A, B, F, S, X		1	FEW 14429-A
67/69	B, X		1	
14431 CABLE ASSY. - RELAY TO STARTER				
65/70	F	15.00" long-use as engine to ground strap	1	D1PZ 14431-A
68/70	B, X	Dash to engine ground	1	(7136)
65/67	A(6 cyl.)	Dash to engine	1	
65/70	A(8 cyl.)	Dash to engine	1	
68/	S	Dash to engine	1	
72	S(460)		1	
68	U	Dash to engine	1	

Identification marking

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14431 CABLE ASSY. - RELAY TO STARTER - continued				
65/67	*B, F(6 cyl.)	28.50" long	1	D1PZ 14431-C
68/70	B, F(6 cyl.)		1	(7284)
71/	P(6 cyl. 170,200), U(6 & 8 cyl.)		1	
66/70	X(6 cyl.)		1	
67/69	S(390)		1	
65/67	*B, F(6 cyl.)		1	CCOCZ 14431-B32
65/68	B(8 cyl.)	36" long	1	D1PZ 14431-D
65	A(6 & 8 cyl.)-except 427 Special		1	(7364)
65/70	X(8 cyl.)		1	
65/68	F(8 cyl.)		1	
69/70	B(8 cyl. 351, 429)		1	
66/70	A(6 & 8 cyl.)		1	
68/69	S(429)		1	
69/70	F(8 cyl. 302, 351, 390, 429)		1	
69/70	A(8 cyl. 302, 351)		1	
69/70	A(8 cyl. 429)		1	
69/	B(6 cyl. 250), F(6 cyl. 250)		1	
70/	A(6 cyl.)		1	
70/	P(6 cyl.)		1	
65/66	S	51" long	1	D1PZ 14431-E
65	A(8 cyl. Special)		1	(7514)
68/70	F(427, 428)		1	
70	S(8 cyl.)		1	
70/71	S(8 cyl. 400, 429)	Starter to junction block on fender-51.00" long	1	
72	S(8 cyl. 460)		1	
70/71	A(8 cyl.)	43.00" long(4 gauge)	1	D1PZ 14431-J
70/	B, F(8 cyl.)		1	(WC-8096)
72	A(Except 8 cyl. 429 P/C)		1	
69	B(428CJ)		1	
71/	P(8 cyl.)		1	
72	S(429, 460)	Starter to junction block on fender	1	
71/	L	23.50" long-relay to starter	1	D1PZ 14431-B
66/	A(6. & 8 cyl.)		1	(7244)
72	B	Dash to engine ground	1	
70	P(6 cyl.)	Engine to ground	1	
72	S(400)	Starter to junction block on fender	1	
66/70	*U		1	
65	*X(6 cyl.)		1	
72	A(8 cyl. 429 P/C)	41" long	1	D2AZ 14431-E
72	B(8 cyl. 429 P/C)		1	
70	A, B, F(6 cyl.)	Clip (cable to engine mount)	1	380896-S(GG252)
65/70	A, S, X, B, F	Lockwasher-5/16"	1	34806-S7(X64)
65/70	A, B, F, S, X	Nut (cable to relay)-5/16"-24	1	33798-S8(M62)
65/70	A(except 8 cyl. -Special), B	Screw (cable to No. 2 c/member or L. H. frame side member reinf.)-5/16"-18 x 5/8"	1 or 2	*40156-S8
65/70	A(8 cyl. Special)	Screw (cable support to fender apron or dash panel)-No.14-14 x 1/2"	1 or 2	31497-S8(U254)
65/70	B(8 cyl.)	Screw (relay to starter cable to front suspension bracket)-1/4"-20 x 11/16"	1	*55175-S8
65/70	B(8 cyl.)	Nut-1/4"-20	1	33920-S8(M25)
65/70	B(8 cyl.)	Lockwasher-1/4"	1	34805-S8(X62)
65/70	B(8 cyl.)	Flatwasher-1/4"	1	44719-S8(X17)
70	B, S	Screw 1/4" -14 x 1/2" (cable to ground)	1	55981-S(U254E)
65	F	Screw (ground cable and heater motor ground wire to dash panel)-No. 14-14 x 1/2"	1	31497-S8(U254)
65	F(8 cyl.)	Bolt (ground cable to R. H. cylinder head)-3/8"-16 x 1/2"	1	20312-S7(B75)
65	F(8 cyl.)	Lockwasher-3/8"	1	*34942-S8
71/	L(122)-2000 cc	Screw M8 x 16MM	1	N602548-S72
65/	S	Screw (cable to R. H. front side inner member)-5/16"-18 x 1/2"	1	40923-S8(U264)
65/	S	Clip (relay to starter cable to engine block)	1	*372865-S100
65/	F		1	
65/	S	Clip (relay to starter cable to R. H. front side inner member or mounting ear on generator)	1 or 2	*373945-S100

♦ Canada only ☆ U.S. only

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14431 CABLE ASSY. - RELAY TO STARTER - continued				
65/70	X	Adjustable strap (cable to R. H. frt. suspension)-	1	376914-S(YY2)
65	F	Nylon	1	
71/	U	Attach wiring to R.H. front fender	AR	
14A434 SPACER - BULLET TYPE TERMINAL				
68/70/	A, B, F, S, X	Connects to C8AZ 14489-AA located at turn signal wiring	AR	C8AZ 14A434-A
68	B, X	Connects to C8OZ 14489-B -not replaced	AR	★C8OZ 14A434-A
69/70	A, B, F	Connects to C8OZ 14489-B	AR	C9AZ 14A434-A
70	B	Use in L. H. front door courtesy lamp wiring	AR	D0OZ 14A434-A
70	A, B, F, S, U, X	Use with ignition switch connector	AR	D0AZ 14A434-A
71	A, B, F, L, P, S	Located at ignition switch - connects to D1AZ 14489-C	1	D1AZ 14A434-B
72	A, F, L		1	
71/	A-with intermittent wipers		1	D1AZ 14A434-A
14444 WIRING ASSY. - INSTRUMENT PANEL - Refer to Group 14401				
14448 BLOCK ASSY. - JUNCTION - Also refer to Groups 11A467 & 14A725				
65	A, S -with trans. ignition	Used with ballast resistor mounting plate	1	C5AZ 14448-A
67/69	A(8 cyl. 427)		1	(DY-78)
67	B(8 cyl. 427)	Not used with A/C or Stereo tape player	1	
66/69	S		1	
66/67	A, B-with trans. regulator	Used with 53 amp. Leece-Neville alternator- #C6AB 14448-A	1	C6AZ 14448-A
66/67	A, B-with trans. regulator	Used with 60 amp. Leece-Neville alternator- #C6TB 14448-A	1	D0HZ 14448-E
66/69	A(76), B(76), F(76)	Used with power convertible top	1	D3TZ 14448-A
66	U	Must be used with C6TZ 14290-D and C6TZ 14305-AU wiring	1	
65/66	S(76)	Used with top motor fusible link (wire type) fuse	1	D0SZ 14448-A
66/67	A-with transistorized regulator	Used with L/N 60 amp. alternator	1	(DY-91)
68/70	A	Used with 65 amp. L/N or Ford alternator	1	
69/	S	Located on fender apron	1	
69	F(GT350/500)	Use with ammeter	1	
71/	B, F		1	
66/69	U	"Before Ser. E90,001" Used with 55 amp. Ford alternator	1	C5TZ 14448-C
69/70	U	"From Ser. E90,001" Used with 55 amp. Ford alternator -not required after Ser. No. H50,001"	1	C5TZ 14448-B
72	L(4 cyl. 122-2000 cc)	Located on fender apron	1	D2FZ 14448-A
69	F	Screw -No. 10-12 x 5/8" (attach block to fender shield)	2	42134-S(U249)
65/66	S-with transistorized ignition	Screw (block, relay and bracket to ballast resistor)-No. 14-10 x 5/8"	6	31498-S8(U253B)
70/	S	Screw-No. 8-15 x 1" (attach block to front fender apron)	AR	42151-S(U247)
14453 TERMINAL - SPARK PLUG				
65/68	A, B, F, S, X	Slip on type-used with radio resistor type wiring	AR	B8A 14453-B
69/	A, B, F, L, P, S, U		AR	D2PZ 14453-A
14455 SLEEVE - WIRING				
67/69	S		1	C7SZ 14455-A
14A456 SPRING - BACK WINDOW SWITCH CONTROL				
69	A(71)		1	C9AZ 14A456-A
14461 TERMINAL WIRE				
65/66	A, B, F, S, U, X	Bullet type-crimp on for 14, 16, or 18 gauge wire	AR	C4AZ 14461-A
67/	A, B, F, U	Bullet type wire No. 14 or 16 gauge	AR	C7AZ 14461-B
68/	A, B, F, S, U, X	Bullet type wire for 14 or 16 gauge wire	AR	C8AZ 14461-C
70	P		AR	
68/	A, B, F, S, U, X	Bullet type for 14 or 16 gauge wire	AR	C8OZ 14461-C
70/	L, P		AR	
68/	A, B, F, S, U, X	Bullet type for 18 or 20 gauge wire	AR	C8AZ 14461-B
68/	A, B, F, S, U, X	Bullet type for 18 or 20 gauge wire	AR	C8OZ 14461-B
70/	L, P		AR	
70	A, B, F, S, P, U, X	Bullet type wire No. 18-20 gauge wire	AR	D0AZ 14461-A
71/	A, B, F, L, P, S	Bullet type No. 18 or 20 gauge wire	AR	D1AZ 14461-A
71/	A, B, F, L, P, S	Bullet type No. 14 or 16 gauge wire	AR	D1AZ 14461-E
71/	A, B, F, L, P, S	Bullet type for 16-20 gauge wire	AR	D1AZ 14461-D
71/	A, B, F, L, P, S	Bullet type for 6-20 gauge wire	AR	D1AZ 14461-E

SECTION 144

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14461 TERMINAL WIRE - continued				
68/68	B, U X	Bullet type for 10 or 12 gauge wire	AR	C8AZ 14461-A
71/70	L S	Bullet type No. 18 or 20 gauge wire	AR	D1FZ 14461-A
		Bullet type No. 14, 16 gauge wire-mates with D0SZ 14488-B	AR	D0SZ 14461-B
70	S	Bullet type No. 18, 20 gauge wire-mates with D0SZ 14488-A	AR	D0SZ 14461-A
14463 CLIP - REAR LAMP GROUND				
69	F(GT350/500)	Improvise	6	★
14464 TERMINAL - ELECTRICAL WIRING				
65/	A	Flag eyelet	AR	C4AZ 14464-A
14466 TERMINAL - HIGH TENSION WIRE				
65/69	A, B, S, X		AR	C5TZ 14466-A
65/69	A, B, F, S, X	"J" shaped-distributor end	AR	*B8AZ 14466-A
70/	A, B, F, L, P, S, U	"J" shaped-distributor end	AR	B8AZ 14466-C
65/69	A, B, F, P, S, U	"U" shaped-spark plug end	AR	*B8AZ 14466-B
70/	A, B, F, L, P, S, U	"U" shaped-spark plug end	AR	B8AZ 14466-D
14468 TERMINAL - WIRE				
65	A	Flag type	AR	C3TZ 14468-B
65	S		AR	
14A468 SPACER - WIRE CONNECTOR				
71/	A, B, F, L, P, S	1" x 3/8"-Red	AR	D1AZ 14A468-A
71/	A, B, F, L, P, S	1" x 11/16"-Red	AR	D1AZ 14A468-B
72	B, S	11/16"-Gray	AR	D2OZ 14A468-A
72	B, S	3/8"-Gray	AR	D2OZ 14A468-B
72	S	21/32"-Red	AR	D2SZ 14A468-A
72	S	47/64"-Red	AR	D2SZ 14A468-B
14474 TERMINAL - WIRE				
65/	A, B, F, L, P, S, X	Snap on internal type	AR	B8E 14474-A
65/	A, B, F, L, P, S	Snap on internal flag type	AR	C1AF 14474-A
68/	A, B, F, X, U, S	Snap on female	AR	C8AZ 14474-A
72	A	Male "L" shaped use with 18 or 20 gauge wire	AR	D2AZ 14474-A
72	A	Female-use with 16, 18 or 20 gauge wire	AR	D2AZ 14474-B
72	A, B	Female-14 or 16 gauge wire	AR	D2OZ 14474-C
72	A, B	Male-14 or 16 gauge wire	AR	D2OZ 14474-D
66	B, X	Snap on female	1	C6ZZ 14474-A
66/67	F		1	
72	B	Female (1) or (2) wire type	AR	D2OZ 14474-A
72	B	Male (1) or (2) wire type	AR	D2OZ 14474-B
72	B, S	Female	AR	D2OZ 14474-F
65/	A, B, F, L, P, S, U, X	Snap on female	AR	
71/	L-without A/C		1	D1FZ 14474-A
72	L	Female connects to terminal onto heated backlite	AR	D2FZ 14474-A
72	L	Male connects onto heated backlite	AR	D2FZ 14474-B
72	S	Female-14, 16 or 18 gauge wire	AR	D2SZ 14474-A
14A481 PANEL - RELAY				
72	S	Plastic	1	D2SZ 14A481-A
14487 CONNECTOR - WIRING				
		2 way plug in-for No. 14, 16 & 18 gauge wire	AR	B7A 14487-A
		2 way crimp-on - for No. 16, 18, 20 & 22 gauge wire	AR	B9A 14487-A
		2 way crimp-on - for No. 14 & 16 gauge wire	AR	B9A 14487-B
		4 way plug in-for No. 14, 16 & 18 gauge wire	AR	B6A 14487-A
		1 way crimp-on-for No. 16 & 18 gauge wire	AR	C3TZ 14487-A
68/	A, B, F, S, U, X	Ignition switch (copper)-yellow (vinyl coated)	2	C9AZ 14487-D
72	B, S	Located at fuel tank sender	AR	D2OZ 14487-A
70/	A, B, F, P, U	Located at alternator terminal	2	D0AZ 14487-A
71/	A, B, F, L, P, S	1 way crimp-on-for 10 gauge wire	AR	D1AZ 14487-B
71/	A, B, F, L, P, S	1 way crimp-on-for 12 gauge wire	AR	D1AZ 14487-A
71/	A, B, F, L, P, S	1 way crimp-on-for 12 gauge wire	AR	D1AZ 14487-C
65/	All	4 way crimp-on-for 10 or 12 gauge wire	AR	D5AZ 14487-A

* Used with radio resistor type high tension wire containing linen or fibre glass core


May, 1975

COPYRIGHT © 1975 —


FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN


FINAL ISSUE

SECTION 144**14488-9 CONNECTORS and SLEEVES (WIRE)**


TYPE 1




TYPE 2




TYPE 3




TYPE 4




TYPE 5




TYPE 6




TYPE 7




TYPE 8




TYPE 9




TYPE 10




TYPE 11




TYPE 12




TYPE 13




TYPE 14




TYPE 15




TYPE 16




TYPE 17



TYPE 18




TYPE 19




TYPE 20


14488-9 CONNECTORS and SLEEVES (WIRE) - continued




TYPE 21




TYPE 22




TYPE 23




TYPE 24




TYPE 25




TYPE 26




TYPE 27




TYPE 28




TYPE 29




TYPE 30




TYPE 31




TYPE 32




TYPE 33




TYPE 34




TYPE 35




TYPE 36




TYPE 37



TYPE 38




TYPE 39




TYPE 40


P-11370

SECTION 144**14488-9 CONNECTORS and SLEEVES (WIRE) - continued**


TYPE 41




TYPE 42




TYPE 43




TYPE 44




TYPE 45




TYPE 46




TYPE 47




TYPE 48




TYPE 49




TYPE 50




TYPE 51




TYPE 52




TYPE 53




TYPE 54




TYPE 55




TYPE 56




TYPE 57



TYPE 58




TYPE 59




TYPE 60


14488-9 CONNECTORS and SLEEVES (WIRE) - continued




TYPE 61



TYPE 62



TYPE 63



TYPE 64

P-11374

SECTION 144

YEAR	MODEL/RESTRICTIONS	PART NUMBER	TYPE	DESCRIPTION	QTY.
14488-9 CONNECTORS and SLEEVES (WIRE) - continued					
CONNECTORS					
65/	All	B6A 14488-A		"L" shape crimp-on-for 12,14,16,18 gauge wire	AR
		B7A 14488-B		Terminal connector	AR
		B7A 14488-D		Terminal connector	AR
		B7A 14488-C		Wire end connector	AR
		C4AZ 14488-A	5	Female-for 18,20 & 22 gauge wire	AR
		C4AZ 14488-B	5	Female-for 14, 16 & 18 gauge wire	AR
		C7AZ 14488-A	5	Female-for 18 or 22 gauge wire	AR
		C7AZ 14488-B	5	Female-for 14 or 16 gauge wire	AR
		C7AZ 14488-C	5	Female-use with 16 or 18 gauge stacked wire	AR
		C8AZ 14488-A	1	Female-for 10,12 gauge wire	AR
		C8AZ 14488-B	3	Female-for 16,24 gauge wire	AR
		D0AZ 14488-A		Female-3/4" long for 18-20 gauge wire	AR
		D1AZ 14488-B	4	1 way crimp-on-for 18 or 20 gauge wire	AR
		D1AZ 14488-E		1 way crimp-on-for (1) 16 and 18, or (1) 16 and 20, or (1) 18 and 20, or (2) 18 or (2) 20 gauge wires	AR
		C8OZ 14488-A	25	Female-3 circuit type-with male end	AR
		D0SZ 14488-A		Female-for 18,20 gauge wire-mates with D0SZ 14461-A	AR
		D0SZ 14488-B		Female-for 14,16 gauge wire-mates with D0SZ 14461-B	AR
SLEEVES					
65/	All	C5AZ 14489-C	56	2 wire (nylon)-to stop lamp switch	1
65/67	A-with A/C	C5AZ 14489-D		5 wire (nylon)-to heater switch	1
67/	All	C7AZ 14489-J	53	Turn signal and emergency flasher- (polypropylene)	1
68/	All	C8AZ 14489-V	14	2 plug in (nylon)-connects to headlamp bulb	2
		C8AZ 14489-Y	15	3 plug in (nylon)-connects to headlamp bulb	2
71/72	All	D1FZ 14489-B		Nylon-female (used with throttle solenoid and 10374 diode)	1
72	S			With power door locks-located between 14A005 and 14A412	AR
68/69	All	C8AZ 14489-D	60	Nylon ignition switch	1
70	P-exc. locking steering column				1
69	A	C9AZ 14489-F	46	R.H. front door-with power window- attach to 14630	1
		C9AZ 14489-G	61	L.H. front door outer-with power window- attach to 14631-mates with C9AZ 14489-J	1
		C9AZ 14489-J		L.H. front door inner-with power window- attach to 14631	1
69/70	A	D0AZ 14489-G	46	R.H. & L.H. rear door or quarter window- attaches to 14632 or 14633	2
71/	F			R.H. front door or R.H. and L.H. rear quarter	3
70	A	D0AZ 14489-H	46	R.H. front door-attach to 14630	1
70	A	D0AZ 14489-J	61	L.H. front door-attach to 14631	1
71/	F			L.H. front door-attach to 14633	1
70	A	D0AZ 14489-K	61	L.H. front door	1
71/	F			L.H. front door	1
71	A	D1AZ 14489-D		L.H. front door-attach to 14631	1

† Tab locking type

‡ Insert pressure locking type

FORD CAR PARTS

29

SECTION 144

YEAR	MODEL/RESTRICTIONS		PART NUMBER	TYPE	DESCRIPTION	QTY.
14488-9 CONNECTORS and SLEEVES (WIRE) - continued						
SLEEVES						
71	A		D1AZ 14489-G		L.H. rear door-attach to 14633 L.H. rear quarter-attach to 14644 R.H. front door-attach to 14630	1 1 1
71	A		D1AZ 14489-E		R.H. rear door-attach to 14632 R.H. rear quarter-attach to 14644	1 1
72	A,B	"Before 1/17/72"	D2AZ 14489-H	62	L.H. front door-with power windows	1
72	A,B	"From 1/17/72"	D2AZ 14489-L		L.H. front door-with power windows-attach 14631 to 14529	1
72	A	"Before 1/17/72"	D2AZ 14489-K	43	R.H. front door or R.H. and L.H. rear doors or quarters-attaches 14630,14632,14633, 14644 to 14529 switch	AR
72	B	"Before 1/17/72"			R.H. front door or R.H. and L.H. rear door power windows	AR
72	B(exc. 63R)	"Before 1/17/72"			R.H. and L.H. rear quarter power windows-attach 14644 to 14529	AR
72	S	"Before 1/17/72"			R.H. and L.H. rear quarter power windows-attach 14644 to 14529	AR
72	A	"From 1/17/72"	D2AZ 14489-M		R.H. front door or R.H. and L.H. rear doors or quarters-attaches 14630,14632,14633, 14644 to 14529 switch	AR
72	B	"From 1/17/72"			R.H. front door or R.H. and L.H. rear door power windows-attaches 14630,14632, 14633 to 14529	AR
72	B(exc. 63R)	"From 1/17/72"			R.H. and L.H. rear quarter power windows-attach 14644 to 14529	AR
72	S	"From 1/17/72"			R.H. and L.H. rear quarter power windows-attach 14644 to 14529	AR
72	B(63R)	"Before 1/17/72"	D2OZ 14489-L		R.H. and L.H. rear quarter power windows-attach 14644 to 14529	AR
72	B(63R)	"From 1/17/72"	D2OZ 14489-M		R.H. and L.H. rear quarter power windows-attach 14644 to 14529	AR
72	S		D1MY 14489-A		L.H. front door-attach 14631 wiring to 14529	1
72	S	"Before 2/15/72"	D1MY 14489-B	63	R.H. front door-attach 14630 wiring to 14529	1
72	S	"From 2/15/72"	D2LY 14489-D		R.H. front door-attach 14630 wiring to 14529	1

YEAR	MODEL	WIRING CIRCUIT	COLOR	TYPE	MATING PART	TYPE	PART NUMBER	QTY.
SLEEVES - Listed by Circuit Number (Number of Wire Connections)								
65/	All	1	Gray	16	D2AZ 14489-B	18	D2AZ 14489-E	AR
		1	Gray	18	D2AZ 14489-E	16	D2AZ 14489-B	1
		1			Connects to courtesy lamp	44	D2SZ 14489-F	AR
		2	Black	22	C5AZ 14489-E	21	†C5AZ 14489-F	1
		2	Black	21	C5AZ 14489-F	22	†C5AZ 14489-E	1
		2	Blue	23	C7AZ 14489-B	24	†C7AZ 14489-A	1
		2	Blue	24	C7AZ 14489-A	23	†C7AZ 14489-B	1
		2	Natural	8	C8AZ 14489-L	7	C8AZ 14489-K	1
		2	Natural	7	C8AZ 14489-K	8	C8AZ 14489-L	1
		2	Brown	11	D2AZ 14489-D	12	D2AZ 14489-C	1
		2	Brown	12	D2AZ 14489-C	11	D2AZ 14489-D	1
		2	Gray	13	D2SZ 14489-C	45	D2AZ 14489-F	1
		2	Gray	45	D2AZ 14489-F	13	D2SZ 14489-C	1
		2	Natural		Connects to parking brake lamp	19	D2OZ 14489-J	1
		2	Natural		Connects to alternator	17	D2OZ 14489-K	1
		2	Red		Roof side lamp		D2VY 14489-B	1
		2	Black			22	C8AZ 14489-U	AR
		2	Black		Attach to 14405	20	D0SZ 14489-E	AR
		2	Natural		Connects to 10346		D2AZ 14489-A	AR

† Tab locking type ‡ Insert pressure locking type

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

FORD CAR PARTS**SECTION 144****14488-9 CONNECTORS and SLEEVES (WIRE) - continued**

YEAR	MODEL	WIRING CIRCUIT	COLOR	TYPE	MATING PART	TYPE	PART NUMBER	QTY.
SLEEVES - Listed by Circuit Number (Number of Wire Connections)								
65/	All	3	Green	23	C7AZ 14489-F	24	†C7AZ 14489-E	1
		3	Green	24	C7AZ 14489-E	23	†C7AZ 14489-F	1
		3	Black		R.H.-attaches to 14405	20	D0SZ 14489-F	AR
		3	Black		L.H.-attaches to 14405	20	D0SZ 14489-G	AR
		3	Black		Connects to 14512 or 14677	54	D2AZ 14489-J	AR
		4or6	Black	30	C5AZ 14489-G	31	†C5AZ 14489-H	1
		4or6	Black	31	C5AZ 14489-H	30	†C5AZ 14489-G	1
		4	Black		Attaches to 14401	20	D0SZ 14489-K	AR
		5	Blue		D1AZ 14489-B		D1AZ 14489-A	1
		5	Blue		D1AZ 14489-A		D1AZ 14489-B	1
		5	Natural		Connects to ignition switch	41	D2OZ 14489-F	AR
		6	Natural	32	C7AZ 14489-N	30	†C7AZ 14489-T	1
		6	Natural	30	C7AZ 14489-T	32	†C7AZ 14489-N	1
		6	Brown	33	D2SZ 14489-E	29	D2SZ 14489-D	1
		6	Brown	29	D2SZ 14489-D	33	D2SZ 14489-E	1
		6	Black		Attaches to 14405		D0SZ 14489-L	AR
		6	Black		Attaches to 14405		D0SZ 14489-M	AR
		6	Red		Electric spark control		D2AZ 14489-G	AR
		6	Black			40	D2OZ 14489-G	AR
		7	Gray	64	D0AZ 14489-C	28	D0AZ 14489-B	1
		7	Gray	28	D0AZ 14489-B	64	D0AZ 14489-C	1
		7	Black	29	D1AZ 14489-L	33	D1AZ 14489-C	1
		7	Black	33	D1AZ 14489-C	29	D1AZ 14489-L	1
		8	Black	31	C4AZ 14489-F	30	†C4AZ 14489-E	1
		8	Black	30	C4AZ 14489-E	31	†C4AZ 14489-F	1
		8	Black		C7AZ 14489-AD	32	†C7AZ 14489-M	1
		8	Gray	32	D2SZ 14489-H	29	D2SZ 14489-G	1
		8	Gray	29	D2SZ 14489-G	32	D2SZ 14489-H	1
		8	Black		Connects to power seat switch		D2LY 14489-A	AR
		10	Black	31	C5SZ 14489-B	30	†C5SZ 14489-A	1
		10	Black	30	C5SZ 14489-A	31	†C5SZ 14489-B	1
		10	Natural		C7AZ 14489-AG		C7AZ 14489-AF	1
		10	Natural		C7AZ 14489-AF		C7AZ 14489-AG	1
		10	Brown	32	C7AZ 14489-L	18	†C7AZ 14489-AC	1
		10	Brown	18	C7AZ 14489-AC	32	†C7AZ 14489-L	1
		10	Natural	39	C8AZ 14489-S	38	C8AZ 14489-AA	1
		10	Black	38	C8AZ 14489-AA	39	D0AZ 14489-L	1
		11	Gray	39	D2OZ 14489-B	38	D2OZ 14489-A	1
		11	Gray	38	D2OZ 14489-A	39	D2OZ 14489-B	1
		12	Black		Connects to printed circuit	50	D0VY 14489-G	AR
		18			Connects to printed circuit	34	C7SZ 14489-A	1
		18	Black		Connects to printed circuit	34	D0DZ 14489-A	AR
		21	Gray	37	D2OZ 14489-C	35	D2OZ 14489-D	1
		21	Gray	37	D2OZ 14489-C	35	D2OZ 14489-E	1
		27	Green or Orange		Attaches to 14401 at 14A068	26	C8OZ 14489-A	1
		27	Natural		Attaches to 14290	27	C8OZ 14489-B	1
		27	Green or Orange				D1ZZ 14489-A	1
		42	Gray	35	D2OZ 14489-D & D2OZ 14489-E	37	D2OZ 14489-C	1

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14490 BOOT - WIRING CONNECTOR SLEEVE				
72	B		2	D2OZ 14490-A

† Tab locking type

‡ Insert pressure locking type

FORD CAR PARTS

SECTION 145

1

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A501 SWITCH and WIRE ASSY. - SEAT BELT RETRACTOR SENSOR				
72	A, B-w/bench seat	" Before 11/1/71"	1	D2OZ 14A501-A
72	B-w/bucket seats		1	
72	F-w/bucket seats	" Before 12/1/71"	1	
72	L-w/o ignition restraint system-		1	
		" Before 4/3/72"		
72	P-w/bench seat	" Before 12/1/71"	1	
72	S-w/bucket seats	" From 9/16/71"	1	Passenger seat
72	A, B-w/bench seats	" From 11/1/71"	1	D2AZ 14A501-D
72	A,B-w/bench or split bench seat	Heavy duty	1	D2AZ 14A501-E
72	S-w/split bench seat	"Before 2/11/72"	1	D2SZ 14A501-A
72	S-w/split bench seat	"From 2/11/72"	1	D3SZ 14A501-A
72	S-w/bucket seats	" Before 9/16/71"	1	D2AZ 14A501-A
72	P-w/bench seat	" From 12/1/71"	1	D2DZ 14A501-A
72	P-w/bucket seat	" From 12/1/71"	1	
72	P-w/bucket seats	" Before 12/1/71"	1	D2ZZ 14A501-A
72	F-w/bucket seats	" From 12/1/71"	1	
72	L-w/o ignition restraint system-		1	
		" From 4/3/72"		
72	L-w/ignition restraint system-		2	D2FZ 14A501-A
		" Before 4/3/72"		
72	L-w/ignition restraint system-		2	D2FZ 14A501-B
		" From 4/3/72"		
14A502-3 SWITCH ASSY. - SEAT BELT RETRACTOR - Refer to Body Group 611A72-3				
14A504 WIRE ASSY. - SEAT BELT RETRACTOR SWITCH				
72	B	" Before 1/17/72"	1	D2OZ 14A504-A
72	B	" From 1/17/72"	1	D2OZ 14A504-B
72	F	R.H.	1	D2ZZ 14A504-A
		L.H.	1	D2ZZ 14A504-B
72	L -w/o ignition restraint system-	R.H.	1	D2FZ 14A504-A
		" Before 4/3/72"		
		L.H.	1	D2FZ 14A504-B
72	L-w/o ignition restraint system-	R. H.	1	D2FZ 14A504-E
		" From 4/3/72"		
		L. H.	1	D2FZ 14A504-G
72	L-w/ignition restraint system-	R. H.	1	D2FZ 14A504-C
		" Before 4/3/72"		
		L. H.	1	D2FZ 14A504-D
72	L-w/ignition restraint system-	R. H.	1	D2FZ 14A504-F
		" From 4/3/72"		
		L. H.	1	D2FZ 14A504-H
72	P	" Before 4/3/72"	1	D2DZ 14A504-A
		L.H.	1	D2DZ 14A504-B
72	P	" From 4/3/72"	1	D2DZ 14A504-C
		L. H.	1	D2DZ 14A504-D
14512 RELAY ASSY. - WINDOW and SEAT REGULATOR CONTROL - Also refer to Groups 14A707 & 15A668				
70	A,B,F,X-with automatic seat back latch	#D0VB 14C690-A, D1AB 14C690-AA	1	D0VY 14512-A
70/71	B-with automatic seat back latch		1	
70/	A-with automatic seat back latch		1	
71/	A(71)-with power back lite	#D1AB 14512-AA	1	D1AZ 14512-A
72	B,S-with automatic seat belt latch	#D2LB 14C690-AA	1	D2LY 14512-A
71/	F-with automatic seat back latch	#D1ZB 14C690-AA	1	D1ZZ 14512-A
65/66	S(76)	"From 9/15/62"	1	C3VY 14512-D
67/68	S	Adjustable steering column actuating-located on parking brake mounting bracket	1	C3VY 14512-C
70/71	S(65)-with automatic seat back latch	#D0SB 14C690-A	1	D0SZ 14512-A
71/	F	Screw (attach relay to relay panel)-1/4"-14 x 1/2"	AR	55981-S(U254E)
65/66	S(76)	Screw (relay to R. H. cowl side panel) - No. 14-14 x 3/4"	1	42143-S8(U255)
		Screw (relay and rear lamp wiring clip to R. H. cowl side panel)	1	

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

SECTION 145

FORD CAR PARTS

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14513 BUS BAR - WINDOW REGULATOR SWITCH				
69/70	A-with power windows	Attaches to 14529 switch	2	C9AZ 14513-A
65/66	S		2or3	C3SZ 14513-A
14A522 SOCKET ASSY. - INSTRUMENT CLUSTER				
68	F(GT 350/500)		2	★S8MS 14A522-A
14523 PLATE - WINDOW REGULATOR SWITCH				
68	A, B(except 66)	Single type-R. H. front & R. H., L. H. rear	1or3	C8AZ 14523-A
69/71	B		3	
14524 PLATE - WINDOW REGULATOR SWITCH				
68	A, B(except 66)	Front-L. H. -multiple	1	C8AZ 14524-A
69/71	B		1	
14526 BREAKER ASSY. - ELECTRICAL CIRCUIT - GLASS TUBE FUSE				

AMPERAGE	LENGTH	INDUSTRY NUMBER	QTY. PER VEHICLE	PART NUMBER	AMPERAGE	LENGTH	INDUSTRY NUMBER	QTY. PER VEHICLE	PART NUMBER
1	.62"	AGA-1	AR	B6AZ 14526-D	10	1.25"	AGC-10	AR	B8TZ 14526-A
2	.62"	1AG-2	AR	D4AZ 14526-C	14	1.06"	SFE-14	AR	A0AZ 14526-A
2.5	.62"	1AG-2 1/2	AR	C4GY 14526-A	15	1.25"	AGC-15	AR	A2AZ 14526-A
3	.62"	AGA-3	AR	A6AZ 14526-A	15	.88"	AGW-15	AR	C4SZ 14526-B
3	1.00"	8AG-3	AR	D4AZ 14526-E	20	.62"	AGA-20	AR	8HC 14526
4	.62"	SFE-4	AR	C9SZ 14526-C	20	1.00"	AGX-20	AR	C5AZ 14526-B
4	.84"	AGW-4	AR	C0LY 14526-B	20	1.25"	SFE-20	AR	A0AZ 14526-B
5	.62"	AGA-5	AR	B6AZ 14526-B	25	1.25"	3AG-25	AR	C6TZ 14526-AB
6	.75"	SFE-6	AR	C1VY 14526-A	30	1.25"	AGC-30	AR	A9AZ 14526-A
7.5	.88"	SFE-7 1/2	AR	B6AZ 14526-A	30	1.00"	AGX-30	AR	C8OZ 14526-A
9	.88"	SFE-9	AR	A6AZ 14526-B					

GLASS TUBE FUSE APPLICATION CHART

FUNCTION	PINTO	MAVERICK	BRONCO	FORD	THUNDER-BIRD	FALCON	FAIRLANE TORINO	MUSTANG	INDUSTRY NUMBER	PART NUMBER
Air Conditioner (Polar Aire or Hang-on Type)				65/		65/67	65/67	65	AGC-15	A2AZ 14526-A
Air Conditioner	71/	70/			65	68/70	68/71 72	69/	SFE-7 1/2 AGX-30 AGC-30	B6AZ 14526-A C8OZ 14526-A A9AZ 14526-A
Antenna (power)					72				AGC-15	A2AZ 14526-A
Auxiliary stop lamp system					69				AGX-20	C5AZ 14526-B
Back-up lamp			69/			65/67	65/67	65/70	SFE-14 SFE-7 1/2 SFE-20 AGC-15	A0AZ 14526-A B6AZ 14526-A A0AZ 14526-B A2AZ 14526-A
	71/	71/		69/	65/	68/70	68/70 71/	69 71/		
Brake release lamp (*same as dome lamp) (#see back-up lamp)				*	#	*	*			
Cigar lighter	71/	70/	66 68/	72 65/71	65/67 68/	65/70	71/	65/71 72	AGC-15 SFE-20 SFE-14 AGW-15 AGX-20 SFE-20	A2AZ 14526-A A0AZ 14526-B A0AZ 14526-A C4SZ 14526-B C5AZ 14526-B A0AZ 14526-B
Clock (consolette)	71/	70/								
Clock				65/68	65/67 68	65/70	65/68		1AG-2 AGC-15 SFE-14 AGW-4 SFE-4	D4AZ 14526-C A2AZ 14526-A A0AZ 14526-A C0LY 14526-B C9SZ 14526-C
Clock illumination		72		69		69	69	72 69 72	AGW-15 SFE-7 1/2 SFE-20	C4SZ 14526-B B6A 14526-A A0AZ 14526-B
Cornering lamp				72	69/71 72					

14526 BREAKER ASSY. - ELECTRICAL CIRCUIT - GLASS TUBE FUSE - continued

GLASS TUBE FUSE APPLICATION CHART

FUNCTION	PINTO	MAVERICK	BRONCO	FORD	THUNDER-BIRD	FALCON	FAIRLANE TORINO	MUSTANG	INDUSTRY NUMBER	PART NUMBER
Courtesy lamp	71	70/		69/	69	69	69	69/	SFE-14 AGX-20 SFE-20 AGW-15 SFE-7 1/2	A0AZ 14526-A C5AZ 14526-B A0AZ 14526-B C4SZ 14526-B B6AZ 14526-A
Dome lamp	71/	70/		69	65/67 68/	65/67 68/70	65/67 68/	65/67 68/	SFE-7 1/2 AGC-15 SFE-14 AGX-20 1AG-2 AGW-15	B6AZ 14526-A A2AZ 14526-A A0AZ 14526-A C5AZ 14526-B D4AZ 14526-C C4SZ 14526-B
Door locks (electric)					72				SFE-20	A0AZ 14526-B
Defroster (see heater)										
Directional signals			69			65/70	65/		SFE-14	A0AZ 14526-A
Defogger	71 72	71/		68/		68/70	68/	68/	SFE-20 SFE-14 AGC-15 SFE-7 1/2	A0AZ 14526-B A0AZ 14526-A A2AZ 14526-A B6AZ 14526-A
Electric antenna				65/	69	68	68	68	SFE-14 AGC-10	A0AZ 14526-A B8TZ 14526-A
Emergency warning flasher	71/	70/	70/	69	65/67	68/70	68/	69	SFE-20 AGX-20	A0AZ 14526-B C5AZ 14526-B
Emission control							71		SFE-20	A0AZ 14526-B
Four note horn system					69				SFE-20	A0AZ 14526-B
Fuel level system					68				SFE-6	C1VY 14526-A
Fuel level system				69				69	SFE-20	A0AZ 14526-B
Glove compartment lamp							69	70/	SFE-14	A0AZ 14526-A
Heater	71/	70/	66 66/	65/71 72		65/70	65/70	65/	SFE-14 SFE-20 3AG-25	A0AZ 14526-A A0AZ 14526-B C6TZ 14526-AB
Heated backlight				72	72				AGX-30 SFE-20	C8OZ 14526-A A0AZ 14526-B
Heater illumination				69	69	69	69	69	SFE-6 AGW-4 SFE-4	C1VY 14526-A C0LY 14526-B C9SZ 14526-C
Ignition key warning	71/	70/		71/				70/	SFE-14	A0AZ 14526-A
Instrument cluster warning lights	72	70/					70/	70/	SFE-4	C9SZ 14526-C
	71			72					SFE-14	A0AZ 14526-A
Instrument panel (cluster)				65/70	68	65/70	65/	65/	AGC-15 AGW-4 SFE-6 1AG-2 1/2 SFE4 1AG-2 SFE-6	A2AZ 14526-A C0LY 14526-B C1VY 14526-A C4GY 14526-A C9SZ 14526-C D4AZ 14526-C C1VY 14526-A
License plate lamp (see dome lamp)										
Low fuel warning					67/					B6AZ 14526-A
Luggage compartment lamp (see cigar lighter)		72						72	SFE-14	A0AZ 14526-A
Map lamp (see dome lamp)										
Overdrive				65/67			65/67		AGC-15	A2AZ 14526-A
Parking brake warning lamp				69				69/	SFE-20	A0AZ 14526-B
Parking lamp (see dome lamp)										

Δ Stop, Park & Rear Lamps • Courtesy Lamp Only † "Before 9/13/65" ‡ "From 9/13/65"

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR COMPANY — DEARBORN, MICHIGAN

FINAL ISSUE

14526 BREAKER ASSY. - ELECTRICAL CIRCUIT - GLASS TUBE FUSE - continued

GLASS TUBE FUSE APPLICATION CHART

FUNCTION	PINTO	MAVERICK	BRONCO	FORD	THUNDER- BIRD	FALCON	FAIRLANE TORINO	MUSTANG	INDUSTRY NUMBER	PART NUMBER
Pillar lamp (see dome lamp)										
Power tail gate				68/		68/70	68/		SFE-20	A0AZ 14526-B
Power window				68/	68/71	68/70	68/	69/	SFE-20	A0AZ 14526-B
Relay				72	72				SFE-7 1/2	B6AZ 14526-A
									SFE-20	A0AZ 14526-B
Radio	71/	72 70/71	72	69/	72	69	69	69	SFE-20	A0AZ 14526-B
							72		AGC-15	A2AZ 14526-A
									SFE-4	C9SZ 14526-C
									SFE-14	A0AZ 14526-A
Radio illumination				69	69	69	69	69	SFE-6	C1VY 14526-A
				72				72	AGW-4	C0LY 14526-B
									SFE-4	C9SZ 14526-C
Radio lamp (8 tube)			66 69/	65/	69 65/71	65/66 67	65/67	65/	SFE-7 1/2	B6AZ 14526-A
		70				68	68		SFE-7 1/2	B6AZ 14526-A
									SFE-14	A0AZ 14526-A
									SFE-20	A0AZ 14526-B
Rear seat speaker switch								65	SFE-7 1/2	B6AZ 14526-A
Reverberation speakers				69	69	69	69	69	AG-1	B6AZ 14526-D
Rolling door locks (vacuum)					67					C1VY 14526-A
Safety package		70/		65/	65/				SFE-7 1/2	B6AZ 14526-A
									SFE-20	A0AZ 14526-B
									AGX-20	C5AZ 14526-B
Seat belt warning lamp		72 70/71		71/ 69	65/67	66/70	66/	66/ 69	AGW-4	C0LY 14526-B
	72				69				SFE-14	A0AZ 14526-A
									SFE-20	A0AZ 14526-B
									AGW-15	C4SZ 14526-B
							72		SFE-4	C9SZ 14526-C
Seat belt warning lamp (console)					69/				SFE-7 1/2	B6AZ 14526-A
Skid control					69/71 72				8AG-3	D4AZ 14526-E
									AGA-3	A6AZ 14526-A
Speed control				66 72				69	SFE-14	A0AZ 14526-A
					69/				SFE-20	A0AZ 14526-B
					69				AGW-15	C4SZ 14526-B
Feed line at fuse panel				69/	72				AGA-5	B6AZ 14526-B
									SFE-7 1/2	B6AZ 14526-A
Spot lamp				65/	65/67	65/70	65/	65/	SFE-7 1/2	B6AZ 14526-A
Stereo tape radio					69				AGW-15	C4SZ 14526-B
Stop lamp (see dome lamp)										
Swing away steering column					69				AGX-20	C5AZ 14526-B
Tail lamp (see dome lamp)										
Transistorized Ignition				65					AGX-20	C5AZ 14526-B
Transmission Selector Indicator Lamp				68/	68/	68/70	68/		AGA-5	B6AZ 14526-B
									SFE-6	C1VY 14526-A
								68/	SFE-20	A0AZ 14526-B
Turn signal			70/		68/71				AGW-15	C4SZ 14526-B
					72			69	SFE-20	A0AZ 14526-B
					72			72	AGC-15	A2AZ 14526-A
									SFE-4	C9SZ 14526-C
Windshield washer	71/	71/ 70	69/	72	65/	68/70	71/ 68/70	71/ 69	SFE-14	A0AZ 14526-A
									SFE-7 1/2	B6AZ 14526-A
									AGC-15	A2AZ 14526-A
									SFE-20	A0AZ 14526-B

14526 BREAKER ASSY. FUSE - ELECTRICAL CIRCUIT

-Listed by Ampere



YEAR	MODEL	AMP.	VOLT	LENGTH	WIDTH	IDENTIFICATION MARKING COLOR	MTG. BRACKET		QTY.	PART NUMBER
							HOLE	DIAM.		
67/70	S-headlamp door solenoid (on brake pedal support)	5	12	1.25"	.78"	Green & white dot	2	9/32"	1	C7SZ 14526-A
67	S-stop lamps & turn signal								1	
71/72	S-with power deck lid release	6	12	1.06"	.40"	Blue dot	1	3/16"	1	D1VY 14526-A
69	A-with power deck lid release								1	
69	A (intermittent wiper motor)	7	12	1.25"	.79"		1	9/32"	1	C9AZ 14526-A
67/70	A (with 2 speed wiper)-on units built after 3-1-67	7.5	12	1.25"	.78"	Green & Violet	1	No. 8-32	1	C7AZ 14526-C
70	A-with intermittent wipers	8.25	12	1.25"	.79"				1	C9AZ 14526-F
65/67	F (fog lamp)	10	12	1.25"	.78"	White	2	9/32"	1	C5ZZ 14526-A
68	F (with fog lamps)	10	12	1.25"	.79"	White	1	13/64"	1	C8ZZ 14526-B
69/70	F (GT 350/500)-stop lamp & fog lamp	15	12						1	C9ZZ 14526-A
65	S (76)-top control	15	12	1.07" or 1.25"	.40" or .78"	Green	2	9/32"	2	C5SZ 14526-B
65	S (body main wiring)-turn signal	15	12	1.25"	.78"	Green			1	C4SZ 14526-C
66	S (body main wiring)-stop lamps & turn signal	15	12	1.07"	.40"	Green dot			AR	C6SZ 14526-A
67	S (body main wiring)-stop lamps								1	
71/71	F-with stop lights	15	12	1.27"	.79"		1	9/32"	1	D1MY 14526-A
71/71	A-with stop lights	15	12	1.28"	.79"	Green dot	1	9/32"	1	D1AZ 14526-D
65/71	A (76), X (76)-top control	20	12	1.07"	.40"	Red			1	C4DZ 14526-C
65/65	A (71), B (71), X (71)-tailgate								1	
65/65	A (window or seat regulator, automatic seat back latch)								1	
67/70	B (71), X (71)-electric windows or seats								1	
71	F-with automatic seat back latch								1	
71	B-with heated back window								1	
65/69	F (76)-top control								1	
69/70	F (GT 350/500)-fog lamp	20	12	1.25"	.75"				1	C9ZZ 14526-B
65	S (body main wiring)-heater or horn	20	12	1.07"	.40"	Red			2	C1VZ 14526-B
67	S (body main wiring)-horn & ammeter								1	
68	S (body main wiring)-stop lamps								1	
69/70	S (body main wiring)-horn, power windows and seats								2	
70/71	S-with heated back lite								1	
69	S-with heated back lite	20	12	1.25"	.79"	Red dot	1	13/64"	1	C9SZ 14526-A
69/71	S-sun roof								1	
71/71	A, B, F-located at I1450 relay-for heated backlite, power top, power windows or automatic seat back latch	20	12	1.07"	.40"	Red dot	1	11/32"	1	D1AZ 14526-A
72	S-power windows, stop lights	20	12	1.26"	.40"	Red dot			1	D0VY 14526-B
72	B, S-with power door locks		12	2.00"	.50"	Located at actuator			1	D2SZ 14526-A
65/67	A (air conditioner)	25	12	1.07"	.40"	Red, Yellow			1	C5AZ 14526-C
66	B, X (Select Aire A/C)								1	
67	B, F, X (with A/C)								1	
67	A, B, F, X (with A/C)	25	12	1.26"	.79"	Red, Yellow			1	C7AZ 14526-A
68/69	A (with A/C)	25	12	1.25"	.79"	Red & Green	1	9/32"	1	*C8AZ 14526-A r/b D0AZ 14526-A
68	F (6 cyl. 200, 8 cyl. 289)-with A/C	25	12	1.25"	.79"	Red & Green	1	13/64"	1	C8ZZ 14526-A
69	F (GT 350/500)-with fog lamp								1	
72	S-with sun roof								1	
69/70	A (with A/C)	30	12	1.06"	.40"	Orange	1	13/69"	1	D0AZ 14526-A
67	S (body main wiring)-heater	30	12	1.96"	.40"	Orange			1	C1VZ 14526-C
68/68	S (body main wiring)-accessory feed								1	
71/71	A-with A/C	30	12	2"	.50"	Orange dot	1		1	D1AZ 14526-B
65	S (76)-top control "Before 3/1/65"	60	12	2.40"	1.88"		2	17/64"	1	C3SZ 14526-A
72	S-A/C, power seat	30	12			Orange dot			1	D0VY 14526-C
72	B, S-heater A/C or A/T/C	35	12	1.27"	.70"	Orange			1	D2SZ 14526-B
72	S-with power door locks		12			White			1	D2SZ 14526-C

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14526 BREAKER ASSY. - FUSIBLE LINK - WIRE TYPE FUSE 				
66/67	A(76), B(76), F(76)-top control	6.00" long-14 gauge wire	1	C6AZ 14526-A
68	A(76)-top control		1	
68	B(76)-top control		1	
68	F(76)-top control	6.00" long-#C8ZB 14A094-A-16 gauge wire	1	C8ZZ 14526-C
65	S(76)-top control	6.00" long -12 gauge wire-not replaced (3-74)	1	★C5SZ 14526-C
66	S(76)-top control	9.00" long -12 gauge wire	1	C6SZ 14526-D
66	S(power window or seats)-on apron	6.00" long -14 gauge wire	1	C6SZ 14526-B
67/69	S	7.00" long-#C6VB 14A094-F(located at starter relay) -14 gauge wire	1	C6VY 14526-B
69/	A, B, F, S, X-w/55,61 or 65 amp. Ford alternator	9" long-14 gauge wire-r/b D3AZ 14526-D (4-74)	1	★C9AZ 14526-D
69/	A, B, F, L, P, S, U, X-with 38, 42, or 45 amp. Ford alternator	9" long-16 gauge wire fuse link (alternator protection)	1	C9AZ 14526-E
65/	S-with electric seats	Screw (breaker to R. H. or L. H. front floor pan or cowl side panel)-No. 10-12 x 1/2"	2or4	42014-S8(U240)
65/	S (76A)	Screw (breaker to inner deck panel)	2	
65/70	X (71)-with electric tailgate	Screw(breaker to R. H. rear corner pillar reinforcement)	1	
65/	A(71)	Screw (breaker to L. H. rear corner pillar lower reinforcement)	1	
65/	S-with electric windows	Screw (breaker to floor upper No. 3 cross member or to R. H. & L. H. cowl side panel)	2or4	
65/70	X-with electric windshield wipers	No. 10-32 x 5/8"	1	50525-S8(U159)
65/	A-with A/C		1	
65/	B-with electric windshield wipers		1	
65/	S(76A)	Screw (breaker (60 amp.) to R. H. front fender apron)-No. 14-10 x 1"	2	42154-S7(U256)
65/	A, S, X, B	Lockwasher-No. 10	AR	34903-S8(X96)
65/	A, S, X, B	Nut-No. 10-32	AR	34079-S7(M163)
71	B	Screw-No. 8-15 x 5/8"(circuit breaker to instrument panel)	AR	52554-S(U230)
65	F	Screw-No. 10-24 x 1/2"-attach circuit breaker to fender	2	40918-S(U260)
65/	B	Flatwasher-No. 10	1	44716-S8(X15)
66/	A(76), B(76)-top control	Nut-No. 10-24	1	34053-S8(M156)
69	S		2	
66/	A(76), B(76)-top control	Lockwasher-1/4" spring	1	34803-S7(X60)
69	S	Attach wiring to circuit breaker	2	
14527-8 HOUSING - WINDOW REGULATOR SWITCH				
65/66	A(54, 57B, 62, 63B, 71, 76A)	Multiple type-5 switch-on driver's door	1	C6GY 14527-A
65/66	★A(57F, 63F)		1	
67	A-without safety convenience panel		1	
65	★A(57F, 63F)	Multiple type-5 switch-on driver's door	1	C5MY 14527-B
65/66	A(54, 57B, 62, 63B, 71, 76A)	Single type-R.H. front door or R.H. & L.H. rear doors or quarters	3	C6GY 14528-A
65/66	★A(57F, 63F)		3	
65/66	A(63C, D, 76B, D)	R.H. & L.H. rear quarter	2	
67	A-without safety convenience panel	R.H. front door or R.H. & L.H. rear doors or quarters	3	
65/66	★A(57F, 63F)	R.H. front or R.H. & L.H. rear door or quarter	3	C5MY 14528-B
68	A(exc. 54B, E, 62B, E, 71D)-with manual vent	Multiple type-5 switch	1	C8AZ 14527-B
68/71	B		1	
68	A "Before 1/15/68"	Single type-on R.H. -front door or R.H. & L.H. rear doors or quarters	1 or 3	C8AZ 14528-A
68/71	B(except 71E)			
68	A "From 1/15/68"	Single type-R.H. -front door or R.H. & L.H. rear door or quarter	1 or 3	C8AZ 14528-B
68/69	B(except 71E)			
70/71	B	R. H. -front door or R.H. & L.H. rear door or quarter	3	
69/70	A	Multiple type-5 switch -L. H. front door	1	C9AZ 14527-A
71/	F	Multiple type-5 switch-L. H. front door	1	
71	A	Multiple type-L. H. front door	1	D1AZ 14527-A

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14527-8 HOUSING - WINDOW REGULATOR SWITCH - continued				
69/70	A	Single type-R. H. front door or R. H. and L. H. rear door or quarter	AR	C9AZ 14528-A
71/	F	Single type-R. H. front door or R.H. & L.H. rear quarter	3	
71	A	Single type-R. H. front or R. H. and L. H. rear door or quarter windows	3	D1AZ 14528-A
72	A	Multiple type on L.H. front door	1	D2AZ 14527-A
72	A	Single type-R.H.front door or R.H. & L.H. rear door or quarter	3	D2AZ 14528-A
72	B(exc.97)	Multiple type on L.H. front door	1	D2OZ 14527-A
72	B(exc.97)	Single type-R.H. front door or R.H. & L.H. rear door or quarter windows	3	D2OZ 14528-A
68/69	B(71E)	Single type R.H. & L.H. rear door	2	C8OZ 14528-B
65	S -without power vent windows	Multiple type	1	C4SZ 14528-B
66	S(63A, 76)-without power vent windows		1	
66	S(63C, D)-with power vent windows		1	
67	S	Multiple type	1	C5MY 14527-B
67	S(57)	Single type-on R. H. & L. H. rear door	2	C5MY 14528-C
67	S(65)	Single type -on R. H. & L. H. rear quarter	2	C7SZ 14528-B
67	A(63C, 76B)-with power reclining seat	On passenger seat	1	
67/70	S-with power reclining seat	On passenger seat-bench or bucket	1	
68	S(57, 65)-except safety convenience panel-	R. H. -front door	1	C8SZ 14528-B
	"Before 12/15/67"			
68	S(57)	R. H. & L. H. -rear doors	2	
68/69	S(65)	R. H. & L. H. -rear quarter	2	
69/	S	Sliding roof switch	1	
68/69	S(65, 57)-except safety convenience package-	R. H. -front door	1	C8SZ 14528-D
	"From 12/15/67"			
68/69	S(57)-with vacuum door locks	R. H. -front door	1	
68/71	S(57)-except safety convenience panel	R. H. & L. H. rear door	2	
69	S(57)-without vacuum door locks	Single type R. H. front door	1	C9LY 14528-A
70	S(57)	R. H. -rear door	1	
68/69	S(57, 65A, C)-with vacuum door locks-	Multiple type	1	C8SZ 14527-A
	"Before 3/29/69"			
68/69	S(57, 65A, C)-without vacuum door locks-	Multiple type	1	C8SZ 14527-B
	"Before 3/29/69"			
69	S(57, 65A, C)-with vacuum door locks-	Multiple type	1	C9SZ 14527-E
	"From 3/29/69"			
69	S(57, 65A, C)-without vacuum door locks-	Multiple type	1	C9LY 14527-B
	"From 3/29/69"			
69	S(65B, D)-without vacuum door locks-	Multiple type	1	C9SZ 14527-A
	"Before 3/29/69"			
69	S(65B, D)-without vacuum door locks-	Multiple type	1	C9SZ 14527-C
	"From 3/29/69"			
69	S(65B, D)-with vacuum door locks-	Multiple type	1	C9SZ 14527-B
	"Before 3/29/69"			
69	S(65B, D)-with vacuum door locks-	Multiple type	1	C9SZ 14527-D
	"From 3/29/69"			
70/71	S(57)-with power windows and power seat	R. H. -with lettering "Rear Tilt", "Front Tilt", "Seat", "Window"	1	D0SZ 14527-M
70/71	S(65)-with power windows and power seat	R. H. -with lettering "Rear Tilt", "Front Tilt", "Window"	1	D0SZ 14527-S
70/71	S-with remote control mirror	L. H. -"Mirror"	1	D0SZ 14528-A
70	S(65)-power window	R. H. & L. H. -quarter-single	2	D0SZ 14528-B
71	S(65A, C)-power windows	R. H. & L. H. -quarter-single	2	
70/71	S(57)-power window	R. H. -"Window"	1	D0SZ 14528-K
70/71	S(65)-power window	R. H. -"Window"	1	D0SZ 14528-P
70/71	S-with vacuum door locks	L. H. -with lettering "Mirror"- "Unlock"- "Lock"	1	D0SZ 14527-A
70/71	S-with power seat	L. H. -with lettering "Mirror"- "Front Tilt"- "Rear Tilt"- "Seat"	1	D0SZ 14527-B

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14527-8 HOUSING - WINDOW REGULATOR SWITCH - continued				
70	S-with power windows	L.H. -with lettering "Mirror"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"	1	D0SZ 14527-C
71	S(65A, C, 57)-with power windows	L.H. -with lettering "Mirror"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"	1	D0SZ 14527-D
70	S-with power windows and power seat	L.H. -with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"	1	D0SZ 14527-E
71	S(65A, C, 57)-with power windows and power seats	L.H. -with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"-"Door"	1	D0SZ 14527-F
70	S-with power window, power seat and vacuum door locks	L.H. -with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"-"Door"	1	D0SZ 14527-G
71	S(65A, C, 57)-with power windows, power seats, power door locks	L.H. -with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"-"Door"	1	D0SZ 14527-L
70/71	S-with power window and vacuum door locks	L.H. -with lettering "Mirror"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"-"Door"	1	D0SZ 14527-R
70/71	S-with power seat and vacuum door locks	L.H. -with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"-"Door"	1	D0SZ 14527-A
70/71	S(57)-with 6 way power seat	R.H. -with lettering "Rear Tilt"-"Front Tilt"-"Seat"	1	D0SZ 14527-B
70/71	S(65)-with 6 way power seat	R.H. -with lettering "Rear Tilt"-"Front Tilt"-"Seat"	1	D0SZ 14527-C
71	S(65B, D)-with power windows and power seat	L.H. -with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"	1	D1SZ 14527-A
71	S(65B, D)-with power windows	L.H. -with lettering "Mirror"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"	1	D1SZ 14527-B
71	S(65B, D)-with power windows and door locks	L.H. -with lettering "Mirror"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"-"Door"	1	D1SZ 14527-C
71	S(65B, D)-with power windows, power seat and door locks	L.H. -with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Unlock"-"Lock"-"Window"-"Door"	1	D1SZ 14527-D
72	S-with power windows without power seat	R.H.-front door with lettering "Window"	1	D2SZ 14528-A
72	S-with power windows with power seats	R.H. front door with lettering "Rear Tilt"-"Front Tilt"-"Seat"-"Windows"	1	D2SZ 14528-C
72	S-without power windows with power seats	R.H. front door with lettering "Rear Tilt"-"Front Tilt"-"Seat"	1	D2SZ 14528-B
72	S-with power windows, power seats & remote control mirror	L.H.-with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Window Lock"	1	D2LY 14527-A
72	S-with power windows, remote control mirror without power seats	L.H.-with lettering "Mirror"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Window Lock"	1	D2SZ 14527-D
72	S-without power windows with power seats and remote control mirror	L.H.-with lettering "Mirror"-"Rear Tilt"-"Front Tilt"-"Seat"	1	D2SZ 14527-E
72	S-without power windows-with power seats-without remote control mirror	L.H. - with lettering "Rear Tilt"-"Front Tilt"-"Seat"	1	D2SZ 14527-G
72	S-with power windows-without power seats-without remote control mirror	L.H. - with lettering "L-Front"-"R-Front"-"Lock"	1	D2SZ 14527-F
72	S-with power windows-with power seats-without remote control mirror	L.H. - with lettering "Rear Tilt"-"Front Tilt"-"Seat"-"L-Front"-"R-Front"-"L-Rear"-"R-Rear"-"Window Lock"	1	D2SZ 14527-H
72	S-without power window without power seats with remote control mirror	L.H. front door with lettering "Mirror"	1	D2SZ 14528-D
72	S-with power windows	R.H. & L.H. rear quarter window	2	D2LY 14528-A
70	S	Screw (attach housing to arm rest plate)-No.8-32 x 1/2"	AR	51764-S(U366)
71	S	Nut-1/8"-self thread-attach housing to door trim panel	4	370713-S(MM292)

FORD CAR PARTS

SECTION 145

9

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14529 SWITCH ASSY. - WINDOW REGULATOR CONTROL - Also refer to Groups 14540, 14632-3 & 15688				
65	B(71), X(71, 78)	Single type-rear window-key operated	1	C4AZ 14529-A
65/67	A(71)	Single type-rear window-key operated	1	C5AZ 14529-C
66/67	B(71)		1	
66/69	X(71)-single action tailgate		1	
68	A(71)-dual action tailgate	Single type-rear window-key operated	1	C8AZ 14529-E
68/70	B(71), X(71)		1	
65/66	A(71)	Single type-switch & wiring-toggle type	1	C5AZ 14529-D
67	A(71)	Single type-switch & wiring-toggle type	1	C7AZ 14529-A
68	A(71)	Single type-switch-toggle type-rear window	1	C8AZ 14529-B
69/70	A(71)	Single type-rear window-located at instrument panel	1	C9AZ 14529-C
68	A	Single type-R. H. front door-R. H. & L. H. rear windows	1or3	C8AZ 14529-A
68/71	B		3	
68	A	Double type-L. H. front door	2	C8AZ 14529-C
68/71	B		2	
69/70	A	Single type-located in master control	4	C9AZ 14529-B
71/	F	Located in master control	4	
69/70	A	Single type-on R. H. front door or R. H. & L. H. rear doors or quarters	3	C9AZ 14529-D
71/	F	Single type-located in R. H. front or R. H. & L. H. quarter window	3	
69	A(71)	Single type-rear window-key operated	1	C9AZ 14529-E
71	A	Single type-R. H. front door, R. H. & L. H. rear door or quarter windows-#D1AB 14529-C1B or C2B-r/b D3AZ 14529-F (10-74)	3	*D1AZ 14529-E
72	A	" Before 3/15/72" Single type-R.H. front door, R.H. & L.H. rear doors or quarters-D2AB 14529-A1A, A2A-r/b D3AZ 14529-F (6-74)	AR	*D2AZ 14529-A
72	A	" From 3/15/72 to 6/19/72" Single type-R. H. front door, R. H. & L. H. rear doors or quarters-#D2AB 14529-A1B, A2B-r/b D3AZ 14529-F (10-74)	AR	*D2AZ 14529-B
71/72	A	" From 6/19/72" Single type-R. H. front door or R. H. & L. H. rear doors or quarters-#D3AB 14529-CA	AR	D3AZ 14529-F
71/	A	Multiple type-5 switches-L.H. front door-#D1MB 14540-AA, AB, #D2MB 14540-AA	1	D2MY 14529-B
71/	A(71)-without backlite washer	Toggle type-located on instrument panel-#D1AB 14529-AB	1	D1AZ 14529-A
71/	A(71)-with backlite washer	Toggle type & push to wash-located on instrument panel-#D1AB 14529-BB	1	D1AZ 14529-B
71	A(71)-with backlite washer-"Before 11/2/70"	Rear window-key operated-#D1AB 14046-BD	1	D1AZ 14529-D
70/	A(71)-without backlite washer	Rear window-key operated	1	D1AZ 14529-C
71/	A(71)-with backlite washer - "From 11/2/70"		1	
65	B(71)	On dash panel -toggle type - rear window	1	C3OZ 14529-A
66/67	B(71), X(71)	Single type-switch & wiring-toggle type - rear window	1	C6OZ 14529-A
68/69	B(71), X(71)	Single type-rear window-toggle type	1	C8OZ 14529-A
70/71	B(71)	Single rear window-toggle type	1	D0OZ 14529-A
71	B(71)	Single switch-key operated-#D1OB 14529-AA	1	D1OZ 14529-A
72	B(71)	Toggle type-#D2OB 14529-AA	1	D2OZ 14529-A
72	B(71)	Key operated-#D2OB 14046-AA	1	D2OZ 14529-B
72	B(exc. 97)	" Before 3/15/72" R.H. front door or R.H. and L.H. rear door or quarter windows-#D2AB 14529-A1A, A2A-r/b D2AZ 14529-B (6-74)	3	*D2AZ 14529-A
72	B(exc. 97)	" From 3/15/72 to 6/19/72" Single type-R. H. front door or R. H. & L. H. rear door or quarter windows-#D2AB 14529-A1B, A2B-r/b D3AZ 14529-F (10-74)	AR	*D2AZ 14529-B
72	B	"From 6/19/72" Single type-R. H. front door or R. H. & L. H. rear doors or quarters-#D3AB 14529-CA	AR	D3AZ 14529-F
72	B(exc. 97)	Multiple type-5 switches-L. H. front door-#D2MB 14540-AA	1	D2MY 14529-B

Identification marking

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14529 SWITCH ASSY. - WINDOW REGULATOR CONTROL - continued				
Also refer to Groups 14540, 14632-3 & 15668				
88	S	"Before 12/15/67"	R. H. front door	1 C8SZ 14529-C
38	S(57)		R. H. & L. H. rear door	2
69	S(57)-with vacuum door locks		R. H. front door	1
68/69	S(65)- except safety convenience panel		Single type-R. H. & L. H. rear quarter	2 C8SZ 14529-A
68/69	S	"From 12/15/67 to 3/29/69"	R. H. front door	1
68/69	S(57)		R. H. & L. H. rear door	2
69/70	S-with sliding roof		Actuate sliding sun roof	1
70/71	S(65)		R. H. & L. H. quarter windows	2 C8LY 14529-A
69/71	S		Single switch and wiring used as replacement switches for 14633 wiring assy. L. H. front door	AR C9SZ 14529-A
69/71	S (57, 65A, C)		Multiple type-4 switches and wiring-L. H. front door-#C9LB 14A265-B, D1SB 14A265-AA	1 D1SZ 14529-A
69/71	S(65B, D)	"From 3/29/69"	Multiple type-2 switches and wiring-L. H. front door-#C9SB 14A265-C, D1SB 14A265-DA	2 D1SZ 14529-D
71	S-without power seats		Single type-1 switch-R. H. front door-#C9LB 14A265-A, D1SB 14A265-BA	1 D1SZ 14529-B
69/70	S	"From 3/29/69"	R. H.-front door-#C9LB 14A265-A-	1
69/71	S(57)	"From 3/29/69"	Single type-1 switch-R. H. rear door-#C9SB 14A265-A, D1SB 14A265-CA	1 D1SZ 14529-C
69/71	S(57)	"From 3/29/69"	Single type-1 switch-L. H. rear door-#C9SB 14A265-B, D1SB 14A265-EA	1 D1SZ 14529-E
70/71	S		Single switch for master control-#D1VB 14A265-BA	1 D1VY 14529-B
70/71	S-with 6 way power seats		Single switch-R. H. front door-#D1VB 14A265-CA	1 D1VY 14529-C
72	S	" Before 3/15/72"	R.H.& L.H. rear quarter-#D2AB 14529-A1A, A2A-r/b D3AZ 14529-F (10-74)	2 ★D2AZ 14529-A
72	S	" Before 3/15/72"	R.H. front door-#D2MB 14529-AA	1 D2MY 14529-A
72	S	" From 3/15/72 to 5/22/72"	R. H. & L. H. rear quarter-#D2AB 14529-A1B, A2B-r/b D3AZ 14529-F (10-74)	2 ★D2AZ 14529-B
72	S	" From 3/15/72 to 5/22/72"	R. H. front door	1
72	S	" From 5/22/72"	R. H. & L. H. rear quarter-#D3AB 14529-CA	AR D3AZ 14529-F
72	S		R. H. front door	1
72	S		Multiple type-5 switches-L.H. front door-#D2MB 14540-AA	1 D2MY 14529-B
71	B(71)		Screw (attach switch to tailgate)-No. 8-32 x 1/2"	2 57075-S(B330A)
71	A(71)		Snap ring retain 14529 switch to control	1 97409-S(Q5A)
71	A(71)		Screw (attach switch & wiring to tailgate panel)-No. 8-15 x 1/2"	2 52012-S(U202)
			Clip assy. (attach switch & wiring to tailgate panel)	2 383182-S(GG359)
65/	A (71)		Clip (wiring leads of switch to back window regulator control)	1 372866-S100(GG89)
65/	A (71)		Clip (wiring leads of switch to back window regulator mounting panel)	1 372047-S100 (GG217)
65/67	X (71, 78)		Nut (switch to tailgate lock & cover plate)-No. 8-32	2 34052-S7(M155)
65/68	A (71), B(71)		Nut (switch to back window handle plate)	2
			Lockwasher - No. 8	2 34802-S7(X59)
70	B (71)		Nut-1/2"-28-thin	1 356098-S (MM122A)
71	B		Clip-No. 8-32 x 1/2" -attach switch to tailgate inner panel	2 382031-S(GG280)
14530 BUTTON ASSY. - WINDOW REGULATOR CONTROL SWITCH				
71/	A		Used on single type switches	AR D1AZ 14530-A
72	B, S			AR
71/	A		Used on multiple type switches	AR D1MY 14530-A
72	B, S			AR

Identification marking

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14531 SHIELD - WINDOW REGULATOR CONTROL SWITCH				
71/	A	Multiple type	1	D1AZ 14531-A
72	B,S		1	
71/	A	Single type	AR	D1MY 14531-A
72	B,S		AR	
14536 BRACKET - INSTRUMENT PANEL WIRING				
68/70	S	L. H. side of instrument panel	1	C8SZ 14536-A
72	B	Located on parking brake control	1	D2OZ 14536-C
14540 SWITCH ASSY. - WINDOW REGULATOR- Also refer to Groups 14529 & 14632-3				
65/66	A(54,57B,62,63B,71,76A)	Master window control	1	C5AZ 14540-B
65/66	A(57F,63F)		1	
67	A		1	
66	A(57F,63F)	Master window control	1	C6MY 14540-B
67	A-w/safety convenience panel	Master window control	1	C7AZ 14540-B
68	A	Master control -#C8AB 14A695-A	1	C8AZ 14540-A
68/71	B		1	
69/70	A	Located in L. H. master control - #C9AB 14A695-B	1	C9AZ 14540-B
71/	F	Master window control	1	
65	S	Master window control	1	C4SZ 14540-B
65/66	A(63C,D,76B,D)		1	
66	S(63A,76)		1	
67	S	Master window control	1	C7SZ 14540-B
68/69	S	"Before 3/29/69" Master control -#C8VB 14A695-A	1	C8SZ 14540-A
69	S	"From 3/29/69" Master control -#C9VB 14A695-A	1	C9VY 14540-A
68/69	S	"Before 3/29/69" Double switch used in master control housing	2	C8SZ 14540-B
69	S	"From 3/29/69" Refer to basic 14529		
14546 RELAY ASSY. - SEAT REGULATOR CONTROL - Refer to Groups 14512 & 14A707				
14A546 WIRE ASSY.- SEAT BELT SWITCH				
72	B-with 3 speed manual trans.	Extension	1	D2OZ 14A546-A
72	B-with 3 & 4 speed manual trans.	Jumper	1	D2OZ 14A546-B
14547 MOTOR ASSY. - SEAT REGULATOR				
65/66	A(except 63C,D,76B,D)	With 6 way bench seat	1	C5AZ 14547-B
69/71	B	With power bench seat	1	(MM-202)
67/71	S	With 6 way bucket seat	2	C7SZ 14547-A
67/72	A	" Before 12/1/71" With 6 way split bench or bucket seat	1or2	(MM-221)
67/72	A	" Before 12/1/71" With 6 way bench seat	1	C7SZ 14547-B
68/71	S		1	(MM-222)
72	B	With 6 way bench seat	1	D2OZ 14547-A
72	A	" From 12/1/71"	1	(MM-304)
72	S	With 6 way bucket or split bench seat	1	D2SZ 14547-A
72	A	" From 12/1/71"	1	(MM-305)
65	S		1or2	C5SZ 14547-A
65	A(63C,76B)		1or2	(MM-203)
66	S	With 6 way bucket seat	AR	C6SZ 14547-A
66	A(63C,D,76B,D)		AR	(MM-215)
		Nut (motor to vertical or horizontal regulator housing)- No. 10-32	2or4	34079-S7(M163)
		Lockwasher	AR	34803-S7(X60)
♦ 14553 MOTOR ASSY. - WINDOW REGULATOR - Also refer to Body Groups 23394-5,30304-5 & 40964				
65/66	B(71),X(71)	12 volt-2" dia. -#C4AF 14553-A	1	C4AZ 14553-B
				(MM-148)
14A554 ACTUATOR - SEAT BELT and IGNITION - WARNING SYSTEM				
72	L-with ignition restraint system	Located under R. H. instrument panel	1	D2FZ 14A554-A
14559 CLIP - WINDOW OR SEAT REGULATOR SWITCH RETAINING				
65/66	A,S	.31" x .51"-2 tabs	AR	FAA 14559-A
65/66	A(except 63C,76B)	.31" x .41"-1 tab	AR	C5AZ 14559-C
67/69	A,S	Used on master control switch	AR	

♦ For 1965/ Models (except Falcon & Fairlane tailgate window) Body Basic Groups 23394-5, 30304-5 & 40964 must be used
 # Identification marking ☆ U. S. only ♦ Canada only

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

SECTION 145

FORD CAR PARTS

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14559 CLIP - WINDOW OR SEAT REGULATOR SWITCH RETAINING -continued				
65/67	A	.31" x .50"- "J" type	AR	C5AZ 14559-A
67/71	S-with power windows		AR	
67/71	S-with safety convenience package		2	
67	A(63C, 76B)-with power reclining seat	On passenger seat	2	
67	S-with power reclining seat	On passenger seat	2	
67	S-with vacuum door lock between switch and retainer		2	
68/71	S(57C, 65C, D)-with 6 way power bench seat		2	
65/	A(71)	Steel spring wire	1	C5AZ 14559-B
66/	B(71)-with swing-away tailgate		1	
66/70	X(71)-with swing-away tailgate		1	
65/66	S(76)		2	C5SZ 14559-A
14570 CLIP - WINDOW REGULATOR HOUSING RETAINER				
69/71	A	Attach 14527, 14528 to 14489 switch retainer	6	D1AZ 14570-A
71	S	Attach 14527, 14528 to 14489 switch retainer	AR	
71/	F	Attach 14528 to 14489 switch retainer	AR	
70	A	Attach 14527 to multiple switch retainer	2	D0AZ 14570-A
71/	F	Attach 14527 to 14489 switch retainer	2	
65/66	S		4	C4AZ 14570-A
67	S-with power windows "Before 12/9/66"		4	C5MY 14570-B
67	S-with power reclining seat "Before 12/9/66"	On passenger seat	2	
67	A(63C, 76B)-with power reclining seat- "Before 12/16/66"	On passenger seat	2	
67	A(63C, 76B)-with power reclining seat- "From 12/16/66"	On passenger seat	2	C7AZ 14570-A
67/69	S-with power reclining seat "From 12/9/66"	On passenger seat-bench or bucket	2	
67/69	S-with power windows "From 12/9/66"		4	
69	F-with forced vent system or a/cond.		4	
69/70	S-with sun roof	Attach sun roof housing	2	
70	B-with a/cond.	Attach register to duct	4	
14574 WIRE ASSY. - RADIO REAR SEAT SPEAKER EXTENSION				
69/70	A(except 71, 76)-AM radio		1	C9AZ 14574-A
69/70	A(71)-dual rear speakers-AM radio		1	C9AZ 14574-B
71	A(54, 57, 65)-with dual rear seat speakers		1	D1AZ 14574-A
71	A(71)-with dual rear seat speakers		1	D1AZ 14574-B
71	F-with single rear seat speaker		2	D1OZ 14574-A
71	B	Refer to basic 18A900	1	
72	A(71)-AM radio	With dual rear speakers	1	D2AZ 14574-B
72	A(exc. 71, 76)-AM radio	With dual rear speakers	1	D2AZ 14574-A
70	B(except 71), F-with dual rear seat speakers		1	D0OZ 14574-A
72	B(exc. 71, 97)-AM radio	With dual rear speakers	1	D2OZ 14574-A
72	L, P	With dual rear speakers	1	
72	B-AM/FM radio		1	D2OZ 14574-B
70	S		1	D0SB 14574-A
70/	A	Clip No. 8-18 (attach rear seat speaker wiring to inner cowl panel)	AR	383182-S(GG359)
70	A	Strap(nylon) (attach rear seat speaker wiring to inner cowl panel)	AR	383313-S(YY6)
70/	A	Screw-No.8-18 x 1/2" (attach wiring to cowl top)	AR	52012-S(U202)
14603 BUSHING - TERMINAL				
67	F, S		1	C7ZZ 14603-A
14603 GROMMET - WIRING				
69/71	A	Back-up lamp wiring in bumper	4	C9AZ 14603-A
70/	A(71)	Used in tailgate inner panel	2	D0AZ 14603-A
70/71	S(65)	Wiring 10B923 at roof side	1	D0SZ 14603-A
14608 RETAINER ASSY. - COWL WIRING GROMMET THROUGH DASH				
65/67	B, F, X	Wiring thru dash	2	PB9M 14608-A
14613 RETAINER - WIRING GROMMET				
70/	S-with brake skid control	Nylon	1	C9SZ 14613-A
14618 WIRE ASSY. - SEAT REGULATOR CONTROL RELAY FEED EXTENSION				
68/69	S	6 way bucket seat-drivers side and passenger reclining seat	AR	C8SZ 14618-A

14630-1 WIRING - FRONT WINDOW REGULATOR

WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE FOR 1965 and SUBSEQUENT MODELS

The purpose of this guide is to facilitate the identification of the Service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM WIRING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C7SB 14A128-A	★C7SZ 14331-B	D2LB 14630-AG	D2LY 14630-A
C7SB 14A205-A	★C7SZ 14630-A	D2LB 14630-AJ	D2LY 14630-B
C8SB 14A205-A	C8SZ 14630-B	D2OB 14630-AC	D2OZ 14630-A
C8SB 14A205-B	C8SZ 14630-B	D2OB 14630-AD	D2OZ 14630-C
		D2OB 14630-AE	D2OZ 14630-C
		D2OB 14630-AF	D2OZ 14630-C
C5AB 14630-C	★C5AZ 14630-A		
C5AB 14630-D	★C5AZ 14630-B	D2SB 14630-AJ	D2SZ 14630-B
C6AB 14630-G	★C6AZ 14630-A	D2SB 14630-AG	D2SZ 14630-A
C6AB 14630-H	★C6AZ 14630-B	D3SB 14630-AA	D2SZ 14630-B
C6AB 14630-M	★C6AZ 14630-B		
C6AB 14630-L	★C6AZ 14630-A		
		ED-C9LB 14630-C	C9LY 14630-C
C7AB 14630-A	★C7AZ 14630-A	ED-D0AB 14630-L	D0AZ 14630-K
C7AB 14630-B	★C7AZ 14630-D		
C7AB 14630-D	★C7AZ 14630-D	C5AB 14631-C	★C5AZ 14631-A
C7AB 14630-E	★C7AZ 14630-E	C5SB 14631-B	★C5SZ 14631-B
C7MB 14630-G	C7MY 14630-B	C5SB 14631-C	★C5SZ 14631-A
		C6AB 14631-C	C6AZ 14631-A
C8AB 14630-D	C8AZ 14630-A	C7SB 14631-A	C7SZ 14631-C
C8AB 14630-E	C8AZ 14630-A	C7SB 14631-B	C7SZ 14631-C
C8OB 14630-A	★C8OZ 14630-A		
C8OB 14630-B	★C8OZ 14630-B	C8OB 14631-A	★C8OZ 14631-A
C8OB 14630-C	★C8OZ 14630-A	C8OB 14631-B	★C8OZ 14631-B
C8OB 14630-D	★C8OZ 14630-B	C8OB 14631-C	★C8OZ 14631-A
C8OB 14630-E	★C8OZ 14630-E	C8OB 14631-D	★C8OZ 14631-B
C8OB 14630-F	★C9OZ 14630-A	C8OB 14631-E	★C8OZ 14631-A
C8OB 14630-G	C9OZ 14630-B	C8OB 14631-G	★C8OZ 14631-G
C8SB 14630-A	★C8SZ 14630-E	C8OB 14631-H	★C9OZ 14631-A
C8SB 14630-B	★C8SZ 14630-E	C8OB 14631-J	C9OZ 14631-B
C8SB 14630-C	★C8SZ 14630-E		
C8SB 14630-E	★C8SZ 14630-E	C8SB 14631-A	C8SZ 14631-A
C8SB 14630-G	C8SZ 14630-J	C8SB 14631-B	C8SZ 14631-A
C8SB 14630-J	C8SZ 14630-J	C8SB 14631-C	C8SZ 14631-A
		C8SB 14631-D	C8SZ 14631-B
C9AB 14630-E	C9AZ 14630-A	C8SB 14631-E	C8SZ 14631-J
C9AB 14630-F	C9AZ 14630-A	C8SB 14631-F	C8SZ 14631-K
		C8SB 14631-G	C8SZ 14631-J
D0AB 14630-H	D0AZ 14630-K	C8SB 14631-H	C8SZ 14631-K
D0AB 14630-J	D0AZ 14630-K	C8SB 14631-J	C8SZ 14631-J
D0AB 14630-K	D0AZ 14630-K	C8SB 14631-K	C8SZ 14631-K
D0LB 14630-D	D0LY 14630-E		
D0LB 14630-E	D0LY 14630-E	C9AB 14631-G	C9AZ 14631-J
D0OB 14630-B	D0OZ 14630-A	C9AB 14631-J	C9AZ 14631-J
D0SB 14630-C	D0SZ 14630-D	C9AB 14631-K	C9AZ 14631-J
D0SB 14630-D	D0SZ 14630-D	C9AB 14631-L	C9AZ 14631-L
D0SB 14630-E	D0SZ 14630-D		
D1AB 14630-AD	D1AZ 14630-A	D0AB 14631-H	D0AZ 14631-L
D1LB 14630-AB	D0LY 14630-E	D0AB 14631-J	D0AZ 14631-L
D1OB 14630-AA	D0OZ 14630-A	D0AB 14631-N	D0AZ 14631-L
D1OB 14630-AB	D1OZ 14630-A		
D1SB 14630-AB	D1SZ 14630-A	D0OB 14631-B	D0OZ 14631-A
D1WB 14630-AD	D1WY 14630-A	D0LB 14631-E	D0LY 14631-G
		D0LB 14631-F	D0LY 14631-G
D2AB 14630-AB	D2AZ 14630-A	D0LB 14631-G	D0LY 14631-G
D2AB 14630-AC	D2AZ 14630-B	D0LB 14631-H	D0LY 14631-G

14630-1 WIRING - FRONT WINDOW REGULATOR - continued

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM WIRING OR TAG NUMBER	SERVICE WIRING PART NUMBER
D0SB 14631-D	D0SZ 14631-B	D2LB 14631-AG	D2LY 14631-A
D0SB 14631-E	D0SZ 14631-E	D2LB 14631-AJ	D2LY 14631-B
D0SB 14631-F	D0SZ 14631-E		
D0SB 14631-G	D0SZ 14631-E	D2OB 14631-AC	D2OZ 14631-A
D0SB 14631-H	D0SZ 14631-E	D2OB 14631-AD	D2OZ 14631-C
		D2OB 14631-AE	D2OZ 14631-C
		D2OB 14631-AF	D2OZ 14631-C
D1AB 14631-AD	D1AZ 14631-A		
D1LB 14631-AB	D1LY 14631-A	D2SB 14631-AH	D2SZ 14631-A
		D2SB 14631-AJ	D2SZ 14631-B
D1OB 14631-AB	D0OZ 14631-A		
D1OB 14631-AD	D1OZ 14631-A	D3SB 14631-AA	D2SZ 14631-B
D1SB 14631-AC	D1SZ 14631-A		
D1WB 14631-AE	D1WY 14631-A	ED-C9AB 14631-J	C9AZ 14631-J
D1WB 14631-AF	D1WY 14631-B	ED-C9AB 14631-K	C9AZ 14631-J
D2AB 14631-AB	D2AZ 14631-A	ED-C9SB 14631-D	C9SZ 14631-D
D2AB 14631-AC	D2AZ 14631-B	ED-C9SB 14631-E	C9SZ 14631-E

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
- A -				
67	A-without safety convenience panel -	Used with door mounted switches	1	C7MY 14630-B
69	A	R.H.-front door	1	C9AZ 14630-A
69	A	"Before 6/2/69" L.H.-front door	1	C9AZ 14631-J
69	A	"From 6/2/69" L.H.-front door	1	C9AZ 14631-L
70	A	R.H.-front door	1	D0AZ 14630-K
70	A	L.H.-front door	1	D0AZ 14631-L
71	A	R.H.-front door	1	D1AZ 14630-A
		L.H.-front door	1	D1AZ 14631-A
72	A	"Before 1/17/72" R.H.-front door	1	D2AZ 14630-A
		L.H.-front door	1	D2AZ 14631-A
72	A	"From 1/17/72" R.H.-front door	1	D2AZ 14630-B
		L.H.-front door	1	D2AZ 14631-B
- B -				
69	B(63,65,76)	R.H.-front door	1	C9OZ 14630-B
		L.H.-front door	1	C9OZ 14631-B
70	B	R.H.	1	D0OZ 14630-A
		L.H.	1	D0OZ 14631-A
71	B	R.H.-front door	1	D1OZ 14630-A
		L.H.-front door	1	D1OZ 14631-A
72	B(exc.97)	"Before 10/1/71" R.H.-front door	1	D2OZ 14630-A
		L.H.-front door	1	D2OZ 14631-A
72	B(exc.97)	"From 10/1/71" R.H.-front door	1	D2OZ 14630-C
		L.H.-front door	1	D2OZ 14631-C
- F -				
71/	F	R.H.-front door	1	D1WY 14630-A
71/	F	L.H.-front door	1	D1WY 14631-B
- S -				
68	S	"Before 12/15/67" R.H.-front door	1	★C8SZ 14630-E
68/69	S	"From 12/15/67 to 10/14/68" R.H.-front door	1	C8SZ 14630-J
69	S	"From 10/14/68" R.H.-front door	1	C9LY 14630-C
68	S(57)	"Before 11/17/67" L.H.-front door	1	C8SZ 14631-A

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14630-1 WIRING - FRONT WINDOW REGULATOR - continued				
- S -				
68/69	S(57)	"From 11/17/67 to 10/14/68"	L. H. -front door	1 C8SZ 14631-J
69	S(57)	"From 10/14/68"	L. H. -front door	1 C9SZ 14631-E
68/69	S(65)	"Before 10/14/68"	L. H. -front door	1 C8SZ 14631-K
69	S(65)	"From 10/14/68"	L. H. -front door	1 C9SZ 14631-D
68/69	S(without safety convenience panel)	Jumper wire R.H. front door safety relay to R.H.-front door wiring	1	C8SZ 14630-B
70	S-without power seats	"Before 11/1/69"	R. H. L. H.	1 D0SZ 14630-D 1 D0SZ 14631-B
70	S-without power seats	"From 11/1/69"	R. H. L. H.	1 D0SZ 14630-D 1 D0SZ 14631-E
70/71	S-with power seats		R. H.	1 D0LY 14630-E
70	S-with power seats		L. H.	1 D0LY 14631-G
71	S-with power seats		L. H.	1 D1LY 14631-A
71	S-without power seat		R. H. -front door L. H. -front door	1 D1SZ 14630-A 1 D1SZ 14631-A
72	S-with power seat	"Before 2/15/72"	R. H. -front door L. H. -front door	1 D2LY 14630-A 1 D2LY 14631-B
72	S-with power seat	"From 2/15/72"	R. H. front door L. H. -front door	1 D2LY 14630-B 1 D2LY 14631-B
72	S-without power seats	"Before 2/15/72"	R. H. -front door L. H. -front door	1 D2SZ 14630-A 1 D2SZ 14631-A
72	S-without power seat	"From 2/15/72"	R. H. -front door L. H. -front door	1 D2SZ 14630-B 1 D2SZ 14631-B
65/	A	Clip (L. H. wiring to cowl top inner panel)	1	356628-S(GG175)
65/	A	Clip (R. H. wiring to cowl top inner panel)	2	372866-S100(GG89)
65/	A	Clip (wiring to front door inside panel)	1or2	372047-S100 (GG217)
65/	A	Clip (L. H. wiring to upper front body pillar)	1	372049-S100 (GG208)
65/	A	Clip (R. H. wiring to front floor inner panel)	1or2	371645-S100 (GG210M)
65/	A	Nut (wiring to motor) - No. 10-32	AR	34079-S7(M163)
65/	A	Lockwasher - No. 10	AR	34803-S7(X60)
65/	A	Screw (R. H. or L. H. wiring to cowl top inner panel)-No. 10-12 x 5/8"	2 or 4	42127-S8 (U248-C)
65/66	S	Screw (wiring to L. H. cowl side panel)	2	
65/	A	Clip-No. 8-32 (attaches wiring power windows to door)	4	383266-S (BB643CE)
65/	A	Strap (R. H. & L. H. wiring to front body upper inner pillar)	2	376914-S(YY2)
69/	A	Clip (door wiring to inside panel)	6	382185-S100- (GG283)
		Screw-No.8-32 x 3/4"	6	57077-S(B330B)
		Washer-No.10	6	374576-S(XX55A)
70	A	Bolt and clip-No. 8-32 (attach wiring sleeve to door inside panel)	AR	383266-S (BB643CE)
70/	A, S	Clip and nut-No. 8-32 (attach wiring to door inside panel)	AR	383034-S(GG358)
71	A	Nut & washer-No. 8-32(attach wiring to door inside panel)	AR	34653-S36(M106X)
71	A	Nut-No.8-32(attach wiring & sleeve (14489) to door panel)	4	377523-S(MM291C)
70/	A	Screw-No.8-15 x 1/2"(attach wiring to cowl panel)	4	52012-S (U202)
70/	B	Nut-No.8-32(attach locater on wiring to door panel)	4	382147-S100 (MM118H)
68/	B	Clip (wiring to instrument panel L.H. side)	AR	382033-S100 (GG303)
69	B	Nut-5/16"-18 (attach wiring to dash hinge lower)	2	353766-S(MM269)
70	B, S	Screw (attach wiring to cowl panel)-1/4"-14 x 1/2"	AR	55981-S(U254E)

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14630-1 WIRING - FRONT WINDOW REGULATOR - continued				
71	S	Screw-No.8-32 x 3/4"(attach wiring to inner door panel)	4	353609-S13(BB25)
71	S	Screw-No.8- 18 x 3/8"(attach wiring to inner door panel)	4	52720-S(U380)
71	A	Clip (attach wiring to cowl panel)	4	383182-S(GG359)
14A630 WIRE ASSY. - WINDOW REGULATOR JUMPER				
72	B(53,71)	"Before 10/1/71" #ED-D2OB 14A488-BE	1	D2OZ 14A630-B
72	B(53,71)	"From 10/1/71" #D2OB 14A488-BE	1	D2OZ 14A630-D
72	B(63,65)	"Before 10/1/71" #D2OB 14A488-AC	1	D2OZ 14A630-A
72	B(63,65)	"From 10/1/71 to 2/1/72" #D2OB 14A488-AE	1	D2OZ 14A630-C
72	B(63,65)	"From 2/1/72" #D2OB 14A488-AH	1	D2OZ 14A630-E
14632-3 WIRING - WINDOW REGULATOR - Also refer to Groups 14529 & 14540				

WIRING LOOM MARKING or TAG NUMBER TO SERVICE WIRING PART NUMBER GUIDE FOR 1965 and SUBSEQUENT MODELS

The purpose of this guide is to facilitate the identification of the Service Wiring Part Number. The chart that follows lists in numerical sequence the Wiring Loom Markings or Tag Numbers for 1965 and subsequent model vehicles. For many vehicles the Service Wiring Part Number will be the same as the Loom Marking or Tag Part Number. This type of replacement will cause little or no installation problems. However, when the Service Wiring differs from the Loom Marking or Tag Number it will be necessary to match lead wires and to tape up those lead wires which are not required. This is necessary when the Service Wiring has a more general application than the original wiring installed by the factory. Following this guide chart, Service Wiring Part Numbers are listed by model year and vehicle usage which will permit the identification of replacement wiring when the loom identification marking or tag number is not known.

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER
C4SB 14086-B	C4SZ 14632-C	C5SB 14A265-A	C5SZ 14632-A
C4SB 14086-C	C4SZ 14632-F	C6AB 14A265-A	C5AZ 14632-D
C5AB 14086-H	C5AZ 14633-D	C7AB 14A265-A	C7AZ 14632-A
C5SB 14086-A	C5SZ 14633-A	C7AB 14A265-B	C7AZ 14633-A
		C7SB 14A265-A	C7SZ 14632-C
C7SB 14086-A	C7SZ 14632-B		
C7SB 14086-B	C7SZ 14632-D	D0VB 14A265-B	D1VY 14529-C
C7SB 14086-C	C7SZ 14632-E	D0VB 14A265-E	D1VY 14529-B
C4SB 14087-B	C4SZ 14633-E	C4SB 14A266-B	C4SZ 14633-F
C6AB 14087-A	C6AZ 14633-H	C7SB 14A266-A	C7SZ 14633-C
C7SB 14087-A	C7SZ 14633-B		
C7SB 14087-B	C7SZ 14633-D		
		C5AB 14632-B	C5AZ 14632-B
		C7SB 14632-A	C7SZ 14632-A
		C7SB 14632-B	C7SZ 14632-F
C8AB 14A264-A	C8AZ 14633-A	C7SB 14632-C	C7SZ 14632-F
C8AB 14A264-B	★C8AZ 14632-A	C8OB 14632-A	★C8OZ 14632-A
C8AB 14A264-C	★C8AZ 14632-B	C8OB 14632-B	★C8OZ 14632-A
C8AB 14A264-D	★C8AZ 14633-B	C8SB 14632-A	★C8SZ 14632-A
C8AB 14A264-E	★C8AZ 14632-C	C8SB 14632-C	C8SZ 14632-C
C8AB 14A264-F	★C8AZ 14633-C		
C8OB 14A264-A	★C8OZ 14633-B	C9AB 14632-G	C9AZ 14632-B
C8OB 14A264-B	★C8OZ 14632-B	C9AB 14632-H	D0AZ 14632-A
C8OB 14A264-C	C8OZ 14632-C	C9AB 14632-K	D0AZ 14632-A
C8OB 14A264-D	C8OZ 14633-C	C9AB 14632-L	C9AZ 14632-B
C8OB 14A264-G	★C8OZ 14633-B	C9OB 14632-A	C9OZ 14632-A
C8OB 14A264-E	C8OZ 14632-D	C9SB 14632-A	C9SZ 14632-A
C8OB 14A264-F	C8OZ 14633-D		
C8SB 14A264-A	C8SZ 14632-B	D0AB 14632-A	D0AZ 14632-A
C8SB 14A264-B	C8SZ 14632-B	D0AB 14632-B	D0AZ 14632-B
		D0OB 14632-B	D0OZ 14632-A
		D0SB 14632-B	D0SZ 14632-A
C9LB 14A264-A	C9LY 14632-A		
C9LB 14A264-B	C9LY 14633-A	D1AB 14632-AB	D1AZ 14632-A
C9LB 14A264-C	C9LY 14632-B	D1AB 14632-AC	D1AZ 14632-A
		D1AB 14632-BB	D1AZ 14632-B
C4SB 14A265-B	C4SZ 14632-G	D1AB 14632-BC	D1AZ 14632-B
C5AB 14A265-G	C5AZ 14633-E	D1SB 14632-AB	D1SZ 14632-A
C5AB 14A265-J	C5AZ 14633-F		

Identification marking

14632-3 WIRING - WINDOW REGULATOR - continued - Also refer to Groups 14529, 14540 & 14644

LOOM MARKING OR TAG NUMBER	SERVICE WIRING PART NUMBER	LOOM WIRING OR TAG NUMBER	SERVICE WIRING PART NUMBER
D2AB 14632-BA	D2AZ 14632-B	C9AB 14633-M	D0AZ 14633-B
D2AB 14632-BB	D2AZ 14632-B	C9AB 14633-R	D0AZ 14633-B
D2AB 14632-BD	D2AZ 14632-D	C9OB 14633-A	C9OZ 14633-A
D2AB 14632-CA	D2AZ 14632-C	C9SB 14633-A	C9SZ 14633-A
D2AB 14632-CB	D2AZ 14632-C		
D2AB 14632-CC	D2AZ 14632-C	D0AB 14633-A	D0AZ 14633-A
D2AB 14632-CD	D2AZ 14632-E	D0AB 14633-C	D0AZ 14633-B
D2OB 14632-AB	D2OZ 14632-A	D0OB 14633-B	D0OZ 14633-A
D2OB 14632-AC	D2OZ 14632-C	D0SB 14633-B	D0SZ 14633-A
D2OB 14632-AD	D2OZ 14632-C	D1AB 14633-AB	D1AZ 14633-A
ED-D0AB 14632-A	D0AZ 14632-A	D1AB 14633-AC	D1AZ 14633-A
ED-D0AB 14632-B	D0AZ 14632-B	D1AB 14633-BB	D1AZ 14633-B
		D1AB 14633-BC	D1AZ 14633-B
		D1SB 14633-AB	D1SZ 14633-A
C6AB 14633-A	C6AZ 14633-A		
C7SB 14633-A	★C7SZ 14633-A	D2AB 14633-BA	D2AZ 14633-B
C7SB 14633-B	C7SZ 14633-E	D2AB 14633-BB	D2SZ 14633-B
C7SB 14633-C	C7SZ 14633-E	D2AB 14633-BD	D2AZ 14633-D
		D2AB 14633-CA	D2AZ 14633-C
C8OB 14633-A	★C8OZ 14633-A	D2AB 14633-CB	D2AZ 14633-C
C8OB 14633-B	★C8OZ 14633-A	D2AB 14633-CC	D2AZ 14633-C
C8SB 14633-A	★C8SZ 14633-A	D2AB 14633-CD	D2AZ 14633-E
C8SB 14633-B	★C8SZ 14633-A	D2OB 14633-AB	D2OZ 14633-C
C8SB 14633-C	C8SZ 14633-C	D2OB 14633-AC	D2OZ 14633-C
C9AB 14633-G	C9AZ 14633-A	D2OB 14633-AD	D2OZ 14633-C
C9AB 14633-H	C9AZ 14633-B	ED-C9AB 14633-L	D0AZ 14633-B
C9AB 14633-K	C9AZ 14633-A	ED-D0AB 14633-C	D0AZ 14633-B
C9AB 14633-L	D0AZ 14633-B	ED-D0AB 14633-A	D0AZ 14633-A

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
	- A -			
65/68	A(54, 57, 71)	Wiring-R. H. -rear door	1	C5AZ 14632-B
65/66	A(54, 57, 71)	Wiring-L. H. -rear door	1	
66/68	A	Wiring-L. H. -rear door	1	C6AZ 14633-A
68	A	R. H.-front door switch feed	1	★C8AZ 14632-A
		L. H.-front door switch feed	1	C8AZ 14633-A
68	A(54, 57, 71)	R. H.-rear door switch feed	1	★C8AZ 14632-B
		L. H.- rear door switch feed	1	★C8AZ 14633-B
68	A(63, 65, 76)	R. H.-rear quarter switch feed	1	★C8AZ 14632-C
		L. H.-rear quarter switch feed	1	★C8AZ 14633-C
69	A(54, 57, 71A, B, C, E)-except vacuum door locks	R.H.- rear door-repl.by D0AZ 14632-A(12-73)	1	★C9AZ 14632-A
		L.H.- rear door	1	C9AZ 14633-A
69	A(54, 57, 71A, B, C, E)-with vacuum door locks	R.H.- rear door	1	C9AZ 14632-B
		L.H.-rear door	1	D0AZ 14633-B
70	A-without power door locks	R. H. - rear door	1	D0AZ 14632-A
		L. H. - rear door	1	D0AZ 14633-A
70	A-with power door locks	R. H. - rear door	1	D0AZ 14632-B
		L. H. - rear door	1	D0AZ 14633-B
71	A(53, 54, 57, 71)-without power door locks	R. H.-rear door	1	D1AZ 14632-A
		L. H.-rear door	1	D1AZ 14633-A
71	A(53, 54, 57, 71)-with power door locks	R. H.-rear door	1	D1AZ 14632-B
		L. H.-rear door	1	D1AZ 14633-B
72	A(53, 54, 57, 71)-with power door locks - " Before 1/17/72"	R.H.-rear door	1	D2AZ 14632-C
		L.H.-rear door	1	D2AZ 14633-C
72	A(53, 54, 57, 71)-with power door locks- " From 1/17/72"	R. H. -rear door	1	D2AZ 14632-E
		L. H. -rear door	1	D2AZ 14633-E
72	A(53, 54, 57, 71)-without power door locks - " Before 1/17/72"	R.H.-rear door	1	D2AZ 14632-B
		L.H.-rear door	1	D2AZ 14633-B
72	A(53, 54, 57, 71)-without power door locks- " From 1/17/72"	R. H. -rear door	1	D2AZ 14632-D
		L. H. -rear door	1	D2AZ 14633-D

SECTION 145

FORD CAR PARTS

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14632-3 WIRING - WINDOW REGULATOR - continued - Also refer to Groups 14529, 14540 & 14644				
- A -				
65/66	A(Tudor)	Screw (R. H. & L. H. rear quarter wiring to front floor pan)-No. 10-16 x 3/8"	1or2	42120-S8(U248)
65/66	A(Tudor)	Clip-Nylon	1or2	★377846-S
65/66	A(Tudor-62, 63, 76)	Lockwasher-No. 10	1or2	34939-S8(X86)
69	A(54, 57, 71)	Screw-No. 8-32 x 3/4" hex. hd. (attach wiring to rear door extension)	2	57077-S2(B330B)
70	A(54, 57, 71)	Screw-No. 8-32 x 1/2" (attach door open wire to rear door inner panel)	4	57075-S(B330A)
70	A(54, 57, 71)	Clip (attach door open wire to rear door inner extension)	4	382185-S(GG283)
70	A(54, 57, 71)	Bolt and clip-No. 8-32 (attach wiring sleeve to rear door inner panel)	AR	383266-S (BB643CE)
70	A(54, 57, 71)	Screw-No. 8-32 x 3/4"-attach wiring to rear door inner panel	AR	57077-S(B330B)
- B -				
68	B(54, 71)	R. H.-rear door	1	★C8OZ 14632-A
		L. H.-rear door	1	★C8OZ 14633-A
68/69	B(54, 71)	R. H.-rear door switch feed	1	C8OZ 14632-C
		L. H.-rear door switch feed	1	★C8OZ 14633-C
68	B	R. H.-front door switch feed	1	★C8OZ 14632-B
		L. H.-front door switch feed	1	★C8OZ 14633-B
68/69	B(63, 65, 76)	R. H.-rear quarter switch feed	1	C8OZ 14632-D
		L. H.-rear quarter switch feed	1	C8OZ 14633-D
69	B(54, 71)	R. H.-rear door	1	C9OZ 14632-A
		L. H.-rear door	1	C9OZ 14633-A
70/71	B(54, 57, 71)	R.H.-rear door	1	D0OZ 14632-A
		L.H.-rear door	1	D0OZ 14633-A
72	B(53, 71)	"Before 10/1/71" R.H.-rear door	1	D2OZ 14632-A
		L.H.-rear door	1	D2OZ 14633-C
72	B(53, 71)	"From 1/17/72" R. H.-rear door	1	D2OZ 14632-C
		L. H.-rear door	1	D2OZ 14633-C
- S -				
67	S(57)	"Before 1/16/67" Wiring-R. H.-rear door	1	C7SZ 14632-A
67	S(57)	"From 1/16/67" Wiring-R. H.-rear door	1	C7SZ 14632-F
67	S(57)	"Before 1/16/67" Wiring-L. H.-rear door	1	★C7SZ 14633-A
67	S(57)	"From 1/16/67" Wiring-L. H.-rear door	1	C7SZ 14633-E
68	S(57)	"Before 12/15/67" R. H.-rear door	1	★C8SZ 14632-A
		L. H.-rear door	1	★C8SZ 14633-A
68/69	S(57)	"From 12/15/67 to 10/14/68" R. H.-rear door	1	C8SZ 14632-C
		L. H.-rear door	1	C8SZ 14633-C
69	S(57)	"From 10/14/68" R. H.-rear door	1	C9SZ 14632-A
		L. H.-rear door	1	C9SZ 14633-A
69	S-used for model 57 with vacuum door locks-	R. H.-front door-switch feed	1	C9LY 14632-A
	"Before 12/16/68"	R. H. & L. H. rear door	2	
		L. H.-front door-switch feed	1	C9LY 14633-A
69	S(57)-with vacuum door locks-	R. H.-front door	1	C9LY 14632-B
	"From 12/16/68"			
68/69	S(65)	Switch feed	2	C8SZ 14632-B
70	S(57)	R. H.-rear door	1	D0SZ 14632-A
		L. H.-rear door	1	D0SZ 14633-A
71	S(57)	R.H.-rear door	1	D1SZ 14632-A
		L.H.-rear door	1	D1SZ 14633-A
71	B	Screw-No.8-32 x 1/2"(wiring to door panel)	4	57075-S(B330A)
		Nut (wiring to circuit breaker)-No. 10-32	AR	34079-S7(M163)
		Lockwasher - No. 10	AR	34803-S7(X60)
70	A	Bolt & clip-No.8-32(attach wiring and sleeve to to inner door panel)	AR	383266-S (BB643CE)
		Nut-No. 8-32	AR	34653-S(M106X)

19

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14644 WIRING - REAR QUARTER WINDOW REGULATOR - continued				
- A -				
70	A	"Before 12/10/69" Rear quarter-#D0AB 14644-A	1	D0AZ 14644-A
70	A	"From 12/10/69" Rear quarter-# ED D0AB 14644-C,D	1	D0AZ 14644-C
71	A(65,76)	R.H. to L.H. side-#D1AB 14644-AC	1	D1AZ 14644-A
72	A(65,76)	"Before 1/17/72" R.H. to L.H. side-#D2AB 14644-AA	1	D2AZ 14644-A
72	A(65,76)	"From 1/17/72" R.H. to L.H. side-#D2AB 14644-AC,AD	1	D2AZ 14644-B
- B -				
68/69	B(63,65)	R.H.-front door to R.H.-rear quarter-#C6GB 14644-A	1	★C6GY 14644-A Not replaced
68/69	B(63,65)	L.H.-front door to L.H.-rear quarter-#C8OB 14A081-B	1	★C8OZ 14644-B Not replaced
68/69	B(76)	R.H.-front door to R.H.-rear quarter-#C6GB 14644-B	1	★C6GY 14644-B Not replaced
68	B(76)	L.H.-front door to L.H.-rear quarter-#C8OB 14A081-A	1	★C8OZ 14644-A Not replaced
70/71	B(63,65,76)	R.H.-rear quarter-#D0OB 14644-A, D1OB 14644-AA	1	D0OZ 14644-A
		L.H.-rear quarter-#D0OB 14A081-A D1OB 14A081-AA	1	D0OZ 14644-B
72	B(63,65)	"Before 1/17/72" R.H. to L.H. side-#D2OB 14644-AE	1	D2OZ 14644-A
72	B(63,65)	"From 1/17/72" R.H. to L.H. side-#D2OB 14644-AF	1	D2OZ 14644-B
- F -				
71/	F	R.H.-#D1ZB 14644-AB	1	D1ZZ 14644-A
		L.H.-#D1ZB 14A081-AB	1	D1ZZ 14644-B
- S -				
68/69	S(65)	#C8SB 14644-A	1	C8SZ 14644-A
70/71	S(65)	R.H. & L.H.-rear quarter-#D0SB 14645-B, D1SB 14645-AA,D0SB 14A416-B, D1SB 14A416-AA	1	D0SZ 14644-B
72	S	"Before 3/15/72" R.H. & L.H. side-#D2SB 14644-AB	1	D2LY 14644-A
72	S	"From 3/15/72" R.H. & L.H.-side-#D2SB 14644-AC	1	D2SZ 14644-A
70	A	Strap(attach wiring to panel)	AR	383313-S(YY6)
70	A(63,65,76)	Bolt & clip No. 8-32(attach wiring sleeve to inner quarter panel)	AR	383266-S (BB643CE)
70	A	Nut-No.8-32	AR	34653-S(M106X)
70	A	Clip(attach wiring to front floor cross member)	2	376188-S(GG147M)
14652 BRACKET - SEAT REGULATOR TERMINAL MOUNTING - Also refer to Body Section 618A88				
67/70	A,S-with 6-way power seat		1	C7AZ 14652-B
14677 RELAY ASSY. - WINDOW REGULATOR-SAFETY				
65/66	S		1	C1AF 14677-A
65	B(71),X(71,78)		1	
		Screw(relay to cowl panel or dash panel)- No. 14-14 x 1/2"	2	31497-S8(U254)
		Screw (relay to radiator support)	2	
65/69	A	#C8AB 14677-A	1	C5AZ 14677-A
66/69	B(71),X(71)		1	
68/69	A(71)	Power tailgate	1	
68/69	B	Power windows	1	
70	A	Power windows	1	
70	A(71),B(71),X(71)	Power tailgate	1	
70/71	B	Power windows	1	
71/	F	Power windows	1	
70/71	A(Taxi, P/C)	Accessory relay	1	C6VY 14677-B
71/	A-with power door locks	Time delay-#D1AB 14526-GA	1	D1AZ 14677-D
71	A-power windows	#D1AB 14677-AA,D2AB 14677-AA	1	D2AZ 14677-A
72	A,B-w/power windows and/or electric luggage compt. opener		1	

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14677 RELAY ASSY. - WINDOW REGULATOR - SAFETY - continued				
72	A-with A/T/C	#D2SB 14677-AA	1	D2SZ 14677-B
72	S-with A/T/C	With power windows and/or electric luggage door opener	AR	
72	B(53,71)	Police or taxi with power tailgate window	1	
72	B,S	With power door locks- #D2SB 14A093-AA	2	D2SZ 14677-A
71	A	With automatic temperature control- #D1AB 14677-BA,BB	1	D1AZ 14677-C
67/71	S	Power windows and A/C- #C7SB 14677-A, C8SB 14677-A, D, D0SB 14677-A, D0LB 14677-A, D1LB 14677-AA	1	D1LY 14677-A
68/71	S	Used in heater circuit #C8SB 18A656-A, D1SB 18A656-AA	1	D1SZ 14677-A
71	S	Washer-No.8 flat(attach 14677 relay to brkt.)	AR	44710-S(X10)
71	S	Screw-No.10-12 x 5/8"(attach 14677 relay to brkt.)	AR	42014-S8(U240)
14683 WIRING ASSY. - BACK WINDOW REGULATOR FEED				
- A -				
67/68	A(71)	#C7AB 14683-C, C8AB 14683-A	1	C7AZ 14683-C
69	A(71)	"Before 5/1/69" #C9AB 14683-A	1	C9AZ 14683-A
69	A(71)	"From 5/1/69" #C9AB 14683-C	1	C9AZ 14683-C
70	A(71)	#D0AB 14683-A, B	1	D0AZ 14683-A
- B -				
66/71	B(71)	#C6GB 14683-A, C8OB 14683-A, D1OB 14683-AB	1	C6GY 14683-A
72	B(71)	"Before 10/1/71" #D2OB 14683-AB	1	D2OZ 14683-A
72	B(71)	"From 10/1/71" #D2OB 14683-AC	1	D2OZ 14683-B
- X -				
66/70	X(71)	#C8OB 14683-A, D1OB 14683-AB	1	C6GY 14683-A
65/70	A(71)	Clip (wiring to L. H. corner upper inner panel)	1	372864-S100(GG91)
65/70	A(71)	Clip (wiring to L.H. rear lower corner pillar reinforcement)	1	372866-S100(GG89)
65/70	A(71)	Clip (wiring to fuel filler housing inner panel or to L. H. quarter panel)	1 or 2	
65/70	A(71), X(71,78)	Nut-No. 10-32	AR	34079-S7(M163)
65/70	A(71), X(71,78)	Lockwasher-No. 10	AR	34903-S8(X96)
65/70	X(71,76)	Clip (wiring to R. H. rocker panel or floor side outer member)	AR	377864-S(GG230)
70	A(71)	Clip No. 8-18 (attach wiring to inner cowl panel)	3	383182-S(GG359)
		Strap (nylon) (attach wiring to inner cowl panel)	1	383313-S(YY6)
14687 WIRING ASSY. - BACK WINDOW REGULATOR				
- A -				
65	A(71)		1	C5AZ 14687-A
66/67	A(71)		1	C6AZ 14687-B
68	A(71)	#C8AB 14687-A	1	C8AZ 14687-A
69	A(71)	#C9AB 14687-C, D	1	C9AZ 14687-D
70	A(71)-without vacuum door locks	#D0AB 14687-A, D	1	D0AZ 14687-D
70	A(71)-with vacuum door locks	#D0AB 14687-C	1	C9AZ 14687-F
71/	A(71)-w/o power door locks and/or t/gate window washer	#D1AB 14687-AB	1	D1AZ 14687-A
71/	A(71)-with power door locks-w/o t/gate window washer	#D1AB 14687-CB	1	D1AZ 14687-C
71	A(71)-with t/gate window washer-w/o power door locks "Before 11/2/70"	#D1AB 14687-BC	1	D1AB 14687-B
71/	A(71)-with t/gate window washer-w/o power door locks "From 11/2/70"	#D1AB 14687-BD	1	D1AZ 14687-E

Identification marking
May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14687 WIRING ASSY. - BACK WINDOW REGULATOR - continued				
- A -				
71	A(71)-with t/gate window washer-w/power door locks "Before 11/2/70"	#D1AB 14687-DC	1	D1AZ 14687-D
71/	A(71)-with t/gate window washer-w/power door locks "From 11/2/70"	#D1AB 14687-DD	1	D1AZ 14687-F
- B -				
68/71	B(71)-with dual action tailgate	#C8OB 14687-A, D1OB 14687-AB	1	C8OZ 14687-A
72	B(71)-	#D2OB 14687-AA, AC	1	D2OZ 14687-E
- X -				
66/70	X(71)-with single action tailgate		1	C6DZ 14687-A
68/70	X(71)-with dual action tailgate	#C8OB 14687-A, D1OB 14687-A	1	C8OZ 14687-A
65/69	A(71)	Clip (wiring to window regulator mounting panel)	2	372046-S100
65/69	A(71)	Clip (wiring to rear floor rear sill panel)	AR	(GG186)
65/69	A(71)	Clip (wiring to lower back panel or window regulator mounting panel)-rubber coated	1or2	372737-S100 (GG153A)
65/69	A(71)	Screw (wiring to lower back panel or back window regulator mounting panel)-No.8-15x1/2"	1or2	52726-S13 (U381)
65/69	A(71)	Clip (wiring to lower back panel)	1	372751-S(GG187)
71	B	Screw-No.8-32 x 1/2"(attach wiring to tail gate)	2	57075-S(B330A)
70	B(71)	Clip-No.8-18(attach wiring tailgate to inside panel)	AR	383182-S(GG359)
70	B(71)	Clip-No.8-32(attach wiring tailgate to inside panel)	AR	382031-S(GG280)
14B691 BRACKET - SEAT REGULATOR CONTROL MOUNTING				
72	B		1	D2OZ 14B691-A
14C691 WIRE ASSY. - SEAT BACK LATCH EXTENSION				
70/	A-except reclining seat	R. H. - #D0MB 14C691-A	1	D0AZ 14C691-A
		L. H. - #D0MB 14C693-A	1	D0AZ 14C691-B
70/	A(with passenger reclining seat)	R. H. - #D0AB 14C691-E	1	D0AZ 14C691-E
71	A(65F, 76)-hi back bucket seat	R. H.	1	
71/	A(65K)-with hi back bench or split bench seat	R.H. - #D1AB 14C691-AA	1	D1AZ 14C691-A
		L.H. - #D1AB 14C693-AA	1	D1AZ 14C691-B
70/71	B, X split or bench seat	R. H. - #D0OB 14C691-A, B, D	1	D0OZ 14C691-C
		L. H. - #D0OB 14C693-A, B, D	1	D0OZ 14C691-D
70/71	B, F, X-bucket seats	R. H. - #D0ZB 14C691-C, D, G	1	D0ZZ 14C691-A
70	A-with split bench seat	R.H.	1	
		L. H. - #D0ZB 14C693-B, C, E	1	D0ZZ 14C691-B
72	B-w/bench seat	R.H. - #D2LB 14C691-AB	1	D2LY 14C691-A
72	S-split bench seat-exc. recliner	R.H.	1	
72	S-w/split bench seat with recliner	R. H. - #D2LB 14C691-BA, BB	1	D2LY 14C691-D
72	S-w/bucket seat with recliner	R. H. - #D2SB 14C691-AB	1	D2SZ 14C691-B
72	B-w/bench seat	L. H.	1	D2LY 14C691-B
72	S-w/split bench seat	L. H.	1	
72	B-w/bucket seats	R.H. & L.H. - #D2OB 14C691-AC	2	D2OZ 14C691-A
72	S-w/bucket seats-without recliner	R.H.	1	
72	S-w/bucket seats	L. H.	1	
70/71	S(65)	L. H. - #D0SB 14C691-B	1	D0SZ 14C691-A
		R. H. - #D0LB 14C693-A	1	D0LY 14C691-A
71/	F	R.H. - #D1ZB 14C691-BA	1	D1ZZ 14C691-C
71/	F	L.H. - #D1ZB 14C691-AB, D1ZB 14C693-AA	1	D1ZZ 14C691-A
70	S	Clip-attach wiring to seat frame	2	381575-S100 (GG366)
70	S	Cup-attach wiring to seat cushion	1	381921-S(GG330)

Identification marking

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14C692 WIRE ASSY. - SEAT BACK LATCH				
72	S-with reclining seat	R. H. jumper	1	D2SZ 14C692-A
14B694 PIN - SEAT REGULATOR CONTROL KNOB PIVOT				
65	A(except 63C, 76B)		2	C1VZ 14B694-A
66	A(63C, D, 76B, D)		2	
66	S		2or4	
14C694 WIRE ASSY. - SEAT BACK LATCH FEED				
70	B(63, 65, 76)	#D0OB 14C694-B, C	1	D0OZ 14C694-A
70	X		1	
71	B(63, 65, 76)	#D1OB 14C694-AB	1	D1OZ 14C694-A
71	B	Screw (attach wire assy. to seat brace)- No. 8-15 x 1/2"	AR	52012-S(U202)
14695 NUT - SEAT REGULATOR CONTROL SWITCH BEZEL				
65	A(except 63C, 76B)		1	C1VF 14695-A
66	A		1	
66	S		1or2	
69/71	B	4-way bench or bucket seat	1	C6GY 14695-A
65	S	9/16"-24	1or2	B5A 14695-B
65	A(63C, 76B)		1or2	
14B696-7 SWITCH ASSY. - SEAT REGULATOR TILT CONTROL				
65	A (except 63C, 76B)	"Before 3/15/65" R. H.	1	C1VF 14B696-A
		"From 3/15/65" R. H. -not replaced	1	★C5AZ 14B696-A
		"Before 3/15/65" L. H.	1	C1VF 14B697-A
		"From 3/15/65" L. H. -not replaced	1	★C5AZ 14B697-A
66	A(except 63C, D, 76B, D)	R. H. -Chromed button-not replaced	1	★C6AZ 14B696-A
		L. H. -not replaced	1	★C6AZ 14B697-A
66	S	R. H. -not replaced	1or2	★C6VY 14B696-A
66	A(63C, D, 76B, D)	R. H.	1	
66	S	L. H. -not replaced	1or2	★C6VY 14B697-A
66	A(63C, D, 76B, D)	L. H.	1	
14A697 WIRING ASSY. - SEAT REGULATOR SWITCH TO RELAY				
65/66	A(except 63C, D, 76B, D)	With 6 way bench seat -not replaced	1	★C5AZ 14A697-D
67	A(54, 57, 62, 63B, F, J, 71, 76A)	With 6 way bench seat	1	
69/70	B	With 4 way bench or bucket seat	1	C6GY 14A697-B
65	S	Not replaced	1or2	★C4SZ 14A697-A
65	A(57C, 63C, 76B)		1	
66	S	Used with 6 way bucket seat -not replaced	1or2	★C6SZ 14A697-A
66	A(63C, D, 76B, D)		1or2	
71	B	#D1GB 14A697-AA	1	D1GY 14A697-A
65/67	A(except 63C, 65B, 71G, 71H, 75C, 76B)	Clip (wiring to front seat track)	2	★359580-S32
		Clip (wiring to frt. seat cushion frame frt. cross member)	AR	372046-S100 (GG186)
		Clip	1	356628-S(GG175)
		Clip (wiring to front floor pan)	AR	★354188-S32
		Clip (wiring to front seat adjusting regulator)	1	★354473-S2
65/67	A(63, 65B, 71G, 71H, 75C, 76B)	Clip (wiring to front seat track)	1	372047-S100 (GG217)
65/67	A(63C, 65B, 71G, 71H, 75C, 76B)	Clip (wiring to front seat track)	2	★375644-S100
65/67	A(63C, 65B, 71G, 71H, 75C, 76B)	Clip (wiring to seat track)	1or2	356628-S(GG175)
65/67	A(63C, 65B, 71G, 71H, 75C, 76B)	Clip (wiring with nut that attaches motor to seat track)	1or2	
14A698 WIRING ASSY. - SEAT REGULATOR RELAY FEED - Unless listed improvise from Basic 14296 wire				
67	A(54C, 57F, 63J)	Used with split bench seat #C7MB 14A698-C	1	★C7AZ 14A698-A
67/68	A(63C, 76B) -with power reclining seat	Used with 6 way bucket seat #C8MB 14A698-B	1	Not replaced
68	A	Used with 6 way bench seat-cut from 14296 wire	1	★
69	A	Used with bench seat-#C9AB 14A698-B, C	1	C9AZ 14A698-B
70	A	#D0AB 14A698-A, B	1	D0AZ 14A698-A
71/	A -6 way split bench seat	#D1AB 14A698-AA	1	D1AZ 14A698-A
71	A -6 way bench seat	#D1MY 14A698-AA	1	D1MY 14A698-A

Identification marking

May, 1975

◆ When used on units with Power Windows change open end terminal to bullet type

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A698 WIRING ASSY. - SEAT REGULATOR RELAY FEED - continued				
71	B	#D1GB 14A698-AA	1	D1GY 14A698-A
72	B(exc.97)-with 6 way bench seat	#D2OB 14A698-AA	1	D2OZ 14A698-A
67	S-with power reclining seat	Not replaced	1	★C7SZ 14A698-A
70	A	Strap (Nylon)-attach wiring to cowl panel	AR	383313-S(YY6)
71	A	Clip-attach wiring to seat frame	2	382239-S(GG285)
70/71	B	Strap (attach wiring to front floor)	AR	376914-S(YY2)
14A699 WIRE - SEAT CONTROL FEED - JUMPER				
69	S	L.H.-drivers 6 way bench or 6 way bucket seat-#C9SB 14A699-B or C	1	★C9SZ 14A699-C Not replaced
70/71	S(57)-6 way bucket seat and split bench seat-passenger side	#D0LB 14A699-H, D1SB 14A699-BA	1	D0LY 14A699-B
70/71	S-6 way bench seat-bucket and split bench seat-drivers side	#D0SB 14A699-E, D1SB 14A699-AA	1	D0SZ 14A699-B
69/71	S	Strap (attach wiring to floor crossmember)	AR	376914-S(YY2)
69/70	S	Screw (attach wiring to floor crossmember)-No.8-15 x 1/2"	AR	52012-S(U202)
14A700 SOLENOID ASSY. - SEAT REGULATOR CONTROL				
69/70	B	4 way bench or bucket seat	2	C6GY 14A700-A
68/69	S	Located on passenger reclining seat back actuator	1	C7VY 14A700-A
70/	A, B, F, S	Automatic seat back solenoid-refer to body Group #62690		
68	S	Roll pin-3/32" x 1/2"	1	354494-S(NN88)
		Screw-No. 10-32 x 1/2"	1	370050-S(BB537)
		Nut-No. 10-32 (attach solenoid to seat back actuator)	1	34079-S(M163)
14A701 SWITCH - SEAT REGULATOR CONTROL				
65	A(except 63C, 76B)	Center switch-6 way bench seat	1	C5AZ 14A701-B
66	A(54, 57, 62, 71, 63B, F, 76A)	Center switch-6 way bench seat	1	
65	A(except 63C, 76B)	6 way bench power seat	1	C6SZ 14A701-A
66	A(63C, D, 76B, D)	6 way power seat	1	
66	S	L.H. power seat	1	
66	S	R.H. power seat-not replaced	1	★C6VY 14A701-A
66	A(54, 57, 62, 63B, 71, 76A)	Center switch-6 way bench	1	C6AZ 14A701-A
67/70	A(54, 57, 63, 76)	L.H.-6 way split bench seat-includes 3 switches and housing and wiring	1	★C7MY 14A701-A r/b (1) C7MY 14A701-F
67/70	A(54, 57, 62, 63, 71, 76)	L.H.-6 way bench seat	1	&(1) C7MY 14716-B
67/	A	L.H.-6 way split bench seat-includes 3 switches and housing-less wiring	1	C7MY 14A701-F
67/	A	L.H.-6 way bench seat	1	
67/71	A(57, 63)	R.H.-6 way split bench seat	1	
67/71	A(63, 76)	L.H.-6 way bucket seat	1	
67/69	S	L.H.-6 way bench or bucket seat	1	
68	A(63, 76)	L.H.-6 way bucket seat-includes 3 switches and housing-less wiring	1 or 2	C7MY 14A701-E
72	B	L.H.-6 way power bench seat	1	
67/69	A57F, 63J	R.H.-used with split bench seat -includes 3 switches, housing and wiring	1	★C7MY 14A701-C r/b (1) C7MY 14A701-F &(1) C7MY 14716-A
67/68	A(63C, 76B)-with power reclining seat	R.H.-passenger seat	1	C7AZ 14A701-A
67/71	S-with power reclining seat	R.H.-seat back control	1	
67	A(63C, 76B), S	L.H.-drivers seat-used with 6 way bucket seat-includes 3 switches, housing and wiring	1	★C7SZ 14A701-A r/b (1) C7MY 14A701-F
68	S	L.H.-drivers seat-used with 6 way bench or bucket seats	1	&(1) C7SZ 14716-A
69/70	A	L.H.-drivers seat-6 way full or split bench seat	1	
68	A(63C, 76B)	L.H.-6 way bucket seat-includes 3 switches, housing and wiring	1	★C7MY 14A701-B r/b (1) C7MY 14A701-F
69/71	B	4 way bench or bucket seat	1	C6GY 14A701-A

Identification marking

FORD CAR PARTS

SECTION 14S

25

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14A701 SWITCH - SEAT REGULATOR CONTROL - continued				
72	S	R.H. & L.H. -6 way power seat contains 3 switches less wiring	2	D2LY 14A701-A
69	A	Strap-adjustable (attach wiring to seat track)	1	383313-S(YY6)
65	S	R. H.	1	C4SZ 14A701-A
65	A(57C, 63C, 76B)	L. H.	1	C4SZ 14A701-B
69	S	"Before 10/10/68" L.H.-drivers seat-6 way bench or bucket seat	1	★C8LY 14A701-C r/b (1) C7MY 14A701-E & (1) C8LY 14716-C
69	S	"From 10/10/68" 6 way power seat-#C9LB 14B711-B	1	C9LY 14A701-B
70/	S-6 way seat	R.H. & L.H. -#D0VB 14B723-D, D1VB 14B723-BA (3) switches and wiring	2	D0VY 14A701-B
		Refer to Group 14716 for wiring assemblies		
65/	S	Lockwasher-No. 10	2	34903-S8(X96)
		Clip (wiring with screw that attaches cushion to seat track)	1or2	372047-S100 (GG217)
68	S	Screw (switch to shield)-No. 8-18 x 1"	2	52445-S13(U317)
71	F	Screw (attach switch to seat)	2	
70	S	Strap (attach wiring and switch to front crossmember)	1	376914-S(YY2)
70/	A	Screw (attach 14A701 to front seat side shield)-No. 8-18 x 1 1/2"	AR	376290-S(UU56D)
70/	S	Screw (attach 14A701 to front seat side shield)-No. 8-32 x 1/2"	AR	51764-S(U366)
14A705 BRACKET - SEAT REGULATOR CONTROL MOUNTING - Also refer to Group 14B691				
69/	B	4 way bench or bucket seat-not replaced	1	★C6GY 14A705-A
69/	B	Screw (attach bracket to seat cushion frame)-No. 8-18 x 1/2"	AR	52012-S(U202)
14A707 RELAY ASSY. - SEAT REGULATOR CONTROL - Also refer to Group 14512				
65	A(except 63C, 76B)	Center	1	C5AZ 14A707-A
66	A	Center	1	
66	S	Center	1	
69/71	B	4 way bench or bucket seat	1	
65	A(except 63C, 76B)	L. H.	1	C5AZ 14A707-B
66	A	L. H.	1	
66	S	L. H.	1	
69/71	B	4 way bench or bucket seat	1	
65	A(except 63C, 76B)	R. H.	1	C4VY 14A707-A
66	A	R. H.	1	
66	S	R. H.	1	
65/66	A	Screw (relay to seat track)-No. 10-24 x 3/8"	2	51765-S8(U370)
14B710 WIRE ASSY. - SEAT REGULATOR RELAY FEED EXTENSION				
65/66	S	65.00" long-cut from B6A 14296-B wire and cover with 5/32" I. D. -non-metallic conduit	1	★C5SB 14B710-A
67/68	S	Used with 6 way bucket seat-34.00" long-cut from B6A 14296-B wire & insulate with 3/16" I. D. -non-metallic conduit	1	★C7SB 14B710-A
14711 KNOB - SEAT REGULATOR CONTROL SWITCH				
65	A(except 63C, 76B)		2	C1VF 14711-A
66	S		2or4	
66	A(63C, D, 76B, D)		2	
14716 WIRE ASSY. - SEAT REGULATOR FEED				
67/70	A	R. H. -6 way split bench	1	C7MY 14716-A
71/72	A	"Before 6/1/72" L.H.-bench seat or split bench seat	AR	D1AZ 14716-B
72	A	"From 6/1/72" L.H.-bench or split bench seat-#D2AB 14716-AA	1	D2AZ 14716-A
67/70	A	L. H. -6 way split bench	1	C7MY 14716-B
		L. H. -6 way bench seat	1	

Identification marking

May, 1975

COPYRIGHT © 1975 —

FORD MOTOR
COMPANY

— DEARBORN, MICHIGAN

FINAL ISSUE

YEAR	MODEL	DESCRIPTION	QTY.	PART NUMBER
14716 WIRE ASSY. - SEAT REGULATOR FEED - continued				
67	A(63, 76)	L.H. -6 way bucket seat	1	C7SZ 14716-A
67/68	S	L.H. -6 way bench or bucket seat	1	
69/70	A	L.H. -6 way bench or split bench seat	1	
72	B	"Before 6/1/72" Feed #D2OB 14716-AA	1	D2OZ 14716-A
72	B	"From 6/1/72" Feed #D2OB 14716-BA	1	D2OZ 14716-B
69	S	L.H. -drivers seat-6 way bench or bucket seat	1	C8LY 14716-C
69	S	R.H. -6 way split power seat	1	C9LY 14716-D
69	S	L.H. -6 way split power seat	1	C9LY 14716-C
70/71	S(65C, D)-6 way bucket, split bench, solid bench seat with auto/seat back latch-drivers side	#D0SB 14716-A, D1SB 14716-AA	1	D0SZ 14716-A
70/71	S(57, 65A, B)-6 way bucket, split bench seat with auto/seat back latch-passenger side	#D0SB 14716-B, D1SB 14716-BA	1	D0SZ 14716-B
72	S-6 way power seat	Refer to 14630-1		
		Nut (wire to circuit breaker and brkt.)-No. 10-32	1	34079-S7(M163)
		Lockwasher - No. 10	1	34903-S8(X96)
		Grommet (wire thru dash panel)	1	353626-S(KK1)
14A720 SOLENOID ASSY. - REGULATOR CONTROL - Also refer to Body Group Basic 61925				
65/66	A(except 63C, 76B)		1	C5AZ 14A720-A (SW-785)
65/66	S		2or4	C1TZ 14A720-A
65/66	A(57C, 63C, 65B, 76B)		2	
14B720 WIRE ASSY. - SEAT BACK CONTROL EXTENSION				
67	A(63C, 76B)-with power reclining seat		1	C7AZ 14B720-C
67/69	S-with power reclining seat		1	
14B724 WIRE ASSY. - AUTOMATIC SEAT BACK LATCH				
70	A(63, 65, 76)	#D0AB 14B724-B, C, D	1	D0AZ 14B724-A
70	B(63, 65, 76), X	#D0OB 14B724-A	1	D0OZ 14B724-A
70	F(63, 65, 76)	#D0ZB 14B724-A, B	1	D0ZZ 14B724-B
70/71	S(65)	#D0SB 14B724-B, D1SB 14B724-AA	1	D0SZ 14B724-A
71/	A(65, 76)	#D1AB 14B724-AA	1	D1AZ 14B724-A
71	B(63, 65, 76)	#D1OB 14B724-AB	1	D1OZ 14B724-A
71/72	F	"Before 12/1/71" #D1ZB 14B724-AB	1	D1ZZ 14B724-A
72	F	"From 12/1/71" R.H. - #D2ZB 14B724-AA	1	D2ZZ 14B724-A
		L.H. - #D2ZB 14B724-AC, AD	1	D2ZZ 14B724-B
72	S	#D2SB 14B724-AA, AB, AC	1	D2SZ 14B724-B
71/	A	Clip-attach wire to cowl panel	2	383182-S(GG359)
71/	A	Clip-attach wire to front cross member	3	378674-S(GG150H)
14A725 JUNCTION BLOCK ASSY. - ACCESSORY TERMINAL - Also refer to Groups 11A647 & 14448				
65/66	A	Not required on units built after 12/13/65	1	C5AZ 14A725-A
14785 WIRE ASSY. - IGNITION SWITCH TO WINDOW REGULATOR SAFETY SWITCH-Improvise from B6A 14296-C				
14790 WIRING ASSY. - DOOR OPEN WARNING LAMP-Unless listed-improvise from B6A 14296-C Wire				
69	A-with safety convenience package	Without power windows-#C9AB 14790-E	1	C9AZ 14790-A
70	A-with safety convenience package	#D0AB 14790-C	1	D0AZ 14790-A
69/70	A(54 Taxi)	R.H. & L.H.-front-cut from B6A 14296-C wire	1	*C9AB 14790-D
71	A(54 Taxi)	R.H. & L.H.-front-cut from B6A 14296-C wire	1	*D1AB 14790-AA
72	B(53)(taxi)	R.H. & L.H.-rear door 130" long	2	D2OZ 14790-A
72	B(53)(taxi)	R.H.-front door	1	D2OZ 14790-B
		L.H.-front door	1	D2OZ 14790-C
70/	A, Taxi	Clip (attach door open warning lamp & wiring to inner cowl panel)	AR	383182-S(GG359)
70	A	Screw 1/4-14 x 1/2"(attach wiring to brake pedal support)	AR	55981-S(U254E)
70	A	Screw (attach wiring to cowl panel)-No.8-15 x 1/2"	5	52012-S(U202)
70/71	A	Clip-attach wiring to rear door inside support	4	382185-S(GG283)
14931 EXTERIOR LAMP WARNING BUZZER KIT				
65/70	A, B, F, P, S, U, X	Consists of: 1-C9PJ 13150-A Buzzer 1-52735-S Screw 1-C9PJ 14487-A Connector 1-I.S. -3429	1	C6AZ 14931-C

Identification marking