Pearlz Installation Guide — AquaPearl Series

Document ID: GUIDE-INST-2026.1 | Version 2026.1

1. Pre-installation checklist

Confirm inlet water pressure is between 0.1 and 0.4 MPa. Confirm a grounded socket matching the supplied adapter region. Allow 10 cm clearance on all sides for ventilation. Verify cold-water feed only — never connect to a hot-water line. Have a bucket and towels ready for the flush.

2. Tools required

- Adjustable wrench
- PTFE thread tape
- Phillips screwdriver
- Bucket and absorbent towels
- Spirit level (for wall-mount)

3. Wall-mount installation steps

1. Mark mounting holes using the template. 2. Drill and insert wall plugs rated for 15 kg. 3. Hang the unit and verify level. 4. Connect inlet tubing with PTFE tape on threaded joints. 5. Connect drain and purified outlet. 6. Plug in power only after leak-check of dry joints.

4. Under-sink installation steps

1. Shut off the cold-water angle valve. 2. Install the feed adaptor. 3. Route tubing without kinks. 4. Place the unit on a stable flat base inside the cabinet. 5. Restore water and inspect for drips for ten minutes before leaving the site.

5. First-run flushing procedure (required)

After installing new filters or a new unit, you must flush before drinking. Why: carbon fines and membrane preservatives can cause a strange or chalky taste and cloudy water. Procedure: (1) Open the inlet and power on. (2) Fill the tank completely. (3) Dispense and discard the entire first tank. (4) Fill again and discard the second tank. (5) The third tank is ready for use. If taste remains odd, repeat one additional flush cycle. This procedure is the correct response when customers report weird taste immediately after a filter change.

6. Professional installation

Professional installation by a Pearlz Authorised Service Partner can be booked for PKR 2,500 in metro areas (Karachi, Lahore, Islamabad). Secondary-city rates are quoted on request. SKU INST-PROF-METRO on the Pricing Guide.

7. What voids warranty during self-installation

Connecting to hot water, exceeding inlet pressure without a reducer, using non-Pearlz adapters that crack fittings, or applying sealant inside electrical compartments voids warranty for the damaged subsystems. Follow this guide carefully. When unsure, book professional installation.

8. Leak check protocol

After pressurising, dry all joints with a paper towel and watch for wicking moisture for ten minutes. Any drip requires shut-off and re-seating of the fitting before use.

9. Electrical notes

Use a surge-protected socket where possible. Do not share the circuit with high-draw kitchen heaters if nuisance trips occur.

10. Post-install customer briefing

Show the customer the RESET and PAIR buttons, explain filter intervals, and leave the quick-start card visible. Remind them that filters are consumables and not covered by warranty.