Lab 7 - Interrupt programming


Objectives

- To learn to use PIC18F4550 microcontroller's INTO external hardware interrupt & TimerO interrupt.
- To learn to the sequence of code execution in an interrupt event.

Introduction / Briefing

What is interrupt?

- A microcontroller can use the interrupt method to respond to an event.
- In this method, when a peripheral (e.g. an I/O pin or a timer) needs something to be done, it notifies the micro-controller, which stops whatever it is doing and "serves" the peripheral. After that, the micro-controller goes back to continue what it was doing.
- As an analogy, you could be reading newspaper. When there is a buzz tone on your hand phone, you are "interrupted" - you stop reading and reply an SMS. After that, you continue reading your newspaper where you left off.
- The program associated with the interrupt is aptly called the interrupt service routine or ISR.
- In this experiment, you will learn the basics of interrupt, focusing on INTO external hardware interrupt and TimerO interrupt, (though there are many other interrupt sources in the PIC).




Lab 7 - Interrupt programming

1 of 14

Otherwise, another interrupt will occur after returning to Main, even if there is no new interrupt signal.

Sequence of code execution

☐ The diagram below shows the sequence of code execution in an interrupt event:



- After interrupt has been set up, the while loop in the main function is executed over and over again (1, 2...).
- Let's say an interrupt event occurs when statement_a is being executed (3).
- The microcontroller will complete the execution of this statement. Then it goes to a specific location (*) called the interrupt vector to look for the ISR (interrupt service routine).
- Usually a single GOTO instruction can be found at the interrupt vector (4). This causes a branch to the ISR.
- \square In the ISR, the codes to handle the interrupt get executed (5).
- After that, the microcontroller returns to the main function to continue with statement_b (6), and the while loop gets executed over and over again (7...).
- (*) In the lab, a "boot-loader" is used in the PIC18F4550. This program downloads a user program from a PC via the USB port. The "boot-loader" changes the high and low-priority interrupt-vectors to 0x000808 and 0x000818, respectively.

The PIC18F4550 has 3 external hardware interrupts: INTO, INT1 and INT2
which use pins RBO, RB1 and RB2 respectively. We will discuss INTO (and
INT1 and INT2 are similar in terms of operation).

☐ The INTO interrupt responds to a change of voltage i.e. a transition at RBO.

Acts as the main switch

for all interrupt sources

Act as individual switch for INTO (at pin RBO)

To enable the <u>INTO</u> interrupt, set both the <u>GIE</u> (Global Interrupt Enable) and the <u>INTO</u>IE (<u>INTO</u> Interrupt Enable) bits in the INTCON register.

INTCON (Interrupt Control Register)

GIE		INTOIE		INTOIF	
1		1			

Q1. Give the C-code to enable the INTO interrupt.

This bit (Interrupt Flag) will become 1 if INTO interrupt has occurred.

The INTEDGO bit of the INTCON2 register is used to specify whether interrupt is to occur on a falling (i.e. a high to low transition) or a rising (i.e. a low to high transition) edge at RBO:

INTCON2 (Interrupt Control Register 2)

	INTEDGO						
	0						
NGT							

INTEDGO = 0: INTO interrupt on falling edge at RBO

INTEDGO = 1: INTO interrupt on rising edge at RBO (power-on reset default)

PĞT _

Q2. Give the C-code to select falling edge triggering.

INTCON2bits.<u>///TEDG0</u>=_0___;

Note that falling edge triggering has been chosen because on the microcontroller board, the push button switch at RBO has been connected as "active low".

When interrupt has been enabled and there is a falling edge at RBO, the flag INTOIF (external hardware INTerrupt 0 Interrupt Flag) in the INTCON register will be set. To clear this flag, so that future interrupt can be noticed, use the code INTCONbits.INTOIF = 0; With these, you should be able to understand the code in Int_INTO.c. Interrupt priority (D.I.Y.) By default, all interrupts are "high priority". It is also possible to make some interrupts "high priority" and others "low priority". This is done by setting the IPEN (Interrupt Priority ENable) bit in the RCON register. When interrupt priority is enabled, we must classify each interrupt source as high priority or low priority. This is done by putting 0 (for low priority) or 1 (for high priority) in the IP (interrupt priority) bit of each interrupt source. The IP bits for the different interrupt sources are spread across several registers - INTCON, INTCON2, INTCON3, IPR1 and IPR2. We will not go into the details of all these. A higher priority interrupt can interrupt a low priority interrupt but NOT vice-versa.

TimerO interrupt

Polling method □ Disadvantage: Spend most of the time waiting.

In the last experiment, you used TimerO to introduce a delay of 1 second. The C code was:

TMROIF == 0 2

T0CON=0b00000111; // Off Timer0, 16-bits mode, Fosc/4, prescaler to 256

TMR0H=0X48; // Starting count value

INTCONbits.TMR0IF=0; // Clear flag first

T0CONbits.TMR0ON=1; // Turn on Timer 0

while(INTCONbits.TMR0IF==0); // Wait for time is up when TMR0IF=1 T0CONbits.TMR0ON=0; // Turn off Timer 0 to stop counting

First, TimerO is configured but turned OFF. Then, the starting count value is written to TMROH, followed by TMROL. Next, the flag is cleared and TimerO turned ON. After that, the while loop is used to wait for 1 second to elapse i.e. for the TMROIF interrupt flag to be set. Finally, TimerO is turned OFF.

☐ Instead of "polling" for the timer overflow (from FFFF to 0000) using while (INTCONbits.TMR0IF == 0);

the "interrupt" method can be used. The advantages of the interrupt method over the polling method are discussed in the lecture.

- ☐ The TimerO interrupt responds to TimerO overflow.
- To enable the TimerO interrupt, set both the GIE (Global Interrupt Enable) and the TimerOIE (TimerO Interrupt Enable) bits in the INTCON register.

INTCON (Interrupt Control Register)

GIE	TMROIE		TMROIF	
1	1			

Q3. Give the C-code to enable the TimerO interrupt.

- When interrupt has been enabled and there is a TimerO overflow, the flag TimerOIF (TiMeRO overflow Interrupt Flag) in the INTCON register will be set. To clear this flag, so that future interrupt can be noticed, use the code INTCONbits.TMROIF = 0;
- ☐ With these, you should be able to understand the TimerO Interrupt code outlined as follows. (This is similar to, but not exactly the same as, the Int_TMRO.c used in the experiment.)

