


Wireless Technology Applications

Wireless Local Area Network Technology Part I

Melvyn U Myint Oo T16620 68790688 melvyn_oo@sp.edu.sg





At the end of this lecture, you should be able to:

Explain WLAN technology

- 1. Architecture
- Different Implementations of IEEE802.11a/b/g Standard
- 3. Explain the radio frequencies used in WLAN
- 4. Explain the physical layers (DSSS and OFDM) used in WLAN



Wireless LAN

- Wireless LAN or IEEE
 802.11 is the most
 successful wireless local
 area network technology
- Implements only the first2 OSI layers
 - Physical
 - Data link








What does this means?

 Other OSI layers are still needed to fully understand computer networking





Example 3-1

Why does IEEE802.11 specify only Physical and Data Link layers only?

- IEEE802.11 changes the physical connection from wires to wireless.
- With the change in physical connection, the mechanism to allow multiple devices sharing the same wireless medium is also different from the mechanism used in wired networks. Therefore, the Data Link layer is also different.



Two Modes of Operation

Ad-hoc

 direct connection between STAs (Stations) for accessing each other information and services

Infrastructure

 connection to an Access Point for accessing the computer network (Intranet and Internet)



What's the basic building block?






Basic Service Set (BSS)



The BSS is known as Independent BSS (or IBSS) and the mode of operation is ad-hoc

STAs in the same BSS can communicate with one another, but not across BSS





What is an STA?





What is an STA?






What is an STA?



Official (Open), Non-sensitive








What is an AP?





In short...

- STAs that can communicate with each other forms a BSS
- Two Modes of operation
 - If no AP ad-hoc mode (Independent BSS)
 - If AP Infrastructure mode
- Multiple BSS connected through a DS - ESS







- To interconnect multiple BSSs to form Extended Service Set (ESS), a Distribution System (DS) is needed
- A DS provides logical services necessary to handle address to destination mapping and seamless integration of multiple BSSs







- Four different configurations of ESS
 - Partially overlap BSSs
 - Physically disjointed
 - Physically co-located
 - Co-existence of IBSS or ESS networks











Official (Open), Non-sensitive





- Four different configurations of ESS
 - Partially overlap BSSs
 - Physically disjointed
 - Physically co-located
 - Co-existence of IBSS or ESS networks






- Four different configurations of ESS
 - Partially overlap BSSs
 - Physically disjointed
 - Physically co-located
 - Co-existence of IBSS or ESS networks






- Four different configurations of ESS
 - Partially overlap BSSs
 - Physically disjointed
 - Physically co-located
 - Co-existence of IBSS or ESS networks






- Four different configurations of ESS
 - Partially overlap BSSs
 - Physically disjointed
 - Physically co-located
 - Co-existence of IBSS or ESS networks





Portal





Example 3-2

In a hotspot in Starbucks, a user can access Internet through either SingNet or StarHub systems. Which of the four configurations above is used to explain this scenario?


 Fourth configuration where one or more IBSS or ESS networks may be physically present in the same space as one or more ESS networks.



Example 3-3

Wireless networks are inherently less secure than wired networks. Where is the best place to install firewall to filter unauthorized users from accessing sensitive information located in Intranet?


Portal





3 main flavours in 802.11

802.11a



802.11g

Toppings

- Nuts
- Chocolate chips
- Fudge
- ..



Different Implementations

Standard	Multiple Assess Protocol	Frequency	Modulation	Bit rate
IEEE 802.11a	OFDM	5.2 GHz UNII 5.8 GHz ISM	BPSK, QPSK, 16 QAM, 64 QAM	6, 9, 12, 18, 24, 36, 48, 54 Mbps
IEEE 802.11b	DSSS, FHSS	2.4 GHz ISM	DBPSK, DQPSK, CCK	1, 2, 5.5, 11 Mbps
IEEE 802.11g	OFDM	2.4 GHz ISM	BPSK, QPSK, 16QAM, 64QAM	6, 9, 12, 18, 24, 36, 48, 54 Mbps
IEEE 802.11n	OFDM/MIMO	2.4 GHz ISM, 5 GHz (Optional)	BPSK, QPSK, 16QAM, 64QAM	600 Mbps (Max)
IEEE 802.11ac	OFDM/MU-MIMO	5.2 GHz UNII 5.8 GHz ISM	BPSK, QPSK, 16QAM, 64QAM, 256QAM	1.3 Gbps (Max)

Note: ISM → Industrial Science and Medical

UNII → Unlicensed National Information Infrastructure Note: BPSK → Binary Phase Shifting

OFDM → Orthogonal Frequency Division Multiplexing QPSK → Quadrature Phase Shift Keying

DSSS → Direct Sequence Spread Spectrum

FHSS → Frequency Hopping Spread Spectrum

MIMO → Multiple Input Multiple Output

MU-MIMO → Multi User MIMO

Official (Open), Non-sensitive

QAM

Quadrature Amplitude Shift Keying

CCK → Complementary Code Keying




Example 3-4

- Example 3.4
- Which of the following standards IEEE802.11a/b/g has the best features?
- IEEE802.11g has the best features since it has the highest bit rate (similar to IEEE802.11a) and also largest coverage areas (similar to IEEE802.11b).



IEEE 802.11b - DSSS

- Direct Sequence Spread Spectrum
- 1 bit of info is represented by a sequence of bits (chips)
 E.g. 1 "1 0 0 1", 0 "0 1 1 0"
- Chip rate number of chips per sec, is maintained at 11Mcps
- Bandwidth is 22MHz




Official (Open), Non-sensitive



IEEE 802.11 - bit rate

- Different bit rates supported
 - 1 Mbps, 2 Mbps, 5.5 Mbps, 11
 Mbps
- Depends on wireless environment
 - Better signal received, higher bit rate
- How does bit rate change?
 - By using different modulation, symbol rate



Toppings

- Nuts
- Chocolate chips
- Fudge
- ..



How 802.11b increases bit rate?

1 Mbps

- Modulation = DBPSK
 - ⇒ 1 bits/symbol
- Symbol rate = 1 Msymbols/sec (i.e. 1 Mbaud)
 Therefore, bit rate = 1 Mbaud x 1 bits/symbol
 = 1 Mbps

2 Mbps

- Modulation = DQPSK
 - ⇒ 2 bits/symbol
- Symbol rate = 1 Mbaud
 Therefore, bit rate = 1 Mbaud x 2 bits/symbol
 = 2 Mbps



How 802.11b increases bit rate?

5.5 Mbps

- Modulation = 2-DQPSK
 - \Rightarrow 2 bits/symbol x 2 bits/sequence
- Symbol rate = 1.375 Mbaud

Therefore, bit rate = 1.375 Mbaud x 2 bits/symbol x 2 bits/sequence

= 5.5 Mbps

11 Mbps

- Modulation = 4-DQPSK
 - \Rightarrow 2 bits/symbol x 4 bits/sequence
- Symbol rate = 1.375 Mbaud

Therefore, bit rate = 1.375 Mbaud x 2 bits/symbol x 4 bits/sequence

= 11 Mbps



802.11b - Chip rate

- Chip rate is 11 Mcps regardless of bitrates
- 1 Mbps
 - Chip rate = 1 Mbaud x 11 chips/symbol = 11 Mcps
- 2 Mbps
 - Chip rate = 1 Mbaud x 11 chips/symbol = 11 Mcps
- 5.5 Mbps
 - Chip rate = 1.375 Mbaud x 8 chips/symbol = 11 Mcps
- 11 Mbps
 - Chip rate = 1.375 Mbaud x 8 chips/symbol = 11 Mcps



But more importantly...

How to answer question in MST or exams?





What you need to know


- Chip rate = X Mbaud x Y chips/symbol = 11 Mcps
- For 1 Mbps and 2 Mbps
 - Bit rate = X Mbaud x a bits/symbol
 - 1 Mbps uses DBPSK, where a = 1
 - 2 Mbps uses DQPSK, where a = 2
- For 5.5 Mbps and 11 Mbps
 - Bit rate = X Mbaud x a bits/symbol x b bits/sequence
 - 5.5 Mbps uses 2-DQPSK, where a = 2 and b = 2
 - 11 Mbps uses 4-DQPSK, where a = 2 and b = 4

So you can easily find X and Y



IEEE 802.11b - Channels

14 frequency channels with 5 MHz apart



- 4 non-overlapping frequency channels 1, 6, 11, 14
- Only Japan uses channel 14
- Everywhere else, non-overlapping channels are 1, 6 and 11



3 main flavours in 802.11

802.11a

802.11b

Official (Open), Non-sensitive

802.11g




Toppings

- Nuts
- Chocolate chips
- Fudge
- ..



3 main flavours in 802.11




Official (Open), Non-sensitive



802.11a - OFDM

- Orthogonal Frequency Division Multiplexing
- Main protocol in 802.11a
- Each user allocated multiple sub-carriers and data is transmitted independently over these subcarriers
- The peak of any sub-carriers correspond to the null of other sub-carriers, resulting in no interference between sub-carriers



Official (Open), Non-sensitive



802.11a

Total number of subcarriers = 52




- Once again, we're interested in how to get different bit rates
- This time, there are 6 9, 12 18, 24 36, 48, 54 Mbps possible bit rates

Compulsory to be supported



How to get the bit rates?





Example

What is the bit rate for IEEE 802.11a if the modulation is QPSK and convolutional coding rate is

$$\frac{3}{4}$$

- 18 Mbps
- 9 Mbps
- 6 Mbps
- 24 Mbps



Rate	Mod	R	NBPSC	NCBPS	NDBPS
6	BPSK	1/2	1	48	24
9		3/4	1	48	36
12	QPSK	1/2	2	96	48
18		3/4	2	96	72
24	16-QAM	1/2	4	192	96
36		3/4	4	192	144
48	64-QAM	(2/3)	6	288	192
54		3/4	6	288	216



- Bit rate computation for BPSK, ½-coding rate
- Using BPSK, (M= 2) Number of Bits per Sub-Carrier (NBPSC) = 1 bit
- With 48 sub-carriers, Number of Coded Bits per OFDM Symbol (NCBPS) =1 bit x 48 = 48 bits
- With ½-coding rate (R),
- Number of Data Bits per OFDM Symbol (NDBPS) = 48 bits $\times \frac{1}{2}$ = 24 bits
- With symbol rate of 0.25 Mbaud,
- Rate_b= 24 bits \times 0.25 \times 10⁶ = 6 Mbps
- Rate_b = $0.25xRx48xlog_2M$ = $0.25x(\frac{1}{2})x48xlog_2(2) = 6$ Mbps

where R = Coding Rate
M = the order of modulation
0.25 (Mbaud) = symbol rate
48 = no. of data channels

Rate	Mod	R	NBPSC	NCBPS	NDBPS
6	BPSK	1/2	1	48	24
9		3/4	1	48	36



Example 3.6

What is the bit rate if the modulation technique is 64-QAM (M = 64) and the convolutional coding is (3/4)?


- 64-QAM means six bits per symbol (2⁶ = 64).
- With 48 data channels, the coded bits per OFDM Symbol is 48 x 6 = 288.
- Then, data bits per OFDM Symbol is 288 x (3/4) = 216. Finally, the bit rate is 0.25 * 216 = 54.
- Rate_b = $0.25 \times R \times 48 \times \log_2 M$ = $0.25 \times (3/4) \times 48 \times \log_2 64 = 54 \text{ Mbps}$

Rate	Mod	R	NBPSC	NCBPS	NDBPS
48	64-QAM	1/2	6	288	192
54		3/4	6	288	216



IEEE 802.11a - Channels

Just like in 802.11b



So, how many channels are there? How many are non-overlapping?



3 main flavours in 802.11

802.11a 802.11g 802.11b **Toppings** Nuts Chocolate chips Fudge

Official (Open), Non-sensitive



Why is there a need for 802.11g

Compare IEEE 802.11b and IEEE 802.11a





Better coverage – due to 2.4 GHz frequency

Better protocol Higher bit rate Better error correction



Why is there a need for 802.11g

IEEE 802.11g marries both advantages



Better coverage – due to 2.4 GHz frequency

Better protocol
Higher bit rate
Better error correction



Summary

- WLAN Architecture
- 2. Explain the differences between different WLAN standards (IEEE 802.11 a/b/g)
- 3. Explain the radio frequencies used in WLAN
- Explain the physical layers (DSSS and OFDM) used in WLAN