
With the last assignment, you explored two simple nonlinear systems. You solved Problem 1-1 using displacement control (in its most primitive), and Problem 1-2 using incremental load control (prescribing the load level).

This week, you'll be exploring path following techniques for tracking equilibrium paths beyond a snap-through¹ or a snap-back² point.

Problem 2-1: Displacement control for a two-degrees-of-freedom (2 DOF) problem



This problem expands Problem 1-2 from Assignment #1 such that you shall track the entire equilibrium path from (u = 0, v = 0) and $\lambda = 0$ at least through $\lambda \ge 2.0$.

1. Using Henky strain, a linear relation $\sigma = E\varepsilon$, A = const., and equilibrium on the deformed system, derive the relationship between displacements and forces on the free node. Adjust it for path following as

$$\mathbf{R}(\gamma, \mathbf{u}) = \gamma \bar{\mathbf{P}} - \mathbf{F}(\mathbf{u}(s)) = \mathbf{0}$$
(1a)

with reference load, $\bar{\mathbf{P}} = -(0.99 \text{ kN}) \mathbf{j}$, load intensity factor γ and displacement \mathbf{u} .

Find the tangents $\partial \mathbf{R}/\partial \gamma$ and $\partial \mathbf{R}/\partial \mathbf{u}$ as you will need them in what follows.

You should have all the necessary parts for this question from Assignment #1.

2. Develop a, or adjust your existing Newton method to incrementally find γ and \mathbf{u} using displacement control on the vertical displacement, $v = \bar{v}$. The respective constraint equation is

$$g(\mathbf{u}) := \mathbf{e}_v \cdot \mathbf{u} - \bar{v} = 0 \tag{1b}$$

with

$$\Delta \mathbf{u} \Rightarrow \left\{ \begin{array}{c} u \\ v \end{array} \right\} \quad \text{and} \quad \Delta \mathbf{e}_v \Rightarrow \left\{ \begin{array}{c} 0 & 1 \end{array} \right\} \ .$$
 (1c)

- 3. Plot load level γ versus vertical displacement v, as well as γ versus horizontal displacement u for the converged points on the equilibrium path. Observe how only one of them actually looks like the curve you (might have) expected.
- 4. Add a plot u versus v to explore yet another view of the solution path. Try and overlay this curve on a contour plot of $F_x(u,v)$ and on a contour plot for $F_y(u,v)^3$.


¹This is where load control will fail.

²This is where displacement control will fail.

³The first should show that the solution path is hugging the $P_x(u,v) = 0$ contour line. The latter is like a road going through a hilly landscape with elevation along the road being $\lambda(s)\bar{P}$.

Problem 2-2: Going into higher dimensions

Now let's take the problem into the third dimension and look at a 3D-truss system with 6 nodes and 7 truss members as shown.



Only node 5 shall be loaded by a vertical load, $P_5 = \gamma \bar{P}$.

- (a) Adjust your code to accommodate the higher dimensional system. At this point, it is highly advisable to drop the brute-force approach and use appropriate functions or my TrussElement class to represent each system component. Assembly may still be done beforehand, though transitioning to a more generic concept will be helpful for future assignments.
- (b) Use the vertical displacement $v_5 = \bar{v}$ as control parameter and find the equilibrium path using displacement control. Trace the equilibrium path until members 3–6 and 4–6 are in tension.
- (c) Present load-displacement diagrams by plotting the load factor γ against displacement components of nodes 5 and 6.
- (d) Plot the planar view of the equilibrium path for nodes 5 and 6 (can be in one or two plots).