OCTAL PARA HEXADECIMAL			
100 8 001 000 000	77 8 111 111	14 8 001 100	7 8 111
0 0100 0000 0 4 0	11 1111 3 F	00 1100 0 12	
R 40 16	R 3F 16	R C 16	R 7 16
2 8 010 2	50 8 101 000 10 1000 2 8	46 8 100 110 0010 0110 2 6	25 8 010 101 0001 0101 1 5
R 2 16	R 28 16	R 26 16	R 15 16
71 8 111 001 0011 1001 3 9	33 8 011 011 0001 1011 1 B	52 8 101 010 0010 1010 2 A	66 8 110 110 0011 0110 3 6
R 39 16	R 1B 16	R 2A 16	R 36 16
21 8 010 001 0001 0001 1 1	34 8 011 100 0001 1100 1 C	12 8 001 010 0000 1010 A	
R 11 16	R 1C 16	R A 16	