# Illumina DNA Prep Checklist

# Tagment Genomic DNA

$\Box$ 1	Add 2-30 µl DNA to a 96-well PCR plate.	
$\square$ 2	If DNA volume < 30 µl, add nuclease-free	
	water to bring the volume to 30 µl.	
$\square$ 3	Vortex BLT vigorously to resuspend.	
$\Box$ 4	For each sample, combine the following	
	volumes.	
	▶ BLT (11 µl)	
	▶ TB1 (11 μl)	
$\Box$ 5	Vortex the master mix to resuspend.	
□6	Divide the master mix volume into an 8-tube	
	strip.	
$\Box$ 7	Transfer 20 µl to each well containing a	
	sample.	
8	Discard the 8-tube strip.	
9	Pipette 10 times to resuspend.	
□10	Seal the plate, place on the thermal cycler,	
	and run the TAG program.	

# Post Tagmentation Cleanup

□ 1 Add 10 µl TSB.

$\square 2$	Slowly pipette 10 times to resuspend the
	beads.
$\square$ 3	Seal the plate, place on the thermal cycler,
	and run the PTC program.
$\square$ 4	Place the plate on the magnetic stand until
	liquid is clear.
$\square$ 5	Remove and discard supernatant.
$\Box$ 6	Remove from the magnetic stand and 100 µl
	TWB.
$\Box$ 7	Pipette to resuspend or shake at 1600 rpm for
	1 minute
8	Repeat steps 4–7 two times for a total of 3
	washes.
9	Seal the plate and place on the magnetic
	stand until the liquid is clear

# Amplify Tagmented DNA

<b>□</b> 1	For each sample, combine the following
	volumes.
	▶ EPM (22 μl)
	Nuclease-free water (22 µl)
2	Vortex, and then centrifuge at 280 × g for 10
	seconds.
□3	Remove and discard supernatant.
4	Remove from the magnet.
□ 5	Add 40 µl master mix in each sample well.
□ 6	Pipette 10 times or shake at 1600 rpm for 1
	minute.
□ 7	Seal the plate and centrifuge at $280 \times g$ for $3$
	seconds.
8	Add the appropriate index adapters to each
	sample.
9	Pipette 10 times or shake at 1600 rpm for 1
	minute.
□10	Seal the plate, and then centrifuge at $280 \times 000$
	for 30 seconds.
□11	Place on the thermal cycler and run the BLT
	PCR program.

#### SAFE STOPPING POINT

If you are stopping, store at 2°C to 8°C for up to 3 days.

# Illumina DNA Prep Checklist

For Research Use Only. Not for use in diagnostic procedures.

p Libraries
rifuge at 280 × g for 1 minute. on the magnetic stand until the liquid is
fer 45 µl supernatant to a new midi plate. x and invert SPB to resuspend. andard DNA input, perform the following
 Add 40 µl nuclease-free water. Add 45 µl SPB. Pipette 10 times or shake at 1600 rpm for
minute. Seal the plate and incubate for 5 minutes. Place on the magnetic stand until the quid is clear.
Yortex SPB ( <i>undiluted</i> stock tube), and hen add 15 µl to a <i>new</i> midi plate.  Transfer 125 µl supernatant to the new
plate. Pipette 10 times or shake at 1600 rpm for minute.
Discard the first plate.  mall PCR amplicon input, perform the ving steps.  Add 81 µl SPB.  Pipette 10 times or shake at 1600 rpm for minute.
pate at room temperature for 5 minutes. on the magnetic stand until the liquid is
ove and discard supernatant. In two times with 200 µl fresh 80% EtOH. In two times with 200 µl fresh 80% EtOH. In two times with 200 µl fresh 80% EtOH. In the form the magnetic stand.

□16	Incubate at room temperature for 2 minutes.	
□ 17	7 Place the plate on the magnetic stand until	
	liquid is clear.	
□18	Transfer 30 µl supernatant to a new plate.	

#### SAFE STOPPING POINT

If you are stopping, seal the plate with Microseal 'B' adhesive or Microseal 'F' foil seal, and store at -25°C to -15°C for up to 30 days.

### Check Library Quality (Optional)

- □1 Run 1 μl library or pooled libraries on one of the following instruments:
  - Add 1 µl RSB to the library to achieve the 2 µl volume required for Fragment Analyzer.

### Illumina DNA Prep Checklist

### Dilute Libraries to the Starting Concentration

- ☐ 1 Calculate the molarity value of the library or pooled libraries.
- ☐ 2 Using the molarity value, calculate the volumes of RSB and library needed to dilute libraries to the starting concentration.

Sequencing System	Starting Concentration (nM)	Final Loading Concentration (pM)
HiSeq 2500 and HiSeq 2000 (high output modes)	2	12
HiSeq 2500 (rapid run mode)	2	8.5
HiSeq X, HiSeq 4000, and HiSeq 3000	2–3	200-300
iSeq 100	2	200
MiniSeq	2	1.2-1.3
MiSeq (v3 reagents)	4	12
NextSeq 550 and NextSeq 500	2	1.2–1.3
NextSeq 2000	2	750
NovaSeq 6000	2	See document # 1000000019358 (NovaSeq 6000 System Guide)

- Dilute libraries using RSB:
  - Libraries quantified as a multiplexed library pool - Dilute the pool to the starting concentration.

- Libraries quantified individually—Dilute each library to the starting concentration. Add 10 µl each diluted library to a tube.
- ☐ 4 Dilute to the final loading concentration.

### Acronyms

Acronym	Definition
BLB	Blood Lysis Buffer
BLT	Bead Linked Transposome
CD	Combinatorial Dual
EPM	Enhanced PCR Mix
EtOH	Ethanol
IEM	Illumina Experiment Manager
PK1	Proteinase K
RSB	Resuspension Buffer
SPB	Sample Purification Beads
TB1	Tagmentation Buffer 1
TSB	Tagment Stop Buffer
TWB	Tagment Wash Buffer
UD	Unique Dual