
How to Reset the KickSat Boards:

- 1) Connect ground to RESET
- 2) Tap it twice quickly
- 3) If you are doing this quickly, the LED will blink when you tap the reset pin



Reset on Board A:



Reset on Board B

