Slam Brands and Avio products are guaranteed to be free from defect and missing parts.



Please Call First!

IF PARTS ARE MISSING, DO NOT RETURN TO STORE

To order missing or replacement parts, please call

Toll Free: 1 (866) 632-6632 support@slambrands.com

Business Hours: M-F 8am-5pm PST

06.08 A

AXIO TV STAND

COMPATIBLE WITH UNIVERSAL FLAT PANEL BRACKET #222709*

Assembly Instructions Item #220499-03 UPC #8-44892-00002-7



PLEASE READ & KEEP FOR FUTURE REFERENCE

LOT #_____
Date of Purchase

* Bracket not included.





IMPORTANT INFORMATION

THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



This TV Stand is intended for use only with the products and maximum weights indicated. Use with other products or products heavier than maximum weights indicated may result in instability causing possible injury. The base of the television must be able to rest on the supporting surface of the unit without over-hanging the edges.

Model: 220499-03

Distribution / Manufacturer:

Slam Brands, Inc. Country of Origin: China Manufacture Date: 07.01.08 Accommodates Most:

60in.


Flat Panel (152.4cm)

Maximum Load Weight:

Top shelf: 180lb./81.6kg.

Maximum Load Weight:

Component shelf: 40lb./18.1kg.





2260 152nd Ave NE Redmond, WA 98052 www.slambrands.com Toll Free: 1 (866) 632-6632 Email: support@slambrands.com

Business Hours: M-F 8am-5pm PST



Compatible only with Slam Brands' Universal Flat Panel Bracket #222709. Bracket is not included.



IMPORTANT INFORMATION

THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

SAFETY FIRST

- ! When moving TV Stand, remove TV first. Do NOT move TV Stand with a TV on top.
- ! To avoid injury, assemble TV Stand in final location. Moving the stand after it is assembled is not recommended.
- ! Ensure that all parts and hardware are located before assembly.
- ! A drill and Phillips or Flat Head screwdriver may be necessary to complete assembly (not included).
- If you have purchased a Universal Flat Panel Bracket separately, assemble the Bracket to the TV Stand <u>BEFORE</u> securing glass shelves.

ANTI-TIP HARDWARE


This product is sold with anti-tip hardware and it is suggested that the product be used with this hardware attached. Danger from tipping may result if the hardware is not attached to both the wall and the TV Stand. Slam Brands, Inc. is not responsible for any personal injury or damage to stand, television, components, or household effects resulting from improper use of this product.

UNIVERSAL FLAT PANEL BRACKET COMPATIBILITY


This Universal Flat Panel Bracket is intended for use only with Slam Brands' TV stands identified as compatible with product #222709. Use with TV stands other than those manufactured by Slam Brands, or those not labeled for use with product #222709, is unsafe and may result in instability causing possible injury. Slam Brands, Inc. is not responsible for any personal injury or damage to stand, television, components, or household effects resulting from improper use of this product.




ASSEMBLY OVERVIEW



PARTS IDENTIFICATION




(A) Left Side Support (1) T00914



(B) Right Side Support (1) T00915



© Base (1) T00782



D Backboard (1) T00783



E Medium Cleats (4) H00381



F Top Support Brace (1) T00784



G Middle Glass Shelf (1) T00785



H Top Glass Shelf (1) T00786




Angled Brace (2) T00916

HARDWARE IDENTIFICATION

Assembly requires a Phillips or Flat Head screwdriver (not included).


1 Hex Bolts	6 x 12mm	Qty. (15)		H00481
② Hex Bolts	6 x 35mm	(8)		Н00089
③ Phillips Screws	M4 x 10mm	(14)		Н00507
4 Bolts	6 x 15mm	(8)		Н00534
5 Suction Cups		(4)		Н00017
6 Allen Key Wrench	4 x 4mm	(1)		∍ H00005
7 Shelf Supports		(2)		H00535
8 Small Spacers		(4)		Н00536
Spacer		(2)		Н00537
① L-Joint Wall Brackets	13 x 16 x 1.4mr	n (2)	6	H00142
11) Wall Anchor		(1)		H00141
12 Loop	219mm	(1)		H00021
(13) Phillips Screw	M4 x 37mm	(1)	(-) ,,,,,,,,,,,,,,,,,,,,,,,	H00163

STEP 1: ATTACH SIDE SUPPORTS TO BASE






STEP 2: ATTACH BACKBOARD




STEP 3: ATTACH TOP SUPPORT BRACE AND SHELF SUPPORTS






STEP 4: INSTALL SPACERS AND L-JOINT WALL BRACKET



STEP 5: INSTALL ANGLED BRACES










Cable Pro[™] Advanced Cable Control[™]



Patent# D569, 711





Cable Pro[™] Advanced Cable Control[™]

Cable Pro's Advanced Cable Control mounts directly to the back of your TV stand. Multiple cleats of different sizes and custom placement enable you to shorten, separate and route both single and bundled cables. Open, flexible design accommodates any cable diameter and when used in multiples, creates a system for routing cables through channels, between components and to power sources without the usual tangled mess or annoying signal interference.





Designed and Manufactured by: SLAM BRANDS, INC 2260 152nd Ave NE Redmond, WA 98052 www.slambrands.com MADE IN CHINA



STEP 6: ATTACH ADVANCED CABLE CONTROL

A drill or screwdriver is necessary to complete assembly (not included).





If you have purchased the optional Universal Flat Panel Bracket, continue to STEP 6.

If you DID NOT purchase the optional Universal Flat Panel Bracket, skip ahead to STEP 7.

IMPORTANT INFORMATION

THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

SAFETY FIRST

- ! When moving TV Stand, remove TV first. Do NOT move TV Stand with a TV on top.
- To avoid injury, assemble TV Stand in final location. Moving the stand after it is assembled is not recommended.
- ! Ensure that all parts and hardware are located before assembly.
- ! A drill and Phillips or Flat Head screwdriver may be necessary to complete assembly (not included).
- ! If you have purchased a Universal Flat Panel Bracket separately, assemble the Bracket to the TV Stand BEFORE securing glass shelves.

ANTI-TIP HARDWARE

This product is sold with anti-tip hardware and it is suggested that the product be used with this hardware attached. Danger from tipping may result if the hardware is not attached to both the wall and the TV Stand. Slam Brands, Inc. is not responsible for any personal injury or damage to stand, television, components, or household effects resulting from improper use of this product.


UNIVERSAL FLAT PANEL BRACKET COMPATIBILITY

This Universal Flat Panel Bracket is intended for use only with Slam Brands' TV stands identified as compatible with product #222709. Use with TV stands other than those manufactured by Slam Brands, or those not labeled for use with product #222709, is unsafe and may result in instability causing possible injury. Slam Brands, Inc. is not responsible for any personal injury or damage to stand, television, components, or household effects resulting from improper use of this product.




STEP 7: ATTACH OPTIONAL FLAT PANEL BRACKET TO THE BACKBOARD

If you have purchased a Universal Flat Panel Bracket 222709 separately, assemble the Bracket to the TV Stand **BEFORE** securing glass shelves.




STEP 8: INSERT SUCTION CUPS INTO SHELF SUPPORTS AND INSERT MIDDLE GLASS SHELF AS SHOWN

If you have purchased a Universal Flat Panel Bracket 222709 separately, assemble the Bracket to the TV Stand **BEFORE** securing glass shelves.





STEP 9: INSTALL AND SECURE TOP GLASS SHELF



STEP 10: SECURE TV STAND TO WALL

To prevent tipping, product must be secured to wall.

