Slam Brands and Avio products are guaranteed to be free from defect and missing parts.



Please Call First!

IF PARTS ARE MISSING, DO NOT RETURN TO STORE

To order missing or replacement parts, please call

Toll Free: 1 (866) 632-6632 support@slambrands.com

Business Hours: M-F 8am-5pm PST

01.08 A

HESTIA TV STAND

Assembly Instructions Item #222410 UPC #8-52836-00130-6



PLEASE READ & KEEP FOR FUTURE REFERENCE

LOT #_____

Date of Purchase



IMPORTANT INFORMATION

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

products or products heavier than maximum weights indicated may result in instability causing possible injury. Please place TV behind the wood strip. The base of the television must be able to rest on the This TV Stand is intended for use only with the products and maximum weights indicated. Use with other supporting surface of the unit without over-hanging the edges.

A PRECAUCIÓN

Esta mesa para Televisión está diseñada para usarla sólo con los productos y el peso máximo que se indican. El uso de otros productos o productos que excedan el peso máximo que se indica, puede tener como consecuencia inestabilidad y causar muerte o lesión seria. Por favor coloque la Televisión detrás de la tira de madera. La base de la televisión debe de reposar sobre la superficie de soporte de la unidad sin rebasar las orillas.

Accommodates Most: Capacidad Máxima:

42in. (1 m)

Pantalla Plana Flat Panel/

Television Shelf:

Flat Panel TV or 27in. (.6 m) CRT A maximum TV shelf load weight A maximum of a 42in. (1 m)

A maximum load weight of **Component Shelves:** of 100lb./45.3kg. 40lb./18.1kg.



Distribution / Manufacturer/Distribuido/Fabricado por: Slam Brands, Inc. Manufacture Date/Fecha de fabricación: 02.15.08 Country of Origin/País de orígen: China/China

Model/Modelo: 222410

Medida máxima de 1 m para Televisión de Pantalla Plana, para Televisión de 45,3 kg Peso máximo de la repisa Repisa para Televisión: 27 Pulg. (.6 m) CRT

Componentes de Repisas: (100lb).

Jn peso máximo de la repisa

Email: support@slambrands.com de 18,1 kg (40lb).

Correo electrónico: support@slambrands.com Business Hours: M-F 8am-5pm PST

_unes-Viernes 8 am-5 pm (Hora del Pacífico) (Válido sólo en E.U.A.) Horario de servicio al cliente:

AVIO[®]

IMPORTANT INFORMATION

THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

SAFETY FIRST

- ! When moving TV Stand, remove TV first. Do NOT move TV Stand with a TV on top.
- ! TVs are front heavy. Place TV behind the wood strip and as far from front surface of stand as possible.
- ! To avoid injury, assemble TV Stand in final location. Moving the stand after it is assembled is not recommended.
- ! Ensure that all parts and hardware are located before assembly.
- ! A drill or Phillips Head screwdriver is necessary to complete assembly. (Steps 1 and 6)

ANTI-TIP HARDWARE


This product is sold with anti-tip hardware and it is intended that the product be used with this hardware attached. Danger from tipping may result if the hardware is not attached to both the wall and the TV Stand. Slam Brands, Inc. is not responsible for any personal injury or damage to stand, television, components, or household effects resulting from improper use of this product.






ASSEMBLY OVERVIEW

PLACE TV BEHIND THE WOOD STRIP TO ENSURE SAFETY.



PARTS IDENTIFICATION



T00618


T00619

T00617

HARDWARE IDENTIFICATION









- ① 1/4" x 1/2" Hex Bolts (12) H00203
- ② ¹/₄" x 1" Hex Bolts (3) H00047
- $3^{1}/4$ " x $1^{1}/4$ " Hex Bolts (10) H00008
- (4) ø ¹/₄" Spring Washers (6) H00193










- (5) ø ¹/₄" Washers (8) H00184
- (6) 4 x 4 Allen Key (1) H00005
- $(7) \ \emptyset \ ^{1}/_{2}$ " Rubber Bumpers (8) H00025
- (8) Cam Bolts (4) H00074










- (9) Cams (4) H00092
- (10) Headless Bolts (2) H00388
- (11) Wood Screw (1) H00080
- (12) Phillips Screw (1) H00079












- (13) Dry Wall Anchor (1) H00385
- (4) Safety Strap (1) (5) Ø 19 x 25 mm H00386
- Feet (2) H00387
- ⁵/₃₂" x ⁵/₈" Phillips Head Screws (8) H00390
 - Medium Cleats (4) H00381




THE "CAM" ASSEMBLY SYSTEM

THIS PAGE IS A <u>REFERENCE</u> FOR COMPLETING THE STEP-BY-STEP INSTRUCTIONS ON THE FOLLOWING PAGES. BEGIN ASSEMBLY WITH STEP 1. REFER TO THIS PAGE FOR ADDITIONAL INFORMATION AS DIRECTED.




Screw Cam Bolts (8) into designated holes.




Press Cams (9) into designated holes.

Arrow on Cams should face the hole at the edge of the board.




Align Cam Bolt with hole at Cam and press boards together.



Turn Cam ½ turn clockwise to lock.




STEP 1: ASSEMBLE FRAME






STEP 2: ATTACH SHELF SUPPORTS TO FRAME




STEP 3 & 4: ATTACH BACKBOARD TO SHELF SUPPORTS, ATTACH HEIGHT-ADJUSTABLE FEET




Screw feet to desired height to level the stand on uneven floor surfaces.




STEP 5: PLACE RUBBER PADS ON SIDE SUPPORTS




STEP 6: PLACE HEADLESS BOLTS IN TOP GLASS



STEP 7: SECURE TOP GLASS TO SIDE SUPPORTS AND PLACE SHELVES






Cable Pro[™] Advanced Cable Control[™]







Cable Pro Advanced Cable Control Total


Cable Pro's Advanced Cable Control mounts directly to the back of your TV stand. Multiple cleats of different sizes and custom placement enable you to shorten, separate and route both single and bundled cables. Open, flexible design accommodates any cable diameter and when used in multiples, creates a system for routing cables through channels, between components and to power sources without the usual tangled mess or annoying signal interference.





STEP 8: ATTACH CABLE PRO ADVANCED CABLE CONTROL


A drill or screwdriver is necessary to complete assembly (not included).





STEP 9: SECURE TV STAND TO WALL

A drill or Phillips Head screwdriver is necessary to complete assembly (not included).



To prevent tipping, product must be secured to the wall.



Slam Brands and Avio products are guaranteed to be free from defect and missing parts.



Please Call First!

IF PARTS ARE MISSING, DO NOT RETURN TO STORE

To order missing or replacement parts, please call

Toll Free: 1 (866) 632-6632 support@slambrands.com

Business Hours: M-F 8am-5pm PST

IMPORTANT INFORMATION

THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.





♠ CAUTION

njury. Please place TV behind the wood strip. The base of the television must be able to rest on the products or products heavier than maximum weights indicated may result in instability causing possible This TV Stand is intended for use only with the products and maximum weights indicated. Use with other supporting surface of the unit without over-hanging the edges.

A PRECAUCION

Esta mesa para Televisión está diseñada para usarla sólo con los productos y el peso máximo que se como consecuencia inestabilidad y causar muerte o lesión seria. Por favor coloque la Televisión detrás de la tira de madera. La base de la televisión debe de reposar sobre la superficie de soporte de la indican. El uso de otros productos o productos que excedan el peso máximo que se indica, puede tener

Model/Modelo: 222410

Distribution / Manufacturer/Distribuido/Fabricado por: Slam Brands, Inc.

unidad sin rebasar las orillas.

Country of Origin/País de orígen: China/China

27in. (.6 m)

(1 m)

Accommodates Most:

Sapacidad Máxima:

Manufacture Date/Fecha de fabricación: 02.15.08

Repisa para Televisión:

Medida máxima de 1 m para Televisión de Pantalla Plana, para Televisión de 45,3 kg Peso máximo de la repisa 27 Pulg. (.6 m) CRT

Componentes de Repisas:

(100lb).

Un peso máximo de la repisa de 18,1 kg (40lb)

Correo electrónico: support@slambrands.com Email: support@slambrands.com

Business Hours: M-F 8am-5pm PST

Horario de servicio al cliente:

-unes-Viernes 8 am-5 pm (Hora del Pacífico) (Válido sólo en E.U.A.)

