Introduction to ChimeraTK.

Part 2: ApplicationCore






Martin Hierholzer

- M. Heuer, M. Killenberg, T. Kozak, L. Petrosyan, C. Schmidt, N. Shehzad,
 - G. Varghese, M. Viti, DESY, Hamburg, Germany
 - S. Marsching, aquenos GmbH, Baden-Baden, Germany A. Piotrowski, FastLogic Sp. z o.o., Łódź, Poland
- C. P. latrou, J. Rahm, Technische Universität Dresden, Dresden, Germany
 - R. Steinbrück, M. Kuntzsch, HZDR, Dresden-Rossendorf, Germany
 - P. Prędki Łódź University of Technology, Łódź, Poland
- A. Dworzanski, K. Czuba, Warsaw University of Technology, Warsaw, Poland









- ▶ Kick-off meeting for the OPC UA adapter with TU-DD (Summer 2016)
- ▶ Why do we treat control system variables and registers differently?



- ► Kick-off meeting for the OPC UA adapter with TU-DD (Summer 2016)
- ▶ Why do we treat control system variables and registers differently?
- ▶ Control system variable ⇒ Server
- ▶ DeviceAccess register ⇒ Client
- Conceptionally the same, can sometimes even be exchanged!




- ► Kick-off meeting for the OPC UA adapter with TU-DD (Summer 2016)
- ▶ Why do we treat control system variables and registers differently?
- ▶ Control system variable ⇒ Server
- ightharpoonup DeviceAccess register \Rightarrow Client
- Conceptionally the same, can sometimes even be exchanged!
- DOOCS example:
 - ► Client write via RPC → Server
 - ► Server send via 0MQ Client




- ▶ Kick-off meeting for the OPC UA adapter with TU-DD (Summer 2016)
- Why do we treat control system variables and registers differently?
- ▶ Control system variable ⇒ Server
- ▶ DeviceAccess register ⇒ Client
- Conceptionally the same, can sometimes even be exchanged!
- DOOCS example:
 - ► Client write via RPC Server
 - ► Server send via 0MQ Client
- ▶ Of course one has to decide for one implementation, but no fundamental difference in the application





The structure of ApplicationCore







Goal: provide framework for implementing applications which are "naturally" control-system independent

▶ If we abstract away differences between control system and device variables, we will less likely make our application sensitive to specific control systems!



- ▶ If we abstract away differences between control system and device variables, we will less likely make our application sensitive to specific control systems!
- Separate actual application code (algorithms etc.) from control system and device implementation details



- ▶ If we abstract away differences between control system and device variables, we will less likely make our application sensitive to specific control systems!
- Separate actual application code (algorithms etc.) from control system and device implementation details
- lacktriangle Encourage modular applications (o conceptional abstraction)



- ▶ If we abstract away differences between control system and device variables, we will less likely make our application sensitive to specific control systems!
- Separate actual application code (algorithms etc.) from control system and device implementation details
- lacktriangle Encourage modular applications (o conceptional abstraction)
- ▶ Clean and simple interface, avoid boiler plate code as much as C++11 allows



- ▶ If we abstract away differences between control system and device variables, we will less likely make our application sensitive to specific control systems!
- Separate actual application code (algorithms etc.) from control system and device implementation details
- ightharpoonup Encourage modular applications (ightharpoonup conceptional abstraction)
- lacktriangle Clean and simple interface, avoid boiler plate code as much as C++11 allows
- Avoid the need for user callback functions (excessive use makes code unreadable)



- ▶ If we abstract away differences between control system and device variables, we will less likely make our application sensitive to specific control systems!
- Separate actual application code (algorithms etc.) from control system and device implementation details
- ightharpoonup Encourage modular applications (ightharpoonup conceptional abstraction)
- lacktriangle Clean and simple interface, avoid boiler plate code as much as C++11 allows
- Avoid the need for user callback functions (excessive use makes code unreadable)
- ▶ Allow publishing a device register into the control system with a single code line



- ► API abstraction:
 - Make your application independent of 3rd-party APIs



- ► API abstraction:
 - ▶ Make your application independent of 3rd-party APIs
 - Example: use one common API for access to any register-based hardware independent of the transport protocol



- API abstraction:
 - Make your application independent of 3rd-party APIs
 - Example: use one common API for access to any register-based hardware independent of the transport protocol
 - ▶ Other example: printer library drawing line on a PostScript and a PCL printer



- API abstraction:
 - Make your application independent of 3rd-party APIs
 - Example: use one common API for access to any register-based hardware independent of the transport protocol
 - ▶ Other example: printer library drawing line on a PostScript and a PCL printer
- Conceptional abstraction:



- API abstraction:
 - Make your application independent of 3rd-party APIs
 - Example: use one common API for access to any register-based hardware independent of the transport protocol
 - Other example: printer library drawing line on a PostScript and a PCL printer
- Conceptional abstraction:
 - ▶ Make your application independent even of concepts implied by the use of a particular technology



- API abstraction:
 - Make your application independent of 3rd-party APIs
 - Example: use one common API for access to any register-based hardware independent of the transport protocol
 - Other example: printer library drawing line on a PostScript and a PCL printer
- Conceptional abstraction:
 - ▶ Make your application independent even of concepts implied by the use of a particular technology
 - Example: printer library drawing line on vector plotters and pixel printers



- API abstraction:
 - Make your application independent of 3rd-party APIs
 - Example: use one common API for access to any register-based hardware independent of the transport protocol
 - Other example: printer library drawing line on a PostScript and a PCL printer
- Conceptional abstraction:
 - Make your application independent even of concepts implied by the use of a particular technology
 - Example: printer library drawing line on vector plotters and pixel printers
 - ▶ This is a difficult one! Often not possible on level of entire applications
 - Instead: break down application into abstract parts, combine them with little code



- ► API abstraction:
 - Make your application independent of 3rd-party APIs
 - Example: use one common API for access to any register-based hardware independent of the transport protocol
 - Other example: printer library drawing line on a PostScript and a PCL printer
- Conceptional abstraction:
 - ▶ Make your application independent even of concepts implied by the use of a particular technology
 - Example: printer library drawing line on vector plotters and pixel printers
 - ▶ This is a difficult one! Often not possible on level of entire applications
 - Instead: break down application into abstract parts, combine them with little code
- Conceptional abstraction usualy involves also API abstraction
- Both improve code quality a lot!

Short refresh of C++ 11



▶ Default arguments to member constructors with braces

```
struct SomeClass {
  std::string myText{"Hello World"};
};
```



▶ Default arguments to member constructors with braces


```
struct SomeClass {
  std::string myText{"Hello World"};
};
```

▶ Brace-initialisers when passing arguments

```
void someFunction(std::vector<int> values);
void main() {
  someFunction({1, 42, 33});
}
```

Direct access to device registers





Define the application (idealised code)



```
struct ExampleApp : public ctk::Application {
    ctk::DeviceModule heater{"oven","heater"};
    ctk::ControlSystemModule cs{"Bakery"};
    void defineConnections();
};
ExampleApp theExampleApp;
```

Define the application



```
struct ExampleApp : public ctk::Application {
    ExampleApp() : Application("exampleApp") {}
    ~ExampleApp() { shutdown(); }

    ctk::DeviceModule heater{"oven", "heater"};

    ctk::ControlSystemModule cs{"Bakery"};

    void defineConnections();
};
ExampleApp theExampleApp;
```

Description of connections (idealised code)



```
void ExampleApp::defineConnections() {
    cs("heatingCurrent") >> heater("heatingCurrent");
    heater("temperatureReadback") >> cs("temperatureReadback");
}
```

Description of connections (idealised code)



```
void ExampleApp::defineConnections() {
    cs("heatingCurrent") >> heater("heatingCurrent");
    heater("temperatureReadback") >> cs("temperatureReadback");
}
```

- ▶ Neither DeviceModule nor ControlSystemModule define their variable types
- DeviceAccess allows to read a register as any type
- ControlSystemAdater variables are created on-the-fly
- ▶ We need to specify the type and array length here!

Description of connections (idealised code)




```
void ExampleApp::defineConnections() {
    cs("heatingCurrent", typeid(int), 1) >> heater("heatingCurrent");
    heater("temperatureReadback", typeid(int), 1) >> cs("temperatureReadback");
}
```

- ▶ Neither DeviceModule nor ControlSystemModule define their variable types
- DeviceAccess allows to read a register as any type
- ControlSystemAdater variables are created on-the-fly
- ▶ We need to specify the type and array length here!




► Generalise the client/server concept






Generalise the client/server concept






Generalise the client/server concept






Generalise the client/server concept




Introduction of triggers





Introduction of triggers






Introduction of triggers



When connecting a poll-type output (e.g. a PCIe register) with a push-type input, a trigger for the transfer is needed



- Any push-type variable can act as a trigger, its value will be ignored
- ▶ It can come from a device, another ApplicationModule or even the ControlSystemAdapter

Description of connections (actual code!)



Description of connections (actual code!)



- DeviceAccess variables are by default poll-type
- ► Need to change this to push-type

Define the application (actual code!)



```
struct ExampleApp : public ctk::Application {
    ExampleApp() : Application("exampleApp") {}
    ~ExampleApp() { shutdown(); }

    ctk::DeviceModule heater{"oven", "heater"};
    ctk::DeviceModule timer{"Timer"};
    ctk::ControlSystemModule cs{"Bakery"};

    void defineConnections();
};
ExampleApp theExampleApp;
```

Define the application (actual code!)



```
struct ExampleApp : public ctk::Application {
    ExampleApp() : Application("exampleApp") {}
    ~ExampleApp() { shutdown(); }

    ctk::DeviceModule heater{"oven", "heater"};
    ctk::DeviceModule timer{"Timer"};
    ctk::ControlSystemModule cs{"R" shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined, it is coming from the adapter!

    void defineCon shall be defined shall be defined shall be defined.

    void defineCon shall be defined sh
```

Define the application (actual code!)



```
struct ExampleApp : public ctk::Application {
    ExampleApp() : Application("exampleApp") {}
    ~ExampleApp() { shutdown(); }


    ctk::DeviceModule heater{"oven", "heater"};
    ctk::DeviceModule timer{"Timer"};
    ctk::ControlSystemModule cs{"Bakery"};

    void defineConnections();
};
ExampleApp theExampleApp;
```

Live demo now! (01)

Make the application smarter!





Add an ApplicationModule (idealised code)



```
struct Controller : public ctk::ApplicationModule {
    ctk::ScalarInput<double> sp{"sp", "degC", "Description"};
    ctk::ScalarInput<double> rb{"rb", "degC", "..."};
    ctk::ScalarOutput<double> cur{"cur", "mA", "..."};
                                                                        Application Module "Controller"
    void mainLoop() {
                                                                       heatingCurrent
      const double gain = 100.0;
      while(true) {
                                                                   temperatureReadback
                                                                                            Module Thread
        rb.read();
        sp.read():
                                                                    temperatureSetpoint
        cur = gain * (sp - rb);
        cur.write();
};
```





```
struct Controller : public ctk::ApplicationModule {
    ctk::ScalarInput<double> sp{this, "sp", "degC", "Description"};
    ctk::ScalarInput<double> rb{this, 'rb", "degC", "..."};
    ctk::ScalarOutput<double> cur{this, "cur", "mA", "..."};
    void mainLoop() {
      const double gain = 100.0;
                                      Need to know the owner!
      while(true) {
        rb.read();
        sp.read():
        cur = gain * (sp - rb);
        cur.write();
};
```

Application Module (towards actual code - step 2)



```
struct Controller : public ctk::ApplicationModule {
                                                                  ← Inherit constructor
    using ctk::ApplicationModule::ApplicationModule;
    ctk::ScalarInput<double> sp{this, "sp", "degC", "Description"};
    ctk::ScalarInput<double> rb{this, "rb", "degC", "..."};
    ctk::ScalarOutput<double> cur{this, "cur", "mA", "..."};
    void mainLoop() {
      const double gain = 100.0;
      while(true) {
        rb.read();
        sp.read():
        cur = gain * (sp - rb);
        cur.write();
};
```



```
struct Controller : public ctk::ApplicationModule {
    using ctk::ApplicationModule::ApplicationModule;
    ctk::ScalarPollInput<double> sp{this, "sp", "degC", "Description"};
    ctk::ScalarPushImput<double> rb{this, "rb", "degC", "..."};
    ctk::ScalarOutput<double> cur{this, "cur", "mA", "..."};
                  Define the update mode. Outputs are always push-type.
    void mainLoop() {
      const double gain = 100.0;
      while(true) {
        rb.read();  // waits until update arrives
        sp.read(): // just reads latest value
        cur = gain * (sp - rb):
        cur.write();
};
```



```
struct Controller : public ctk::ApplicationModule {
    using ctk::ApplicationModule::ApplicationModule;
    ctk::ScalarPollInput<double> sp{this, "sp", "degC", "Description"};
    ctk::ScalarPushImput<double> rb{this, "rb", "degC", "..."};
    ctk::ScalarOutput<double> cur{this, "cur", "mA", "..."};
                   Define the update mode. Outputs are always push-type.
    void mainLoop() {
      const double gain = 100.0;
      while(true) {
                                                                                Application Module "Controller"
        rb.read();  // waits until update arrives
        sp.read(): // just reads latest value
                                                           output \rightarrow
                                                                              heatingCurrent
        cur = gain * (sp - rb);
        cur.write():
                                                push-type input \rightarrow
                                                                           temperatureReadback
                                                                                                     Module Thread
                                                 poll-type input \rightarrow
                                                                            temperatureSetpoint
};
```



```
struct Controller : public ctk::ApplicationModule {
   using ctk::ApplicationModule::ApplicationModule;
   ctk::ScalarPollInput<double> sp{this, "sp", "degC", "Description"};
   ctk::ScalarPushInput<double> rb{this, "rb", "degC", "..."};
   ctk::ScalarOutput<double> cur{this, "cur", "mA", "..."};
     Interface from DeviceAccess
       ScalarPollInput / ScalarPushInput / ScalarOutput
          ⇒ ScalarRegisterAccessor
       ArrayPollInput / ArrayPushInput / ArrayOutput
          ⇒ OneDRegisterAccessor
};
```



```
struct Controller : public ctk::ApplicationModule {
   using ctk::ApplicationModule::ApplicationModule;
   ctk::ScalarPollInput<double> sp{this, "sp", "degC", "Description"};
   ctk::ScalarPushInput<double> rb{this, "rb", "degC", "..."};
   ctk::ScalarOutput<double> cur{this, "cur", "mA", "..."};
     Interface from DeviceAccess
       ScalarPollInput / ScalarPushInput / ScalarOutput
          ⇒ ScalarRegisterAccessor
       ArrayPollInput / ArrayPushInput / ArrayOutput
          ⇒ OneDRegisterAccessor
       Actual inheritance!
       Only adds inversion of control
```



```
struct Controller : public ctk::ApplicationModule {
    using ctk::ApplicationModule::ApplicationModule;
    ctk::ScalarPollInput<double> sp{this, "sp", "degC", "Description"};
    ctk::ScalarPushInput<double> rb{this, "rb", "degC", "..."};
    ctk::ScalarOutput<double> cur{this, "cur", "mA", "..."};
    void mainLoop() {
      const double gain = 100.0;
      while(true) {
        rb.read();  // waits until update arrives
        sp.read(); // just reads latest value
        cur = gain * (sp - rb);
        cur.write();
};
```

Live demo now! (02)

Definition of connections with the ApplicationModule



Already shown during live demo 02



► Triggers are in many cases not strictly needed, one could do periodic polling in the ApplicationModule instead (i.e. poll-type input and sleep)



- Triggers are in many cases not strictly needed, one could do periodic polling in the ApplicationModule instead (i.e. poll-type input and sleep)
- ▶ If consistency (or at least near consistency) is required, periodic polling must be done in the same ApplicationModule



- Triggers are in many cases not strictly needed, one could do periodic polling in the ApplicationModule instead (i.e. poll-type input and sleep)
- If consistency (or at least near consistency) is required, periodic polling must be done in the same ApplicationModule
- Conceptional abstraction:
 - Keep a variable out an ApplicationModule if it doesn't belong there! Don't place supplyVoltages into the Controller module



- Triggers are in many cases not strictly needed, one could do periodic polling in the ApplicationModule instead (i.e. poll-type input and sleep)
- ▶ If consistency (or at least near consistency) is required, periodic polling must be done in the same ApplicationModule
- Conceptional abstraction:
 - Keep a variable out an ApplicationModule if it doesn't belong there! Don't place supplyVoltages into the Controller module
 - ▶ If an ApplicationModule acts upon change of an input, make that clear by using a push-type input



- Triggers are in many cases not strictly needed, one could do periodic polling in the ApplicationModule instead (i.e. poll-type input and sleep)
- If consistency (or at least near consistency) is required, periodic polling must be done in the same ApplicationModule
- Conceptional abstraction:
 - Keep a variable out an ApplicationModule if it doesn't belong there! Don't place supplyVoltages into the Controller module
 - ▶ If an ApplicationModule acts upon change of an input, make that clear by using a push-type input
- ▶ NB: Application-wide periodic triggers are like the cycle time in PLCs

Let's add some monitoring!




```
void ExampleApp::defineConnections() {
    mtca4u::setDMapFilePath("devices.dmap");
    auto triggerNr = timer("triggerNr", typeid(int), 1, ctk::UpdateMode::push);
    cs("temperatureSetpoint") >> controller.temperatureSetpoint;
    controller.heatingCurrent >> heater("heatingCurrent");
    heater("temperatureReadback") [ triggerNr ] >> controller.temperatureReadback
        >> cs("temperatureReadback"):
    heater("supplyVoltages", typeid(int), 4) [ triggerNr ] >> cs("supplyVoltages");
    triggerNr >> cs("triggerNr");
```

Live demo now! (03)




- ▶ Connect all variables of module with variables of same name in other module
- ▶ Works recursively (variables can be grouped with VariableGroup)






- ▶ Connect all variables of module with variables of same name in other module
- Works recursively (variables can be grouped with VariableGroup)
- ▶ Does not care about additional variables in the target module
- Even acts on inputs and outputs simultaneously





- ▶ Connect all variables of module with variables of same name in other module
- ▶ Works recursively (variables can be grouped with VariableGroup)
- ▶ Does not care about additional variables in the target module
- Even acts on inputs and outputs simultaneously
- Works nicely with ControlSystemModule which creates variables on demand





The already known connection code...



An equivalent notation...

```
void ExampleApp::defineConnections() {
   mtca4u::setDMapFilePath("devices.dmap");
   auto triggerNr = timer("triggerNr", typeid(int), 1, ctk::UpdateMode::push);
   cs("temperatureSetpoint") >> controller.temperatureSetpoint;
   controller.heatingCurrent >> heater("heatingCurrent");
   heater("temperatureReadback") [ triggerNr ] >> controller.temperatureReadback;
   controller.temperatureReadback >> cs("temperatureReadback");
   heater("supplyVoltages", typeid(int), 4) [ triggerNr ] >> cs("supplyVoltages");
   triggerNr >> cs("triggerNr");
```



Now written shorter!

```
void ExampleApp::defineConnections() {
    mtca4u::setDMapFilePath("devices.dmap");

    auto triggerNr = timer("triggerNr", typeid(int), 1, ctk::UpdateMode::push);

// cs("temperatureSetpoint") >> controller.temperatureSetpoint;
    controller.heatingCurrent >> heater("heatingCurrent");
    heater("temperatureReadback") [ triggerNr ] >> controller.temperatureReadback;

// controller.temperatureReadback >> cs("temperatureReadback");

heater("supplyVoltages", typeid(int), 4) [ triggerNr ] >> cs("supplyVoltages");
    triggerNr >> cs("triggerNr");

controller.connectTo(cs); // could connect arbitrary number of variables
}
```



Now written shorter!

```
void ExampleApp::defineConnections() {
    mtca4u::setDMapFilePath("devices.dmap");

    auto triggerNr = timer("triggerNr", typeid(int), 1, ctk::UpdateMode::push);

// cs("temperatureSetpoint") >> controller.temperatureSetpoint;
    controller.heatingCurrent >> heater("heatingCurrent");
    heater("temperatureReadback") [ triggerNr ] >> controller.temperatureReadback;

// controller.temperatureReadback >> cs("temperatureReadback");

heater("supplyVoltages", typeid(int), 4) [ triggerNr ] >> cs("supplyVoltages");
    triggerNr >> cs("triggerNr");

controller.connectTo(cs); // could connect arbitrary number of variables
}
```

Live demo now! (04)



The shortcut had a side effect...





- Variables can have any number of tags attachted
- A tag is any alpha-numeric string (no spaces)
- ▶ Not visible outside the application
- ▶ Can be used to search for a subset of variables



```
// ApplicationModule "Controller":
ctk::ScalarPollInput<double> temperatureSetpoint{..., {"CS"}};
ctk::ScalarOutput<double> heatingCurrent{..., {"HEATER"}};
ctk::ScalarPushInput<double> temperatureReadback{..., {"CS", "HEATER"}};

// defineConnections():
controller.findTag("HEATER").connectTo(heater, triggerNr);
controller.findTag("CS").connectTo(cs);
```



```
// ApplicationModule "Controller":
ctk::ScalarPollInput<double> temperatureSetpoint{..., {"CS"}};
ctk::ScalarOutput<double> heatingCurrent{..., {"HEATER"}};
ctk::ScalarPushInput<double> temperatureReadback{..., {"CS", "HEATER"}};

// defineConnections():
controller.findTag("HEATER").connectTo(heater, triggerNr);
controller.findTag("CS").connectTo(cs);
```

```
/**

* Connect the entire module into another module. [...]

*

* If an optional trigger node is specified, this trigger node is applied to all

* poll-type output variables of the target module, which are being connected during

* this operation, if the corresponding variable in this module is push-type.

*/

void Module::connectTo(const Module &target, VariableNetworkNode trigger={}) const;
```



```
// ApplicationModule "Controller":
ctk::ScalarPollInput<double> temperatureSetpoint{..., {"CS"}};
ctk::ScalarOutput<double> heatingCurrent{..., {"HEATER"}};
ctk::ScalarPushInput<double> temperatureReadback{..., {"CS", "HEATER"}};

// defineConnections():
controller.findTag("HEATER").connectTo(heater, triggerNr);
controller.findTag("CS").connectTo(cs);
```

The order matters!

- ▶ The oder of connectTo() statements may matter
- ▶ Device and control system variables decide their direction from the context
- Swapping the two statements would feed temperatureReadback from the control system and pass a copy to the device



```
// ApplicationModule "Controller":
ctk::ScalarPollInput<double> temperatureSetpoint{..., {"CS"}};
ctk::ScalarOutput<double> heatingCurrent{..., {"HEATER"}};
ctk::ScalarPushInput<double> temperatureReadback{..., {"CS", "HEATER"}};

// defineConnections():
controller.findTag("HEATER").connectTo(heater, triggerNr);
controller.findTag("CS").connectTo(cs);
```

Live demo now! (05)



- ► A pipe is a standard ApplicationModule simply passing on a variable
- Very useful for direct connections between devices and control system



- ► A pipe is a standard ApplicationModule simply passing on a variable
- Very useful for direct connections between devices and control system



- ► A pipe is a standard ApplicationModule simply passing on a variable
- Very useful for direct connections between devices and control system

Live demo now! (06)



- ► A pipe is a standard ApplicationModule simply passing on a variable
- Very useful for direct connections between devices and control system



flatten(

- ► Eliminates all hierarchies (just for the current operation)
- ► Common use case: device with flat hierarchy but register access scattered over many modules

```
// defineConnections() smarter:
findTag("HEATER").flatten().connectTo(heater, triggerNr);
findTag("CS").connectTo(cs);
```

Information model





- ▶ Model already improved a bit by introducing the "controller" directory
- ▶ Still, a bakery does not has a controller the oven has it!

Information model





- ▶ Model already improved a bit by introducing the "controller" directory
- Still, a bakery does not has a controller the oven has it!
- Assuming this application represents an entire bakery, we shall introduce the oven an entity in both the source code and the control system hierarchy
- ▶ In other words: pick the right level of conceptional abstraction for each part of the application

Group modules



Live demo now! (07)

Controlling multiple ovens



```
// Application:
std::vector<Oven> ovens;
std::vector<ctk::DeviceModule> heaters;

// defineConnections():
for(size_t i=0; i<2; ++i) {
    ovens.emplace_back(this, "oven"+std::to_string(i), "Oven "+std::to_string(i));
    heaters.emplace_back("oven"+std::to_string(i), "heater");

    ovens[i].findTag("HEATER").flatten().connectTo(heaters[i], triggerNr);
}</pre>
```

Live demo now! (08)

More possibilities for improving the information model




- excludeTag() is the opposite of findTag()
- ▶ findTag() and excludeTag() both support regular expressions
- Any level in the hierarchy might be "eliminated" if introduced only for technical reasons (e.g. need for readAll() on a VariableGroup), see Module::setEliminateHierarchy()
- ▶ In case of doubt: use Module::dump() or the result of findTag() etc., e.g.:

```
ovens[0].dump();
findTag("CS").dump();
```

▶ Or use Module::dumpGraph() to generate GraphViz dot code







- ▶ Advised to build applications from many small modules:
 - ▶ Improves application structure (easier conceptual abstraction, reusing code)



- ▶ Advised to build applications from many small modules:
 - ▶ Improves application structure (easier conceptual abstraction, reusing code)
 - Often improves performance (on multi-core CPUs)



- Advised to build applications from many small modules:
 - Improves application structure (easier conceptual abstraction, reusing code)
 - Often improves performance (on multi-core CPUs)
- ▶ Effectively quite advanced theading system based on futures and lock-free queues
- Message-based: values of variables are passed to other modules



- Advised to build applications from many small modules:
 - ▶ Improves application structure (easier conceptual abstraction, reusing code)
 - Often improves performance (on multi-core CPUs)
- ▶ Effectively quite advanced theading system based on futures and lock-free queues
- ▶ Message-based: values of variables are passed to other modules
- Lock-free: no dead locks can occur




- Advised to build applications from many small modules:
 - Improves application structure (easier conceptual abstraction, reusing code)
 - Often improves performance (on multi-core CPUs)
- Effectively quite advanced theading system based on futures and lock-free queues
- Message-based: values of variables are passed to other modules
- Lock-free: no dead locks can occur
- ► Futures: can effectively wait without using the cpu




- Advised to build applications from many small modules:
 - Improves application structure (easier conceptual abstraction, reusing code)
 - Often improves performance (on multi-core CPUs)
- ▶ Effectively quite advanced theading system based on futures and lock-free queues
- Message-based: values of variables are passed to other modules
- Lock-free: no dead locks can occur
- Futures: can effectively wait without using the cpu
- ▶ No mutexes: non-parallel code sections would spoil scalability






























- ▶ Tag "CH5": other modules also provide variables for Channel 5
- ▶ Tags "REG" and "CS": device registers and control system variables
- ► Tag "CALIB": global calibration values
- ► Tag "DAQ": variables go into the internal DAQ system (if enabled)





► For more details about the LLRF server, come to my poster:

ApplicationCore: A Framework for Modern Control Applications at the Example of a Facility Independent LLRF Server

Git repository with soure code used in this demo

- ▶ URL: https://github.com/mhier/ApplicationCoreLiveDemo
- ► Full source code incl. cmake files
- Also includes these slides