


CEG 3136 – Computer Architecture II Tutorial 1 - Introduction to Assembler Programming Fall 2019







Contents of the S19 File

S0030000FC S113**0400**CF2000160413CC068115FBEA7B16045397 S113**0410**20FB3F1410CE00000DE039800CE03A4080 S113**0420**86056AE03486016AE0350FE03708FB0C84 S113**0560**323DCE06BA0710B7101806180636CE0666 S113**0570**CF07043218063D34EC8015FBE90A15FB5D S113**0580**E9023715FBE8FFCC071C15FBE8FA33C179 S113**0590**302D04C1332D09CC06A415FBE8EA20D87C S112**0710**776F6E0A0D004472617721210A0D0084 S113**2500**202020202020202020000053434F52452B S113**2510**3A20506C6179657220583A20303020504E S113**2520**6C61796572204F3A2030300A0D00506C8E S113**2530**617965722058206D6F76650A0D00203030 S113**2540**20202031202020320A0D2020207C202031 S113**2550**207C20202020300A0D2D2D2D2B2D2D2DDB S113**2560**2B2D2D2D0A0D2020207C2020207C2020A6 S113**2570**2020310A0D2D2D2D2D2D2D2D2D2D2D2D2D2 S113**2580**0A0D2020207C2020207C20202020320ABC S105**2590**0D0038 S9030000FC

Contents of the S29 File


\$2240F**0400**CF2000160413CC068115FBEA7B16045320FB3F1410CE00000DE039800CE03A401F\$
\$2240F**0420**86056AE03486016AE0350FE03708FB0CE03980CC009C5CC8860C5ACBCE05F0CDF8
\$2240F**0440**250B180A3070A60081FF26F679250979250A3DCE250034CC06E715FBEA2A1604AA


•


\$2240F**0560**323DCE06BA0710B7101806180636CE06CF07043218063D34EC8015FBE90A15FB2C \$2240F**0580**E9023715FBE8FFCC071C15FBE8FA33C1302D04C1332D09CC06A415FBE8EA20D87E \$2240F**05A0**C030303DCE0678E63026040732200E180FC40F444444440705812027EA3D34CED0


•


Select « Options » in Terminal menu to get the options dialog




















```
This subroutine contains a bug
; Subroutine - shscore
; Arguments: none
; Returns: nothing
; Global Variables: Xscr - X score number
                    Xscr a - X score ASCII
                    Oscr - O score number
;
                    Oscr a - O score ASCII
; Description: Outputs current score, but first
     translates the hexadecimal value to a 2 byte
    ASCII value. Value is passed in Acc D to scr2asc
     for translation. Register X contains address
    where converted bytes are to be stored.
    After scores are converted, score string is displayed.
shscore
             pshd
      pshx
             ; preserve registers
      ldab Xscr
      clra
      ldx #Xscr a
      bsr scr2asc
      ldab Oscr
      clra
      ldx #Oscr a
      bsr scr2asc
      ldd #Score
      jsr [printf,PCr] ; display current Score
      pulx ; restore registers
      puld
      rts
; Subroutine; scr2asc (num,addr)
; Parameters: num - in accumulator D (need in D for divide)
              addr - in Y register
; Local variables: rem - in accumulator D
                   qu - in X register
; Converts number to ascii decimal equivalent
scr2asc
        pshx
        pshd
                   ; preserve
        ldx #10
        idiv
                             ; remainder in D, i.e. B
        addb #ASCCONVNUM ; converts digit to ASCII
        stab 1,y
                    ; save first digit
        tfr x,d
                                ; move quotient back to d
        addb #ASCCONVNUM ; convert digit to ASCII
        stab 0,y
                   ; save second digit
        puld
                  ; restore
        pulx
        rts
```

Basic Programming

Ouestions:

- 1. What is the meaning of the sign bit = 1 when unsigned binary coded numbers are added?
- 2. What is the meaning of the carry bit = 1 when two unsigned binary coded numbers are subtracted? When two's complement binary coded numbers are subtracted?
- 3. What addressing mode is best to use when you want to access several sequential elements in a data array immediate, direct, indexed?
- 4. Pointer addressing with auto-increment and auto-decrement is referred to as what type of addressing for the MC68HC12?

Exercise 1

Give the values of the starting address, offset (indicate the size of the offset) and calculate the effective address of each of the following examples. Illustrate on the programmer's model the effect of the instructions to the CPU registers and memory.

Exercise 2:

An array of bytes contains a set of non-zero unsigned values. The last value in the array contains the value 0 to indicate the end of the array. Write a piece of code that contains a loop to read the contents of each byte into accumulator A. The array starts at address ARRAY. Write a first version that uses indexed addressing with accumulator B as the offset. Write a second version that auto-increments the index register. (Use the programming model to follow the steps used in running the program for this first version and if time permits the second version).

Exercise 3

Consider two three byte numbers stored at addresses NUM1 and NUM2 as defined by the following assembler pseudo-operations:

NUM1	EQU	\$0850
NUM2	EQU	\$0853
DIFF	EQU	\$0856

It is possible to load into the accumulators the bytes (or store into memory) using the labels as follows:

LDAA NUM1 ; Loads most significant byte into accumulator A STAB DIFF+2 ; Store the contents of accumulator B into the least

; Significant byte of the SUM number

The assembler will translate the labels to the appropriate addresses as shown below:

LDAA \$0850 ; NUM1 STAB \$0858 ; DIFF+2

The objective of this exercise is to write assembler source code to compute the difference between the two three-byte numbers (NUM1-NUM2) and store the result at address DIFF.

You will need the following 68HC12 instructions:

LDAA: Load accumulator A

SUBA: Subtract memory from A: A <- A- (M)

SBCA: Subtract memory and carry from A: A <- A - (M) - C

STAA: Store accumulator A

Use the programming model to follow the steps used in running the program.

	A	В			
D					
X					
Y					
PC					
SP					
	CCR				
Microprocessor SXHINZVC					

