

Leakage Current Model Note

March 20, 2026

A common first-order trend for reverse leakage-current increase is

$$\Delta I = \alpha \Phi V.$$

This is useful as a compact device-level metric for radiation damage.