Chapter 3

Driving LEDs and Keypad

Objectives

- Understanding how to set a port pin for digital Input or Output
- Understanding how to design an interface circuit for LEDs with Microcontroller and how to drive them
- Understanding Mask ON/OFF techniques
- Understanding software time delay technique and utilizing it for blinking LEDs
- Understanding how to manipulate Switches in the Keypad

☐ Configuring Port Pins for Digital Input/Output

- Each Port x has 3 Registers for configuration
 - DDRx: Data Direction Register of Port x
 - PORTx: Controls Output or Internal Pull up Resistor of Port x
 - PINx: Input Register of Port x
 - Here, x can be replaced with A or B or C or D or E or F or G

DDRx(Data Direction Register)

- Determine bitwise Data Direction of Port x
 - DDRxn ← 1: Bit n of Port x(Pxn pin) will be used for Digital Output
 - DDRxn ← 0 : Bit n of Port x(Pxn pin) will be used for Digital Input
- Examples

```
    DDRC = 0x0F; // 00001111<sub>2</sub>
    → Lower 4 Bits of PORTC(PC3 ~ PC0): Digital Output Upper 4 Bits of PORTC(PC7 ~ PC4): Digital Input DDRA = 0x10; // 000100000<sub>2</sub>
    → Bit 4(PA4 Pin) of Port A: Digital Output
```

Remaining Bits(Pins) of Port A: Digital Input DDRB = 0xFF; // 111111111_2 , All Pins of Port B: Digital Output DDRF = 0x00; // 00000000_2 , All Pins of Port F: Digital Input

☐ Configuring Port Pins for Digital Input/Output

PORTx Register

- When Pxn Pin is set for Digital Output
 - PORTxn bit is used as Data Latch for Output
 - Logical Value written in PORTxn bit will be output through Pxn Pin and latched
 - Examples

```
DDRA = 0xFF; // Set all the Port A Pins for digital output PORTA = 0xAA; // Binary 10101010 will be output to PA7 \sim PA0 Pins
```

- When Pxn Pin is set for Digital Input
 - PORTxn bit is used to enable/disable the internal Pull-up Resistor for the Pxn pin
 - PORTxn ← '1': the internal Pull-up Resistor for Pxn pin will be enabled
 - PORTxn ← '0': the internal Pull-up Resistor for Pxn pin will be disabled
 - Examples


```
DDRC = 0x0F; // Binary 00001111
```

- → Set Upper Nibble of Port C for Input and Lower Nibble for Output PORTC = 0xC6; // Binary 11000110
- → Binary data '0110' will be output to the Lower Nibble Pins of Port C
- → Internal Resistors for PC7 and PC6 Pins are activated(enabled) and Internal resistors for PC5 and PC4 Pins are deactivated(disabled)

☐ Configuring Port Pins for Digital Input/Output


PINx Register

- PINx Register contains logical status of Input Pins of Port x
 - We can take input values from outside of MCU by reading PINx Register
- Examples
 - x = PINE; // takes Input data from Port E and assigns it to the variable x if(PINA==0x2A) // if Input data from Port A equals $0x2A(=00101010_2)$...




☐ LED Driving Circuit

LED - circuit symbol and typical sample




LED – driving techniques




☐ LED Driving Circuit

Circuit for driving 8 LEDs and Design Theory




Modified Circuit for easy Construction



☐ LED Driving Circuit

- Hardware Construction
 - LEDs are connected to Port A of the MCU



☐ Practice 3–1: LED Lighting(ex3–1)


- Goal of the Practice
 - Turn on left 4 LEDs which are connected to the lower 4 bits of Port A

Necessary Techniques and Programming Algorithms

- Necessary Techniques
 - Problem Statement
 - For Practice 3-1 we need to set lower 4 bits of Port A for digital Output
 DDRA = 0x0F;
 - It has serious Problem to forcedly set the upper 4 bits of Port A for digital Input while setting lower 4 bits of Port A for digital Output
 - To avoid this problem we need Mask ON/OFF techniques to set/reset selected bits in a byte while other bits are unaffected(unchanged)
 - Mask ON Technique
 - Technique for Setting selected bits while other bits are unaffected
 - Utilizing the characteristic of OR Operation
 - Examples

DDRA I= 0x0F; // PA3 ~ PA0 pins for Output, other pins unchanged PORTA |= 0x03; // Output '1' to PA1, PA0 Pins, other pins unchanged

☐ Practice 3-1: LED Lighting(ex3-1)



Mask OFF Technique

- Technique for Resetting selected bits while other bits are unaffected
- Utilizing the characteristic of AND Operation
- Examples 5 3 Bit number DDRA $\&= 0 \times F0$: AND Χ Χ Χ Port A: before PORTA &= 0xFC; Mask : OxFCΧ Χ Χ Port A: after
- Programming Algorithm
 - Set all pins of Port A for digital output : DDRA = 0xFF;
 - Turn On lower 4 LEDs and turn off upper 4 LEDs: PORTA = 0x0F;
 - Program Termination: while(1)

☐ Practice 3–1: LED Lighting(ex3–1)

■ Program Source Code: ex3-1.c

- Goal of the Practice
 - Turn ON and OFF the left 4 LEDs periodically

Necessary Techniques and Programming Algorithms

- Necessary Techniques
 - Time Delay function
 - A function doing nothing but consuming time for a specified interval
 - Software time delay vs. Hardware time delay
 - Library function
 - _delay_ms(): maximally getting [262.14/F_CPU(MHz)]ms
 - _delay_us(): maximally getting [768/F_CPU(MHz)]us
 - You should include the following two compiler directives before using time delay library fuctions(normally beginning of the program)

```
#define F_CPU 16000000UL #include <util/delay.h>
```

 Arguments for calling delay functions should be constants(variables are not allowed)

- Custom made function
 - Delay_ms(): $1 \sim 65535$ ms
 - Delay_us(): 1 ~ 65535us
 - Variables can be used for calling Arguments
- > To get more accurate delays, Compiler Optimization should be activated
- Programming Algorithm
 - Straightforward!
 - Just turn ON the LEDs and wait a little while by calling time delay function(Delay_ms()) and after that turn OFF the LEDs and again wait a little while by calling time delay function and repeat the whole process endlessly.
- Refer to the program in the textbook

Preparation for easy Programming

- Make a file named ex.h which contains essential definitions, declarations and functions for all the practices in this textbook.
- Store the ex.h file in the "inc" folder

Contents of the ex.h file up to chapter 3 // definitions and Declarations added in chapter 3 F_CPU 1600000UL // MCU Clock Frequency #define #include <avr/io.h> #include <util/delay.h> // Time delay functions for obtaining millisecond or microsecond order void Delay_ms(unsigned int MilliSeconds) { unsigned int i; for(i=0;i<MilliSeconds;i++) _delay_ms(1); } void Delay_us(unsigned int MicroSeconds) { unsigned int i; for(i=0;i<MicroSeconds;i++) _delay_us(1);


■ Program Source Code: ex3-2.c #include "../../inc/ex.h" int main(void) { // DDRA의 모든 비트를 '1'로 설정하여 포트 A의 모든 비트를 출력으로 설정 DDRA = 0xFF;PORTA = 0x00; // 초기 상태 모든 LED 소등 while(1) { // 다음의 과정을 무한히 반복하게 한다 // PA3 ~ PA0 핀에 "1111"을 출력시켜 LED 4개 점등 PORTA = 0x0F; // 비트 3 ~ 0 mask on, 나머지 비트들은 이전 값 유지 // 딜레이 함수 호출 Delay_ms(500); // 약 0.5초(500mS) 딜레이 // PA3 ~ PA0 핀에 "0000"을 출력시켜 LED 소등 // PORTA 레지스터의 비트 3 ~ 0 mask off. 나머지 비트들은 이전 값 유지 PORTA &= 0xF0;// 딜레이 함수 호출 Delay ms(500); // 약 0.5초 지연 } // while 루프의 끝 ㅏ// 주 프로그램 끝


Goal of the Practice

- Add a Pushbutton switch as an Input to control LED lighting
- If a switch is pushed then the 8 LEDs will be turned ON and if the switch is released then all LEDs will be turned OFF
- Here we will use 4 x 4 Keypad instead of using a single Switch

Necessary Techniques and Programming Algorithms

- Necessary Techniques
 - Designing a Pushbutton Input circuit





SW_A SW_1 - 4 x 4 Keypad Interface Use Port C Flat Cable SW_4 SW_5 SW_6 SW_B SW_7 SW_8 SW_9 SW_C SW_0 SW_# SW_D Flat Cable Pin 8 Pin 1 ATmega128 MCU Pin number of Flat Cable SW_1 Port C V_{CC} **GND** '0' output PC0 PORTCO PC1 SW_5 PC2 PC3 Pull up Resistor R PINC4 PC4 PC5 PC6 SW_7 SW_8 Internal Pull PC4 PC7 up Resistor SW_1 V_{CC} SW_0 PC0 Basic input circuit of Pushbutton switch


- Testing the digital logic value of a specified bit in a byte data
 - Applying mask ON or mask OFF Operation
 - For example, in order to identify the status of SW_1 in this practice we should test the value of bit 4 of PINC register to which the Input side of the SW_1 switch is connected
 - Applying mask ON Operation to the PINC register using OR operation

$$if(PINC \mid 0xEF) == 0xEF) ----;$$

Applying mask OFF Operation to the PINC register using AND operation

```
if(PINC & 0x10)==0x00) ----;
if(!(PINC & 0x10) ----;
```

Hardware construction – adding Keypad to PORTC



- Programming Algorithm
 - Straightforward!
- A new technique used in this program
 - Using shift operator to create Masks for Mask ON or OFF
 - Examples
 - To set bit 5 of DDRB register(Mask ON), use
 DDRB |= 1<<5; instead of DDRB |= 0x20;
 - To clear bit 5 of DDRB register(Mask OFF), use PORTB &= \sim (1<<5); instead of PORTB &= 0xDF; // more easier

Program Source Code: ex3-3.c

```
#include <avr/io.h>
int main(void) {
  // LED 출력 포트 설정
  // LED가 연결된 포트 A 전체를 출력으로 설정
  DDRA = 0xFF;
  // SW 1 스위치의 접지 쪽 단자 설정
  // 포트 C의 비트 0 핀(PC0)를 출력으로 설정
  DDRC | = 1 << 0;
  // PC0 핀에 '0'을 출력시켜 SW 1 스위치의 한쪽을 접지 시킨다.
  PORTC \&= \sim (1 << 0);
  // SW 1 스위치의 입력 쪽 단자 설정
  // 포트 C의 비트 4 핀(PC4)을 입력으로 설정
  DDRC &= ~(1<<4); // PC4 핀은 SW_1 스위치의 다른 쪽에 연결되어 있음
```

```
// 포트 C의 비트 4 핀(PC4)에 대한 내부 풀업 저항 활성화
PORTC |= 1<<4;
while(1) { // 다음의 과정을 무한히 반복하게 한다
    // SW_1 스위치가 눌러졌으면 LED 8개를 모두 점등한다
    if(!(PINC & (1<<4))) PORTA = 0xFF;
    // SW_1이 눌러져 있지 않으면 LED를 모두 소등한다
    else PORTA = 0x00;
} // while 루프의 끝
    // 프로그램 끝
```


Goal of the Practice

- When Power is turned on, leftmost LED will be lit
- Afterwards, whenever a specified switch is pressed LED light moves one position to the right
- If LED light reaches to the rightmost place then LED light will move to the leftmost position again by the next switch press and repeat above process infinitely

Necessary Techniques and Programming Algorithms

- Necessary Techniques
 - In order to move LED light one position to the right with every switch press you should output a sequence of binary data to Port A as follows;
 00000001, 00000010, 00000100, 00001000, 00010000, 00100000, 01000000, 10000000
 - To do this we can use "shift left" operator '<<'
 - > To understand the relationship between the binary sequence and LED light movement direction, examine the arrangement of LEDs in the assembled circuit on the breadboard

Programming Algorithm 1 – Problem Introduction




Program Source Code: ex3-4-1.c

```
#include <avr/io.h>
int main(void) {
  unsigned char LED_Data;
  // LED 출력 포트 설정
  // LED가 연결된 포트 A 전체를 출력으로 설정
  DDRA = 0xFF;
  // SW_1 스위치의 접지쪽 단자 설정
  // 포트 C의 비트 0 핀(PC0)를 출력으로 설정
  DDRC | = 1 << 0;
  // PC0 핀에 '0'을 출력시켜 SW 1 스위치의 한쪽을 접지 시킨다.
  PORTC \&= \sim (1 << 0);
```

```
// SW_1 스위치의 입력쪽 단자 설정
// 포트 C의 비트 4 핀(PC4)을 입력으로 설정
DDRC &= ~(1<<4); // PC4 핀은 SW 1 스위치의 다른 쪽에 연결되어 있음
// 포트 C의 비트 4 핀(PC4)에 대한 내부 풀업 저항 활성화
PORTC |= 1<<4;
// LED 데이터 초기화
LED_Data = 0x01; // = 00000001<sub>2</sub>, 초기 맨 왼쪽 LED부터 시작
while(1) { // 다음의 과정을 무한히 반복하게 한다
  PORTA = LED_Data;// LED 구동 포트로 데이터를 보내 LED 점등
  // SW 1 스위치가 눌러질 때까지 기다린다.
  while(PINC & (1<<4)); // SW 1이 눌러지지 않으면 계속 루핑
  // SW_1이 눌러졌으면 LED_Data 값을 한 비트 완쪽으로 시프트
  LED_Data <<= 1;
```

```
// 왼쪽으로 완전히 시프트가 되었는지(LED_Data 값이 00000000<sub>2</sub> 인지)
// 검사하여 그렇다면 LED_Data 값을 다시 00000001<sub>2</sub>로 초기화 한다.
if(!LED_Data) LED_Data = 0x01;
} // while 루프의 끝
} // 프로그램 끝
```

Programming Algorithm 2 - First Solution




Program Source Code: ex3-4-2.c

```
#include <avr/io.h>
int main(void) {
  unsigned char LED_Data;
  // LED 출력 포트 설정
  // LED가 연결된 포트 A 전체를 출력으로 설정
  DDRA = 0xFF;
  // SW 1 스위치의 접지쪽 단자 설정
  // 포트 C의 비트 0 핀(PC0)를 출력으로 설정
  DDRC | = 1 << 0;
  // PC0 핀에 '0'을 출력시켜 SW_1 스위치의 한쪽을 접지 시킨다.
  PORTC \&= \sim (1 << 0);
```

```
// SW_1 스위치의 입력쪽 단자 설정
// 포트 C의 비트 4 핀(PC4)을 입력으로 설정
DDRC &= ~(1<<4); // PC4 핀은 SW 1 스위치의 다른 쪽에 연결되어 있음
// 포트 C의 비트 4 핀(PC4)에 대한 내부 풀업 저항 활성화
PORTC |= 1<<4;
// LED 데이터 초기화
LED_Data = 0x01; // = 00000001<sub>2</sub>, 초기 맨 왼쪽 LED부터 시작
while(1) { // 다음의 과정을 무한히 반복하게 한다
  PORTA = LED_Data; // LED 구동 포트로 데이터를 보내 LED 점등
  while(!(PINC & (1<<4))); // SW 1 스위치가 떨어질 때까지 기다린다.
  while(PINC & (1<<4)); // SW_1 스위치가 다시 눌러질 때까지 기다린다.
  LED_Data <<= 1; // LED_Data 값을 한 비트 왼쪽으로 시프트
```

```
// 왼쪽으로 완전히 시프트가 되었는지(LED_Data 값이 00000000<sub>2</sub> 인지)
// 검사하여 그렇다면 LED_Data 값을 다시 00000001<sub>2</sub>로 초기화 한다.
if(!LED_Data) LED_Data = 0x01;
} // while 루프의 끝
} // 프로그램 끝
```


- Programming Algorithm 3 Second Solution: Complete Solution
 - Bouncing



Debouncing

Techniques for eliminate bounces and generate only one pulse for one press of a switch -> can be done by Hardware or Software


- Software Debouncing
 - Debouncing should be done at both of press and release



(a) Debouncing for Switch Press

(b) Debouncing for Switch Release

Final Algorithm 3 with Switch Debouncing



Program Source Code: ex3-4-3.c
#include " / / /inc/ex h"

```
#include "../../inc/ex.h"
#define DEBOUNCING_TIME 20 // 디바운싱 시간 20ms
int main(void) {
  unsigned char LED_Data;
  // LED 출력 포트 설정
  // LED가 연결된 포트 A 전체를 출력으로 설정
  DDRA = 0xFF:
  // SW 1 스위치의 접지쪽 단자 설정
  // 포트 C의 비트 0 핀(PC0)를 출력으로 설정
  DDRC |= 1<<0;
  // PC0 핀에 '0'을 출력시켜 SW_1 스위치의 한쪽을 접지 시킨다.
  PORTC \&= \sim (1 << 0);
```

```
// SW_1 스위치의 입력쪽 단자 설정
// 포트 A의 비트 4 핀(PC4)을 입력으로 설정
DDRC &= ~(1<<4); // PC4 핀은 SW 1 스위치의 다른 쪽에 연결되어 있음
// 포트 C의 비트 4 핀(PC4)에 대한 내부 풀업 저항 활성화
PORTC |= 1<<4;
// LED 데이터 초기화
LED_Data = 0x01; // = 00000001<sub>2</sub>, 초기 맨 왼쪽 LED부터 시작
while(1) { // 다음의 과정을 무한히 반복하게 한다
  PORTA = LED_Data; // LED 구동 포트로 데이터를 보내 LED 점등
  while(1) { // SW 1 스위치 누름이 해제될 때까지 루핑
    if(!(PINC & (1<<4))) continue; // 눌러져 있으면 떨어질 때까지 기다림
    // 버튼스위치가 떨어지고 난 후 바운싱이 종료될 때까지 기다린다.
    _delay_ms(DEBOUNCING_TIME);
    // 바운싱 종료 후 다시 스위치의 상태 확인
```

```
if(!(PINC & (1<<4))) continue; // 아직 스위치가 눌러져 있는 상태면
                         // noise 입력으로 간주하고 다시 while
                         // 루프를 반복하며 버튼 해제를 기다림
  else break; // 디바운싱 시간 경과 후 버튼 해제가 안정적으로 유지되고
           // 있으면 while 루프를 빠져 나가 다음 프로세스로 진행
} // 내부 while 루프 끝
while(1) { // SW_1 스위치가 눌러질 때까지 루핑
  if(PINC & (1<<4)) continue; // SW_1 스위치가 눌러질 때까지 기다림
           // 스위치가 눌러지고 난 후 바운싱이 종료될 때까지 기다린다.
  _delay_ms(DEBOUNCING_TIME);
  // 바운싱 종료 후 다시 스위치의 상태 확인
  if(PINC & (1<<4)) continue; // 이 때 스위치가 해제된 상태이면 noise
                       // noise 입력으로 간주하고 다시 while
                       // 루프를 반복하며 버튼 누름을 기다린다.
  else break; // 디바운싱 시간 경과 후 버튼 누름이 안정적으로 유지되고
           // 있으면 while 루프를 빠져 나가 다음 프로세스로 진행
 // 내부 while 루프 끝
```

```
LED_Data <<= 1; // LED_Data 값을 한 비트 왼쪽으로 시프트

// 왼쪽으로 완전히 시프트가 되었는지(LED_Data 값이 000000002 인지)

// 검사하여 그렇다면 LED_Data 값을 다시 000000012로 초기화 한다.

if(!LED_Data) LED_Data = 0x01;
} // while 루프의 끝
```