

Nagravision SA 22, route de Genève CH-1033 Cheseaux Switzerland www.nagravision.com

# **SMS GATEWAY INTERFACE**

# **Test Strategy**





#### **Introduction**

## **Integration Service**

- Documentation and Training
- Business Model and Command matrix
- Remote access tests
- Site acceptance test (SAT)

#### **Contact**

- Fabiano Galimberti +41 21 732 03 96
- fabiano.galimberti@nagra.com





## **Introduction**


# **Terminology**

- SMS
- SMS connector
- SMS gateway
- CAS
- Terminal STB IRD Decoder
- Smartcard



## **Introduction**

## **End-to-end system view**







#### **Test Phases**

#### **Phase 1 – Unitary test**

- Low-level mechanism (i.e. device-IO)
- Cmd data structure
- Transaction Number

#### Phase 2 - Matrix compliance test


- Functions of command matrix
- Stimulus come from real SMS agent console
- Multiplex of 3 end-users





## **Test Phases**

## **Phase 1 - Unitary test**








## **Test Phases**

## **Phase 2 - Command matrix compliance test**








## **Test Plan**

#### **Protocol**





## **NAGRAVISION**

#### **Test Plan**

### **Keep alive command (cmd-1002)**

- Is first command while interface is opened
- Is sent every "n" sec (n is typically 60 sec)
- Is SMS-source-id, MOP a flexible setting in SMS connector

#### **Transaction numbers (T.N.)**

- Uniqueness of T.N.
- Persistency of T.N.

### **Channel activity**

- Asynchronous
- SMS should send cmd without waiting ACK/NACK



## **NAGRAVISION**

#### **Test Plan**

#### **Command matrix**

- Run realistic scenarios with 3 subscribers (i.e. 3 UA)
- Multiplex "functions" of the command matrix
  - 1. Init subscriber A (sub-A)
  - 2. Add Prod-1 and Prod-2 to sub-A
  - 3. Init sub-B
  - 4. Add Prod-2 to sub-B
  - 5. Cancel Prod-2 of sub-A
  - 6. Init sub-C
  - 7. Add Prod-1 and Prod-3 to sub-C
  - 8. Suspend sub-B
  - 9. Add Prod-3 to sub-A
  - 10. etc...



## **NAGRAVISION**

#### **Test Plan**

#### **Problem while SMS opens interface**

 If any problem occurs while SMS interface is opened, the SMS connector must close and reset the socket. Then the SMS connector retries following Device-IO protocol.

#### **Errors**

- Error are reported as a 1001 cmd (NACK)
- If Error occurs, then SMS connector shall raise an alarm to the SMS monitoring tool.
- The interface can continue to operate even though error occurs.
- If error is due to NACK-POSTPONED, the SMS shall send again the same command but the T.N. must be a new one





#### **Test Plan**

## **Data-flow handling - Stress test**

- Any out-going cmd → Counter decrements
- Any in cmd (ACK/NACK) → Counter increments
- Condition to send a cmd → Counter > 0





## **Test Plan**

## **Loading IMS-Product-id into SMS**

- Subscription
- PPV





# **Accessing Test Lab**

#### What is the remote access

- Dial in connection over phone line
- Test slot with booking
- Real time support during test slot





## **Accessing Test Lab**

