
### MultiWii 1.8 Stick Configuration Mode 2

**Motor Arm** 









Motor Arm on TRI












Motor Disarm on TRI








Calibration Stable ACC

(disarm Motor first)







### Start/Stop Auto-







## Telemetry-Mode

LCD – Configuration Mode

(disarm Motor first) Enter









Select Param

Change Value





Save and Exit





Exit without Save





To view a copy of this license, visit

Unported License.

This work is licensed under the Creative Commons Attribution-NonCommercial-ShareAlike 3.0

http://creativecommons.org/licenses/by-nc-sa/3.0/ or send a letter to Creative Commons, 171 Second Street, Suite 300, San Francisco, California, 94105, USA. A Product made by Hamburger Version 0.57721 (lookup Euler-Mascheroni constant) Document 2011-05-06

### MultiWii 1.8 Stick Configuration Mode 1

**Motor Arm** 





Motor Arm on TRI

**Motor Disarm** 







Motor Disarm on TRI










Calibration Acro Gyro

Calibration Stable ACC (disarm Motor first)





(move right stick from center and back for each click - LED blinks once per click) Trim ACC



Start/Stop Auto-Telemetry-Mode






# LCD – Configuration Mode

(disarm Motor first) Enter















Save and Exit

Exit without Save





This work is licensed under the Creative Commons Attribution-NonCommercial-ShareAlike 3.0

Unported License.

http://creativecommons.org/licenses/by-nc-sa/3.0/ or send a letter to Creative Commons, 171 Second Street, Suite 300, San Francisco, California, 94105, USA. To view a copy of this license, visit

A Product made by Hamburger Version 0.57721 (lookup Euler-Mascheroni constant) Document 2011-05-06

