anticipated loading and associated tankage, including, however, such ballast as may be necessary for stability and/ or immersion. Passenger ship s should include the full complement of passengers and crew on board.

12 Partial subdivision draught (d p) is the light service draught plus 60% of the

---CHUNK---

SOURCE: MSC.216%2882%29.pdf
complement of passengers and crew on board.

12 Partial subdivision draught (d p) is the light service draught plus 60% of the difference between the light service draught and the deepest subdivision draught.

13 Trim is the difference between the draught forward and th e draught aft, where the draughts are measured at the forward and aft terminals respectively, disregarding any rake of keel.

14 Permeability (μ) of a space is the proportion of the immersed volume of that space which can be occupied by water.

15 Machinery spaces are spaces between the wate rtight boundaries of a space containing the main and auxiliary propulsion machinery, including boilers, generators and electric motors primarily intended for propuls ion. In the case of unusual arrangements, the Administration may define the limits of the machinery spaces.

16 Weathertight means that in any sea conditions water will not penetrate into the ship.

---CHUNK---

SOURCE: MSC.216%2882%29.pdf
the Administration may define the limits of the machinery spaces.

16 Weathertight means that in any sea conditions water will not penetrate into the ship.

17 Watertight means having scantlings and arrangements capable of preventing the passage of water in any direction under the h ead of water likely to occur in intact and damaged conditions. In the damaged condition, th e head of water is to be considered in the worst situation at equilibrium, including intermediate stages of flooding.

18 Design pressure means the hydrostatic pressure for which each structure or appliance assumed watertight in the intact and damage stability calculations is designed to withstand.

19 Bulkhead deck in a passenger ship means the uppe rmost deck at any point in the subdivision length (Ls) to which the main bulkheads and the ships shell are carried watertight and the lowermost deck from which passenger and crew evacuation will not be

---CHUNK---

SOURCE: MSC.216%2882%29.pdf
subdivision length (Ls) to which the main bulkheads and the ships shell are carried watertight and the lowermost deck from which passenger and crew evacuation will not be impeded by water in any stage of flooding for damage cases defined in regulation 8 and in

part B-2 of this chapter. The bulkhead deck may be a stepped deck. In a cargo ship the freeboard deck may be taken as the bulkhead deck.

20 Deadweight is the difference in tonnes between the displacement of a ship in water of a specific gravity of 1.025 at the draught corresponding to the assigned summer freeboard and the lightweight of the ship.

21 Lightweight is the displacement of a ship in tonnes without cargo, fuel, lubricating oil, ballast water, fresh water and feedwater in tanks, consumable stores, and passengers and crew and their effects.

---CHUNK---

SOURCE: MSC.216%2882%29.pdf
oil, ballast water, fresh water and feedwater in tanks, consumable stores, and passengers and crew and their effects.

22 Oil tanker is the oil tanker defined in regulat ion 1 of Annex I of the Protocol of 1978 relating to the International Conven tion for the Prevention of Pollution from Ships, 1973.

23 Ro-ro passenger ship means a passenger ship with ro-ro spaces or special category spaces as defined in regulation II-2/3.

24 Bulk carrier means a bulk carrier as defined in regulation XII/1.1.

25 Keel line is a line parallel to the slope of the keel passing amidships through:

.1 the top of the keel at centreline or line of intersection of the inside of shell plating with the keel if a bar keel ex tends below that line, on a ship with a metal shell; or

.2 in wood and composite ships, the distance is measured from the lower edge of the keel rabbet. When the fo rm at the lower part of the midship

---CHUNK---

SOURCE: MSC.216%2882%29.pdf
metal shell; or

.2 in wood and composite ships, the distance is measured from the lower edge of the keel rabbet. When the fo rm at the lower part of the midship section is of a hollow character, or where thick garboards are fitted, the distance is measured from the point where the line of the flat of the bottom continued inward intersects the centreline amidships.

26 Amidship is at the middle of the length (L).

Regulation 3

Definitions relating to parts C, D and E

For the purpose of parts C, D and E, unless expressly provided otherwise:

1 Steering gear control system is the equipment by which orders are transmitted from the navigating bridge to the steering gear power units. Steering gear control systems comprise transmitters, receivers, hydraulic control pumps and their associated motors, motor controllers, piping and cables.

2 Main steering gear is the machinery, rudder actuat ors, steering gear, power units,

---CHUNK---

SOURCE: MSC.216%2882%29.pdf
motor controllers, piping and cables.

2 Main steering gear is the machinery, rudder actuat ors, steering gear, power units, if any, and ancillary equipment and the means of applying torque to the rudder stock (e.g., tiller or quadrant) necessary for effecting movement of the rudder for the purpose of steering the ship under normal service conditions.

3 Steering gear power unit is:

.1 in the case of electric steering gear, an electric motor and its associated electrical equipment;
RESOLUTION MSC.216(82)
(adopted on 8 December 2006)
AMENDMENTS TO THE INTERNATIONAL CONVENTION FOR THE SAFETY OF LIFE AT SEA, 1974, AS AMENDED-16 -

.2 in the case of electrohydraulic st eering gear, an electric motor and its associated electrical equipment and connected pump; or

.3 in the case of other hyd raulic steering gear, a driving engine and connected pump.

4 Auxiliary steering gear is the equipment other than any part of the main steering

---CHUNK---

SOURCE: MSC.216%2882%29.pdf
.3 in the case of other hyd raulic steering gear, a driving engine and connected pump.

4 Auxiliary steering gear is the equipment other than any part of the main steering gear necessary to steer the ship in the event of failure of the main steering gear but not including the tiller, quadrant or components serving the same purpose.

5 Normal operational and habitable condition is a condition under which the ship as a whole, the machinery, services, means and aids ensuring propulsion, ability to steer, safe navigation, fire and flooding safety, in ternal and external communications and signals, means of escape, and emergency boat winches, as well as the designed comfortable conditions of habitability are in working order and functioning normally.

6 Emergency condition is a condition under which any services needed for normal operational and habitable conditions are not in working order due to failure of the main source of electrical power.

---CHUNK---

SOURCE: MSC.216%2882%29.pdf
operational and habitable conditions are not in working order due to failure of the main source of electrical power.

7 Main source of electrical power is a source intended to supply electrical power to the main switchboard for distribution to all serv ices necessary for maintaining the ship in normal operational and habitable conditions.

8 Dead ship condition is the condition under which the main propulsion plant, boilers and auxiliaries are not in operation due to the absence of power.

9 Main generating station is the space in which the ma in source of electrical power is situated.

10 Main switchboard is a switchboard which is direc tly supplied by the main source of electrical power and is intended to distribute electrical energy to the ships services.

11 Emergency switchboard is a switchboard which in the event of failure of the main