S I 4.8.6 I Bilge valve indicator I II-1121.2.12"' I
I I I
S I 4.9.8 I Ballast valve position I I
I I indicator I
I I I s I 4.11.11- I Cable tension Windlass power I I
I I Amount of cable paid out I
I I I
I I I
Cross reference to SOLAS regulation
W/1649n/EWP
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.1
ANNEX 23
Page 6
Add the following to Table 9.1.4 (continued)
- Location: at the equipment or at the location being monitored
lMO
Pri ority Instrument Function Type Notes
Diving Code
P 2.5.3 Diving bell internal pressure MI ! At the location of the
attendant monitoring
diving operations
p 2.5.5 Diving bell etc. overpressure A,V ! At the location of the
alarm attendant monitoring
diving operations
P 2.9.3 Diving equipment fire A,V ! At the location of the
detection alarm attendant monitoring
diving operations

---CHUNK---

SOURCE: MSC.39(63).pdf
p 2.5.5 Diving bell etc. overpressure A,V ! At the location of the
alarm attendant monitoring
diving operations
P 2.9.3 Diving equipment fire A,V ! At the location of the
detection alarm attendant monitoring
diving operations
B Add the following to Table 9.1.5 - Location: engineers' accommodation
I I
I lMO I
Priority I Instrument Function Type I Notes
I I
I I
I 1989 MODU I
I Code I
I I
P I 7.8 Engineers' alarm A I Column 4, table 8.3
I I II-l/38"'
I I
P I 8.7.1 Fault requiring attention A I Activate engineers' alarm
I I required by 7.8 includingl

I I 8.3.5.1,8.4.1,8.8.6 I
I I and 8.9 I
I I 11-1/51.1.5" I
I I I
I I I
Cross reference to SOLAS regulation
W/1649n/EWP
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.l
ANNEX 23
Page 7
9 Add the following to Table 9 . 1 . 6 - Location: miscellaneous
I I
IMO I I
Pdori ty Instrument Function I Type Notes I
I I
I I
1989 HODU I I
Code I I
I I
S 3.6.2 Watertight boundary valve I I At the remote control I
position indicator I station I
I I
P 4. 3.2 Oil-fired boiler low water I A,V Alarm at an attended I

---CHUNK---

SOURCE: MSC.39(63).pdf
I I
I I
1989 HODU I I
Code I I
I I
S 3.6.2 Watertight boundary valve I I At the remote control I
position indicator I station I
I I
P 4. 3.2 Oil-fired boiler low water I A,V Alarm at an attended I
level, air supply failure I location I
or flame fail ure I II-1/32.2"' I
I I
S 4.8.1 Presence of water indicator I I I
I I
S 4.11.12 Cable tension speed and I I At a manned station I
direction of wind I
I
s I 6.3.1.1.3 Loss of ventilation A,V At a manned station I
I I
s I 6.3.1.2.3 Loss of ventilation A,V At a manned station I
I I
s I 6.3.1.3.3 Loss of ventilation A,V At a manned station I
I overpressure I
I I

p I 8.7.1 Fault requiring attention A,V Including 8.3.5.1, I
I 8.4.1,8.8.6 and 8.9 I
I II-l/Sl.1"' I
I I
P I 9.7.1 Fire detection system alarm A,V I At alarm location
I I easily accessible to
I I crew at all times
I I II-2!l3.1 .6"'
I I
EM I 9.7.1 Fire detection alarm not A I Alarmed to crew,
receiving attention I may be part of general
I emergency alarm
I II-2!l3.1.4"'
I
P 9.8 Gas detection and alarm A,V I ! Alarm at a location
system I easily accessible to
1 crew at all times
I

---CHUNK---

SOURCE: MSC.39(63).pdf
receiving attention I may be part of general
I emergency alarm
I II-2!l3.1.4"'
I
P 9.8 Gas detection and alarm A,V I ! Alarm at a location
system I easily accessible to
1 crew at all times
I
EM 10 . 16. 1 . General emergency alarm A I Clearly perceptible inl
I all parts of the unit I
I lll/6.4.2"' I
I III/50"' I
I I
Cross reference to SOLAS regulation
W/1649n/EWP
RESOLUTION MSC.39(63)
(adopted on 19 May 1994)
ADOPTION OF AMENDMENTS TO THE CODE ON
ALARMS AND INDICATORS MSC 63/23/Add.l
ANNEX 23
Page 8
Add the following to Table 9.1.6 (continued) - Location: miscellaneous
IMO I
Priority Instrument Function I Type Notes
I
I
Diving Code I
I
P 2.5.2 Compression chamber internal I HI At central control position
pressure I
I
P 2.5.3 Diving bell external I MI Within the bell

pressure I
I
P 2.9.3 Diving equipment fire I A,V ! At an attended location
detection alarm I other than the above
I
I
P 2. 11 . 2 Compression chamber/diving I MI At central control position
bell parameters I
I
P 2.11.3 Diving bell oxygen I MI Within the bell
and C02 levels I
I
10 Add the following to Table 9.1.8 - Location: not indicated by IMO
instruments
IMO

---CHUNK---

SOURCE: MSC.39(63).pdf
bell parameters I
I
P 2.11.3 Diving bell oxygen I MI Within the bell
and C02 levels I