Key
1 Waist belt (1,867 mm) attachment to out side of back cover and inside cover (see figure A.12)
2 Zipper (440 mm) attachment
3 Interior fabric retainer attachment to inside front cover
4 Interior fabric retainer attachment to centre of inside front cover
5 Belt loop webbing (89 mm) attachment to outside of cover
6 Dart

Figure A.13 – Attachments to inside cover
RESOLUTION MSC.200(80)
(adopted on 13 May 2005)
ADOPTION OF AMENDMENTS TO THE REVISED
RECOMMENDATION ON TESTING OF
LIFE-SAVING APPLIANCESMSC 80/24/Add.1
ANNEX 17
Page 33

---CHUNK---

SOURCE: MSC.200(80).pdf
6 Dart

Figure A.13 – Attachments to inside cover
RESOLUTION MSC.200(80)
(adopted on 13 May 2005)
ADOPTION OF AMENDMENTS TO THE REVISED
RECOMMENDATION ON TESTING OF
LIFE-SAVING APPLIANCESMSC 80/24/Add.1
ANNEX 17
Page 33

I:\MSC\80\24-ADD-1.DOC

Key
1 Collar webbing (1,384 mm) attachment on the outside of the inner cover with reinforcement fabric inside
2 Zipper (280 mm) attachment to the outer and inner covers

Figure A.14 – Attachments to outer and inside collar cover

APPENDIX

RTD Serial number: _____

ADULT REFERENCE TEST DEVICE – BUOYANCY TRACKING AND VERIFICATION

To achieve repeatability in human subject testing, the overall buoyancy and distribution of buoyancy between the front and back of th e RTD must be maintained within a tight tolerance as specified in Table 1.

Table 1 SOLAS adult RTD buoyancy and tolerance

Limit / Units Front
buoyancy1 Back buoyancy Total buoyancy Buoyancy distribution2

---CHUNK---

SOURCE: MSC.200(80).pdf
tolerance as specified in Table 1.

Table 1 SOLAS adult RTD buoyancy and tolerance

Limit / Units Front
buoyancy1 Back buoyancy Total buoyancy Buoyancy distribution2
Design / N 103.5 46.5 150 69% in front
Maximum / N 107 48 155 70.5% in front
Minimum / N 100 45 145 67.5% in front
1 Values at or corrected to standard temperature and pressure.
2 Buoyancy distribution is calculated by dividing the front buoyancy by the total buoyancy.

The buoyancy of a new RTD may exceed the al lowable tolerance range until the normal shrinkage or compression of the foam inserts stabilizes. Until the buoyancies of the foam inserts have stabilized, buoyancy and distribut ion should be checked at regular intervals (perhaps weekly), and then at least monthly thereafter or whenever used for testing, whichever is longer (frequent use may require more frequent checks). Only RTDs with buoyancies within tolerance should be used fo r certification testing. A data sheet to document the buoyancy and buoyancy distribution of the RTD is attached.

Adjustment of buoyancy: At the time of manufacture th e left-to-right distribution of

---CHUNK---

SOURCE: MSC.200(80).pdf
document the buoyancy and buoyancy distribution of the RTD is attached.

Adjustment of buoyancy: At the time of manufacture th e left-to-right distribution of buoyancy in the front inserts was adjusted to be within 1.3 N of each other. To achieve

this tolerance, thin layers of foam (“make- up” inserts) may have been inserted between the front and inside front foam inserts. Th e test house may need to increase the size of these make-up inserts from time to time to keep these parameters within tolerance, or may need to add buoyancy to the back or collar inserts (or trim buoyancy, if the back insert has not shrunk as anticipated). Figure 2 provides guidance for sizing of make-up inserts to adjust buoyancy. After a full sheet of 6.5 mm thick foam is required in any one of the four major areas, an inside front or back insert probably needs to be replaced. If the front buoyancy is under the minimum value, measure the buoyancy of the right and left sides so that the proper distribution of buoyancy (no more than a 1.3 N difference) between the right and left front panels can be maintained.

Table 2 – SOLAS adult RTD insert design buoyancies
Combined left front

---CHUNK---

SOURCE: MSC.200(80).pdf
so that the proper distribution of buoyancy (no more than a 1.3 N difference) between the right and left front panels can be maintained.

Table 2 – SOLAS adult RTD insert design buoyancies
Combined left front
and inside front 1 Combined right front and inside front 1 Back Collar
Design (N) 34 + 17.75 = 51.75 34 + 17.75 = 51.75 18.5 28
S/N ____
Date:

1 Plus make-up inserts, if used.


RTD BUOYANCY DATA SHEET

RTD Serial number/identification: _____

Date Left front
buoyancy
(N)
Right
front
buoyancy
(N)
Total
front
buoyancy
(N)
Total

| | | |
|---|---|---|
| back buoyancy (N) | | |
| Total buoyancy (N) | | |
| Buoyancy distribution (% in front) | | |
| Remarks | | |
| | (1) | (2) |