SOURCE: MSC.252(83).pdf
configuration that is fitted to the ship.

2 On-board familiarization training for INS

2.1 The aim of familiarization training is to e xplain the configurati on, functions, limitations, controls, displays, alerts and indications of the specifically installed INS.

2.2 It should allow an OOW, unfamiliar with the ship's equipment but trained in the generic use of INS, to become rapidly acquainted with the installed system.

2.3 Emphasis should be given on producing effec tive familiarization training that can be completed in the shortest possible time. This wi ll help maximize the probabi lity that the process will be properly completed.

2.4 For a typical system it may be expected that it will take no longer than 30 minutes for a qualified user to undertake INS familiarization training. This time does not include the time taken to become familiar with major interconnected functionality, such as radar and ECDIS.

2.5 Familiarization can take a number of forms. The following are illustrative examples but other effective methods of training are acceptable:

computer-based training on the ship. Such training may also be appropriate to be

---CHUNK---

SOURCE: MSC.252(83).pdf
2.5 Familiarization can take a number of forms. The following are illustrative examples but other effective methods of training are acceptable:

computer-based training on the ship. Such training may also be appropriate to be used remotely (e.g., on a notebook computer of a new user, prior to joining the ship)
a training mode on the fitted INS
RESOLUTION MSC.252(83)
(adopted on 8 October 2007)
ADOPTION OF THE REVISED PERFORMANCE STANDARDS FOR INTEGRATED NAVIGATION SYSTEMS (INS)MSC 83/28/Add.3
ANNEX 30
Page 39

I:\MSC\83\28-Add-3.doc

a training video (on tape, disk or solid state memory), supported by a self-training manual
a stand-alone self-training manual.

2.6 The topics that need to be covere d are listed in section 3 below.

2.7 The functions of the INS should be broken down into logical top-down descriptions.

2.8 The familiarization material does not repla ce the User Instruction Manual. Appropriate references can be made to it from within the ma terial. This may be beneficial when describing more detailed operations or to reference large diagrams.

---CHUNK---

SOURCE: MSC.252(83).pdf
2.8 The familiarization material does not repla ce the User Instruction Manual. Appropriate references can be made to it from within the ma terial. This may be beneficial when describing more detailed operations or to reference large diagrams.

2.9 For lesser used, non-critical f unctions it is only necessary to reference the relevant section in the User Instruction Manual, rather than them having to be included in their entirety in the familiarization material. Ideally, material is provid ed for such functions but with instructions to enable the user to skip these sections, as appropriate, until a more convenient opportunity.

2.10 Familiarization is best given within the c ontext of the ship's normal bridge operating procedures. These procedures are normally cont ained within the Ship Operating Manual or equivalent document.

3 Familiarization training framework

3.1 General description

3.1.1 This should start with a top- level functionality description including the identification of the types of automatic control that are provided (if any).

3.1.2 A description should be given of the connected equipment that forms the INS, to a level

---CHUNK---

SOURCE: MSC.252(83).pdf
the types of automatic control that are provided (if any).

3.1.2 A description should be given of the connected equipment that forms the INS, to a level that a normal user would require for operation (not maintenance). This description could be in the form of a block diagram.

3.1.3 The general philosophy of operation should be explained, including a description of the human machine interfaces. If automatic modes of operation are provided a general description of these is also required.

3.1.4 The physical location of all workstations a nd other displays and controls should be identified.

3.1.5 A description of the CCRS a nd identification of the CCRS (s) should be given. If more than one point is defined, the intended use of all individual reference points should be given, together with an explanation of how a point is selected and indicated.

3.1.6 For all navigation parameters the manua l and/or automatic backup and fall-back sequences when sensors become inoperable should be explained.

3.1.7 Instructions on setting basic display controls such as brig htness, contrast, colour and day/night colour schemes should be given.
RESOLUTION MSC.252(83)

---CHUNK---

SOURCE: MSC.252(83).pdf
sequences when sensors become inoperable should be explained.

3.1.7 Instructions on setting basic display controls such as brig htness, contrast, colour and day/night colour schemes should be given.
RESOLUTION MSC.252(83)
(adopted on 8 October 2007)
ADOPTION OF THE REVISED PERFORMANCE STANDARDS FOR
INTEGRATED NAVIGATION SYSTEMS (INS)MSC 83/28/Add.3
ANNEX 30
Page 40

I:\MSC\83\28-Add-3.doc
3.2 Detailed operation (normal conditions)

3.2.1 The functions described should include all sy stems and subsystems that are part of the INS and any ship's functionality that can be controlled through the INS, such as the:

- navigation subsystems
- steering controls
- propulsion controls

3.2.2 Depending on the type of INS fitted, the followi ng specific information should be given:

- detailed operation of the automatic cont rols that are included, such as track controller functions
- the method(s) used to switch between operating modes and how to revert to manual operation
- the method of accessing the main/top-level display of all workstations and other INS equipment, including inst ructions to rapidly revert to such a display from

---CHUNK---

SOURCE: MSC.252(83).pdf
operation
- the method of accessing the main/top-level display of all workstations and other INS equipment, including inst ructions to rapidly revert to such a display from whatever configuration has been set previously
- description of the displayed informati on on non-controllable displays, (if included within the installed configuration), e.g., a basic conning display
- the route planning and checking functions that are available
- the route monitoring functions that are available
- the operation of the Bridge navigational watch alarm facility, if fitted.

3.2.3 Where appropriate, for each function, the fo llowing information should be included:

- function name
- function description
- description of menu structure and displayed information
- description of operator controls
- required manually input information, if any
- description of how to configure task stations and user-modifiable displays and other data to user preferences. The method to rapidly revert to 'sensible' defaults must be

given, even if it is considered that user configurations are not essential functions that need to be included as part of the familiarization material

---CHUNK---

SOURCE: MSC.252(83).pdf
data to user preferences. The method to rapidly revert to ‘sensible’ defaults must be given, even if it is considered that user configurations are not essential functions that need to be included as part of the familiarization material
 description of alerts and indicators, including mode indication. Procedural action on receiving alarms and warnings is covered in section 3.3
 the access of latency, integrity and accuracy data.

3.3 Detailed operation (abnormal and emergency conditions)

3.3.1 The following information should be included:

 details of conditions in which any automatic mode should not be used or should be used with certain restrictions or cautions
 identification of major failure alarms and warnings
 procedures involving the INS to follow on encountering alarms and warnings, other major failures, incidents or accidents, including: