If no reactive
cleaning is
performed prior to
departure, a reactive
cleaning activity
should be scheduled
at earliest possible
opportunity.
If no reactive
cleaning is
performed, an
acceptance could be
required to arrive in
the next port.
Contact next port for
further advice.>

---CHUNK---

SOURCE: MEPC.378(80).pdf
departure, a reactive
cleaning activity
should be scheduled
at earliest possible
opportunity.
If no reactive
cleaning is
performed, an
acceptance could be
required to arrive in
the next port.
Contact next port for
further advice.>
<EXAMPLE>
<More frequent
reactive cleaning
may be necessary
actions for proper
biofouling
management.
Evaluate the need to
update the cleaning
schedule.>
<EXAMPLE>
<Extended ship idle
time (berthed,
anchored, moored)>
<EXAMPLE>
<If the idle time is
longer than estimated
in the ship's operating
profile, it could lead to
<EXAMPLE>
<If the idle time is

within the guarantee
of the AFS supplier,
a short voyage with
speed as specified
for the AFS could be
EXAMPLE>
<Evaluate the need
for a potential
improvement of the
AFS selection prior

Biofouling risk
parameters to
monitor
Evaluation of a
deviation including
deviation limit of the
risk parameter
Contingency

---CHUNK---

SOURCE: MEPC.378(80).pdf
Annex 17, page 51

I:\MEPC\80\MEPC 80-17-Add.1.docx
Biofouling risk
parameters to
monitor
Evaluation of a
deviation including
deviation limit of the
risk parameter
Contingency
actions
Long-term actions
an elevated risk of
biofouling.
If the idle time is
beyond the guarantee
of the AFS supplier,
the risk of biofouling
accumulation
increases.
The risk also depends
on biofouling
pressure, e.g.

temperature and
distance to the
coastline. If the ship is
idle in an area far
from shore (>200 nm
and >200 m depth)
and far from other
installations, the risk
may still be
considered low.>
conducted, sea
chests could be
blanked off or, when
recommended by the
AFS manufacturer,
more frequent
proactive cleaning
activities could be
implemented.
If the idle time is
beyond the
guarantee of the
AFS supplier, an
inspection should be
carried out.>
to the next
dry-docking.>
<EXAMPLE>
<Performance loss as
per Performance
Monitoring System>
<EXAMPLE>
<Performance
monitoring may detect
biofouling growth on
the hull, but not
necessarily in niche
areas.
Performance
monitoring of fuel
consumption may
give indication on
possible biofouling

---CHUNK---

SOURCE: MEPC.378(80).pdf
per Performance
Monitoring System>
<EXAMPLE>
<Performance
monitoring may detect
biofouling growth on
the hull, but not

necessarily in niche areas.
Performance monitoring of fuel consumption may give indication on possible biofouling accumulation on the hull and may include the following methods:
.1 Sensors and collecting high-frequency data.
.2 Semi-automatic or manual
<EXAMPLE>
<When the data show a trend in performance loss over time, the time