satisfactory to a standard*, in
respect of strength and fire integrity having regard to the
* Refer to Guidelines for materials other than steel for pipes adopted by the Organization by resolution A.753(18).
W/1576n/pp/EWP
RESOLUTION MSC.36(63)
(adopted on 20 May 1994)
ADOPTION OF THE INTERNATIONAL CODE OF SAFETY
FOR HIGH SPEED CRAFT 7.5.5
7.5.6
MSC 63/23/Add.2
ANNEX 18
Page 63
service pressure and the spaces in which they are installed.
Wherever practicable, the use of flexible pipes should be avoided.
Pipes, valves and couplings conveying flammable fluids should be
arranged as far from hot surfaces or air intakes of engine
installations, electrical appliances and other potential sources of
ignition as is practicable and be located or shielded so that the
---CHUNK---
SOURCE: MSC.36(63).pdf
arranged as far from hot surfaces or air intakes of engine
installations, electrical appliances and other potential sources of
ignition as is practicable and be located or shielded so that the
likelihood of fluid leakage coming into contact with such sources of
ignition is kept to a minimum.
Fuel with a flashpoint below 35°C should not be used. In every
craft in which fuel with a flashpoint below 43°C is used, the
arrangements for the storage, distribution and utilization of the
fuel should be such that, having regard to the hazard of fire and
explosion which the use of such fuel may entail, the safety of the
craft and of persons on board is preserved. The arrangements should
comply, in addition to the requirements of 7.5.1 to 7.5.5, with the
following provisions:
.1 tanks for the storage of such fuel should be located outside
any machinery space and at a distance of not less than 760 mm
inboard from the shell side and bottom plating, and from decks
and bulkheads;
.2 arrangements should be made to prevent overpressure in any
fuel tank or in any part of the oil fuel system, including the
filling pipes. Any relief valves and air or overflow pipes
---CHUNK---
SOURCE: MSC.36(63).pdf
and bulkheads;
.2 arrangements should be made to prevent overpressure in any
fuel tank or in any part of the oil fuel system, including the
filling pipes. Any relief valves and air or overflow pipes
should discharge to a position which, in the opinion of the
Administration, is safe;
.3 the spaces in which fuel tanks are located should be
mechanically ventilated using exhaust fans providing not less
than six air changes per hour. The fans should be such as to
avoid the possibility of ignition of flammable gas air
mixtures. Suitable wire mesh guards should be fitted over
inlet and outlet ventilation openings. The outlets for such
exhausts should be discharged to a position which, in the
opinion of the Administration, is safe. 'No Smoking' signs
should be posted at the entrances to such spaces;
.4 earthed electrical distribution systems should not be used,
with the exception of earthed intrinsically safe circuits;
.5 suitable certified safe type* electrical equipment should be
used in all spaces where fuel leakage could occur including
ventilation system. Only electrical equipment and fittings
essential for operational purposes should be fitted in such
spaces;
---CHUNK---
SOURCE: MSC.36(63).pdf
used in all spaces where fuel leakage could occur including
ventilation system. Only electrical equipment and fittings
essential for operational purposes should be fitted in such
spaces;
Refer to the Recommendations published by the International Electrotechnical Commission and, in particular, publication 92 - Electrical installations in ships.
W/1576n/pp/EWP
RESOLUTION MSC.36(63)
(adopted on 20 May 1994)

.6 a fixed vapour detection system should be installed in each space through which fuel lines pass, with alarms provided at the continuously manned control station;
.7 every fuel tank should, where