nversion factor for fuel oil type
, in line with those specified in the 2018 Guidelines on the method of
calculation of the attained Energy Efficiency Design Index (EEDI) for new ships
(resolution MEPC.308(73)), as may be further amended. In case the type of the
---CHUNK---
SOURCE: MEPC.336%2876%29.pdf
calculation of the attained Energy Efficiency Design Index (EEDI) for new ships
(resolution MEPC.308(73)), as may be further amended. In case the type of the
fuel oil is not covered by the guidelines, the conversion factor should be obtained
from the fuel oil supplier supported by documentary evidence.
4.2 Transport work (W)
In the absence of the data on actual transport work, the supply-based transport work (Ws) can
be taken as a proxy, which is defined as the product of a ship ■s capacity and the distance
travelled in a given calendar year, as follows:
Ws= C×Dt (3)
where:
■ C represents the ship■s capacity:
- For bulk carriers, tankers, container ships, gas carriers, LNG carriers, ro- ro
cargo ships, general cargo ships, refrigerated cargo carrier and combination
carriers, deadweight tonnage (DWT)1 should be used as Capacity;
- For cruise passenger ships, ro- ro cargo ships (vehicle carriers) and ro- ro
---CHUNK---
SOURCE: MEPC.336%2876%29.pdf
carriers, deadweight tonnage (DWT)1 should be used as Capacity;
- For cruise passenger ships, ro- ro cargo ships (vehicle carriers) and ro- ro
passenger ships, gross tonnage (GT)2 should be used as Capacity; and
■ Dt represents the total distance travelled (in nautical miles), as reported under
IMO DCS.
1 Deadweight tonnage (DWT) means the difference in tonnes between the displacement of a ship i
n water of
relative density of 1,025 kg/m3 at the summer load draught and the lightweight of the ship. The
summer load
draught should be taken as the maximum summer draught as certified in the stability booklet app
roved by
the Administration or any organization recognized by it.
2 Gross tonnage (GT) should be calculated in accordance with the International Convention on T
onnage
Measurement of Ships, 1969.
/ shipattained CII M W=
j
jFC j
jFC
j
RESOLUTION MEPC.336(76) (adopted on 17 June 2021)
---CHUNK---
SOURCE: MEPC.336%2876%29.pdf
Measurement of Ships, 1969.
/ shipattained CII M W=
j
jFC j
jFC
j
RESOLUTION MEPC.336(76) (adopted on 17 June 2021)
2021 GUIDELINES ON OPERATIONAL CARBON INTENSITY INDICATORS AND THE CALCULATION METHODS (CII GUI
DELINES, G1)MEPC 76/15/Add.2
Annex 10, page 4
I:\MEPC\76\MEPC 76-15-Add.2.docx
5 Operational carbon intensity indicator (CII) of individual ships for trial purpose
The following metrics are encouraged to be used for trial purposes, where applicable:
.1 Energy Efficiency Performance Indicator (EEPI)
■■■■■■■■ = ■■■■×■■■■
.2 cbDIST
■■■■■■ ■■■■■■ = ■■■■ ■■■■×■■■■
.3 clDIST
■■ ■■■■■■■■■■ = ■■■■■■ ■■■■■■■■■■■■■■■×■■■■
.4 EEOI, as defined in MEPC.1/Circ.684 on Guidelines for voluntary use of the
ship energy efficiency operational indicator (EEOI).
In the formulas above:
• the mass of CO2 (M), the ship■s capacity (C) and the total distance travelled (Dt) are
---CHUNK---
SOURCE: MEPC.336%2876%29.pdf
ship energy efficiency operational indicator (EEOI).
In the formulas above:
• the mass of CO2 (M), the ship■s capacity (C) and the total distance travelled (Dt) are
identical with those used to calculate the attained CII of individual ships, as specified
in section 4.1 and 4.2;
• Dl means the laden distance travelled (in nautical miles) when the ship is loaded;

• ALB means the number of available lower berths of a cruise passenger ship; and
• Lanemeter means the length (in metres) of the lanes of a ro-ro ship.
***
RESOLUTION MEPC.336(76) (adopted on 17 June 2021)
2021 GUIDELINES ON OPERATIONAL CARBON INTENSITY INDICATORS AND THE CALCULATION METHODS (CII GUI DELINES, G1)RESOLUTION MEPC.336(76) (adopted on 17 June 2021)
2021 GUID