.35(63)

(adopted on 20 May 1994)

ADOPTION OF GUIDELINES FOR EMERGENCY

TOWING ARRANGEMENTS ON TANKERS MSC 63/23/Add.l

ANNEX 7

Page 2

1 PURPOSE

ANNEX

GUIDELINES FOR EMERGENCY TOWING

ARRANGEMENTS ON TANKERS

1.1 Under regulation V/15-1 of the 1974 SOLAS Convention, as amended by resolution MSC.31(63) in 1994, new and existing tankers of 20,000 tonnes deadweight and above shall be fitted with an emergency towing arrangement, the design and construction of which shall be approved by the Administration, based on the Guidelines developed by the Organization.

-

the design and construction of which shall be approved by the Administration, based on the Guidelines developed by the Organization.

1.2 The present Guidelines are intended to provide standards for the design and construction of emergency towing arrangements which Administrations are recommended to implement.

1.3 For existing tankers fitted with the emergency towing arrangements in accordance with resolution A.535(13), the existing towing arrangements forward of the ship may be retained, but the towing arrangements aft of the ship should be upgraded to comply with the requirements of the present Guidelines.

2 REQUIREMENTS FOR THE ARRANGEMENTS AND COMPONENTS

2.1 General

The emergency towing arrangements should be so designed as to facilitate salvage and emergency towing operations on tankers primarily to reduce the risk of pollution. The arrangements should at all times be capable of rapid deployment in the absence of main power on the ship to be towed and easy

-

risk of pollution. The arrangements should at all times be capable of rapid deployment in the absence of main power on the ship to be towed and easy connection to the towing vessel. Figure 1 shows arrangements which may be used as reference.

2.2 Towing components

The major components of the towing arrangements should consist of the following:

Forward of ship"' Aft of ship

Pick-up gear

Towing pennant

Chafing gear

Fairlead

Strongpoint
Roller pedestal
optional
optional
Yes
Yes
Yes
Yes
See paragraph 3.1.4.
W/1648n/EWP
Yes
Yes
Depending on design
Yes
Yes
Depending on design
Strength requirements
Yes
Yes
Yes
Yes
RESOLUTION MSC.35(63)
(adopted on 20 May 1994)
ADOPTION OF GUIDELINES FOR EMERGENCY
TOWING ARRANGEMENTS ON TANKERS M6C 63/23/Add.1
ANNEX 7
Page 3
2.3 Strenqth of the towinq components
2.3.1 Towing components as specified in 2.2 for strength should have a
working strength of at least 1,000 kN for tankers of 20,000 tonnes
-
ANNEX 7
Page 3
2.3 Strenqth of the towinq components
2.3.1 Towing components as specified in 2.2 for strength should have a
working strength of at least 1,000 kN for tankers of 20,000 tonnes
deadweight and over but less than 50,000 tonnes deadweight, and at
least 2,000 kN for tankers of 50,000 tonnes deadweight "and over
(working strength is defined as one half ultimate strength). The
strength should be sufficient for all relevant angles of towline,
i.e. up to 90
0
from the ship's centreline to port and starboard and
30 0 vertical downwards.
2.3.2 Other components should have a working strength sufficient to

withstand the load to which such components may be subjected during the towing operation.

2.4 Lenqth of towinq pennant

The towing pennant should have a length of at least twice the lightest seagoing ballast freeboard at the fairlead plus 50 m.

2.5 Location of stronqpoint and fairlead

The bow and stern strongpoint and fairleads should be located so as to

-

seagoing ballast freeboard at the fairlead plus 50 m.

2.5 Location of stronqpoint and fairlead

The bow and stern strongpoint and fairleads should be located so as to facilitate towing from either side of the bow or stern and minimize the stress on the towing system.

2.6 Stronqpoint

The inboard end fastening should be a stopper or bracket or other fitting of equivalent strength. The strongpoint can be designed integral with the fairlead.

2.7 Fairleads

2.7.1 ~

2.7.2

2.7.3

Fairleads should have an opening large enough to pass the larqest portion of the chafing gear, towing pennant or towing line.

Geometry

The fairlead should give adequate support for the towing pennant during towing operation which means bending 90

0

to port and to

starboard side and 30

0

vertical downwards. The bending ratio (towing pennant bearing surface diameter to towing pennant diameter) should be not less than 7 to 1.

Vertical location

-

starboard side and 30

0

vertical downwards. The bending ratio

(towing pennant bearing surface diameter to towing penna