from a storage, settling or daily service tank should be fitted with a cock or valve dir ectly on the tank capable of being closed from a position outside the space concerned in the event of a fire occurring in the space in which such tanks are situated.

7.5.4 Pipes, valves and couplings conveying flammable fluids should be of steel or such alternative material satisfactory to a standard*, in respect of strength and fire integr ity having regard to the * Refer to Guidelines for materials other than steel for pipes adopted by the Organization by resolution A.753(18).

W/1576n/pp/EWP RESOLUTION MSC.36(63) (adopted on 20 May 1994) ADOPTION OF THE INTERNATIO NAL CODE OF SAFETY FOR HIGH SPEED CRAFT 7.5.5 7.5.6 MSC 63/23/Add.2 ANNEX 18 Page 63 ser vice pressure and the spaces in which they are installed.

Wherever practicable, the use of flexible pipes should be avoided.

Pipes, valves and couplings conveying flammable fluids should be arranged as far from ho t surfaces or air intakes of engine installations, electrical appliances and other poten tial sources of ignition as is practicable and be located or shielded so that the - arra nged as far from hot surfaces or air intakes of engine installations, electrical applian ces and other potential sources of ignition as is practicable and be located or shielded so that the likelihood of fluid leakage coming into contact with such sources of ignitio n is kept to a minimum.

Fuel with a flashpoint below 35°C should not be used.

In every craft in which fuel with a flashpoint below 43°C is used, the arrangements for the storage, distribution and utilization of the fuel should be such that, having regard to the hazard of fire and explosion which the use of such fuel may entail, the safety of the craft and of persons on board is preserved.

The arrangements should comply, in addition to the requirements of 7.5.1 to 7.5.5, with the following provisions: .1 tanks for the storage of such fuel should be located outsid e any machinery space and at a distance of not less than 760 mm inboard from the shell s ide and bottom plating, and from decks and bulkheads; .2 arrangements should be made to prevent overpressure in any fuel tank or in any part of the oil fuel system, including t he filling pipes.

Any relief valves and air or overflow pipes - and bulkheads; .2 arrangements should be m ade to prevent overpressure in any fuel tank or in any part of the oil fuel system, incl uding the filling pipes.

Any relief valves and air or overflow pipes should discharge to a position which, in the opinion of the Administration, is safe; .3 the spaces in which fuel tanks are located sh ould be mechanically ventilated using exhaust fans providing not less than six air chang es per hour.

The fans should be such as to avoid the possibility of ignition of flammable gas air mix tures.

Suitable wire mesh guards should be fitted over inlet and outlet ventilation openings.

The outlets for such exhausts should be discharged to a position which, in the opinion o f the Administration, is safe.

'No Smoking' signs should be posted at the entrances to such spaces; .4 earthed electric al distribution systems s