ME: What does usable DoD mean?

CHATGPT: DoD = Depth of Discharge

It's the fraction of a battery's total rated capacity that you can safely use without damaging its lifespan.

- Rated capacity: what the manufacturer states (e.g., 100 Ah at 48 V = 4.8 kWh).
- Usable DoD: how much of that you can actually pull out regularly.
- Remaining fraction: must stay in the battery to protect its chemistry.

Examples

- Li-ion (LiFePO₄) \rightarrow Usable DoD \approx 80–90%
- A 100 Ah LiFePO₄ battery gives you ~80–90 Ah usable.
- You leave ~10–20% charge inside as a buffer.
- Lead Acid (AGM/GEL) \rightarrow Usable DoD $\approx 50\%$
- A 100 Ah SLA battery really gives only ~50 Ah usable.
- Draining more shortens life drastically.

Why it matters in your project

When we sized your battery (Step 4), we took the energy needed for 3 days and then divided by the Usable DoD.

That ensures the battery bank is large enough so that even after using the safe fraction, it still covers the load.

Formula:

 $\text{text}\{Battery\ Wh\ (rated)\} = \frac{\text{Required}\ Wh}\} \{\text{Usable DoD}\}$

So if your IoT node needs 2,000 Wh for 3 days:

- Li-ion (DoD 0.8) \rightarrow 2,000 / 0.8 = 2,500 Wh rated.
- Lead Acid (DoD 0.5) $\rightarrow 2,000 / 0.5 = 4,000$ Wh rated.

That's why Li-ion packs are smaller for the same usable energy.

ME:I've chosen a power systems project to size a 48V solar battery pack for a remote IoT node. including a load profile, 3 days autonomy and cable loss

First explain in simple terms what I need to do to achieve this. Explain what a load profile is and 3 days autonomy

Then draft two alternate ten step plans with inputs, outputs and tests.

Include file names, units and a target plot. Don't make it too complex, I want to be able to

understand and explain it to someone.

CHATGPT: Simple explanation — what you need to do

- 1. Measure or estimate how much energy your remote IoT node uses each hour (this is the load profile).
 - 2. Convert that energy into daily Wh (watt-hours).
- 3. Multiply by 3 days (autonomy) and add losses (cable losses, converter/inverter inefficiency, battery depth-of-discharge limits) to get the required battery energy.
 - 4. Choose a 48 V battery capacity (Ah) that meets that energy requirement.
- 5. Design the solar charging (PV) and cable sizing so the battery is charged reliably and cable losses are acceptable.
 - 6. Document everything and test with real or simulated data.

What is a load profile? What is "3 days autonomy"?

- Load profile: a list of the device's power draw over time (typically in watts or amps, per minute or per hour). Example: at 00:00–06:00 the node sleeps at 2 W, 06:00–07:00 it wakes and transmits at 10 W, etc. Summing the profile over 24 hours gives daily energy (Wh/day).
- 3 days autonomy: the battery must supply the node for 3 full days without any solar input (e.g., bad weather for 3 days). So if the node needs 1,000 Wh per day, a 3-day autonomy implies storage for at least 3,000 Wh plus losses and safety margins.

Key formulas (simple)

- Energy per period: $E = P \times t (W \times hours = Wh)$
- Daily energy: E day = Σ hourly P \times 1h (Wh/day)
- Battery required (Wh, before margins): E batt nominal = E day \times autonomy days
- Account for usable fraction (DoD) and system efficiency (η):

Battery Wh required = E batt nominal / (DoD fraction $\times \eta$ system)

Example: DoD fraction = 0.5 (50% usable), η system = 0.9 (90% round-trip)

- Convert Wh to Ah at 48 V: Ah = Wh / 48
- Cable power loss (DC): $P_{loss} = I^2 \times R$ where I = P / V, $R = resistivity \times length / area (or use conductor tables).$

Worked example (simple numbers so you can explain it)

Assume you estimate the node uses 576 Wh/day (this is just an example — replace with your measured profile).

- 1. E day = 576 Wh
- 2. autonomy_days = $3 \Rightarrow E_batt_nominal = 576 \times 3 = 1,728 Wh$

3. Assume DoD = 50% (0.5), η system = 90% (0.9):

Battery Wh required = $1,728/(0.5 \times 0.9) \approx 3,840 \text{ Wh}$

4. Convert to Ah at 48 V: Ah = 3,840 / 48 = 80 Ah

So you'd specify a 48 V, 80 Ah battery pack (≈3,840 Wh) in this example.

Cable loss example: if the system current under average load is I = P/V = 576 Wh/day $\div 24$ h $\div 48$ V ≈ 0.5 A (small), but peak transmit may cause higher currents. For higher currents, use P_loss = I 2 R to check heating and choose conductor area.

Target plot (what to show visually)

Filename: target plot soc vs time.png

Plot to create/attach: State of Charge (SoC) vs Time for a 7-day window showing:

- Day 0: full charge
- Days 1–3: consumption without solar (SoC falling to the autonomy limit)
- Day 4+: charging resumes (solar) and SoC recovers

Axes & units

- X axis: Time (days)
- Y axis: Battery State of Charge (%) or Battery Energy (Wh)

Short checklist for field tests

- Verify load profile.csv with a meter for 24–72 hours.
- Confirm daily Wh matches estimation within $\pm 10\%$.
- Disconnect PV, run 3 days: battery SoC should remain ≥ chosen minimum DoD.
- Check cable temperature & voltage drop under peak.
- Verify PV recharges battery in expected time.