### Grove - LED Socket Kit SKU: 104030009



Grove - LED 是为 Arduino/Seeeduino 的初学者设计的,显示数字端口输出。它可以很简单地安装到你的箱子或桌子的表面,并用作电源或信号的指示灯。其亮度可以通过电位器进行调节。

# 产品特性

- 兼容 Grove 接口
- 兼容 3.3V/5V
- 可调 LED 方向
- 可调 LED 亮度

# 规格参数


**项目**	**描述**
LED 控制方法	使用 Arduino 的数字引脚控制
工作电压	5V

接口 Grove 接口

#### Arduino 入门指导

这里我们展示如何使用 Arduino 来控制 LED 的状态。

- 1. 使用 4pin Grove 电缆将 LED 连接到 Base Shield 的 **D2**。当然,如果需要,也可以更改为其他有效的数字端口,并且端口的定义也需要更改。
- 2. 把它插到 Arduino/Seeeduino 上。 使用 USB 电缆将电路板连接到电脑。



3. 将演示代码复制到 Arduino IDE 的新窗口,然后上传到 Arduino 或 Seeeduino 板。如果您不知道如何上传,请点击 这里。

您可以看到 LED 灯每秒闪一次。

### Raspberry Pi 入门指导

使用 Grove 连接线将 LED 连接到 GrovePi+ 的端口 D4, 然后打开 Raspberry Pi 的电源。例程代码如下:

```
# GrovePi LED Blink example
import time
from grovepi import *
# Connect the Grove LED to digital port D4
led = 4
pinMode(led,"OUTPUT")
time.sleep(1)
while True:
   try:
       #Blink the LED
       digitalWrite(led,1)
                              # Send HIGH to switch on LED
       time.sleep(1)
       digitalWrite(led,₀)
                                      # Send LOW to switch off LED
       time.sleep(1)
    except KeyboardInterrupt: # Turn LED off before stopping
       digitalWrite(led,∅)
       break
    except IOError:
                                               # Print "Error" if communication
error encountered
        print "Error"
```

#### 运行程序

• 转到示例代码文件所在的目录:

```
cd GrovePi/Software/Python/
```

• 运行示例:

sudo python grove\_led\_blink.py

# 资源下载

- [原理图]Grove LED V1.3 Source files (Eagle and pdf)
- [原理图]Grove LED Source files (Eagle and pdf)
- [代码]GroveLEDDemoCode
- [Eagle 文件]Grove-LED Socket Kit