





# 10 Ax











### 12 4x






































21 1x 1x 貼上灰色貼紙,確保黑色部份與指針前部對齊。




# 23 x










## 25 x






















### 31 P

















### 36 ZX

